

for slitting and rewinding newsprint from 41.25 - 45 g/m<sup>2</sup> and LWC from 48 - 67.5 g/m<sup>2</sup> at a maximum web speed of 2,200 m/min. The speeds obtainable in field operation depend on the quality of the material, on local operating conditions and on beat-free unwinding.

## TECHNICAL DATA

Material: newsprint 41.25 - 45 g/m<sup>2</sup>  
LWC 48 - 67.5 g/m<sup>2</sup>

Web draw: 60 N/cm web width

Specific weight: 13,000 N/m<sup>3</sup>

Winder location: on a suspended floor (thickness to be advised)

Operator's side:  
Machine 1 + 2: on left, looking in web travel direction

Drive side:  
Maschine 1 + 2: on right, looking in web travel direction

Control desk location:  
Machine 1 + 2: on left, looking in web travel direction

Core feeding:  
Machine 1 + 2: from left

Elevation: up to 1,000 m above sea level

Untrimmed web width  
at unwind: max. 3,912 mm  
min. 3,632 mm

Trimmed total rewind width: max. 3,860 mm  
min. 3,378 mm

T E C H N I C A L     D A T A   of Unwind:

Unwind diameter:                   max. 2,438 mm  
   min.    403 mm  
   (= reel spool dia.)

Parent reel width:                   max. 3,912 mm  
   min. 3,632 mm

Max. load capacity  
unwind: 300,000 N (30 tons)

Max. weight of parent reel: about 120,000 N (12 tons)  
without reel spool

Reel spool: as per drawings submitted to us, with gear coupling for connection between reel spool and brake generator

**Shifting distance  
(axial regulation):**  $\pm 100 \text{ mm}$

Shifting distance  
(radial regulation):                    +/- 25 mm

Oscillation range:                    +/- 100 mm

**Jagenberg AG 4000 Düsseldorf 1**  
**Schutzvermerk nach DIN 34 beachten.**

T E C H N I C A L   D A T A   of Winder:

Standard nominal trim width: 4.000 mm

Rating of the machine: max. web speed up to 2.200 m/min. for  
basis weights up to 67.5 g/m<sup>2</sup>Diameter of 1st guide roll  
at web infeed: 355 mm, undivided with chevron  
grooving

Diameter of 2nd guide roll: 178 mm

Diameter of guide rolls  
ahead of and following  
slitting station: 178 mm

Minimum slitting width: 198 mm

Number of slitter pairs: 10

Diameter of rewinding rolls: max. 1,525 mm  
min. 400 mm  
(for mechanical ejection)Total rewinding web width: max. 3,860 mm  
min. 3,378 mmMin. outer diameter of the  
rewind cores: 89.15 mm (steel cores)  
101.6 mm (fibre cores)

Diameter of rewind cores: 76.2 mm inside diameter

Maximum core tolerance: +/- 0.3 mm

Adjustment range of core  
chucks of shaftless rewind: 350 mm per sideNumber of tool tapers  
(tapered mandrels): 1 pair for 76.2 mm core i.d.Core Dimensions:1. Steel cores: i.d. 2.930 - 3.125"  
o.d. 3.510 - 3.540"2. Cardboard cores: i.d. 2.996 - 3.060"  
o.d. 4"Maximum trim strip width: 11", divided into 1 x 3" on one side  
and 2 x 4" on the opposite side

Trim removal: via lead-off plates, suction studs and injector system

Trim delivery distance: 61 m

Adjustment range of lead-off plates: 350 mm per side

Face length of winder drums: 4,150 mm

Diameter of winder drums seen in web travel direction:

1st winder drum: 850 mm  
 2nd winder drum: 610 mm

Diameter of rider roll: 265 mm

#### COMPRESSED AIR

Gauge operating pressure for all pneumatic equipment: 4.2 bar

Room temperature: up to max 40° centigrade

Relative humidity: max. 95 %

HYDRAULICS (REXROTH): operating medium  
 mineral oil  
 as per ISO VG 68 (HLP 36)

solenoid voltage: 110 V - 60 Hz  
 control voltage: 110 V - 60 Hz  
 motor voltage: 600 V AC - 60 Hz  
 motor protection: standard IP 54  
 standard motor/frame B 3/B 5  
 motor starting: star-delta

Jagenberg AG 4000 Düsseldorf 1  
 Schutzvermerk nach DIN 34 beachten.

11 84

TZS/07					e
Abt./PG	Name	Datum	Änderung	Spr.	CH

2,40-31 = H

Blatt 4  
 5 Bl.

TECHNICAL DATA Electrics:

Power supply: 3-phase AC with neutral,  
460 V, frequency 60 Hz  
for main drives  
600 V, frequency 60 Hz  
for auxiliary drives

Control voltage: 120 V AC

Pilot lamp voltage: 115 V AC  
Solenoid valve voltage: 115 V AC

Voltage fluctuations: +/- 5 %

Permissible rating for  
direct on-line starting of  
squirrel-cage motors: unlimited

Construction: standard for standard voltages up to  
1,000 V  
as per VDE 0100 and VDE 0113/IEC

Manufacturer: RELIANCE

Ratings/rpm speeds:

brake generator  
184 kW  
300/1,800 rpm

winder drum motor  
174 kW  
850 rpm

rider roll motors  
2 x 5.5 kW  
1,750/2,300 rpm

frequency converter 43 KVA  
laid out for 10 slitte pairs

Mount Hope spreader roll  
5.5 kW  
1,750/2,300 rpm

Jagenberg AG 4000 Düsseldorf 1  
Schutzvermerk nach DIN 34 beachten.

11 84

TZS/07				e	
Abt./PG	Name	Datum	Änderung	Spr.	CH

2.40-31 -H

B1.5  
5 Bl.

## DESCRIPTION OF THE EQUIPMENT

JAGENBERG Two-Drum Winder VARI-STEP Type 65,  
4000 mm (about 157") Nominal Trim Width

## UNWIND

Size 24/24, side-shiftable as a whole, suited for reel spools of one length with two fixed bearings and square coupling, essentially comprising:

two unwind stands, mounted on sole plates, with connecting cross beams, gear motor for side-shifting (shifting distance +/- 100 mm = about 4"), spherical half shells and equipment for manual adjustment of one unwind bearing in web travel direction.

**EMERGENCY BRAKE**

for the brake generator,  
electro-pneumatically operated.

## REEL SPOOL COUPLING

divided, with second driver.

## RAPID REEL SPOOL CHANGE

The empty spool is ejected from the unwind bearings by pivoting levers and rolls onto supporting arms attached to the unwind, so that a new reel can be loaded before the empty spool is removed.

0131B

FRAMING AND CONSTRUCTION OF THE BASIC MACHINE  
mainly comprising:

- base blocks
- machine uprights
- connecting cross beams

## 2 GUIDE ROLLS

of aluminium tubing, grooved, divided into 2 sections each. The second guide roll arranged for electric web draw measurement.

## THREADING TAPE CRADLE

mounted above the guide rolls

# AIRFLOATER

to facilitate web threading.

**JAGENBERG MULTI-SPREAD SPREADING UNIT (patented)**  
with individual adjustment of the segments,  
mounted ahead of the slitting station.

UNISSET SLITTING STATION  
with 10 pairs of slitters.

## MOUNT-HOPE Spreader Roll

## LEAD-OFF PLATES

for removing the trim strips, including suction studs for connection to the trim removal system.

## INJECTOR TRIM REMOVAL SYSTEM

with silencers, silencing hood and motorized damper valve setting.

## WINDER DRUMS

with molybdenum coating and grooved.

The first winder drum in web travel direction is grooved and constructed as suction roll in order to hold the web tails remaining in the machine in place when making an automatic roll set change.

The delivery scope includes the suction fan.

0131B

THREADING TAPE CRADLE  
underneath the first winder drum.

WEB CUT-OFF UNIT  
mounted underneath the two winder drums.

REWIND  
with adjustment/setting of the core chucks through two  
electric motors,  
counterloading of the core chuck carriages hydraulically.

RIDER ROLL  
constructed in sections, for DC drive, with spiral grooving  
and hydraulic rider roll control.

ROLL SET EJECTOR  
with integrated core loading unit, for ejecting the roll set  
and at the same time loading new cores into the winder drum  
valley.

GLUE APPLICATOR  
for applying a glue track as the cores are fed into the  
machine manually.

ROLL LOWERING UNIT  
organically built into the machine,  
doubling as nip safety guard in raised position.

PARKING BRAKE

COUPLING  
for direct coupling of drive motor and winder drum journal.

CONTROL DESK  
with pneumatics installed, but electrics not installed.


HYDRAULIC POWER UNIT  
with back-up pump.

ON-LINE Winding Hardness Measurement

SEQUENTIAL SWITCHINGS I, II and III



# The New Jagenberg Two-Drum Winder VARI-STEP



Jagenberg AG 4000 Düsseldorf 1  
Schutzvermerk nach DIN 34 beachten.

There is one common denominator for all rolls leaving the paper mill; they are not an end product, i. e. they serve no other purpose than to be converted into something else. After having been rewound with care, they are sent once more to the unwind stands for further processing. It goes without saying that converters pose widely varying demands on the quality of individual rolls, considering the multitudes of applications for the final product. However, there is no getting away from one basic demand – regardless of the type or the size of the converting machine: the roll quality must be uniform throughout, ensuring trouble-free unwinding at highest operating speeds.

Amongst converters, the printer is king. His demands on the runability properties of a roll are the most stringent. In view of the fact that 40% of all paper products in the world are printed, it is understandable that the requirements of the printing industry are a winder designer's gospel. And the gospel says that rolls must be of uniform density from the first plies on

the cores to the outer periphery. Only perfectly uniform rolls ensure optimum printability.

The next requirement calls for the largest possible roll diameters. Of course, uptimes grow with the growing diameters. Larger diameters also save operators, since only extended flying splice intervals resulting from large roll diameters permit splice preparation without calling for outside help. And this is all-important as splicing intervals become ever shorter due to continuously increasing press speeds. Larger rolls save material, too, if one considers the waste that accompanies every roll change. These savings are without doubt of great interest to the highly competitive packaging industry which represents another 35% of the paper converters or, in other words, potential VARI-STEP users.

Thus, the task for the design engineers was clearly defined: to develop a new winder concept permitting more uniform winding hardness while at the

same time increasing conventional roll diameters. This task called for a new concept indeed, since the object of the exercise was to combine these demands in a two-drum winder design in view of the higher prices and increased number of operators in the case of single-drum winders with staggered rewind stations – which, design-wise, are a perfect solution to the problem.

The R & D staff first drafted the known parameters which can influence the winding hardness or – as we often say today: the roll density. These parameters were then thoroughly investigated in theory and tested in practice:

- Size and arrangement of winder drums
- Difference of winder drum peripheral speed (advancing and retarding effects, also called over-speed and lag speed)
- Web tension, and
- Rider roll nip load (roll winding pressure).

TZS/07	Nitschke	28.06.84		e	
Abt./PG	Name	Datum	Änderung	Spr.	CH

2.66-02 =H

Fig. 3a) clearly shows the geometry and position of the winder drums of a conventional two-drum winder, as well as the speed relation between the winder drums. If two drums of identical diameter are selected, and if the drum which is not wrapped by the web is not driven, then the roll hardness greatly increases with increasing roll diameter. At small diameter, there is a strong lag speed. This lag speed diminishes with increasing diameter with the eventual near-synchronisation of the peripheral speed of the two drums.

If the drums are mounted in a slanted plane as shown in Fig. 3b), an increase in diameter of the roll corresponds to a gradual shifting of the roll weight from the non-driven (idling) to the driven drum wrapped by the web. The natural result is an increase in roll hardness or density due to the higher nip pressure on the wrapped winder drum. It is also noticeable that in the medium diameter range, the roll hardness curve

levels off. This effect, producing a more uniform density in the medium diameter range, stems from the geometry (slanted plane) in connection with the drum diameters, and results in a certain overspeed of the non-wrapped winder drum from a given roll diameter onwards.

Now it is a known fact that larger drum diameters results in lower roll density. Thus, the diameter of the driven winder drum wrapped by the web was increased (Fig. 3c). In this way, the total hardness level could be reduced and a larger degree of uniformity was obtained. The overspeed inherent in the system already becomes effective at small roll diameters, if larger drum diameters are selected. This effect – in connection with the slanted position of the drums – is the result of a deeper impression of the larger drum in combination with a softer winding structure.

If the second winder drum is further-

more driven by an adequately dimensioned flat belt, adapted to the overspeed requirements as shown in Fig. 3d), a sufficiently high overspeed is obtained in the area of the roll center. In the further winding process, the overspeed then adjusts to the overspeed generated by the system. This contributes to a better level of uniformity.

In order to clearly demonstrate the effect of the new concept, Fig. 3e) now shows the roll hardness curve of a conventional winder. In this comparison, both the web tension and the overspeed were identical. However, in the case of a conventional system, the overspeed must be forced upon the roll through an expandable pulley or two-motor drive, over the full roll diameter range. This permits the conclusion that the overspeed factor inherent in the VARI-STEP system treats the paper much more gently.




Fig. 3




Fig. 4

On top of that, the influence of rider roll nip loading must be considered. A rider roll is required to ensure good roll starts and to achieve the desired optimum roll hardness level in relation to the roll diameter (Fig. 4). In order to reach this goal, the load factor (P) is controlled in such a way that the forces N1 and N2 acting on the nips, i. e. the nip pressure, is raised over a wide diameter range and maintained there, starting right from the roll center (Fig. 5).

A comparison of the roll hardness curves of a conventional winder with a VARI-STEP (Figs. 3d and 3e) shows that in order to obtain the desired roll hardness level, a conventional winder needs a much higher rider roll nip load. But a higher load means also a greater danger of shifting or slipping between layers with the possible end result – in really bad cases – of wrinkling (crepe formation). This means that the new VARI-STEP winding system creates less danger of wrinkling through lower rider roll nip loads. The rider roll nip load is controlled electronically by a parabolic curve representing the pre-set values. Setting is done on the main control board if this is placed sufficiently close to the machine, or at a special control panel.




Fig. 5

Fig. 4: Desirable Roll Density Curve

Fig. 5: Influence of the Rider Roll Nip Load




Fig. 6

The input panel shown in Fig. 6 can be programmed as follows:

- Counterloading pressure in the cylinder at start-up, i. e. for the core diameter
- Minimum counterloading pressure for a given roll diameter, depending on paper grade and finished roll diameter
- Maximum counterloading pressure at which a floating condition of the rider roll is achieved, and
- The roll diameter for beginning of the floating condition.

The system described allows for further fine-tuning the programmed rider roll nip load so that the desired roll hardness level is reached automatically without further operator interference. We are thereby approaching the ideal curve representing a uniform or slightly declining roll hardness level during the total winding process, as shown in Fig. 7.

The differences measured between the measuring points are very slight, and the maximum winding hardness in the center and near the periphery of the roll does not cause any damage.




Fig. 6: Programmable Counterloading Curve

Fig. 7: Roll Hardness Diagram

Jagenberg AG 4000 Düsseldorf 1  
Schutzvermerk nach DIN 34 beachten.

Fig. 7

TZS/07	Nitschke	28.06.84		e		2.66-02	=H	Blatt 4
Abt./PG	Name	Datum	Änderung	Spr.	CH			7 Bl.




Fig. 8

If widely varying paper grades are to be handled, the VARI-STEP can be equipped with a handwheel for readjusting the variable speed pulley during a stop (Fig. 8). The handwheel permits raising or lowering the total hardness level by increasing or lowering the speed difference between the drums. A display dial permits the reproduction of settings once found to be practical. Altering the overspeed during the operation is not necessary since the geometry of the winder drums automatically initiates the desired adaptation. Normally, the most efficient overspeed factor is already ascertained during the commissioning period.

This means that the adjustable pulley will only be required and supplied if certain limits for caliper range are exceeded, or if there are large deviations in the structure of the paper.

In any case, there remains the alteration of the web tension to obtain a rise or fall of the total hardness level. This web tension has a far greater influence on the winding hardness than the variation of the overspeed factor.

Since the conventional hardness test methods such as knocking the finished roll, the gap test, the Smith needle test or the Schmidt-Hammer test are all not too accurate, Jagenberg developed a simple but very safe new method for controlling the winding hardness. In the new method, steel strips of approximately 90 mm (3 1/2") length, 6mm (1/4") width and 5/100 mm (0.002") caliper are inserted during the winding operation into the side of the roll between the sheet plies (Fig. 9). Prior to this, the steel strips have been placed into paper sheaths so that the coefficient of friction remains constant between sheath and metal (whereas it would be different with different paper grades).



Fig. 9

Fig. 8: Adjustable Belt Pulley

Fig. 9: Inserting Steel Strips for Hardness Testing






Fig. 10

The force required to pull the metal strip from the roll – in which it was inserted by about 70 mm (2 3/4") – serves as the test value. Since the friction coefficient between sheath and steel strip is a known magnitude, the result of the test measurement reflects the pressure between the roll layers. These results are computed into hardness diagrams. Such a diagram is shown in Fig. 10. The left-hand curve represents a two-drum winder with two drums of 500 mm (20") dia. each. The right-hand curve shows the diagram of the VARI-STEP winder with 750 mm (30") and 500 mm (20") winder drums. The diagrams represent comparable winding conditions and machine settings.

A recommendable alternative to the above measuring system is the so-called ON-LINE winding hardness test. The system is based on a Jagenberg micro-processor with graphic color CRT. A printer is optional.

The linear footage of paper as well as the roll diameter are determined continuously. For this purpose, pulse generators are fitted to winder drum and rewind. Footage and diameter serve to calculate the caliper. By computing footage and diameter as well as basis weight of paper, we get the roll density or hardness at any desired roll diameter.

Since the order of magnitude is very small (paper caliper measured in thousandths of a mm, and change in tenths of microns), it becomes necessary to measure each time several plies of paper. Realistic numbers are between 100 and 300 plies. Therefore, there will be a reference value at every 5–40 mm (1/8" to 1 1/2"), depending on paper caliper.

Thus, we obtain a picture of the paper caliper and of the specific density or hardness over the total diameter of the roll during operation (Fig. 11). At the end of each winding process there is the possibility to print out the diagram of paper caliper or specific density over the diameter of the roll. Thus,




Fig. 11

Fig. 10: Winding Hardness Diagram

Fig. 11: Picture of an ON-LINE winding hardness test



### Way Valves

The designation is prefixed with the number of ways and the number of switching positions. The number of ways is equal to the number of controlled connections, e.g. a way valve with 5 controlled connections and 3 switch positions: 5/3-way valve. Depending on the type of actuation, there are:

- way valves, mechanically actuated (pushbutton, lever, pedal, feeler, feeler roller)
- way valves, pneumatically actuated
- way valves, electrically actuated (solenoid valves).

### Pressure Regulating Valves:

Mechanically actuated regulating and micro-regulating valves

These are pressure valves with two end positions and infinite intermediate positions. The valves are used to regulate the pressure in a compressed air system following the valve (secondary pressure) independently of the pressure preceding the valve (primary pressure) within a certain defined range in dependence on a distance to be covered.

Pneumatically actuated regulating valves (relay valves, pressure ratio valves)

These are remote controlled pressure valves which hold the output pressure (operating pressure) proportional to the control pressure. The pressure ratio between control and operating pressure is determined by the ratio of the regulating areas in the valve pressurized by the control pressure and by the operating pressure.

### Pressure Reducing Valves

These reduce the pressure in a compressed air system behind the valve independently of the pressure preceding the valve to a certain value and keep this value constant. Setting is made by turning the adjusting spindle until the related pressure gauge shows the value set.

### Blocking and Throttle Valves:

Check valves

These are blocking valves which permit passage in 1 direction only.

Change valves

These are blocking valves with 2 blockable inflows and 1 outflow.

Quick venting valves

These are blocking valves which vent the output line out into the open when the input line is vented, e.g. for quick venting of a cylinder.

Flow control valves

These have free flow in 1 direction and throttled flow in the other and regulate the piston speed of compressed air cylinders.



## 1. Purpose

The purpose of the maintenance unit is to free the compressed air from solid and liquid contaminants, to monitor the mains pressure (underpressure) and to inject oil into the air.

Part of the clean but unoiled air is used for blower air, in case the machine is provided with this, comparisons:

=HE 11 Web threading,

=HH 34 Trim slitters.


## 2. Function

### 2.1 Compressed Air Cleaning

Compressed air filter. The filter separates any remaining condensate and any solid contaminants which may have entered the air from the main piping in form of rust particles.

### 2.2 Compressed Air Monitoring

Pressure monitor =HA 10.N1-F1. The pressure monitor prevents the machine from operating if the pressure drops below the set minimum pressure (setting "lower switching pressure"). An underpressure initiates a machine stop.



Check valve. The check valve prevents the air from being completely emptied from the system in the machine if there is a loss of pressure in the main supply. Pressure gauge, control desk +P2. The pressure gauge measures and displays the operating pressure. For recommended operating pressure, see technical data =H in Section 1.

### 2.3 Oil Mist Lubrication

Compressed air oiler. The oiler lubricates the pneumatic operating control elements. Fine atomization of the lubricant ensures optimum lubrication with a small volume of oil.

## 1. General Remarks

The hydraulic unit is a drive unit, the purpose of which is to create a liquid flow and give this the necessary pressures.

This hydraulic drive unit comprises:  
tank, drive motor, pump (single or double pump),  
return filter, control, measuring and regulating units.

## 2. Function

For a description of the individual units, technical data and details on checking the function prior to commissioning, see:

sub-suppliers' manual      =HA 40 in Book 2,  
hydraulic diagram and/or  
instrument list              =HA 40 in Section IV.


### 2.1 Oil Tank

When the oil tank is initially filled, the pump must be switched off. The oil level can be checked on the oil level indicator. The filling is not included in our delivery scope. For the grade of oil, see the lubrication chart =H in Section 1.

### 2.2 Motor and Pump

Types: 1) Motor and single pump,  
2) Motor and double pump,  
3) Dual motor-pump combination.

#### 2.2.1 Switching Elements, Control Desk +P2



Hydraulic

I

0

=HA40.N1-S1: Selector switch, hydraulic pump motor:  
"1 / 2"

Only for hydraulic units with dual motor-pump combination (type 3)

=HA40.N1-S12 Illuminated pushbutton, hydraulic pump: "ON"

=HA40.N1-S11 Pushbutton, hydraulic pump: "OFF"

### 2.2.2 Pump Switchover Unit

This unit either for double pumps or pump combinations (see hydraulic diagram =HA40) serves to switch over the pumps to pressureless circulation.

This unit comprises a solenoid valve and a pressure limiting valve.

During winding, only the oil volume of pump Q1 is required for rider roll and shaftless rewind. When the machine is stopped, pump -Q2 is switched on for all movements.

### 2.3 Return Filter

The return filter basically comprises: housing, filter element, dirt trap head and electrical dirt indicator. For description and maintenance see: return filter =HA40 in Book 2, sub-suppliers' manual.

### 2.4 Check Valves

The check valves prevent the system from emptying if a pump fails.

JAGENBERG AG 4000 DUESSELDORF 1  
Schutzzeichen nach DIN 34 beachten

10620 Nr

TZS 07	13.7.84	Nitschke		e		198572	- HA40	Blatt 2
Abt./PG	Datum	Name	Änderung	Sp.	CH			

# 1. Parking Brakes, =HB41

Pneumatic diagram: =HB41

## 1.1 Mode of Operation

For rapid braking of the machine (emergency stop) a brake torque is required, which is generated by drive motors through field reversal.

The parking brake engages only when the machine has been decelerated to a low speed (threading speed). The tachogenerator motor acts on a way valve (solenoid =HB41.N1-Y11 is energized).

A limit switch is located on the parking brake of the drive. When the machine is braked, the limit switch is not actuated, so that the control circuit of the motor is not closed. Only after the brake has been released (limit switch is actuated) does the motor start moving.

# 2. Guide Roll and Rider Roll Brakes =HB45

The brake cylinders of the guide and rider roll brakes are also supplied by the parking brake =HB41 way valve. The guide and rider roll brakes engage simultaneously with the emergency brake of the winder drums.

1.

## MODE OF OPERATION

The WEB THREADING elements serve to thread a web of material into the machine.

We differentiate between:

a)

threading a new web after loading a new reel into the unwind

b)

threading the web after a web break.

The most important web threading components are:

- an airfloater to facilitate threading the web up to the first guide roll
- threading tape cradle on the guide rolls. The cradle can be engaged and retracted. The tape rolls are driven by a gear motor.
- guide plates for threading the web up to the slitting station
- guide plates with blower air pipes for transporting the web up to the winder drums
- threading tape cradle on the first winder drum with blower air, for threading the web into the winder drum nip. The tape cradle can be engaged and retracted. The tapes are driven by the winder drum when the cradle is engaged.
- blower air pipes on the ejector unit as well as on the bottom slitter beam as threading aid after a web break.

## 2.

## OPERATION

## 2.1

For threading a new web, see =H, 4.20  
Makeready and Settings on the Machine.

## 2.2

For threading the web after a web break, see =H, 4.20  
Makeready and Settings on the Machine.

## 3.

## SETTINGS

## 3.1

The threading tape cradle on the guide rolls rests on the same  
with its own weight only. The lowering (engaging) speed is  
set on throttle =HE11.-16.

## 3.2

The engaging speed of the tape cradle on the winder drum is  
set on throttle =HE11.-13.

## 3.3

The blower air on the blower air pipes is set on the  
low-pressure valves =HE11.-07, -08, -09, -10.

1.

## MODE OF OPERATION

Purpose of the electrical web tension control is to so regulate the brake generator that the web draw between unwind and winder, once it is set on potentiometer "WEB DRAW" (=HB61.U1-R11), remains constant throughout the winding operation.

The draw measuring units (load cells) are mounted underneath the bearings at both ends of the second guide roll.

The web wraps the guide roll, whereby the resulting force acts on the bearing points. The horizontal share of this force is measured and converted into an electrical signal.

This signal influences the brake torque of the brake generator via amplifier, control unit and potentiometer.

2.

## OPERATION

The required web draw (web tension), which depends, among other factors, on the basis weight, on the paper grade, on the web width and on the desired winding hardness, is set on the potentiometer "WEB DRAW" (=HB61.U1-R11).

The existing web draw at any moment is shown in percent on the indicating instruments (=HB61.U1-P14) (=HB61.U1-P15).

Jagenberg AG 4000 Düsseldorf 1  
Schutzvermerk nach DIN 34 beachten.

# 1. Mode of Operation

The purpose of the first guide roll following the unwind is to transfer the web on to the following sensing roll with a constant angle of wrap.

Whereas the guide roll is installed in a fixed position, the sensing roll is pivotably mounted on one side to take up the web tension control equipment (see HF21).

Both rolls are not driven and, depending on the equipment, are provided with one drum brake or disc brake each.

JAGENBERG AG 4000 DUESSELDORF 1  
Schutzzeichen nach DIN 34 beachten

10620 Nr

TZS 07	13.7.84	Nitschke		e		139868	- HG10	Blatt 1
Abt./PG	Datum	Name	Abänderung	Spr.	CH			



# 1. MODE OF OPERATION

Purpose of the spreading equipment ahead of the slitting station is to spread and tension the web in cross direction so that it runs into the slitting station free of folds or wrinkles.

# 2. OPERATION

The spreading unit can be pivoted around its pivot points into the web or away from the web.

Each roll section of the spreading unit can be adjusted individually by means of the handwheels as required to ensure wrinkle-free web run.

The handwheels are fitted with position indicating dials. The dial shows in each case the respective position of that particular roll section in relation to the middle position (middle position = zero position).

When the screws on both bearings have been loosened, the spreading unit can be raised or lowered.

Jagenberg AG 4000 Düsseldorf 1  
Schutzvermerk nach DIN 34 beachten.



### 1. Mode of Operation

The slitting station divides the paper web into the required number of individual webs. Slitting is done by single slitter pairs consisting of top and bottom slitters. During slitting, the bottom slitter acts as counter knife to the top slitter. The machine is provided with 1 guide roll each ahead of and following the slitting station.

### 2. Slitter drive (=HB10)



Each bottom slitter is driven by a frequency controlled AC motor:

bottom slitter drives "ON"

=HB10.N1-S12 - illuminated pushbutton - control desk +P2,

bottom slitter drives "OFF"

=HB10.N1-S11 - pushbutton - control desk +P2.



### 3. Slitter clamping (HH71)

The top and bottom slitters are mechanically interlocked and shifted in pairs via handwheel, pinion and gear rack.



Pneumatic clamping of the bottom slitters against the slitter beam:

bottom slitters "RELEASE"

=HH71.N1-S12 - illuminated pushbutton - control desk +P2,

bottom slitters "CLAMP"

=HH71.N1-S11 - pushbutton - control desk +P2.




The top slitter shut-off valves must be closed when the slitting widths are reset. The valves remain closed on the top slitters which are not required.

#### 4. Slitter Engagement (=HHB1)

##### 4.1 Manual Settings

##### 4.1.1 Radial and Axial Distance of the Slitter Cutting Edges



Adjustment is made in slitting position.

Radial: Overlap approx. 1.5 mm

Axial : Lateral distance approx. 1 - 2 mm

If these adjustment figures are not adhered to, damage to the top slitters and poor slitting results can be expected.

##### 4.1.2 Slitting Pressure

Slitting pressure adjustment, hydraulic diagram =HHB1 mounting plate: pressure reducing valve, pressure gauge.

Recommended pressure setting: 2 - 2.5 bar.

##### 4.2. Top Slitters

Separate pneumatic cylinders for penetration depth (radial) and slitting pressure (axial) of the top slitters. Groups:

Trim slitters (=HJ00 + ..)

The top slitters for trim slitting normally remain in slitting position, the shut off valves remain closed.

Inner slitters (=HJ01 - ..)

(Top slitters for the web slit)

Slitter Engagement:


Top slitters "ON"



=HHB1.N1-S12 - illuminated pushbutton - control desk +P2

the top slitters pivot radially into slitting position and then press against the slitting edges of the bottom slitters with a delayed axial movement.


Top slitters "OFF"



=HHB1.N1-S11 - pushbutton - control desk +P2

the top slitters retract axially and then radially with delay.

## 1. DESCRIPTION



The drive belt connects:

- the belt pulley on winder drum 1 (winder drum with the larger diameter) which is driven by the main drive and
- the belt pulley or adjustable belt pulley on winder drum 2  
(adjustable belt pulley = special equipment).

For details of the drive belt, see Manual 2, Sub-supplier's Instruction =HL 21. The belt is tensioned by a hydraulic belt tensioning arrangement.

## 2. HYDRAULIC BELT TENSIONER

For the hydraulic diagram see =HL 21 (Manual 4).

### 2.1 SETTING BELT TENSIONING PRESSURE

Pressure setting for the hydraulic cylinder is made on the pressure reducing valve (=HL21. ). For the required pressure, see the hydraulic diagram.

### 2.2 HYDRAULIC CONTROLS

Control is done through a double solenoid valve (=HL21. ) with blocked middle position.  
Switching positions:

1. Solenoid =HL21.N1-Y12 energized:  
"BELT TENSIONER SLACKEN"  
The belt must be slackened during the ejecting and lowering operations so that winder drum 2 can rotate. Winder drum 1 remains locked in position by the parking brake.
2. Solenoid =HL21-N1-Y11 energized:  
"BELT TENSIONER TENSION"  
When the proximity switch "LOWERING PLATFORM DOWN" (=HR41.N1-B16) is actuated, the belt is automatically tensioned again.
3. Solenoids de-energized:  
"BLOCKED MIDDLE POSITION"  
The solenoids switch into blocked middle position so that in case of a power failure the belt remains tensioned until the machine has come to a stop.

# 1. Mode of Operation

The reel diameter indicator basically consists of a diameter scale and a shiftable proximity switch with indicator, held by magnetic force. This switch is actuated by a second indicator which is mounted on the shaftless rewind. The core chucks of the shaftless rewind are guided upwards as the reel diameter increases. When the indicator of the shaftless rewind reaches the proximity switch on the scale, i.e. when the required reel diameter has been reached, the machine switches to halt. It should be borne in mind that the overrun period will be different depending on the machine speed.

# 2. Operating Instructions

Shift the limit switch on the guide strip so that its indicator points to the required reel diameter (take overrun period into account).

## Important Note

When the machine has been switched off on reaching the set reel diameter, it may only be restarted when the proximity switch has been set to a larger reel diameter.

For safety reasons, it is not permissible to override the proximity switch, as in this case the machine would not be automatically switched off when the max. reel diameter is reached.

The vertical position of the core chucks in the bottom end position is ensured by interchangeable limit stops.

## 1.1

Hydraulic Controls (hydraulic diagram =HL 41)

## SHAFTLESS REWIND UP

- Solenoid valves =HL41.-64, or =HL41.-68 switch to UP (solenoids =HL41.N1-Y11 or =HL41.N2-Y11 are energized)
- The pressure set on pressure reducer =HL41.-65<sup>+ =HL41.-69</sup> is applied to the ring-shaped faces of the cylinder pistons.
- The rising speed is set on throttles =HL41.-67 or =HL41.-71
- The shaftless rewind assemblies are raised in jog (inching) mode.
- The solenoid valves SHAFTLESS REWIND COUNTERLOAD (=HL41.-72 or =HL41.-74) remain shut. (Solenoid =HL41.N1-Y10 or =HL41.N2-Y10 are de-energized).
- In case of power failure, the shaftless rewind assemblies stop.

## 1.2

Hydraulic Controls

## SHAFTLESS REWINDS DOWN

- Solenoid valves =HL41.-64 or =HL41.-68 switch to DOWN (solenoids =HL41.N1-Y12 or =HL41.N2-Y12 are energized).
- The lowering speed is set on the throttles =HL41.-66 or =HL41.-70.
- The shaftless rewinds are lowered in jog (inching) mode.





## 2.

## OPERATION

## 2.1 Retract core chucks (pushbutton station +R511 and +R512)

The core chucks are retracted from the cores by pressing the pushbuttons =HL40.N1-S13 and =HL40.N2-S13. (A1 + A2)

The core chucks on both sides of the machine retract from the cores of the finished roll set by a distance of about 60 mm (about 2 3/8") each. The retracting movement is powered by a rotating field magnet and lead screw on each side.

When the core chucks have been retracted, move the rewind carriages (core chuck assemblies) up by pressing pushbuttons (B2) =HL41.N1-S13 and =HL41.N2-S13.

In their upper end position, the rewind carriages actuate limit switches (condition for ejecting the roll set).

## 2.2 Coring up (extending) core chucks into cores

Extend core chuck on fixed side (left side) by pressing pushbutton "CORE CHUCK EXTEND" (+R511 =HL40.N1-S14). (A3)

The core collar of the core chuck must be exactly in line with the left-hand trim slit in the slitting station.

Slide the first core onto the core chuck, then feed in the remaining cores in the proper order.

Then extend the core chuck on the opposite side by pressing pushbutton =HL40.N2-S14 "CORE CHUCK EXTEND". Core chuck must enter core up to the collar. Make certain that the end of the core is in line with the trim slit (same scale value for core chuck and trim slit on both sides).



positioning can only be in the direction "EXTEND", i.e if the core chuck was extended too far, it must be moved back in the direction "RETRACT" by at least 60 mm (about 2 3/8") and positioned anew in the direction "CORE UP".

Pushbuttons: see pushbutton panels +R511 and +R512.

Pushbutton A = "Core Chuck Core Up" =HL40.N1-S14;

=HL40.N2-S14;

Pushbutton B = "Core Chuck Retract" =HL40.N1-S13;

=HL40.N2-S13;

Pushbutton C = "Core Chuck Position" =HL40.N1-S10;

=HL40.N2-S10.

When the pushbuttons are pressed, the following functions are initiated:

Pushbutton A = core chuck moves the fixed distance of about 60 mm in direction "CORE UP".

Pushbutton B = core chuck moves the fixed distance of about 60 mm in direction "RETRACT".

Pushbuttons A-C (pressed simultaneously) = core chuck keeps moving in direction "CORE UP" as long as both pushbuttons remain pressed.

Pushbuttons B-C (pressed simultaneously) = core chuck keeps moving in direction "RETRACT" as long as both pushbuttons remain pressed.

When the core chucks have been positioned, their next movement of the fixed distance of about 60 mm must only be in direction "RETRACT", since a movement in the direction "CORE UP" would result in a change in the trim width which has just been set.



1.

MODE OF OPERATION

Purpose of the rider roll is to press the rewinding roll set against the winder drums, particularly at the start of winding, thereby establishing the necessary contact for the peripheral forces (nip pressures).

Essential Components:

- rider roll, divided into sections  
(diameter 260 mm = about 10 1/4")
- a pivot point shaft mounted on the rider roll beam.  
Gears mounted on the rider roll beam.  
Gears located at the ends of the pivot point shaft mesh in gear racks mounted on the stands. This arrangement ensures the parallel guiding of the rider roll.
- rider roll carriages on both sides, guided in low-friction rails.
- two disc brakes to brake the rider roll when the same is driven by the web only. (If rider roll is driven by two DC motors via flat belts, braking is via the DC motors).
- hydraulic cylinders, pressurized on both sides of the pistons, directly connected to the rider roll carriages, for electronically controlled counterloading and damping of the rider roll.

Jagenberg-Werke AG 4000 Düsseldorf  
Schutzvermerk nach DIN 34 beachten.

10620 Mr

TZS/07					e		1 9 8 7 7 6	= HL 51	Blatt
Abt./PG	Name	Datum	Änderung	Spr.	CH				7 Bl.

## 1.1

## Rider Roll Counterloading Controls

Potentiometer "REWIND DIAMETER" (=QQ80.-R10) registers the momentary rewind diameter. This signal is converted to a hydraulic pressure via the rider roll electronics and an electrically adjustable hydraulic pressure reducer, and this pressure acts on the ring surface sides of the hydraulic cylinder pistons.

During the winding process, this pressure changes according to a curve.

The course of this curve can be altered by adjusting a total of three points along its path:

## Point 1:

Counterloading pressure in the cylinder at start of winding.

## Point 2:

To obtain a uniform roll structure (winding hardness build-up) at the roll center, it is necessary to increase the nip load on the roll set by increasing the pressure of the rider roll. In other words, up to a rewind diameter of about 300 mm (about 12") the counterloading pressure decreases, and thereafter slowly increases again in accordance with the shape of the curve.

## Point 3:

## Vertical adjustment

This corresponds to the maximum counterloading pressure in the hydraulic cylinders; the rider roll just barely touches the rewinding roll set (floating state).

## Horizontal adjustment

This setting determines the roll diameter at which the floating state should be reached.

## 1.2

## Hydraulic Controls

## RIDER ROLL UP

See hydraulic controls (hydraulic diagram =HL51) RIDER ROLL UP

Solenoid valve =HL51.-38 switches to UP  
(solenoid =HL51.N1-Y11 is energized).

Full pressure is applied to the ring-shaped faces of the cylinder pistons. The rider roll is raised in holding line, i.e. in self-maintained contact.

(To stop rider roll during upward movement, tip pushbutton "RIDER ROLL DOWN" (=HL51.N1-S14).

The upward speed is set on the throttle =HL51.-41.

In the upper end position of the rider roll, solenoid valve =HL51.38 remains in the position "RIDER ROLL UP" (solenoid =HL51.N1-Y11 energized).

Solenoid valve WINDING PRESSURE =HL51.-07 remains closed.  
(Solenoid =HL51.N1-Y13 is de-energized).

In case of current failure, the rider roll stops. The cylinder connections on the ring surface sides are fitted with pipe-rupture safety valves.



## 1.3

## Hydraulic Controls

## RIDER ROLL DOWN

Solenoid valve =HL51.-38 switches to DOWN.  
(Solenoid =HL51.N1-Y12 is energized).

At the same time, the pilot-controlled check valve =HL51.42 opens. The rider roll lowers through its own weight. The pressure limiting valve =HL51.40 should be set to a pressure which is about 3 to 4 bar (43 - 57 psig) lower than the pressure required for raising the rider roll. However, if this pressure is set too low, the rider roll will deform the cores in the winder drum valley when it seats on them.

The rider roll is lowered in inching (jog) operation. The lowering speed is set on throttle =HL51.-49. The solenoid valve WINDING PRESSURE =HL51.-39 remains closed (Solenoid =HL51.N1-Y13 is de-energized).

In case of current failure, the rider roll stops.

## 1.4

## Hydraulic Controls

## RIDER ROLL WINDING PRESSURE

Valve =HL51.-49 switches to "WINDING PRESSURE". (Solenoid =HL51.N1-Y13 is energized).

Valve =HL51.-38 is in middle position. (Solenoid =HL51.N1-Y11 and =HL51.N1-Y12 are de-energized).

The pressure prescribed by the electrically controlled pressure reducing valve =HL51.-44 builds up in the raising line (ring-shaped area) of the cylinder.

The hydraulically pilot-controlled check valve (=HL51.-48) prevents oil from flowing off via the leakage oil line of the pressure reducer (=HL51.-44) when the rider roll is stopped. This valve is opened by solenoid valve =HL51.-49 "WINDING PRESSURE".

### 1.5

#### EMERGENCY OPERATION

If the pressure reducing valve =HLK51.-39 fails, open shut-off valve =HL51.-47 and close shut-off valves =HL51.-33 and =HL51.-45.

Set the counterloading pressure with the pressure reducer =HL51.-42. Correct setting during the winding operation if necessary.

When switching back to normal operation, open the shut-off valve =HL51.-43 and =HL51.-45 again and close shut-off valve =HL51.-47.

JAGENBERG		DESCRIPTION OF FUNCTIONS		RIDER ROLL		HL51		2.7													
2. OPERATION																					
<p>The counterloading or relief pressure existing in the raising line (ring-shaped area) of the cylinders is shown on the hydraulic pressure gauge on the control desk.</p> <p>2.1 RIDER ROLL UP</p> <p>The rider roll is raised by pressing pushbutton=HL51.NI-S13 "RIDER ROLL UP". The rider roll rises in maintained line contact.</p> <p>In the Sequential Switchings (when these are supplied), the rider roll is raised automatically in maintained line contact.</p> <p>2.2 RIDER ROLL DOWN</p> <p>The rider roll is lowered in inching operation by pressing pushbutton "RIDER ROLL DOWN" (=HL51.NI-S14). If the pushbutton is released, the rider roll stops.</p> <p>In the Sequential Switchings (when these are supplied), the rider roll is lowered automatically in maintained line contact.</p> <p>2.3 RIDER ROLL WINDING PRESSURE</p> <p>The counterloading pressure pre-set by the electronically controlled pressure reducer is applied by pressing the pushbutton "RIDER ROLL WINDING PRESSURE" (=HL51.NI-S10).</p> <p>When proximity switch "RIDER ROLL DOWN" has been actuated, the counterloading system is switched over with delay to "WINDING PRESSURE".</p>																					
TZS/07		Abt./PG		Name		Datum		Änderung		Spr.		CH		1 9 8 7 7 6		= HL 51		Blatt 6		7 Bl.	

3.

## SETTING THE RIDER ROLL

The rider roll is set or adjusted parallel to the winder drums by adjusting the gears on the pivot point shaft when the rider roll is in its bottom end position.

To adjust, release the shaft clamp of one gear and, when rider roll is properly parallel, tighten it again (tightening torque of the clamping screws: 70 Nm).

The maximum rotating angle of potentiometer =QP80-R10 "Rewind Diameter" is  $3600^\circ = 10$  rotations. However, only approximately  $2880^\circ = 8$  rotations are utilized.

When installing the potentiometer, make certain that when the rider roll is in its bottom or top end position there is approximately one rotation in reserve as safety, so that the potentiometer is not damaged.

## NOTE!


The timing belts must only be lightly tensioned, so that no radial forces are exerted on the potentiometer shaft.

4.

## MAINTENANCE


Gear racks, pinions, round guides and roller track should be cleaned daily and lightly greased.

Check the parallelism of the rider roll to the winder drums once a month.



## 1. Description

The winder drums support the rewind reel set. The VARI-STEP has 2 winder drums of different diameters in a precisely calculated relationship and at different horizontal levels.



### 1.1 Winder Drum Diameter Combinations (D1 : D2)

- VARI-STEP 30 = 610 : 410,
- VARI-STEP 43 = 750 : 500,
- VARI-STEP 65 = 850 : 610.



### 1.2 Winder Drum Drive

Single motor drive. Direct drive for the first winder drum or with gear transmission. The second winder drum is driven by belt transmission from the first winder drum.

### 1.3 Surface of the Winder Drums

Both winder drums have a rough surface to improve traction.


- Normal version = shot steel blasted,
- special version = molybdenum coated.

### 1.4 First Winder Drum with Grooving (Special Version)

To avoid an air cushion between the web and the first winder drum which is wrapped by the web to a large degree, the drum can be provided with grooving.

### 1.5 First Winder Drum with Suction Perforations (Special Version)

To facilitate web threading and to retain the web during automatic reel set change (if supplied), the drum body can be provided with perforations over the entire surface. A partial vacuum created in the drum by drawing off air through a central bore in the drum journal. The suction air can be switched on or off (suction air fan) on control desk +P2 irrespective of the sequential switching:



- = HE31.N1-S12 illuminated pushbutton, suction air "ON"
- = HE31.N1-S11 pushbutton, suction air "OFF"

## 2. Mode of Operation

The rewinding reel set only lies approximately evenly on the two winder drums at the start of winding. This helps to form a relatively hard reel center. The diameter ratio of the winder drums and their slanted position to each other effect a shift in the weight of the rewind reel as the diameter increases to the larger winder drum. This reduces the web tension generated in the nips, thus achieving greater uniformity in the reel structure.

### 2.1 Winding Technology

See "technical information" 2.66-02, winding technology of the VARI-STEP (Trial Report).

JAGENBERG AG 4000 DUESSELDORF 1  
Schutzzeichen nach DIN 34 beachten

10620 Nr

TZS 07	3.7.84	Nitschke		e		198598	- HL60	Blatt 2
Abt./PG	Datum	Name	Änderung	Spr.	CH			

1.  
MODE OF OPERATION

The adjustable core stop is mounted on the opposite side from the core feeding side.

In its initial or retracted position, the stop is fully retracted. The ejector unit can swing past it.


A pneumatic cylinder (13) extends the core stop unit into the opened core clamp, resp. retracts it.

The cylinder stroke is limited by an adjustable stop (10).

A spring-loaded plate (17) is mounted at the front end of the core stop unit; the cores are pushed against this plate. This actuates a proximity switch (26), which indicates by a pilot lamp that the core set is seated snugly up against the core stop.

The core stop assembly is then retracted into its initial position by pushbutton.

Proximity switches register the extended and retracted positions of the core stop assembly.



Jagenberg AG 4000 Düsseldorf 1  
Schriftvermerk nach DIN 34 beachten.


20-10620 MR

TZS/07				e	
Abl./PG	Name	Datum	Änderung	Spr.	CH

139884

= HP95

Glatt 1  
3 Bl.

 JAGENBERG	DESCRIPTION OF FUNCTIONS CORE STOP	HP 95 2.7																
<p>2. OPERATION</p> <p>2.1 Set the core stop assembly to the same scale value to which the trim splitter and the extended (cored-up) core chuck have been set.</p> <p>2.2 Then press illuminated pushbutton "CORE STOP EXTEND" (=HP95.N3-S13); the core stop is extended pneumatically. When the extended end position has been reached, the proximity switch "CORE STOP EXTENDED END POSITION" (=HP95.N3-S13) is actuated and the illuminated pushbutton lights up.</p> <p>2.3 Insert the cores into the core clamp in the correct sequence. At the same time, press the foot switch "GLUE APPLICATION ON" (=HP96.N1-S13). A track of glue is consequently applied to the cores as they are fed into the core clamp. (See also HP 96 "CORE GLUE APPLICATION").</p> <p>When inserting the cores, take care that they are not twisted or rotated.</p> <p>Feed the cores into the core clamp until they seat snugly against the stop plate of the core stop assembly.</p> <p>This actuates the proximity switch "CORE AT CORE STOP" (=HP95.N3-B17), and the pilot lamp "CORE ON CORE STOP" (=HP95.N3-H1) lights up.</p> <p>2.4 Now press pushbutton "CORE STOP RETRACT" (=HP95.N3-S14); the core stop assembly is retracted pneumatically.</p> <p>In the retracted end position, proximity switch "CORE STOP RETRACTED END POSITION" (=HP95.N3-B16) is actuated. This enables the ejecting operation and/or the sequential switchings.</p>																		
<table><tr><td colspan="2">TZS/07</td><td colspan="2"></td><td colspan="2">e</td><td colspan="2"></td></tr><tr><td>Abl./PG</td><td>Name</td><td>Datum</td><td>Anderung</td><td>Spr.</td><td>CH</td><td>139884</td><td>= HP95</td></tr></table>			TZS/07				e				Abl./PG	Name	Datum	Anderung	Spr.	CH	139884	= HP95
TZS/07				e														
Abl./PG	Name	Datum	Anderung	Spr.	CH	139884	= HP95											

Jagenberg AG 4000 Düsseldorf 1  
Schulzvermerk nach DIN 34 beachten.




**3.  
SETTING CORE STOP**

When the clamping levers (12) are released, the core stop assembly can be shifted in the guides (7 & 8). Set the pointer (23) to the desired web width dimension (AB) on scale (22). The scale is so laid out that a narrower web width than the nominal trim width is symmetrical to the machine centerline.

(The scales for shaftless rewinding and the trim slitte coincide with the scale for the core stop).

When setting is completed, tighten the clamping levers again.

The cylinder can now extend the core stop assembly only up to the cylinder stop (10).



Jagenberg AG 4000 Düsseldorf 1  
Schulzvermerk nach DIN 34 beachten.

# 1. MODE OF OPERATION

The equipment comprises essentially the adjustable core chute and the glue applying system, which consists of a spray valve, glue tank and the pneumatic control equipment.

- 1.1 The adjustable core chute limits the opening stroke for the core clamp.

It is the extension outwards of the core clamp and has the same shape.

The abutting ends of core chute and core clamp must be flush.

- 1.2 For mode of operation and function of the glue applying system, see separate manual of the manufacturer (Manual 2).

The glue should be sprayed on in a thin fog. Spacing between glue nozzle and core surface should be about 10 - 15 mm (3/8" - 5/8").

We recommend a water-soluable adhesive.

Example: DISPERGAN 11-760 from PKL; for description, see the PKL information sheet in Manual 2, Sub-supplier Instructions.

4.2 When applicable, the core chute must be cleaned of glue soiling in the area of the spray nozzle.

### 1.1 Roll Ejector

The roll ejector is mounted pivotable around the center of the first winder drum. The two ejector levers are rigidly connected by the ejector beam to prevent twisting. Movement of the ejector is powered by hydraulic cylinders. The forward (eject) and rear (retracted) end positions are registered by proximity switches.

The machine-wide core clamp is mounted in the ejector beam. The core clamp holds the set of cores, which is brought into a position above the winder drum valley by the pivoting movement of the ejector beam. When the clamp opens in this position, the cores drop vertically into the winder drum valley.

The core clamp halves are supported at several points. The opening and closing (clamping) movements are powered by a pneumatic cylinder.

Uniform opening and closing of the core clamp is ensured by gears mounted on both halves of the core clamp.

0117B

### 1.3 Hydraulic Controls "EJECTOR EJECT / RETRACT"

Valve =HR11.-36 switches to "EJECT".  
(Solenoid =HR11.N1-Y11 is energized).  
Full pressure is applied to the piston rod  
side of the cylinder.

Ejection is in inching operation. When the pushbutton is released, the ejector retracts into its rear end position (solenoid =HR11.N1-Y11 is de-energized).

The speeds of the forwards and retracting movements are set on twin valve =HR11-37.

## 2. OPERATION

Pressing pushbutton =HR11.N1-S13 pivots the ejector in "EJECT" direction in inching operation. When the pushbutton is released, the ejector retracts into its rear end position.

In the Sequential Switching I (if this has been supplied), the core clamp opens automatically in the forward end position of the ejector beam.

### 3. MAINTENANCE

The bearings and gears of the core clamp halves must be checked for easy movement and must be greased once a week.

0117B

### 1. Mode of Operation



With this unit the finished reel sets are lowered from the machine down to the floor. The lowering platform is mounted in flange bearings and is pivoted hydraulically round the second winder drum in travel direction. The cylinders are safeguarded with pipe rupture check valves for the lowering movement.

The upper end position of the lowering platform is simultaneously guard and ejecting position.

When the machine is running, the platform is electrically interlocked with the drive.

### 2. Hydraulic Controls

Hydraulic diagram =HR41, control battery:

#### 2.1 Way valve,

with Servo valve and two solenoids:

=HR41.N1-Y11 (energized), lowering unit up,  
=HR41.N1-Y12 (energized), lowering unit down.

#### 2.2 Flow Control Valve

to adjust the raising speed.

Caliper of the paper and consequently roll density are determined continuously on the run and displayed on the monitor. Thus there is a constant readout of paper thickness or density over diameter during the run. Since the order of magnitude of these measurements is very small - paper calipers in thousandth of mm and changes on the order of tenth of microns - it becomes necessary to measure several layers of paper at one time. Realistic numbers are between 100 and 300 plies. Therefore, there is a reference value at every 5 to 40 mm (1/8" to 1-1/2") depending on the caliper of the paper. These values are displayed graphically on a CRT during the run. The thickness of the paper or roll density over diameter can be printed on hard copy at the end of each run.

### 3. Operation, control desk +P2

The end positions of the platform are interrogated by proximity switches (see basic machine instrument location drawing).

#### 3.1 Lowering Platform "UP"



=HR41.N1-S13 pushbutton, actuated in inching operation. The platform pivots into upper end position (guard position). If the pushbutton is released, the platform remains in position. The way valve switches to center position (solenoids de-energized).

#### 3.2 Lowering Platform "EJECT"



=HR41.N1-S10 pushbutton. The platform lowers out of safety guard position into ejecting position. In this position, the ejected reels are taken up.

#### 3.3 Lowering Platform "DOWN"



=HR41.N1-S14 illuminated pushbutton, actuated in inching operation. The platform lowers from ejecting position into its lower end position. If the pushbutton is released, the platform remains stationary. The way valve switches to center position (solenoids de-energized).

### 4. Movement Sequence of the Lowering Platform within the Sequential Switching (Special Version)

The movements of the lowering platform in connection with sequential switching (if supplied) are described in chapter "Operation and Production".



Instrument: JAG-microprocessor-system with graphic color CRT and printer.


Test Method: Footage of paper and roll diameter are determined continuously by pulse generators on winder drum and rewind. Thickness of the paper is computed from length and diameter data. By factoring in the constant basis weight of the paper we get the density of the roll.

Remarks: Caliper of the paper and consequently roll density are determined continuously on the run and displayed on the monitor. Thus there is a constant readout of paper thickness or density over diameter during the run. Since the order of magnitude of these measurements is very small - paper calipers in thousandth of mm and changes on the order of tenth of microns - it becomes necessary to measure several layers of paper at one time. Realistic numbers are between 100 and 300 plies. Therefore, there is a reference value at every 5 to 40 mm (1/8" to 1-1/2") depending on the caliper of the paper. These values are displayed graphically on a CRT during the run. The thickness of the paper or roll density over diameter can be printed on hard copy at the end of each run.

Jagenberg AG 4000 Düsseldorf 1  
Schulzvermerk nach DIN 34 beachten.


20-10620 MC

TZS/07				e						
Abt./PG	Name	Datum	Änderung	Spr.	CH	198 799 - QQ 64				Blatt 1 2 Bl.



Caliper (microns)

Winding Hardness Sequence on Monitor



Jagenberg AG 4000 Düsseldorf 1  
Schutzvermerk nach DIN 34 beachten.

20-10620 Mr

TZS/07				e			198799	-QQ 64	Blatt 2
Abt./PG	Name	Datum	Änderung	Spr.	CH				2 Bl.

C O N T E N T S

1. General Description
2. Function
3. Setting the Parabolic Function
  - 3.1 Influence of Potentiometer
  - 3.2 Influence of Web Width
4. Possible Read-Outs
5. Swich Functions
6. Error Reports
7. Service and Test Programs
8. Drawings on the DWS Description

# 1. General Description

On a two-drum winder, the rider roll nip pressure is controlled in relation to the rewind diameter in such manner that the finished reel (roll) set has a constant density or hardness throughout the diameter.

The controls are made up from hardware components of the JAGENBERG micro-computer system ZBOJW.

The control program is based on the winder geometry in any specific case, with a high mathematic background, and on specific characteristics in regard to dynamic and static roll density generation.

Rider Roll Relief (Rider Roll Counterloading):

The nip load of the rider roll on the rewinding set must be varied in order to obtain a constant reel density in the finished set.

The rider roll relief via the diameter is a polynomial of higher order, whose co-efficient can be influenced within certain limits through external input of specific factors.

The input variable is the rewind diameter. A dynamic registration of the diameter must be eliminated for various reasons. Since the diameter cannot be registered directly without considerable expenditure for scanners and their installation, a diameter-equivalent is measured.

A ten-turn potentiometer is mechanically coupled with the rider roll (optionally, this can be an absolute angle encoder), and this registers the linear movement of the rider roll in relation to the machine uprights as analog signal.

This analog signal in the range from 0 - + 10 volts is read in by the calculator, filtered mathematically and the momentary diameter is calculated via the winder geometry.

JAGENBERG AG 4000 DUESSELDORF 1  
Schutzvermerk nach DIN 34 beachten

10620 Nr

TZS 07	11.7.84	Thomas		e		139 891	-QQ80	Blatt 2
Pbt./PG	Datum	Name	Abänderung	Spr.	CH			3

The amount of rider roll relief required for the diameter determined is calculated according to the mathematical function and the external inputs, and is output as

1.  
Standardized voltage of 0 - + 10 volts when the hydraulic pressure reducing valve has separate power electronics.

or

2.  
A current within the range from 0.1 - max. 1 Amp., on which a dither adjustable in amplitude and frequency is superimposed. In this case the electronically controlled hydraulic valve can be connected directly.

The diameter equivalent is registered with a resolution of 12 bit.

The set point output for the rider roll control is resolved with 8 bits, corresponding to 255 steps. This resolution is higher than the possibilities of an electrically regulated or controlled hydraulic valve, and consequently adequate.

JAGENBERG AG 4000 DUESSELDORF 1  
Schutzzeichen nach DIN 34 beschriften

10520 Nr

TZS 07	11.7.84	Thomas		e		139 891	-QQ80	Blatt 3
Abt./PG	Datum	Name	Renderung	Spr.	CH			4

## 2. Function

The processor controls the nip pressure of the rider roll in relation to the rewind diameter according to a parabolic function which can be freely selected within wide limits, and therewith indirectly influences the density structure of the paper reel (roll).

The actual value signal generator for registering the rewind diameter is a ten-turn potentiometer, which is connected to the rider roll via a timing belt. The position of the center tap of the potentiometer is a direct measure and proportional to the distance the rider roll has travelled. The processor undertakes the task to calculate the diameter from this.

(The complicated mathematical inter-relationship reel diameter as function of rider roll travel distance is calculated by approximation functions (approximation polynomials of the third degree) in four diameter sections with an accuracy greater than 0.5 mm.)

The control voltage(s) are calculated on the basis of the characteristic curves of the proportional pressure valve ( $P=F(I)$ ) and the peripheral U/I converter card, and the respective (digital) output signals go from the calculator to the periphery.

Reading the potentiometer, calculation of the diameter, calculation of the pressure point set point value on the basis of the pre-set parabolic function and the output of the control voltage(s) are time-controlled through interrupt. The time intervals for measured value reading can be pre-set on a switch.

All important data such as diameter, set point currents or pressure can be called up and displayed on the 7-segment display via a display selector switch.

An analog measuring instrument (optional) integrated into the front panel permits direct control of the actual control current.

The relief or counterloading pressure actually developed is shown on a pressure gauge (mounted on the control desk of the machine controls).

A further ten-turn potentiometer is mounted in the control desk. This enables the machine operator to manually influence the automatic control sequence at any time during the winding operation.

Optionally, a three digit decade switch is provided for setting the different total trim width of the paper to be rewound.

Processing of the trim width and evaluation of the actual position of the control desk potentiometer are done by the processor. The pre-set function sequence of the density control is thus corrected and adapted to the prevailing operating conditions.

The processor monitors the proper function of the diameter determination and the pressure control. Monitoring includes, among other things, checking for possible interruptions in the line to the potentiometer with possible overrun of the max. permissible travel distance. Issued control signals are check-read and switches are checked for their logical settings.

In case of a defect, a defect or error signal is issued to the machine controls, which switches the machine to "Emergency Stop". The processor interrupts the control lines to the pressure regulating valve and at the same time an error report in encoded form appears on the display (ERR XX).

Acknowledgement of this error report is only possible when the machine is stopped. (Signal "Main Drive Stopped").

An "Emergency Stop" signal (defect on the machine) causes the processor either to set the pressure valve to max. counteloading pressure or to remove the counterloading pressure in order to obtain max. damping, depending on the given application.

JAGENBERG AG 4000 DUESSELDORF 1  
Schutzzeichen nach DIN 34 beachten

10520 Nr

TZS 07	11.7.84	Thomas		e		139 891	-QQ80	Blatt 5
Abt./PG	Datum	Name	Abteilung	Spr.	CH			6

### 3. Setting the Parabolic Function

Any desired parabolic function can be set by means of various decimal switches mounted on the front panel, whereby the parabolic function is determined by the following co-ordinates (diameter D/CM, relieving pressure P/%)

DH, PH (Starting values at core)  
DS, PS (Values in apex)  
DE, PE (End values)

The setting points core diameter DH and apex DS are only accessible internally and are pre-set to 10 cm and 30 cm.

The processor automatically calculates the set point curve resulting from the switch positions. The pressure values are interpreted as values in percent of the maximum possible relieving pressure.

The max. relieving or counterloading pressure is adjustable (internally). It is specific to the machine, i.e. it depends on the rider roll weight, friction etc. and is determined by technical measurements at the time of commissioning.

The maximum relieving pressure is that pressure which holds the rider roll in a balanced condition (floating condition) just before it moves upward.

Basing on theoretical considerations and calculations which have been confirmed by extensive trials and measurements, a basic setting is worked out and recommended for each machine.

It is then up to the user to adapt this curve to his desires or requirements if necessary.

Settings which deviate considerably from the given parabolic function are indicated to the operator by the processor in the form of warnings which do not however influence the machine run.

Incorrect, i.e. unlogical switch positions are displayed as error reports (ERR XX).

In such a case, it is no longer possible to run the machine under electronic control (signal "Automatics ON").

**NOTE:** The processor accepts a change in the parabola coordinates only when the machine is standing still.  
(Signal "Main Drive Stopped" present, signal "Winding Pressure" not present)



### 3.1 Influence of the Potentiometer on the Parabolic Function

There is a linear relationship between the position of the potentiometer and the relieving pressure to be controlled: 1 rotation corresponds to 10% of the maximum possible relieving pressure.

The percentage values read in are additively superimposed on the parabola points PH and PS. Since the end point PEND is not changed, the shape of the curve is maintained. An increase in the control pressure is possible only up to the value of the maximum relieving pressure (100%, floating condition of the rider roll).

### 3.2 Influence of the Web Width (Trimmed Width)

The parabola points PH and PS are weighted with different value factors, which are calculated depending on the total web width. PEND and the overall course of the curve remain.

NOTE: The processor accepts a change in web width only when the machine is standing still.

Before starting a winding operation or when starting up the machine again, it must be ensured that the potentiometer is in 0 position. Otherwise, the automatic potentiometer position monitor will cause error reports.

JAGENBERG AG 4000 DUESSELDORF 1  
Schutzvermerk nach DIN 34 beachten

10620 m

TZS 07	11.7.84	Thomas		e		139891	-QQ80	Blatt 7
Abt./PG	Datum	Name	Abänderung	Spr.	CH			8

#### 4. Possible Read-Outs (7-Segment Display)

The following data which are closely connected with the automatic control process can be called up and displayed:

Selector	Switch	Information	Read-Out (e.g. on VARI-DUR 85-15Winder)
00	OFF	OFF	
01		Actual data from panel	83.76.99.80
02		Switches 7 - 0., PCB SK16	00.0A.0F.00
03		Switches 15 - 8, PCB SK16	1E.0A.8C.00
04		Actual web width in cm	-----XXX
05		Maximum relieving pressure (bar)	-----70.0
10		Potentiometer voltage (mV)	-----1000
11		Rider roll travel (mm)	-----100
14		Trim width - diameter	XXX-----100
20		Set point relief pressure (%)	-----3.0
30		Set point relief pressure (bar)	-----58.1
31		Set point value, control current (mA) (Pressure reducing valve)	-----465
32		Set point value, control voltage (mV)	-----5214
40		Rising speed of rider roll (mm/s)	-----0.0
99		Program identification	13-12-82
Others		Roll diameter (mm)	-----100

5. Switch Functions

Printed Circuit Board (PCB) SK1610

Switch      Function

0

1

Program selecting switch, operating program/service/test programs

2

3

Time Constant (TC)

Measured value registration and control of the relieving pressure

TC = S3 S2 X 10 ms

4

5

Multiplication factor of the time constants "Time Frame"  
Integration time for determining average value and digital  
filtering of measuring values  
TC X S5 S4 = Time Frame

6

7

Free

8

9

Free

10

11

S11 S10 X 0.5 bar = Maximum relieving pressure,  
(Floating state of rider roll)

12

13

S13 S12 = Core diameter (DH) in cm

14

15

S15 S14 = Apex of parabola (DS) in cm

Note: Setting of switches 0 - 15 must be made in hexadecimal manner.

Switches 0 - 15 are set at time of commissioning. They should only be corrected, if necessary at all, when operating conditions have altered, e.g. after exchange of hydraulic units.

6. Error Report

Various test and diagnostic functions recognize defects which may turn up and prohibited operator interferences which can cause malfunctions of the electronics controls. The following errors/defects are recognized in the processor and displayed:

Internally accessible switches on the SK16 PCB which must be set at time of commissioning or when operating conditions have changed.

ERR 00	Switches 3,2 (time constant TC) or 5,4 (multiplication factor) have changed
ERR 03	Switches 3,2 (TC) are outside the permissible range
ERR 04	Switches 3,2 and/or 5,4 ("Time Frame" too large)
ERR 07	Switches 7,6
ERR 09	Switches 9,8
ERR 11	Switches 11,10 outside the permissible range (Maximum relieving pressure)
ERR 15	S15, S14 smaller/same as S13 S12 DS    /= DH Parabola apex smaller/same as core diameter)

Error Reports, Continued

- ERR 17 Parabola end diameter smaller/same as apex under  
DE /= DS
- ERR 18 Web width permissible range
- ERR 19 Web width permissible range
- Potentiometer for diameter determination outside the  
mechanically possible travel distance
- ERR 20 Lower limit
- ERR 21 Upper limit
- ERR 25 Reference potential too high
- ERR 31 Control voltage outside the permissible tolerances  
(pressure reducing valve)
- ERR 32 Free
- ERR 88 Potentiometer for manually influencing control  
pressure  
(relief of rider roll) not in starting position

WARNINGS

- E.1 DE DS + (DS-DH)
- E.2 PS = PD
- E.4 PE BO (%)

## 7. Service and Test Programs

The program package of the DWS contains extensive service and test (calibration) programs, which make possible a simple and rapid commissioning of the electronic controls without auxiliary means. In case of a defect, these programs are a valuable aid in recognizing and correcting errors or defects.

The following programs can be selected with the respective position of the program selector switch (switch 1.0 on PCB SK1610)


Switch Position	Function
11	Linearity Test of the D/A outputs D/A output 1.0 - 10 V
12	D/A output 2.0 - 5 V
15	D/A outputs adjustable depending on display selecting switch
21	Calibration of thre D/A outputs D/A output 1, 10 V
22	D/A output 2, 5 V
30/31	Setting the maximum relieving pressure
40	Potentiometer - calibration

JAGENBERG AG 4000 DUESSELDORF 1  
Schutzvermerk nach DIN 34 beachten

10620 77



TZS 07	11.7.84	Thomas		e		139 891	-QQ80	Blatt 12
Abt./PG	Datum	Name	Abänderung	Spr.	CH			13

Anzeigen Wahlschalter  
Display selector switch



7-Segment-Anzeige

7-segment display



Schalter zur Einstellung d. Entlastungsdrucks.  
Switches for setting relieving pressure

Parabelanfang (Hülsen  $\phi$ ) = PH  
Start of parabola (core dia.)

Parabel im Scheitelpunkt = PS  
Parabola in apex


Parabelende = PE  
End of parabola

Einstellung d. End-Durchmesser = DE  
End dia. setting

DH; DS intern einstellbar  
DH; DS can be set internally

Analoges Meßinstrument zur  
Anzeige d. Steuerstroms

Analog measuring instrument  
for displaying control current.





Anzeigen Wahlschalter  
Display selector switch




7-Segment-Anzeige


7-segment display



PH



PS



PE



cm  
DE

Schalter zur Einstellung d. Entlastungsdrucks.  
Switches for setting relieving pressure



Parabelanfang (Hülsen  $\phi$ ) = PH  
Start of parabola (core dia.)

Parabel im Scheitelpunkt = PS  
Parabola in apex

Parabelende = PE  
End of parabola

Einstellung d. End-Durchmesser = DE  
End dia. setting

DH; DS intern einstellbar  
DH; DS can be set internally



cm

Arbeitsbreiteneinstellung  
Trim width setting



# Hydraulic Diagram =HL51

## 1. Rider Roll Controls MANUAL / AUTOMATIC

### 1.1 Manual Control

If there is a malfunction in the rider roll electronics, they can be switched off by switching over to manual control.



AUTO-MATIK

Sequence of operation and functions:

Key switch =HL51.N3-S1, control desk +P2

Switch "MANUAL/AUTOMATIC" to "MANUAL" position:

- Pressure reducing valve =HL51.-44 is de-energized,
- pressure reducer of the rider roll counterloading goes to "0" bar,
- illuminated pushbutton =HL51.N1-S10, control desk +P2 flashes constantly, thus signaling that the valves of the hand controls must be activated.

Set following valves:

- Close shut-off valve =HL51.-43 and =HL51.-45
- Open shut-off valve =HL51.-47,
- Set the pressure regulating valve =HL51.-46 to the desired counterloading pressure.

### 1.2 Automatic Controls

Sequence of operation and functions:

Switch back hand valves:

- Open shut-off valve =HL51.-43 and =HL51.-45,
- Close shut-off valve =HL51.-47,
- Reset pressure regulating valve =HL51.-46 to "0" bar.



AUTO-MATIK

Switch key switch =HL51.N3-S1 Control Desk +P2

"MANUAL/AUTOMATIC" to "AUTOMATIC":

- The electronics are switched on,
- Pressure reducing valve =HL51.-44 assumes the basic set point value of approx. 10 bar.

If there is no malfunction in the electronics (in the case of a malfunction, acknowledge fault report in the control desk), the counterloading curves can be adjusted when the drive is stopped (code switches on the front panel of the electronics).

When switching to the status "WINDING PRESSURE", illuminated pushbutton =HL51.N1-S10 lights up, the position of potentiometer =Q080.R10 "REWIND DIAMETER" is interrogated.

The set point value for the pressure reducing valve "RIDER ROLL COUNTERLOADING" is calculated based on the diameter according to the preselected curve, and the valve assumes the respective valve position. At the same time, solenoid valve =HL51.-49 "RIDER ROLL WINDING PRESSURE" is switched on (solenoid =HL51.N1-Y13 is energized).

## 2. Malfunctions in the Electronics

If there is a malfunction in the electronics during operation, the fault is displayed on the fault annunciator panel =HB90.N2-A10, control desk +P2 and the machine is switched to EMERGENCY STOP.

- Pressure reducing valve =HL51.-44 "RIDER ROLL COUNTER-LOADING" goes to "0" bar.
- Solenoid valve =HL51.-49 "RIDER ROLL WINDING PRESSURE" remains switched on (solenoid =HL51.N1-Y13 is energized).

If the fault cannot be acknowledged, key switch =HL51.N3-S1 control desk +P2 must be switched over to MANUAL control and the hand valve must be set.

## 3. EMERGENCY STOP during threading, operation and switched-on winding pressure

Pressure reducing valve =HL51.-44 "RIDER ROLL COUNTER-LOADING" maintains the momentary pressure.

Solenoid valve =HL51.-49 "RIDER ROLL WINDING PRESSURE" remains open (solenoid =HL51.N1-Y13 is energized).

The fault must then be acknowledged. Pressure reducing valve =HL51.-44 "RIDER ROLL CONTROLS" remains at the curve set point value.

Item No.	Symbol	Equipment Code No.	Equipment Designation, Short Function Description
25		=AE00.N1-H1	Pilot lamp, indicates: "MAIN DRIVE SECURED OFF"
27		=AE00.N1-S1	Selector switch, safety switch, main drive: "ON / OFF"
28,29		=AE00	CONTROL VOLTAGE
29		=AE00.N1-S11	Pushbutton, Controls: "OFF"
28		=AE00.N1-S12	Illuminated pushbutton, Controls: "ON"
87,88		=AQ11	TRIM REMOVAL
88		=AQ11.N1-S11	Pushbutton, Trim removal: "OFF"
87		=AQ11.N1-S12	Illuminated pushbutton, Trim removal: "ON"
89		=AQ12.N12-S10	Selector switch, damper valve setting: "MANUAL - AUTOMATIC"
90		=AQ12.N1-S13	Pushbutton, Trim removal damper valve: "OPEN"
91		=AQ12.N1-S14	Pushbutton, Trim removal damper valve: "CLOSE"
92,93		=BK11	UNWIND SIDE-SHIFTING
92		=BK11.N1-S13	Pushbutton, Side-shift to: "LEFT"
93		=BK11.N1-S14	Pushbutton, Side-shift to: "RIGHT"









Item No.	Symbol	Equipment Code No.	Equipment Designation, Short Function Description
15		=BK11.N3-P1	Oscillation counter, Oscillation of unwind
93		=BK11.N3-S11	Pushbutton, Oscillation: "OFF"
94		=BK11.N3-S12	Illuminated pushbutton, Oscillation: "ON"
20		=HA10.-10	Pressure gauge, compressed air supply operating pressure
60-62	Hydraulic	=HA40	HYDRAULICS
62		=HA40.N1-S1	Selector switch, Hydraulic pump motor: "1 - 2"
61		=HA40.N1-S12	Pushbutton, Hydraulic unit: "OFF"
60		=HA40.N1-S12	Illuminated pushbutton, Hydraulic unit: "ON"
35-37		=HB01	MAIN DRIVE
36		=HB01.N1-S1	Illuminated pushbutton, Main drive: "START - THREAD"
35		=HB01.N1-S3	Illuminated pushbutton, Main drive: "RUN"
37		=HB01.N1-S4	Pushbutton, Main drive: "STOP"

Jagenberg-Werke AG 4000 Düsseldorf  
Schutzvermerk nach DIN 34 beachten.













10620 Wf

Nitsch 9.84

TZS/07				e					
Abt./PG	Name	Datum	Änderung	Spr.	CH	4.11-31	=H	Blatt 2	7 Bl.






Item No.	Symbol	Equipment Code No.	Equipment Designation, Short Function Description
19		=HB01.N2-H6	Pilot lamp, indicates: "MAIN DRIVE EMERGENCY STOP"
51		=HB01.N2-S6	Mushroom pushbutton, Main drive: "EMERGENCY STOP"
50		=HB01.N2-S16	Mushroom pushbutton, Main drive: "EMERGENCY STOP"
1		=HB01.H1-P10	Ammeter, Main drive current take-up
3		=HB01.U1-P15	Web speed indicator, Main drive operating speed
34		=HB01.U1-R11	Potentiometer, Main drive speed pre-selection
4		=HB07.H1-P10	Ammeter, Rider roll drive current take-up
40, 41		=HB10	SINGLE SLITTER DRIVES
41		=HB10.N1-S11	Pushbutton, Bottom slitter drives: "OFF"
40		=HB10.N1-S12	Illuminated pushbutton,, Bottom slitter drives: "ON"

**Jagenberg-Werke AG 4000 Düsseldorf**  
Schutzvermerk nach DIN 34 beachten.

Item No.	Symbol	Equipment Code No.	Equipment Designation, Short Function Description
18		=HB90.N1-B1	Pilot lamp, indicates: "FAULT" IN PC AUXILIARY DRIVES"
26		=HB90.N1-S1	Selector switch, "TEST LAMPS - ACKNOWLEDGE FAULT"
17		=HB90.N1-S10	Pushbutton, PC fault display: "START"
16		=HB90.N2-A010	Digital display, displays: Fault report identification no., for list, see 4.55-30
83, 84		=HE31	WINDER DRUM SUCTION AIR
84		=HE31.N1-S11	Pushbutton, Winder drum suction air: "OFF"
83		=HE31.N1-S12	Illuminated pushbutton, Winder drum suction air: "ON"
55, 56		=HH	SLITTING STATION
56		=HH71.N1-S11	Pushbutton, Slitters: "CLAMP"
55		=HH71.N1-S12	Illuminated pushbutton, Slitters: "RELEASE"
58		=HH81.N1-S11	Pushbutton, Top slitters: "RETRACT"
57		=HH81.N1-S12	Illuminated pushbutton, Top slitters: "ENGAGE"

Item No.	Symbol	Equipment Code No.	Equipment Designation, Short Function Description
66-69		=HL30	SEQUENTIAL SWITCHINGS AUTOMATIC ROLL SET CHANGE
69		=HL30.N1-S11	Pushbutton, Automatic sequencing: "OFF"
66		=HL30.N1-S12	Illuminated pushbutton, Automatic sequencing I: "ON"
67		=HL30.N1-S13	Illuminated pushbutton, Automatic sequencing II: "ON"
68		=HL30.N1-S14	Illuminated pushbutton, Automatic sequencing III: "ON"
78		=HL51.N1-S10	Illuminated pushbutton, Rider roll: "WINDING PRESSURE"
79		=HL51.N1-S13	Pushbutton, Rider roll: "UP"
80		=HL51.N1-S14	Pushbutton, Rider roll: "DOWN"
77		=HL51.N3-S1	Key switch, Rider roll control: "MANUAL - AUTOMATIC"
21		=HL51.N4-U1	Digital display, shows: "RIDER ROLL CONTROL OIL PRESSURE"
81		=HHP81.N1-S13	Illuminated pushbutton, Cut-off knife: "UP"
82		=HP81.N1-S14	Pushbutton, Cut-off knife: "DOWN"



Item No.	Symbol	Equipment Code No.	Equipment Designation, Short Function Description
85		=HR11.N1-S13	Pushbutton, Ejector: "EJECT"(Inching Operation)
71		=HR41.N1-S10	Pushbutton, Lowering Unit: "EJECT POSITION"
72		=HR41.N1-S13	Pushbutton, Lowering unit: "UP"
73		=HR41.N1-S14	Illuminated pushbutton, Lowering unit: "DOWN"
76		=QQ80.R11	Potentiometer, Rider roll: altering rider roll counterloading, shifting the rider roll counter-loading curve.

## 1. Preparations

## 1.1 Check, and/or switch on

1.

Utility systems: electrics, pneumatics, hydraulics, lubrication

2.

Safety equipment

3.

Switchgear, indicating instruments.

## 1.2 Set up, prepare

1.

Slitting station: slitting width, slitter engagement

See Function Description =HH81.

2.

Web length measuring equipment: set counter (shut-off point).

See Function Description =HL10, Manual 2, Sub-Supplier  
Instructions =HL10.

3.

Roll diameter indicator: set scale indicator (shut-off point  
at desired or maximum rewind diameter).

See Function Description =HL41.

4.

Shaftless rewind: load cores into winder drum valley, core up  
core chucks.

See Function Description =HL41.

5.

Lowering platform remains in lowered position during makeready.

See Function Description =HR41.

6.

Parent reel: bring parent reel to unwind.

1.  
Unwind side-shift to LEFT  
Pushbutton =BK11.N1-S13, control desk +P2  
Pushbutton "B3", pushbutton station +R502.
2.  
Unwind, side-shift to RIGHT  
Pushbutton =BK11.N1-S14, control desk +P2  
Pushbutton "B4", pushbutton station +R502.
3.  
Center unwind radially with handwheel on unwind stand.
4.  
Spool Coupling DISENGAGE  
Pushbutton "B2", pushbutton station +R10.
5.  
Spool EJECT  
Pushbutton "B3", pushbutton station +R10.
6.  
Load full new reel into unwind.
7.  
Spool CLAMP and spool coupling ENGAGE.  
Pushbutton "B1", pushbutton station +R10.
8.  
Unwinding from TOP or BOTTOM  
Selector switch =HB61.N1-S7, control desk +P2.
9.  
Unwind diameter NEW REEL  
Pushbutton =HB61.N1-S8, control desk +P2.

10.  
Unwind diameter SET  
Potentiometer =HB61.U1-R13, control desk +P2  
(The unwind diameter setting must be adjusted only when the new reel is smaller than the standard maximum unwind diameter).
11.  
Brake generator ON  
Illuminated pushbutton =HB61.N1-S12, control desk +P2.
12.  
Brake generator MANEUVER  
Potentiometer =HB61.U1-R12, control desk +P2  
(Set the desired peripheral speed of the parent reel).

Jagenberg-Werke AG 4000 Düsseldorf  
Schutzvermerk nach DIN 34 beachten.

T0620 Mr

TZS/07	Nitschke 04 84 E								
Abt./PG	Name	Datum	Änderung	Spr.	CH	4.20-30	= H	Blatt 3	7 Bl.

## 3. Threading the Web

1.

Rotate reel by hand, tear a threading tail on the web.

2.

Main drive START - THREAD

Illuminated pushbutton =HB01.N1-S1, control desk +P2

Illuminated pushbutton "A3", pushbutton station +R503.

Illuminated pushbutton "A8", pushbutton station +R511.

(When pushbutton is pressed, a horn sounds; press pushbutton again when the start enable is indicated by blinking. The machine will then start up at threading speed).

3.

Brake generator MANEUVER

Potentiometer =HB61.U1-R12, control desk +P2

(Adjust the peripheral speed of the parent reel to the threading speed of the winder).

4.

Web threading ON

Illuminated pushbutton "R1", pushbutton station +R502.

Illuminated pushbutton "R2", pushbutton station +R503.

- Top slitters retract,
- Threading tape cradle on guide rolls engages; the tape drive motor is switched on,
- Threading tape cradle on 1st winder drum engages,
- Blower air is switched on,
- Suction fan is switched on.

5.

Thread the web into the machine.

6.  
Threading tape cradle on guide rolls RETRACT  
(OFF)  
Pushbutton "G5", pushbutton station +R503  
(The tape cradle is retracted when the web tail  
has entered the tape cradle on the 1st winder  
drum).

7.  
Web threading OFF  
Pushbutton "G5", pushbutton station +R502  
Pushbutton "G4", pushbutton station +R511  
(Actuate when web tail has been picked up at  
winder drum valley.  
- Tape cradle on winder drum retracts,  
- Blower air is switched off,  
- Suction air fan is switched off).

8.  
Feed web into the machine until it comes out  
machine-wide, free of folds and the web edges  
are in line with the outer core edges.

9.  
Top slitters ENGAGE  
Illuminated pushbutton =HH81.N1-S12, control  
desk +P2  
(Keep feeding web until the slit webs have  
reached the area of the cores).

10.  
Main drive STOP  
Pushbutton =HB01.N1-S4, control desk +P2  
Pushbutton "A3", pushbutton station +R503  
Pushbutton "A8", pushbutton station +R511.

11.  
Tear off the webs by hand near the cores and  
fasten the tails to the cores by suitable means.



## MAKEREADY AND SETTINGS ON THE MACHINE

### Sequence of Operations

**H  
4.20**

12.

Rider roll DOWN

Pushbutton =HL51.N1-S14, control desk +P2  
(Rider roll lowers in inch/jog mode).

13.

Lowering platform UP

Pushbutton =HR41.N1-S13, control desk +P2  
(Raising platform is in inch/jog mode).


14.

The machine is ready to start up.






1. Conditions  
The operating sequences Makeready and Settings on the Machine (4.20-) have been completed, the machine is ready to start up.
2. Switching On, Winding  
Control elements: on control desk +P2 and on pushbutton stations.
- 2.1 Switching On (in part already completed in Section 1./Instructions 4.20):




1.  
Main drive "ON": Selector switch =AE00.N1-S11




2.  
Set fault display to "ACKNOWLEDGE": Selector switch =HB90.N1-S1.



3.  
Control voltage "ON": Ill. pushbutton =AE00.N1-S12.



4.  
Hydraulic power unit "ON": Ill. pushbutton =HA40.N1-S12.




5.  
Bottom slitter drive "ON": Ill. pushbutton =HB10.N1-S12.




6.  
Top slitters "ENGAGE": Ill. pushbutton =HH81.N1-S12.



7.  
Trim removal "ON": Ill. pushbutton =AQ11.N1-S12.



8.  
Trim removal damper valve "MANUAL/AUTOMATIC":  
Selector switch =AQ12.N1-S10,



- in position "MANUAL", set damper:  
Damper valve "OPEN": Pushbutton =AQ12.N1-S13;  
Damper valve "CLOSE":  
Pushbutton =AQ12.N1-S14,



- in position "AUTOMATIC", damper valve opens automatically when preset speed (about 500 m/min. = about 1600 fpm) is reached (limit monitor in main drive.)



1.

2.

"SIDE-SHIFT TO RIGHT" (=BK11.N1-S14)

Radial adjustment is made on the handwheel on that unwind stand which is opposite the braking side. (Required when there is wrinkling at the web infeed).

3.

4.

Observe the winding operation. The web separation can be observed through the observation slots in the lowering unit, but only when the lowering unit is in "EJECT" position. However, in this case the operating speed is limited to maximum 1000 m/min. (abt. 3300 fpm) for safety reasons. A higher web speed, up to the rated maximum for the machine, is possible only when the lowering unit is in nip guard position (upper end position).

- Limit switch =HR41.N1-B17 "Maximum rewind diameter", when the set shut-off point (roll diameter indicator) has been reached
- web length counter =HL10.N1-P1, when the shut-off point set on the web length measuring unit has been reached
- light gate =HL15.N1-B1, web break monitor, in case of a web break. The web break monitor is optional equipment.

## 4. FAST STOP, when Unwind Is Equipped with Brake Generator

The main drive of the winder switches to "STOP" and decelerates to full stop at the normal rate. The brake generator brakes the unwinding reel in the shortest possible time, assisted by the emergency brake.

## 4.1 FAST STOP through Pushbutton Actuation

- Pushbutton =HB61.N2-S5, on control desk +P2
- Pushbutton "G4", pushbutton station +R10
- Pushbutton "G1", pushbutton station +R12
- Pushbutton "G1", pushbutton station +R501
- Pushbutton "G7", pushbutton station +R502.

## 4.2 FAST STOP through Automatic Shut-Off in Case of a Web Break

- Light gate =HL15.N1-B1, photo-cell, web break monitor.

## 5. EMERGENCY STOP through Actuation of Mushroom Pushbutton

The complete line is stopped in the shortest possible time. All movements are interrupted. Exception: the ejector beam retracts into its rear end position.

- Mushroom pushbutton =HB01.N2-S6, control desk +P2
- Mushroom pushbutton =HB01.N2-S16, control desk +P2
- Mushroom pushbutton "R5", pushbutton station +R10
- Mushroom pushbutton "R2", pushbutton station +R12
- Mushroom pushbutton "R2", pushbutton station +R501
- Mushroom pushbutton "R8", pushbutton station +R502.



6. Description of the Sequential Switchings I, II and III  
for Automatic Roll Set Change

## Sequential Switching I

Ejecting the roll set when the unwind reel is not yet empty and web is connected to the rewound roll set.

## Sequential Switching II

- a) The reel spool (reel shell) is empty or the web has broken, i.e. the connection between unwind and rewind through the web is interrupted. The finished roll set is to be ejected and lowered.
- b) Sequential Switching II can also be used when a change in slitting width set-up is to be made within one parent reel without taking the web out of the machine.

Condition: only a slight change in only a few slitting widths, and holes must be torn in the web in the area of the slitters to be shifted.

## Sequential Switching III

This is the continuation of Sequential Switching II, with the loading of a new set of cores after the web has been threaded.



4.  
Not applicable.

5.  
The lowering platform pivots into eject position (if it is not already in that position).

6.  
When the functions 1 - 5 have been completed, the suction air fan switches on. This creates an underpressure (partial vacuum) in the first winder drum.

7.  
As the ejecting movement starts, the core set is clamped by the core clamp. The ejector beam swings forward and ejects the roll set onto the lowering unit. In its forward end position, the ejector beam actuates a limit switch.

8.  
The finished roll set rolls onto the lowering platform, whereby the slit webs tear off along the cut-off knife. The web tails remaining in the machine are drawn against the first winder drum through suction holes and held in position.

9.  
Not applicable.

10.  
Actuation of the limit switch "EJECTOR EJECT (FORWARD)" causes the cut-off knife bar to retract into its lower end position, releasing the limit switch. This causes the core clamp to open, and the core set drops into the winder drum valley.  
In opened position, the core clamp actuates a limit switch.

11.  
Not applicable.

12.  
Not applicable.

13.  
The ejected set rolls over a limit switch on the lowering platform, generating a signal. This signal goes into holding position and causes the pushbutton "LOWERING PLATFORM DOWN" to blink.  
This signals to the operating crew that the set can be lowered.  
Releasing the pushbutton causes the lowering movement to stop. When the lowering unit is in its bottom end position a limit switch is actuated.



14.

When the limit switch "CORE CLAMP OPEN" has been actuated, the ejector beam starts to move into its retracted end position (limit switch "EJECTOR EJECT" is released), the rewind carriages move into their bottom end position, where they actuate a limit switch on each side, which causes the core chucks to move into the cores.

15.

The rider roll lowers when the limit switch "EJECTOR EJECT" is released. If the rider roll reaches its limit switch "RELEASE POSITION" before the ejector beam has reached its retracted end position and before the core chucks have cored up, the rider roll is stopped. After these conditions have been fulfilled, the rider roll continues to lower. When the limit switch "RIDER ROLL DOWN" is actuated, the counterloading system is switched over to winding pressure with a time delay.

16.

Not applicable.

17.

The movements 14 and 15 take place simultaneously.

When the limit switches:

- a) rewind carriages down
- b) core chucks cored up
- c) rider roll down and switched over to winding pressure
- d) not applicable
- e) ejector beam retracted
- f) lowering platform down

have been actuated, Sequential Switching I and the suction air fan are switched off.



6.  
When the functions 1 - 5 have been completed, the suction air fan is switched on, creating an underpressure (partial vacuum) in the first winder drum. However, the suction air fan is switched on only if there is a web in the machine (Sequential Switching IIb).

7.  
As the ejecting movement begins, the core set is clamped in the core clamp. The forward movement of the ejector beam ejects the roll set onto the lowering platform. In its forward (eject) end position, the ejector beam actuates a limit switch.

8.  
Only in Sequential Switching IIb:  
The finished set rolls onto the lowering platform, whereby the webs tear along the cut-off knife. The web tails remaining in the machine are drawn against the first winder drum through suction holes and held in position.

9.  
Not applicable.

10.  
When the ejector beam has reached its forward end position (no cores are loaded into the winder drum valley), or the ejected roll set has rolled over the limit switch on the lowering platform, the ejector retracts. In its rear end position, a limit switch is actuated.

11.  
If no new set of cores was fed into the core clamp during the winding operation, this can be done during the parent reel change which follows.

12.  
As the finished set rolls over the limit switch on the lowering platform, a signal is generated. This signal goes into holding position and causes the pushbutton "LOWERING UNIT DOWN" to blink. This signalizes to the operating crew that the set can be lowered.  
The set is lowered by pressing the pushbutton. Releasing the pushbutton prematurely cause the lowering movement to stop. In its lower end position, the lowering unit actuates a limit switch.

13.  
When the limit switches "LOWERING UNIT DOWN" and "EJECTOR BEAM RETRACTED" and "CUT-OFF KNIFE BAR DOWN" have been actuated, Sequential Switching II shuts off (the suction air is switched on).

See also Sequential Switching IIb.

JW 02901

#### 6.4 Threading a New Web

##### Preparations for Sequential Switching III

1. remove empty spool (shell) from unwind bearings.
2. load new, full reel.
3. switch on brake generator.
4. tear a threading tail on the web by rotating the reel.
5. press pushbutton "THREAD" (or "CRAWL").
6. press pushbutton "WEB THREADING ON"  
(tape cradles and suction air fan on).
7. press pushbutton "SLITTERS RETRACT".
8. using the maneuvering potentiometer,  
rotate reel in unwind direction.
9. thread the web into the machine,  
then retract threading tape cradle on guide rolls.
10. pick up the web in the winder drum valley.
11. press pushbutton  
"THREADING TAPE CRADLE ON WINDER DRUM OFF".
12. draw web into the machine until it is full width and  
free of wrinkles.
13. press pushbutton "SLITTERS ENGAGE".
14. when the slit webs have reached the winder drum valley,  
press pushbutton "STOP".
15. press pushbutton "CUT-OFF KNIFE BAR UP".
16. tear off the individual slit webs  
across the cut-off knife edge.
17. raise lowering unit in manual operation  
at least to "eject position".

## 6.5 Sequential Switching III

Sequential Switching III is the continuation of Sequential Switching II.

The new set of cores must have been fed in and the web must have been threaded.

### Basic Conditions for Starting Sequential Switching III:

- the machine is stopped, the parking brake is pressurized.
- no other Sequential Switching must be in progress.
- the cores, provided with an adhesive track, must have been fed into the core clamp.
- the manual core feeding operation must have been completed and the core stop must be in its retracted end position.
- the core set must not protrude beyond the core clamp.
- the suction fan remains switched on.
- the last positions/conditions of Sequential Switching II must still exist/prevail (except for the lowering platform).
- the lowering platform must be in uppermost or in eject position.

When pushbutton "SEQUENTIAL SWITCHING III ON" is pressed, the following sequence of functions begins:

1.  
Not applicable.
2.  
The cut-off knife bar retracts and actuates a limit switch in its bottom end position.
3.  
As the core loading (roll ejecting) movement of the ejector beam begins, the cores are clamped in the core clamp. In its forward end position, the ejector beam actuates a limit switch.

4.  
When the limit switches "EJECTOR FORWARD" and "CUT-OFF KNIFE BAR DOWN" are actuated, the core clamp opens and the core set drops into the winder drum valley. In its opened position, the core clamp actuates a limit switch.

5.  
Not applicable.

6.  
Not applicable.

7.  
With actuation of the limit switch "CORE CLAMP OPEN", the ejector beam begins to move into its rear end position (limit switch "EJECTOR FORWARD" FREE), the rewind carriages move into their bottom end position, where they actuate a limit switch on each side which causes the core chucks to move into the cores.

8.  
The rider roll moves down when the limit switch "EJECTOR FORWARD" is no longer actuated. If the rider roll reaches its limit switch "RELEASE POSITION" before the ejector beam has reached its rear end position and before the core chucks have cored up, then the rider roll is stopped. When these conditions have been fulfilled, the lowering movement of the rider roll continues. When the limit switch "RIDER ROLL DOWN" is actuated, the counterloading system is switched over to winding pressure with a time delay.

9.  
Not applicable.

10.  
When the limit switches:

- a) rewind carriages down
- b) core chucks cored up
- c) rider roll down
- d) not applicable
- e) ejector beam retracted

have been actuated, Sequential Switching III and the suction air fan shut off.

1.  
Set the core stop assembly to the same scale value which the core chucks have when they are cored up.
2.  
Press pushbutton "CORE STOP FORWARD".
3.  
Push the core sections into the core guide (chute) in the proper sequence according to the slitting width set-up.
4.  
Actuate the foot switch for the glue spray nozzle; this applies a glue track to the core.
5.  
Push the complete core set up against the core stop with the help of a feeding mandrel. The correct location of the core set is indicated by a pilot lamp. (Pilot lamp "CORE SET UP AGAINST CORE STOP" =HP95.N3-H1 lights up.)
6.  
The manual core feeding operation is completed when the illuminated pushbutton "CORE STOP RETRACT" has been actuated and the core stop cylinder has retracted to its rear end position.



8. Unloading the Roll Set W I T H O U T  
Sequential Switching

1.

Conditions:

- retract core chucks from roll set,
- move rewind carriages into upper end position,
- move lowering unit into eject position
- move rider roll into upper end position.

2.

Pushbutton =HR11.N1-S13 EJECTOR EJECT


Keep this pushbutton depressed until the roll set has been deposited on the lowering unit and has there touched the contact strip. As the ejecting movement begins, the belt tensioner of the winder drum transmission belt at the same time slackens the belt. This ensures that the free turning of the second winder drum can take place, as is required for ejecting the set.

3.

Release pushbutton =HR11.N1-S13, the ejector retracts to its end position. Blinking of the ill. pushbutton =HR41.N1-S14 LOWERING UNIT DOWN indicates that the set can now be lowered.

4.

Press ill. pushbutton =HR41.N1-S14 LOWERING UNIT DOWN. For safety reasons, the roll set is lowered in jog or inch mode (i.e. if the pushbutton is released, the lowering movement stops). When the bottom end position is reached, the lowering unit actuates a proximity switch. The belt tensioner then tightens the winder drum transmission belt again. The roll set rolls out of the lowering unit along the sloping surface.



In case of a web break, the web ends must be carefully spliced so that the quality of the rewound reel will not suffer. The same is true when a new unwinding reel is to be spliced to the trailing edge of the previous reel.

To make a splice, proceed as follows:

1. Disengage top knives and point up the web to be spliced.
2. Thread up the web through the machine at crawl speed as usual. If the leading edge of the web does not adhere to the rewound reel, fasten it temporarily (fig. 1).
3. As soon as the web is running through the machine properly, reengage the top knives. Remove the rewound but not slit paper layers (and the damaged trailing end of the used-up parent reel) with a knife (fig. 2).
4. Unwind the broke from the rewinding reel at crawl speed. As soon as the web end is free (fig. 3) stop machine. Tack web end to reel.
5. Stick "Scotch" tape No. 254\* (30 mm wide, adhesive on one side only) on to the front winding drum across the whole crown width as shown in fig. 4. On to this tape, stick the "Scotch" tape No. 405 (19 mm wide, adhesive on both sides, one side protected by a plastic foil). Now remove the protective foil from Scotch tape No. 405.
6. Pull the trailing web edge down across the front winding drum tightly (fig. 5) and press the web against the adhesive face of the Scotch tape No. 405. Crease the overhanging end of the web and tear it off.
7. Lower rider roll (switching position "winding"). Start up machine at crawl speed. The narrow Scotch tape will separate from the smooth surface of the wider tape (fig. 6); the new web entering between the winding drums will adhere to the narrow Scotch tape without wrinkle formation as the latter comes around to the rear winding drum (fig. 7).
8. As soon as the splice appears at the front of the machine, shut off drive motor. Crease and tear off the overhanging web end (fig. 8).
9. The Scotch tape forming the splice is now cut with a knife at each web slit. The splice can now be reinforced with adhesive tape.

The wide Scotch tape on the front winding drum can be left there for making further splices.

Whereas the tape No. 254 must be replaced in short intervals, the tape No. 549 (Teflon film) can be used over a period of up to 6 months.

Scotch tapes are supplied by Messrs. Minnesota Mining & Manufacturing Co. (3M).

\* or "Scotch" tape No 549 (thickness: 0,0039"  $\approx$  0,1mm)




Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6




Fig. 7





Fig. 8

# Scotch

Adhesive Tape No. 405

Instructions for removing the adhesive tape from the protective film



Loosen a short piece of tape from the roll. With this strip, crease a right angle, whereby adhesive face must lie on adhesive face. Press the crease together with the thumb for a short interval.

Release crease and pull adhesive tape back into its original position with a sharp snap.

This is what the tape should now look like. The adhesive tape can now be easily and quickly removed from the protective film!

# WESTVACO FAULTS

Westvaco, Störmeldeliste

## 800MR-W1 (GRAY)

REF NO	LEGEND	QTY	REF NO	LEGEND	QTY
53	FAST STOP	1	66	AUTO ROLL CHANGE	1
54	NORMAL STOP	1	67	MAIN DRIVE	1
55	HYDRAULIC UNIT FILTER	1	68	DRIVE SECURED	1
56	HYDRAULIC UNIT MINIMUM PRESSURE	1	800MR-W61 (RED)		
57	STOP CABLE	1			
58	START INTERLOCKS	1			
59	ACCELERATION INTERLOCKS	1			
60	SLITTER MOTOR	1			
61	AIR PRESSURE	1	REF NO	LEGEND	QTY
62	PROTRUDING CORE AT EJECT	1	69	EMERGENCY STOP	1
63	SPOOL COUPLING DISENGAGED	1	Ref.-Nr. Legende		
64	ROLL ON LOWERING CRADLE	1	53	Schnellhalt	
65	EJECTOR FORWARD	1	54	Normalhalt	
			55	Hydraulikaggregat Filter	
			56	Hydraulikaggregat min.Druck	
			57	Halt-Kabel	
			58	Start Verriegelungen	
			59	Beschleunigung Verriegelungen	
			60	Messermotor	

### Ref.-Nr. Legende

53	Schnellhalt
54	Normalhalt
55	Hydraulikaggregat Filter
56	Hydraulikaggregat min.Druck
57	Halt-Kabel
58	Start Verriegelungen
59	Beschleunigung Verriegelungen
60	Messermotor
61	Luftdruck
62	Vorstehende Hülse beim Ausstoß
63	Tambourkupplung ausgerückt
64	Rolle auf Absenkbühne
65	Ausstoßvorrichtung vor
66	Rollenwechselautomatik
67	Hauptantrieb
68	Hauptantrieb gesichert
69	Nothalt

Betr.: Westvaco, Luke  
Vari-Step 65; 30.23.665

Vari-Step 65;

203,741,2508


84.08.82

18:03.08.84. 00:14

REF. NO.	LEGEND	QTY.
1	SLITTER NO. 0 FAULT	1
2	SLITTER NO. 1 FAULT	1
3	SLITTER NO. 2 FAULT	1
4	SLITTER NO. 3 FAULT	1
5	SLITTER NO. 4 FAULT	1
6	SLITTER NO. 5 FAULT	1
7	SLITTER NO. 6 FAULT	1
8	SLITTER NO. 7 FAULT	1
9	SLITTER NO. 8 FAULT	1
10	SLITTER NO. 9 FAULT	1

MAKE FROM AB800T-X559 (10 REQ'D)

○ DENOTES ITEM NO. ON B.O.M.



REV	89.3091.08179	SCALE	HALF	SHEET	1	OF	2
DRAWN	WOLSON	DATE	6-11-84	APPL			
TITLE				PILOT LIGHT STATION			
NEXT ASSY				R530			
MODIFIED FROM				DATE			
REV				DATE			

89.3091.08179

BRUNING 40-534 60066

+R530

This drawing is our exclusive property and must not be copied or made out in third parties' hands without permission has been given.

The purpose of maintenance is to reduce wear and tear, and to avoid or eliminate damage in good time. Maintenance, inspection and repair work should be carried out as an organized routine.

Special instructions concerning maintenance, inspection and repair work are contained in:  
 Section I of this manual and  
 Book 2 Sub-suppliers manuals.

### General Instructions

#### 1. Supply systems

Check supply systems daily: electrics, pneumatics, hydraulics and lubrication.

#### 2. Checking functions

Daily checks should be made on all safety, guarding, switchgear and operating equipment, e.g.: safety guards, photocells, proximity switches, switchgear and indicating instruments.

#### 3. Lubrication

It is essential that the lubricating instructions are observed. Open bearings, gear racks, pinions, round guides and roller bars should be cleaned daily and lightly greased.

##### 3.1 Sliding surfaces

Lead screws, gear wheels, gear racks, guide surfaces and guide strips. During the running in period (approx. 600 operating hours) there will be slight wear on the sliding surfaces of these machine parts which will tend to smooth down the sliding surfaces. This wear, consisting of fine metal particles, contaminates the lubricating grease. The sliding surfaces of these parts should therefore be cleaned with a suitable medium during and following the running-in phase and regreased.

#### 4. Piping and fittings

Regularly check all piping and fittings for rust formation, dirt deposit and leakage. Loose fittings should be retightened, scuffed piping should be replace.

#### 5. Clamping bolts, screw connections

All clamping bolts, particularly foundation screws, should be checked regularly for proper seating and retightened if necessary.

#### 6. Cleaning

The machine should always be kept clean. Dust should be vacuumed, and not blown off. Rags soaked with cold cleaner (cleansing petrol) or petroleum are suitable for cleaning heavily soiled machine parts.

When using high pressure cleaner units (steam and/or water) all bearing points should be regreased after the machine has been thoroughly cleaned.

JAGENBERG AG 4000 DUESSELDORF 1  
 Schutzzeichen nach DIN 34 beachten

10620 Nr

TZS 07	3.7.84	Nitschke		e		5,01-03	- H	Blatt 2
Abt./PG	Datum	Name	Abänderung	Spr.	CH			



The maintenance instructions, lubrication and operating media tables will be found in the operating instructions Manual II, subsupplier instructions. When maintenance and repair work must be carried out, observe the instructions of our subsuppliers.

In the following, excerpts for maintenance of the pneumatic equipment:

#### Compressed Air Oil Mist Lubricator

When the unit is without pressure, fill the oil mist lubricator up to the mark with lubricating oil of the viscosity group ISO VG 22 (viscosity 2 to 2.5 E° at 50°C, e.g. Shell-Tellus oil C22). Subsequent replenishing can take place without interrupting operation (check valve at the inlet). For cleaning the vessel use test gasoline as per DIN 51632. The oil vessel must not come into contact with aggressive medias such as acetone, nitro-thinner and the like.

Using the adjusting screw, so set the oil delivery volume that one drop of oil is misted for every 300 litres of air flowing through.

#### Compressed Air Filter (Water Trap)

The unit must be drained at regular intervals; under no circumstances may the water level increase above the separating cap, since otherwise the separated-out water would be pulled along again. A manually operated drain valve at the bottom of the container is used for draining off the condensate.

To ensure highest capacity at lowest pressure drop, it is necessary to clean the filter insert regularly. To clean the condensate container, use test gasoline as per DIN 51632 (same as for oil mist vessel).

#### Noise Reducer (Silencer)

If soiled, clean the silencers with nitro-cleaning medium.

#### Other Components

Under normal operating conditions, regular maintenance work is not required. Disturbances in operation are almost always caused by not properly cleaned air.

The primary principle of good maintenance is the correct and regular lubrication with the properly chosen lubricants. For lubricating the machine, observe the following documentation:

- lubrication diagram (lubrication plan, lubrication instructions)
- lubrication instruction - explanation
- lubrication table
- lubrication and maintenance instructions for equipment of our subsuppliers, see Operating Instructions Manual 2, Sub-Supplier Instructions.

### 1. Lubrication Diagram

Shown on the lubrication diagram are:

- location of the lubricating points (central lubrication points), designated with item number.
- type of lubricant, indicated by lubrication symbol and lubricant number as per Jagenberg lubrication table and lubrication instruction - explanation
- type of lubrication, shown by lubrication symbol and picture symbol as per Jagenberg lubricating instruction - explanation
- lubrication interval, shown by picture of symbol (clock) and statement of operating hours, see Jagenberg lubricating instruction - explanation.

### 2. Lubrication Instruction - Explanation


This contains the lubricant designations, guiding test values, fields of application and type of application, furthermore an explanation of the symbols and picture symbols used in the lubrication diagram.

### 3. Lubrication Table


The lubrication table is a selecting and comparison table and contains lubricant recommendations of well-known lubricant manufacturers. The lubricants named there have proven themselves on our machines. We therefore recommend that these or provably equivalent ones be used.

#### 4. Explanation of Lubricating Instructions

Examples:



Lubrication  
Interval:  
50 operating  
hours ( $\hat{=}$  1 x  
weekly in 1-  
shift opera-  
tion)  
Lubricant:  
No. 8 =  
grease



Grease lubrica-  
tion (w/ grease  
gun)



Lubrication &  
Maintenance as  
per Operating  
Instructions  
(see Manual 2,  
Sub-Supplier  
Instructions)