



ROBOTICS

Product specification

IRB 1520



Trace back information:
Workspace 26-1 version a30
Checked in 2026-04-30
Skribenta version 5.6.019

Product specification

IRB 1520

OmniCore

Document ID: 3HAC090443-001

Revision: E

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2012-2026 ABB. All rights reserved.
Specifications subject to change without notice.

Table of contents

Overview of this specification	7
1 Description	9
1.1 Structure	9
1.1.1 Introduction	9
1.1.2 Different robot versions	11
1.2 Applicable standards	14
1.3 Installation	15
1.3.1 Introduction	15
1.3.2 Technical data	16
1.3.3 Mounting the manipulator	20
1.4 Calibration and reference	23
1.4.1 Calibration methods	23
1.4.2 Fine calibration	25
1.5 Robot load and diagrams	26
1.5.1 Introduction	26
1.5.2 Load diagrams	27
1.5.3 Maximum load and moment of inertia for full and limited axis (center line down) movement	29
1.5.4 Wrist torque	31
1.6 Mounting of equipment	32
1.7 Robot motion	36
1.7.1 Introduction	36
1.7.2 Performance according to ISO 9283	38
1.7.3 Velocity	39
1.7.4 Robot stopping distances and times	40
1.8 Customer connections	41
1.9 Maintenance and troubleshooting	42
2 Specification of variants and options	43
2.1 Introduction to variants and options	43
2.2 Manipulator	44
2.3 Floor cables	45
2.4 Application	46
2.4.1 Application floor cables	46
Index	49

This page is intentionally left blank

Overview of this specification

About this product specification

It describes the performance of the manipulator or a complete family of manipulators in terms of:

- The structure and dimensional prints
- The fulfilment of standards, safety and operating requirements
- The load diagrams, mounting of extra equipment, the motion and the robot reach
- The specification of variant and options available

Usage

Product specifications are used to find data and performance about the product, for example to decide which product to buy. How to handle the product is described in the product manual.

Users

It is intended for:

- Product managers and product personnel
- Sales and marketing personnel
- Order and customer service personnel

References

Reference	Document ID
<i>Product manual - IRB 1520</i>	3HAC043435-001
<i>Product manual - Arc welding equipment for IRB 1520ID</i>	3HAC043438-001
<i>Product specification - OmniCore C line RW 7 (RobotWare 7)</i>	3HAC065034-001
<i>Product specification - OmniCore C line RobotWare 8 (RobotWare 8)</i>	3HAC098715-001
<i>Product specification - OmniCore V line RW 7 (RobotWare 7)</i>	3HAC074671-001
<i>Product specification - OmniCore V line RW 8 (RobotWare 8)</i>	3HAC098717-001
<i>Product manual - OmniCore C30 Type B</i>	3HAC097281-001
<i>Product manual - OmniCore C90XT Type A</i>	3HAC089065-001
<i>Product manual - OmniCore V250XT Type B</i>	3HAC087112-001
<i>Product manual - OmniCore V400XT</i>	3HAC081697-001
<i>Product specification - Robot stopping distances according to ISO 10218-1</i>	3HAC048645-001

Revisions

Revision	Description
A	First edition.
B	Published in release 24C. The following updates are done in this revision: • Added support for OmniCore C90XT Type A controller.

Continues on next page

Revision	Description
C	Published in release 24D. The following updates are done in this revision: • Updated the section Technical data on page 16. • Updated the options available to the product. • Added options <i>[3203-X] Mains cable</i>.
D	Published in release 25.3. The following updates are done in this revision: • Company name updated to reflect current legal entities. • Updated portal name from myABB to ABB Robotics One.
E	Published in release 26.1. The following updates are made in this revision: • Company name updated to reflect current legal entities. • Removed duplication of robot weight specification. • Added support for RobotWare 8. • Added support for OmniCore C30 Type B controller and removed information for C30 Type A.

1 Description

1.1 Structure

1.1.1 Introduction

About IRB 1520

ABB's IRB 1520 robot is a dedicated arc welding robot available in one version. It has a compact process upper arm designed for integrated dressing packages for arc welding. The IRB 1520ID-4/1.5 is a part of the ArcPack Lean concept.

Without arc welding package, the robot can be equipped with OmniCore C line controller.

With arc welding package, the robot can be equipped OmniCore V line controller.

Operating system

The robot is equipped with the OmniCore C30/C90XT/V250XT/V400XT controller and robot control software, RobotWare. RobotWare supports every aspect of the robot system, such as motion control, development and execution of application programs, communication etc. See *Operating manual - OmniCore*.

Additional functionality

For additional functionality, the robot can be equipped with optional software for application support - for example communication features - network communication - and advanced functions such as multitasking, sensor control etc. For a complete description on optional software, see the product specification for the robot controller.

Software product range

We have added a range of software products - all falling under the umbrella designation of Active Safety - to protect not only personnel in the unlikely event of an accident, but also robot tools, peripheral equipment and the robot itself.

Safety

Safety standards valid for complete robot, manipulator and controller.


Continues on next page

1 Description

1.1.1 Introduction

Continued

Manipulator axes



xx1100000294

Pos	Description	Pos	Description
A	Axis 1	B	Axis 2
C	Axis 3	D	Axis 4
E	Axis 5	F	Axis 6

1.1.2 Different robot versions

General

The IRB 1520 is available in one version and can only be mounted on the floor or inverted (no tilting allowed around X-axis or Y-axis). See [Robot motion on page 36](#) for limitations.

Robot type	Handling capacity (kg)	Reach (m)
IRB 1520ID	4 kg	1.5 m

Other technical data

Data	Description	Note
Airborne noise level	The sound pressure level outside the working space	< 70 dB (A) Leq (acc. to Machinery directive 2006/42/EG)

Power consumption

With OmniCore C30/C90XT

Type of movement	Power consumption (kW) (all variants)
ISO Cube Max. velocity	0.46
Robot in calibration position	All variants (kW)
Brakes engaged	0.10
Brakes disengaged	0.23

With OmniCore V250XT/400XT

Type of movement	Power consumption (kW) (all variants)
ISO Cube Max. velocity	0.51
Robot in calibration position	All variants (kW)
Brakes engaged	0.14
Brakes disengaged	0.31


Path E1-E2-E3-E4 in the ISO Cube, max.load.

Continues on next page

1 Description

1.1.2 Different robot versions

Continued



xx1000000101


Pos	
A	400 mm

Power factor ($\cos \varphi$)

The power factor is above 0.95 at a steady state power consumption higher than 2.0 kW, when the IRB 1520ID is connected to the OmniCore V line.

Continues on next page

Dimensions IRB 1520ID-4/1.5



xx1100000295

Pos	Description
A	Minimum turning radius R=307 mm

1 Description

1.2 Applicable standards

1.2 Applicable standards

General

This product is designed according to the global product standard ISO 10218-1:2025, *Robots for industrial environments - Safety requirements - Part 1 Robots*, In case of deviation from ISO 10218-1:2025, these are listed in the declaration of incorporation. The declaration of incorporation is part of the delivery.

Robot standards

Standard	Description
ISO 9283	Manipulating industrial robots – Performance criteria and related test methods
ISO 9787	Robots and robotic devices – Coordinate systems and motion nomenclatures
ISO 9946	Manipulating industrial robots – Presentation of characteristics

Other standards used in design

Standard	Description
ISO 9283	Manipulating industrial robots - Performance criteria and related test methods
ISO 9787	Robots and robotic devices -- Coordinate systems and motion nomenclatures
ISO 9946	Manipulating industrial robots - Presentation of characteristics
IEC 61000-6-2	Electromagnetic compatibility (EMC) – Part 6-2: Generic standards – Immunity standard for industrial environments
IEC 61000-6-4	Electromagnetic compatibility (EMC) – Part 6-4: Generic standards – Emission standard for industrial environments
IEC 61326-3-1	Immunity requirements for safety-related systems and for equipment intended to perform safety-related functions (functional safety) – General industrial applications

1.3 Installation

1.3.1 Introduction

General

IRB 1520ID-4/1.5 can only be mounted on the floor or inverted (no tilting allowed around X-axis or Y-axis). An end effector with max. weight of 4 kg including payload, can be mounted on the tool flange. See [Robot load and diagrams on page 26](#).

Extra equipment can be mounted on the upper arm. See [Mounting of equipment on page 32](#).

Extra loads

Extra load, which is included in the load diagrams, can be mounted on the upper arm. See [Robot load and diagrams on page 26](#).

Working range

Electronic Position Switches can be used on all axes for position indication of the manipulator.

Explosive environments

The robot must not be located or operated in an explosive environment.

1 Description

1.3.2 Technical data

1.3.2 Technical data

Weight, robot

The table shows the weight of the robot.

Robot model	Weight
IRB 1520	170 kg



Note

The weight does not include tools and other equipment fitted on the robot.

Mounting positions

The table shows valid mounting options for the manipulator.

Mounting option	Installation angle	Note
Floor mounted	0° ⁱ	
Suspended	180°	

ⁱ A tilt of up to 15° does not affect the payload or reach, but it can have a negative impact on performance and lifetime. The actual value must be set in the system parameters.



Note


The actual mounting angle must always be configured in the system parameters, otherwise the performance and lifetime is affected. See the product manual for details.

Continues on next page

Loads on foundation, robot

The illustration shows the directions of the robots stress forces.

The directions are valid for all floor mounted, suspended and inverted robots.



xx1100000521

F_{xy}	Force in any direction in the XY plane
F_z	Force in the Z plane
T_{xy}	Bending torque in any direction in the XY plane
T_z	Bending torque in the Z plane

The table shows the various forces and torques working on the robot during different kinds of operation.

**Note**

These forces and torques are extreme values that are rarely encountered during operation. The values also never reach their maximum at the same time!

**WARNING**

The robot installation is restricted to the mounting options given in following load table(s).

Floor mounted

Force	Endurance load (in operation)	Max. load (emergency stop)
Force xy	$\pm 1900 \text{ N}$	$\pm 4300 \text{ N}$
Force z	$1850 \pm 900 \text{ N}$	$1850 \pm 2350 \text{ N}$
Torque xy	$\pm 1550 \text{ Nm}$	$\pm 3900 \text{ Nm}$
Torque z	$\pm 390 \text{ Nm}$	$\pm 1200 \text{ Nm}$

Continues on next page

1 Description

1.3.2 Technical data

Continued

Suspended

Force	Endurance load (in operation)	Max. load (emergency stop)
Force xy	± 1900 N	± 4250 N
Force z	- 1850 ±750 N	-1850 ±2350 N
Torque xy	± 1550 Nm	± 3900 Nm
Torque z	± 390 Nm	± 1200 Nm

Requirements, foundation

The table shows the requirements for the foundation where the weight of the installed robot is included:

Requirement	Value	Note
Flatness of foundation surface	0.5 mm	Flat foundations give better repeatability of the resolver calibration compared to original settings on delivery from ABB. The value for levelness aims at the circumstance of the anchoring points in the robot base. In order to compensate for an uneven surface, the robot can be recalibrated during installation. If resolver/encoder calibration is changed this will influence the absolute accuracy.
Minimum resonance frequency	22 Hz  Note It may affect the manipulator life-time to have a lower resonance frequency than recommended.	The value is recommended for optimal performance. Due to foundation stiffness, consider robot mass including equipment. ⁱ For information about compensating for foundation flexibility, see the application manual of the controller software, section <i>Motion Process Mode</i> .

ⁱ The minimum resonance frequency given should be interpreted as the frequency of the robot mass/inertia, robot assumed stiff, when a foundation translational/torsional elasticity is added, i.e., the stiffness of the pedestal where the robot is mounted. The minimum resonance frequency should not be interpreted as the resonance frequency of the building, floor etc. For example, if the equivalent mass of the floor is very high, it will not affect robot movement, even if the frequency is well below the stated frequency. The robot should be mounted as rigid as possible to the floor.

Disturbances from other machinery will affect the robot and the tool accuracy. The robot has resonance frequencies in the region 10 – 20 Hz and disturbances in this region will be amplified, although somewhat damped by the servo control. This might be a problem, depending on the requirements from the applications. If this is a problem, the robot needs to be isolated from the environment.

Storage conditions, robot

The table shows the allowed storage conditions for the robot:

Parameter	Value
Minimum ambient temperature	-25° C
Maximum ambient temperature	+55° C
Maximum ambient temperature (less than 24 hrs)	+75° C
Maximum ambient humidity	95% at constant temperature (gaseous only)

Continues on next page

Operating conditions, robot

The table shows the allowed operating conditions for the robot:

Parameter	Value
Minimum ambient temperature	+5°
Maximum ambient temperature	+45°
Maximum ambient humidity	95% at constant temperature (gaseous only)

Protection classes, robot

The table shows the available protection types of the robot, with the corresponding protection class.

Protection type	Protection class ⁱ
Manipulator, protection type Standard	IP40

ⁱ According to IEC 60529.

1 Description

1.3.3 Mounting the manipulator

1.3.3 Mounting the manipulator

General


Maximum load in relation to the base coordination system. See Figure below.

Floor Mounted

Force	Endurance load (in operation)	Max. load (emergency stop)
Force xy	$\pm 1900 \text{ N}$	$\pm 4300 \text{ N}$
Force z	$1850 \pm 900 \text{ N}$	$1850 \pm 2350 \text{ N}$
Torque xy	$\pm 1550 \text{ Nm}$	$\pm 3900 \text{ Nm}$
Torque z	$\pm 390 \text{ Nm}$	$\pm 1200 \text{ Nm}$

Suspended


Force	Endurance load (in operation)	Max. load (emergency stop)
Force xy	$\pm 1900 \text{ N}$	$\pm 4250 \text{ N}$
Force z	$-1850 \pm 750 \text{ N}$	$-1850 \pm 2350 \text{ N}$
Torque xy	$\pm 1550 \text{ Nm}$	$\pm 3900 \text{ Nm}$
Torque z	$\pm 390 \text{ Nm}$	$\pm 1200 \text{ Nm}$



xx1100000296

Pos	Description
A	Torque _{xy} (T_{xy})
B	Force _z (F_z)
C	Force _{xy} (F_{xy})

Continues on next page



xx1100000297

Pos	Description
A	Torque _z (T _z)

Note regarding M_{xy} and F_{xy}

The bending torque (M_{xy}) can occur in any direction in the XY-plane of the base coordinate system.

The same applies to the transverse force (F_{xy}).


Continues on next page

1 Description

1.3.3 Mounting the manipulator

Continued

Fastening holes robot base



Attachment bolts, specification

The table below specifies required bolts and washers for securing the robot at installation site.

Specification	Description
Attachment bolts, 4 pcs	M16 x 60 (installation directly on foundation) M16 x 70/80 (installation on foundation or base plate, using guiding sleeves)
Washers, 4 pcs	17 x 30 x 3
Quality	Quality 8.8
Tightening torque	200 Nm

1.4 Calibration and reference

1.4.1 Calibration methods

Overview

This section specifies the different types of calibration and the calibration methods that are supplied by ABB.

The original calibration data delivered with the robot is generated when the robot is floor mounted. If the robot is not floor mounted, then the robot accuracy could be affected. The robot needs to be calibrated after it is mounted.

More information is available in the product manual.

Types of calibration

Type of calibration	Description	Calibration method
Standard calibration	The calibrated robot is positioned at calibration position. Standard calibration data is found on the SMB (serial measurement board) or EIB in the robot.	Calibration Pendulum
Absolute accuracy calibration (optional)	Based on standard calibration, and besides positioning the robot at synchronization position, the Absolute accuracy calibration also compensates for: - Mechanical tolerances in the robot structure - Deflection due to load Absolute accuracy calibration focuses on positioning accuracy in the Cartesian coordinate system for the robot. Absolute accuracy calibration data is found on the serial measurement board (SMB) or other robot memory. A robot calibrated with Absolute accuracy has the option information printed on its name plate (OmniCore). To regain 100% Absolute accuracy performance, the robot must be recalibrated for absolute accuracy after repair or maintenance that affects the mechanical structure.	CalibWare
Optimization	Optimization of TCP reorientation performance. The purpose is to improve reorientation accuracy for continuous processes like welding and gluing. Wrist optimization will update standard calibration data for axes 4, 5 and 6.  Note For advanced users, it is also possible to do the wrist optimization using the RAPID instruction <code>WristOpt</code> , see <i>Technical reference manual - RAPID Instructions, Functions and Data types</i> . This instruction is only available for OmniCore robots.	Wrist Optimization

Continues on next page

1 Description

1.4.1 Calibration methods

Continued

Brief description of calibration methods

Calibration Pendulum method

Calibration Pendulum is a standard calibration method for calibration of some ABB robots. On OmniCore, this calibration method is only used on IRB 1510, IRB 1520, IRB 2400, and IRB 4400.

Two different routines are available for the Calibration Pendulum method:

- Calibration Pendulum II
- Reference calibration

The calibration equipment for Calibration Pendulum is delivered as a complete toolkit, including the *Operating manual - Calibration Pendulum*, which describes the method and the different routines further.

Wrist Optimization method

Wrist Optimization is a method for improving reorientation accuracy for continuous processes like welding and gluing and is a complement to the standard calibration method.

The actual instructions of how to perform the wrist optimization procedure is given on the FlexPendant.

CalibWare - Absolute Accuracy calibration

The CalibWare tool guides through the calibration process and calculates new compensation parameters. This is further detailed in the *Application manual - CalibWare Field*.


If a service operation is done to a robot with the option Absolute Accuracy, a new absolute accuracy calibration is required in order to establish full performance. For most cases after replacements that do not include taking apart the robot structure, standard calibration is sufficient.

The Absolute Accuracy option varies according to the robot mounting position. This is printed on the robot name plate for each robot. The robot must be in the correct mounting position when it is recalibrated for absolute accuracy.

1.4.2 Fine calibration

General

Fine calibration is made using the Calibration Pendulum, see *Operating manual - Calibration Pendulum*.



xx1100000294

Pos	Description	Pos	Description
A	Axis 1	B	Axis 2
C	Axis 3	D	Axis 4
E	Axis 5	F	Axis 6

Calibration

Calibration	Position
Calibration of all axes	All axes are in zero position
Calibration of axis 1 and 2	Axis 1 and 2 in zero position
	Axis 3 to 6 in any position
Calibration of axis 1	Axis 1 in zero position
	Axis 2 to 6 in any position

1 Description

1.5.1 Introduction

1.5 Robot load and diagrams

1.5.1 Introduction

Information



WARNING

It is very important to always define correct actual load data and correct payload of the robot. Incorrect definitions of load data can result in overloading of the robot.

If incorrect load data is used, and/or if loads outside the load diagram are used, the following parts can be damaged due to overload:

- motors
- gearboxes
- mechanical structure



WARNING

In RobotWare, the service routine LoadIdentify can be used to determine correct load parameters. The routine automatically defines the tool and the load.

See *Operating manual - OmniCore*, for detailed information.



WARNING

Robots running with incorrect load data and/or with loads outside the load diagram, will not be covered by robot warranty.

General

The load diagrams include a nominal payload inertia, J_0 of 0.012 kgm^2 , and an extra load of 10 kg (hose package included) at the upper arm housing. At different moment of inertia the load diagram will be changed. For robots that are allowed tilted, wall or inverted mounted, the load diagrams as given are valid and thus it is also possible to use RobotLoad within those tilt and axis limits.


Control of load case with RobotLoad

To verify a specific load case, use the RobotStudio add-in RobotLoad.

The result from RobotLoad is only valid within the maximum loads and tilt angles. There is no warning if the maximum permitted arm load is exceeded. For over-load cases and special applications, contact ABB for further analysis.

1.5.2 Load diagrams

IRB 1520ID-4/1.5



xx1100000300

Extra load of 10 kg (hose package included) at the upper arm housing included in the load diagram.


Continues on next page

1 Description

1.5.2 Load diagrams

Continued

IRB 1520ID-4/1.5 "Vertical Wrist" ($\pm 10^\circ$)



xx1100000471

Extra load of 10 kg (hose package included) at the upper arm housing included in the load diagram.

For wrist down (turning disk faced downwards) with $\pm 10^\circ$ deviation from vertical line.

	Description
Max load	4.5 kg
$Z_{\max}$	0.128 m
$L_{\max}$	0.093 m

1.5.3 Maximum load and moment of inertia for full and limited axis (center line down) movement


1.5.3 Maximum load and moment of inertia for full and limited axis (center line down) movement

General

Total load given as: Mass in kg, center of gravity (Z and L) in m and moment of inertia (J_{ox} , J_{oy} , J_{oz}) in kgm^2 . $L = \sqrt{X^2 + Y^2}$, see Figure below.

Full movement of axis 5 (+135° to -135°)

Axis	Robot type	Max. value
5	IRB 15620ID-4/1.5	$J_5 = \text{Mass} \times ((Z + 0.200)^2 + L^2) + \max(J_{ox}, J_{oy}) \leq 0.58 \text{ kgm}^2$
6	IRB 1520ID-4/1.5	$J_6 = \text{Mass} \times L^2 + J_{oz} \leq 0.24 \text{ kgm}^2$



xx1100000301

Pos	Description
A	Center of gravity
	Description
J_{ox} , J_{oy} , J_{oz}	Max. moment of inertia around the X, Y and Z axes at center of gravity.

Limited axis 5, Center line down


Axis	Robot type	Max. value
5	IRB 1520ID-4/1.5	$J_5 = \text{Mass} \times ((Z + 0.200)^2 + L^2) + \max(J_{ox}, J_{oy}) \leq 0.58 \text{ kgm}^2$
6	IRB 1520ID-4/1.5	$J_6 = \text{Mass} \times L^2 + J_{oz} \leq 0.24 \text{ kgm}^2$

Continues on next page

1 Description

1.5.3 Maximum load and moment of inertia for full and limited axis (center line down) movement

Continued



xx1100000475

Pos	Description
A	Center of gravity

	Description
J_{ox} , J_{oy} , J_{oz}	Max. moment of inertia around the X, Y and Z axes at center of gravity.

1.5.4 Wrist torque

General

The table below shows the maximum permissible torque due to payload.



Note

The wrist torque values are for reference only, and should not be used for calculating permitted load offset (position of center of gravity) within the load diagram, since those also are limited by main axes torques as well as dynamic loads. Furthermore, arm loads will influence the permitted load diagram. To find the absolute limits of the load diagram, use the RobotStudio add-in RobotLoad.

Robot type	Max wrist torque axis 4 and 5	Max wrist torque axis 6	Max torque valid at load
IRB 1520ID-4/1.5	12.2 Nm	3.9 Nm	4 kg


1 Description

1.6 Mounting of equipment

1.6 Mounting of equipment

Load areas

Extra loads can be mounted on the wrist, the upper arm housing, and on the frame. Load areas and permitted loads are shown in graphic below. The center of gravity of the extra load shall be within the marked load areas.




xx1100000299

Load area Robot	Max. load			
	A	B	C	B+C
IRB 1520ID-4/1.5	20 kg	10 kg	15 kg	25 kg

Continues on next page

Holes for mounting of extra equipment

The robot has holes for mounting extra equipment.




xx110000302

Continues on next page

1 Description

1.6 Mounting of equipment


Continued



xx1100000303

Continues on next page

Robot tool flange



xx1100000305

Fastener quality

When fitting tools on the tool flange, only use screws with quality 12.9. For other equipment use suitable screws and tightening torque for your application.

1 Description

1.7.1 Introduction

1.7 Robot motion


1.7.1 Introduction

IRB 1520ID-4/1.5

Axis	Type of motion	Range of movement
1	Rotation motion	+170° to -170°
2	Arm motion	+150° to -90°
3	Arm motion	+80° to -100°
4	Rotation motion	+155° to -155°
5	Bend motion	+135° to -135°
6	Turn motion	+200° to -200°

Positions at wrist center IRB 1520ID-4/1.5

Working range with extra mechanical stop on axis 3.



xx1100000306

Continues on next page

1 Description

1.7.1 Introduction

Continued

Pos No. see Figure above	X Position (mm)	Z Position (mm)	Axis 2 Angle (degrees)	Axis 3 Angle (degrees)
Pos 0	883	1243	0	0
Pos 1	160	1793	0	-74,5
Pos 2	483	365	0	+80
Pos 3	1500	453	+90	-74,5
Pos 4	1073	-483	+150	-100
Pos 5	-163	367	+150	+80
Pos 6	247	776	-90	+80
Pos 7	-1180	453	-90	-74,5
Pos 8	-1107	130	-90	-100

1 Description


1.7.2 Performance according to ISO 9283

1.7.2 Performance according to ISO 9283

General

At rated maximum load, maximum offset and 1.6 m/s velocity on the inclined ISO test plane, with all six axes in motion. Values in the table below are the average result of measurements on a small number of robots. The result may differ depending on where in the working range the robot is positioning, velocity, arm configuration, from which direction the position is approached, the load direction of the arm system. Backlashes in gearboxes also affect the result.

The figures for AP, RP, AT and RT are measured according to figure below.



xx0800000424

Pos	Description	Pos	Description
A	Programmed position	E	Programmed path
B	Mean position at program execution	D	Actual path at program execution
AP	Mean distance from programmed position	AT	Max deviation from E to average path
RP	Tolerance of position B at repeated positioning	RT	Tolerance of the path at repeated program execution

Description	IRB 1520ID-4/1.5
Pose repeatability, RP (mm)	0.05
Pose accuracy, AP ⁱ (mm)	0.05
Linear path repeatability, RT (mm)	0.35
Linear path accuracy, AT (mm)	1.3
Pose stabilization time, (PSt) to within 0.2 mm of the position (s)	0.1

ⁱ AP according to the ISO test above, is the difference between the taught position (position manually modified in the cell) and the average position obtained during program execution.

The above values are the range of average test results from a number of robots.

1.7.3 Velocity

Maximum axis speed

Axis No.	IRB 1520ID-4/1.5
1	130 °/s
2	140 °/s
3	140 °/s
4	320 °/s
5	380 °/s
6	460 °/s

1 Description

1.7.4 Robot stopping distances and times

1.7.4 Robot stopping distances and times

Introduction

The stopping distances and times for category 0 and category 1 stops, as required by EN ISO 10218-1 Annex B, are listed in *Product specification - Robot stopping distances according to ISO 10218-1 (3HAC048645-001)*.

1.8 Customer connections



Note

No customer/application connections available for IRB 1520ID-4/1.5.

1 Description

1.9 Maintenance and troubleshooting

1.9 Maintenance and troubleshooting

General

The robot requires only a minimum maintenance during operation. It is designed to make it as easy to service as possible:

- Maintenance free AC motors are used.
- Oil and grease are used for the gear boxes.
- The cabling is routed for longevity, and in the unlikely event of a failure, its modular design makes it easy to change.
- It has a program memory “battery low” alarm.

Maintenance

The maintenance intervals depend on the use of the robot, the required maintenance activities also depends on selected options. For detailed information on maintenance procedures, see Product Manual - IRB 1520.

2 Specification of variants and options

2.1 Introduction to variants and options

General

The different variants and options for the IRB 1520 are described in the following sections. The same option numbers are used here as in the specification form.

The variants and options related to the robot controller are described in the product specification for the controller.

2 Specification of variants and options

2.2 Manipulator

2.2 Manipulator

Variants

Option	IRB Type	Handling capacity (kg)/Reach (m)
3300-114	1520ID	4/1.5

Manipulator color

Option	Color ⁱ	RAL code ⁱⁱ
209-202	ABB Graphite White std Standard color	RAL7035
209	RAL code should be specified (ABB non-standard colors)	

ⁱ The color of ABB robots is not limited to orange, white or graphite white. Select one of the roughly 200 colors of the RAL CLASSIC scheme. See predefined list of colors with option numbers.

ⁱⁱ The colors can differ depending on supplier and the material on which the paint is applied.



Note

Notice that delivery time for painted spare parts will increase for ABB none standard colors.

Manipulator protection

Option	Name	Description
3350-400	Base 40	IP40

Mounting position

Option	Name	Description
3317-1	Inverted	

Resolver connection 7th axis

Option	Description
3322-1	On base

2.3 Floor cables

**Note**

To comply with the EMC directive, the total cable length (including cables for the motor connection box) must not exceed 30 m between:

Controller and robot (IRB)

Controller and motor & gear units (MU/GU) or track motion (IRT)

Controller and positioner (IRP)

Manipulator cable length

Option	Lengths
3200-2	7 m
3200-3	15 m

Mains cable

Option	Lengths	Description
3203-1	EU mains cable, 3 m	Cable assembly with CEE7/VII line-side plug
3203-2	UK mains cable, 3 m	Cable assembly with BS1363 line-side plug, 5A fused
3203-5	CN mains cable, 3 m	Cable assembly with CPCS-CCC line-side plug
3203-6	AU mains cable, 3 m	Cable assembly with AS/NZS 3112 line-side
3203-7	All regions cable, 5 m	Cable assembly without line-side plug

**Tip**

The option *Mains cable* requires option *3000-105 OmniCore E10* or *3000-130 OmniCore C30*.

2 Specification of variants and options

2.4.1 Application floor cables

2.4 Application

2.4.1 Application floor cables

Servo cable 1 axis - Length

Option	Description	Note
3206-2	7 m	
3206-3	15 m	
3206-4	22 m	
3206-5	30 m	



Note

The options *3206-X Servo cable 1 axis - Length* are available for IRB 1520 with OmniCore V line controllers.

Warranty

For the selected period of time, ABB will provide spare parts and labor to repair or replace the non-conforming portion of the equipment without additional charges. During that period, it is required to have a yearly *Preventative Maintenance* according to ABB manuals to be performed by ABB. If due to customer restrains no data can be analyzed with ABB Connected Services for robots with OmniCore controllers, and ABB has to travel to site, travel expenses are not covered. The *Extended Warranty* period always starts on the day of warranty expiration. Warranty Conditions apply as defined in the *Terms & Conditions*.



Note

This description above is not applicable for option *Stock warranty* [438-8]

Option	Type	Description
438-1	Standard warranty	Standard warranty is 12 months from <i>Customer Delivery Date</i> or latest 18 months after <i>Factory Shipment Date</i> , whichever occurs first. Warranty terms and conditions apply.
438-2	Standard warranty + 12 months	Standard warranty extended with 12 months from end date of the standard warranty. Warranty terms and conditions apply. Contact Customer Service in case of other requirements.
438-4	Standard warranty + 18 months	Standard warranty extended with 18 months from end date of the standard warranty. Warranty terms and conditions apply. Contact Customer Service in case of other requirements.
438-5	Standard warranty + 24 months	Standard warranty extended with 24 months from end date of the standard warranty. Warranty terms and conditions apply. Contact Customer Service in case of other requirements.

2 Specification of variants and options

2.4.1 Application floor cables

Continued

Option	Type	Description
438-6	Standard warranty + 6 months	Standard warranty extended with 6 months from end date of the standard warranty. Warranty terms and conditions apply.
438-7	Standard warranty + 30 months	Standard warranty extended with 30 months from end date of the standard warranty. Warranty terms and conditions apply.
438-8	Stock warranty	Maximum 6 months postponed start of standard warranty, starting from factory shipment date. Note that no claims will be accepted for warranties that occurred before the end of stock warranty. Standard warranty commences automatically after 6 months from <i>Factory Shipment Date</i> or from activation date of standard warranty in WebConfig.  Note Special conditions are applicable, see <i>Robotics Warranty Directives</i>.

This page is intentionally left blank

Index

A

Absolute Accuracy, calibration, 24
ambient humidity
 operation, 19
 storage, 18
ambient temperature
 operation, 19
 storage, 18

C

calibration
 Absolute Accuracy type, 23
 standard type, 23
calibration, Absolute Accuracy, 24
Calibration Pendulum, 25
CalibWare, 23
category 0 stop, 40
category 1 stop, 40
connections, 41

D

dimensions, 13

E

EPS, 15

F

fastening holes, 22
fine calibration, 25
foundation
 requirements, 18

H

handling capacity, 11
humidity
 operation, 19
 storage, 18

L

load areas, 32
load diagrams, 27
loads on foundation, 17

M

maintenance, 42
motion, 36

mounting, 11, 20
 equipment, 32

N

noise level, 11

O

operating conditions, 19
options, 43

P

product standards, 14
protection classes, 19
protection type, 19

R

reach, 11
requirements on foundation, 18
robot
 protection class, 19
 protection types, 19
robot versions, 11

S

safety standards, 14
standards, 14
standard warranty, 46
stock warranty, 46
stopping distances, 40
stopping times, 40
storage conditions, 18

T

temperatures
 operation, 19
 storage, 18
tool flange, 35
torques on foundation, 17

V

variants, 43–44
velocity, 39
versions, 11

W

warranty, 46
weight, 16
working range, 15
wrist torque, 31



ABB Robotics Sweden AB
S-721 71 VÄSTERÅS, Sweden
Telephone +46 10-732 50 00

ABB Robotics Norway AS
Nordlysvegen 7, N-4340 BRYNE, Norway
Box 265, N-4349 BRYNE, Norway
Telephone: +47 22 87 2000

ABB Robotics (Shanghai) Limited
No. 39, 99 Miaoqiao Road,
Pudong New Area,
Shanghai, 201315, China
Telephone: +86 21 6105 6666

ABB Robotics LLC
1250 Brown Road
Auburn Hills, MI 48326
USA
Telephone: +1 248 391 9000

abb.com/robotics