



ROBOTICS

Product manual

IRB 14050 gripper



Trace back information:
Workspace 26-1 version a35
Checked in 2026-05-07
Skribenta version 5.6.019

Product manual
IRB 14050 gripper
OmniCore

Document ID: 3HAC064626-001
Revision: G

The information in this manual is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this manual.

Except as may be expressly stated anywhere in this manual, nothing herein shall be construed as any kind of guarantee or warranty by ABB for losses, damage to persons or property, fitness for a specific purpose or the like.

In no event shall ABB be liable for incidental or consequential damages arising from use of this manual and products described herein.

This manual and parts thereof must not be reproduced or copied without ABB's written permission.

Keep for future reference.

Additional copies of this manual may be obtained from ABB.

Original instructions.

© Copyright 2019-2026 ABB. All rights reserved.
Specifications subject to change without notice.

Table of contents

Overview of this manual	7
Product documentation	9
1 Safety	11
1.1 Introduction to safety information	11
1.2 General safety risks	12
1.2.1 Safety risks during installation and service work on the IRB 14050 gripper	12
1.2.2 Safety risks related to tools/work pieces	13
1.2.3 Risks associated with live electric parts	14
2 Installation and commissioning	15
2.1 Introduction	15
2.2 Unpacking	16
2.2.1 Pre-installation procedure	16
2.2.2 Requirements	18
2.3 Technical data	19
2.3.1 General	19
2.3.2 Servo module	23
2.3.3 Vacuum module	26
2.3.4 Vision module	27
2.3.5 Fingers	30
2.4 On-site installation	31
2.4.1 Air and power supply	31
2.4.2 Recommended standard tightening torque	32
2.4.3 Mounting the gripper	33
2.4.4 Mounting the fingers	39
2.4.5 Mounting tools to the vacuum module	40
2.5 IRB 14050 gripper FlexPendant application	42
2.5.1 Installing IRB 14050 gripper FlexPendant application	43
2.5.2 Updating IRB 14050 gripper FlexPendant application	44
2.5.3 IRB 14050 gripper FlexPendant application GUI	45
2.6 Commissioning	51
2.6.1 Firmware update	51
2.6.2 System commissioning	55
3 Maintenance	59
3.1 Inspection activities	59
4 Repair	61
4.1 Introduction	61
4.2 Replacing the filter and suction cup	62
4.3 Replacing the fingers	67
4.4 Replacing the shell	73
4.5 Replacing the pneumatic block	80
4.6 Replacing the camera	92
4.7 Replacing the servo base	100
5 RAPID references	113
5.1 Overview	113
5.2 Instructions	115
5.2.1 RAPID instructions for grippers	115
5.2.1.1 g_Init - Initialize the gripper	115
5.2.1.2 g_JogIn - Jog the gripper to move inward	117
5.2.1.3 g_JogOut - Jog the gripper to move outward	118
5.2.1.4 g_MoveTo - Move the gripper to a target position	119

Table of contents

5.2.1.5	g_GripIn - Jog the gripper to grip inward	121
5.2.1.6	g_GripOut - Jog the gripper to grip outward	124
5.2.1.7	g_Calibrate - Calibrate the gripper	127
5.2.1.8	g_Stop - Stop the gripper	128
5.2.1.9	g_SetMaxSpd - Set the maximum speed	129
5.2.2	RAPID instructions for pneumatic modules	130
5.2.2.1	g_BlowOn1 - Turn on blowing channel 1	130
5.2.2.2	g_BlowOff1 - Turn off blowing channel 1	131
5.2.2.3	g_BlowOn2 - Turn on blowing channel 2	132
5.2.2.4	g_BlowOff2 - Turn off blowing channel 2	133
5.2.2.5	g_VacuumOn1 - Turn on vacuum channel 1	134
5.2.2.6	g_VacuumOff1 - Turn off vacuum channel 1	135
5.2.2.7	g_VacuumOn2 - Turn on vacuum channel 2	136
5.2.2.8	g_VacuumOff2 - Turn off vacuum channel 2	137
5.3	Functions	138
5.3.1	RAPID functions for servo module	138
5.3.1.1	g_IsCalibrated - Get gripper calibration status	138
5.3.1.2	g_GetPos - Get current gripper position	139
5.3.1.3	g_GetSpd - Get current gripper speed	140
5.3.1.4	g_GetState - Get current gripper status	141
5.3.1.5	g_GetErrID - Get current gripper error ID	143
5.3.2	RAPID functions for pneumatic module	145
5.3.2.1	g_GetPressure1 - Get vacuum pressure 1	145
5.3.2.2	g_GetPressure2 - Get vacuum pressure 2	146
5.3.3	RAPID functions for camera module	147
5.3.3.1	g_IsCamOnline - Get handheld camera connection status	147
6	Decommissioning	149
6.1	Environmental information	149
7	Reference information	151
7.1	Introduction	151
7.2	Unit conversion	152
7.3	Standard toolkit	153
8	Spare parts	155
8.1	Introduction	155
8.2	Spare part lists and illustrations	156
8.2.1	Parts	156
Index		161

Overview of this manual

About this manual

This manual contains instructions for:

- mechanical and electrical installation of the IRB 14050 gripper
- maintenance of the IRB 14050 gripper
- mechanical and electrical repair of the IRB 14050 gripper

Usage

This manual should be used during:

- installation to make the IRB 14050 gripper ready for operation
- maintenance work
- repair work and calibration.

Who should read this manual?

This manual is intended for:

- installation personnel
- maintenance personnel
- repair personnel.

Prerequisites

A maintenance/repair/installation craftsman working with the IRB 14050 gripper must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/repair/maintenance work.

Product manual scope

The manual covers all variants and designs of the IRB 14050 gripper. Some variants and designs may have been removed from the business offer and are no longer available for purchase.

Organization of chapters

The manual is organized in the following chapters:

Chapter	Contents
Safety	Safety information that must be read through before performing any installation or service work on the IRB 14050 gripper. Contains general safety aspects as well as more specific information on how to avoid personal injuries and damage to the product.
Installation and commissioning	Required information about installation of the IRB 14050 gripper.
Maintenance	Step-by-step procedures that describe how to perform maintenance of the IRB 14050 gripper. Based on a maintenance schedule that may be used to plan periodical maintenance.
Repair	Step-by-step procedures that describe how to perform repair activities of the IRB 14050 gripper. Based on available spare parts.

Continues on next page

Chapter	Contents
Operation	RAPID reference information and operation using FlexPendant for the IRB 14050 gripper.
Decommissioning	Environmental information about the IRB 14050 gripper and its components.
Reference information	Useful information when performing installation, maintenance or repair work. Includes lists of necessary tools, additional documents, safety standards, etc.
Spare parts	Reference to the spare part list for the IRB 14050 gripper.

References

Documentation referred to in the manual, is listed in the table below.

Document name	Document ID
<i>Product manual - IRB 14050</i>	3HAC064625-001
<i>Product specification - IRB 14050</i>	3HAC064627-001
<i>Technical reference manual - System parameters</i>	3HAC065041-001
<i>Safety manual for robot - Manipulator and IRC5 or OmniCore controllerⁱ</i>	3HAC031045-001

ⁱ This manual contains all safety instructions from the product manuals for the manipulators and the controllers.

Revisions

Revision	Description
A	First edition.
B	Published in release 20A. The following updates are made in this revision: Smart Gripper add-in replaced by Smart Gripper Support option in entire manual.
C	Published in release 20B. The following updates are made in this revision: O-ring 3x2 (3HAB3772-174) changed to O-ring 4x2 (3HAC063220-001).
D	Published in release 21A. The following updates are made in this revision: The instruction g_SetForce is no longer supported and therefore removed from the manual.
E	Published in release 21B. The following updates are made in this revision: Added new spare parts vacuum sensor (3HAC047823-001), connector board (3HAC051609-001), FFC for pneumatic block connector board (3HAC051610-002) and FFC for camera (3HAC054157-002); related repair procedures, spare part list and spare part images are also updated.
F	Published in release 25.3. The following updates are done in this revision: - Company name updated to reflect current legal entities. - Updated portal name from myABB to ABB Robotics One.
G	Published in release 26.1. The following updates are done in this revision: Company name updated to reflect current legal entities.

Product documentation

Categories for user documentation from ABB Robotics

The user documentation from ABB Robotics is divided into a number of categories. This listing is based on the type of information in the documents, regardless of whether the products are standard or optional.



Tip

All documents can be found via ABB Robotics One, <https://one.robots.abb.com/en/knowledge-hub>.

Product manuals

Manipulators, controllers, DressPack, and most other hardware is delivered with a **Product manual** that generally contains:

- Safety information.
- Installation and commissioning (descriptions of mechanical installation or electrical connections).
- Maintenance (descriptions of all required preventive maintenance procedures including intervals and expected life time of parts).
- Repair (descriptions of all recommended repair procedures including spare parts).
- Calibration.
- Troubleshooting.
- Decommissioning.
- Reference information (safety standards, unit conversions, screw joints, lists of tools).
- Spare parts list with corresponding figures (or references to separate spare parts lists).
- References to circuit diagrams.

Technical reference manuals

The technical reference manuals describe reference information for robotics products, for example lubrication, the RAPID language, and system parameters.

Application manuals

Specific applications (for example software or hardware options) are described in **Application manuals**. An application manual can describe one or several applications.

An application manual generally contains information about:

- The purpose of the application (what it does and when it is useful).
- What is included (for example cables, I/O boards, RAPID instructions, system parameters, software).
- How to install included or required hardware.

Continues on next page

- How to use the application.
- Examples of how to use the application.

Operating manuals

The operating manuals describe hands-on handling of the products. The manuals are aimed at those having first-hand operational contact with the product, that is production cell operators, programmers, and troubleshooters.

1 Safety

1.1 Introduction to safety information

Overview

This chapter describes the safety information specific to the IRB 14050 gripper only. It does not contain complete safety information for the IRB 14050 robot system. The following additional documents are essential for correct and safe usage of the IRB 14050 robot system, including the gripper:

- *Product manual - IRB 14050*

Disposition

The safety information in this manual is divided into two categories:

- General safety aspects, important to attend to before performing any service work on the grippers. These are applicable for all service works and can be found in the section [General safety risks on page 12](#).
- Specific safety information, pointed out in the procedures. How to avoid and eliminate the danger is described directly in the procedure.

1 Safety

1.2.1 Safety risks during installation and service work on the IRB 14050 gripper

1.2 General safety risks

1.2.1 Safety risks during installation and service work on the IRB 14050 gripper

Overview

This section includes information about general safety risks to be considered when performing installation and service work on the IRB 14050 gripper.

General risks during installation and service

- The instructions in the product manual in chapters [Installation and commissioning on page 15](#), and [Repair on page 61](#) must always be followed.
- Those in charge of operations must make sure that safety instructions are available for the installation in question.
- Those who install the IRB 14050 gripper must have the appropriate training for the robot system in question and in any safety matters associated with it.
- The power supply of 24 V DC to the robot tool flange must be shut off when installing or servicing the gripper. This can be done from the robot main switch or from a predefined I/O signal that controls the power to the tool flange.
- Air supply to the robot must be shut off when installing or servicing the gripper.
- Make sure that all bolts have been tightened before starting any operation after maintenance work.
- Make sure that no foreign material is lying on the IRB 14050 gripper before starting an operation.
- Damaged or broken equipment can result in a safety risk.

1.2.2 Safety risks related to tools/work pieces

Safe handling

The IRB 14050 gripper is designed to allow manual release and removal of gripped work pieces. Both servo and vacuum modules can be overridden by manual force. If end tools (such as fingers and suction tools) and work pieces are not correctly designed and chosen, gravity or robot acceleration may cause a work piece held by the gripper to drop during motion. The work pieces must meet the weight requirements, and the end tools must be suitably designed to grip the work pieces.

Safe design

The IRB 14050 is intended for collaborative applications, where occasional contacts between the robot and operators is safe. End tools (such as fingers and suction tools), as well as work pieces handled by the robot, must be designed and chosen so that such contacts does not introduce safety hazards.

The IRB 14050 gripper is not designed to retain work pieces in case of power loss. Objects held by the servo and vacuum modules may be released, in the event of pneumatic or electric power loss to the gripper. The work pieces handled by the robot, as well as the collaborative work station where the robot operates, should be chosen and designed so that such release does not introduce safety hazards.

All end tools and work pieces must be included in the risk assessment by the system integrator.

1 Safety

1.2.3 Risks associated with live electric parts

1.2.3 Risks associated with live electric parts

Voltage related risks

The IRB 14050 gripper is powered by 24 V DC from the robot tool flange. A risk for short-circuit and sparks exists. All installation and service works should be done with power disconnected from the gripper and the tool flange. This can be done from the robot main switch or from a predefined I/O signal that controls the power to the tool flange. Service works shall, whenever possible, be done with the gripper mechanically removed from the robot arm.

All work must be performed by qualified personnel.

2 Installation and commissioning

2.1 Introduction

General

This chapter contains information for installing the IRB 14050 gripper at the working site.

More detailed technical data about the gripper can be found in the *Product specification* for the robot.

Safety information

Before any installation work is conducted, it is extremely important that all safety information is observed!

There are general safety aspects that must be read through, as well as more specific safety information that describes the danger and safety risks when performing the procedures. Read the chapter [Safety on page 11](#) before performing any installation work.



Note

If the robot where the gripper shall be mounted is connected to power, always ensure that the robot is connected to protective earth before starting any installation work.

For more information, see *Product manual* for the robot.

2 Installation and commissioning

2.2.1 Pre-installation procedure

2.2 Unpacking

2.2.1 Pre-installation procedure

Introduction

This section describes the unpacking and installation of the IRB 14050 gripper for the first time. It also covers re-installation of the IRB 14050 gripper.

Packing, gripper

The IRB 14050 gripper is packed following the standards of sea transportation, land transportation and air transportation on delivery.

Check the following item list in the standard delivery package before proceeding with the installation of the gripper.

Nb	Item	Description
1	Servo module	For the Servo option
2	Servo module + one vacuum module	For the Servo + Vacuum 1 option
3	Servo module + two vacuum modules	For the servo + Vacuum 1 + Vacuum 2 option
4	Servo module + one vision module	For the servo + Vision option
5	Servo module + one vision module +one vacuum module	For the servo + Vacuum 1 + Vision option
6	Getting-started fingers	For all options
7	Suction tools	Delivered together only with items 2, 3, or 5
8	Screw package	For all options

Checking the pre-requisites for installation

Installation personnel working with the IRB 14050 gripper must:

- be trained by ABB and have the required knowledge of mechanical and electrical installation/maintenance/repair work
- conform to all national and local codes.

	Action
1	Visually inspect the grippers to make sure that they are not damaged.
2	If the grippers are not installed directly, they must be stored as described in: • Storage conditions, gripper on page 18
3	Make sure that the expected operating environment of the grippers conforms to the specifications as described in: • Operating conditions, gripper on page 18
4	Before taking the grippers to the installation site, make sure that the site conforms to: • Protection classes, gripper on page 18 • Requirements, robot tool flange on page 18
5	When these prerequisites are met, the grippers can be taken to the installation site as described in section: • On-site installation on page 31

Continues on next page

2 Installation and commissioning

2.2.1 Pre-installation procedure

Continued

	Action
6	Install required equipment, if any.

2 Installation and commissioning

2.2.2 Requirements

2.2.2 Requirements

Requirements, robot tool flange

Make sure the area around the robot wrist has no particles that would obstruct the installation of the IRB 14050 gripper or be dangerous to the operator.

Storage conditions, gripper

The table shows the allowed storage conditions for the gripper:

Parameter	Value
Minimum ambient temperature	-20 °C
Maximum ambient temperature	+45 °C
Maximum ambient temperature (less than 24 hrs)	+55 °C
Maximum ambient humidity	85% at constant temperature (gaseous only)

Operating conditions, gripper

The table shows the allowed operating conditions for the gripper:

Parameter	Value
Minimum ambient temperature	+5 °C
Maximum ambient temperature	+45 °C
Maximum ambient humidity	85% at constant temperature (gaseous only)

Protection classes, gripper

The table shows the available protection types of the gripper, with the corresponding protection class.

Protection type	Protection class
Gripper, protection type Standard	IP30

Food contact

The gripper is not intended to be in contact with food.

Sterile environments

The gripper is not intended to be operated in sterile environments.

2.3 Technical data

2.3.1 General

Weight and load capacity

Combination	Weight (g) without fingers, suction cup(s), and filter(s) ⁱ	Weight (g) of the whole gripper	Max. load capacity (g) without fingers, suction cup(s), and filter(s) ⁱⁱ	Max. load capacity (g) of the whole gripper ⁱⁱ
Servo	215	230	285	270
Servo + Vacuum 1	225.5	248	274.5	252
Servo + Vacuum 1 + Vacuum 2	250	280	250	220
Servo + Vision	229	244	271	256
Servo + Vision + Vacuum 1	239.5	262	260.5	238

ⁱ The getting-started fingers weighs 15 gram, and the standard suction cups and filters weighs 7.5 gram per set.

ⁱⁱ Load capacity = 500 - weight

Center of gravity (CoG) limitations applied. See the load diagram for the robot.

Detailed mass data - Center of Gravity

Combination	CoG (mm) without fingers, suction cup(s), and filter(s)			CoG (mm) of the whole gripper		
	x	y	z	x	y	z
Servo	8.7	12.3	49.2	8.2	11.7	52
Servo + Vacuum 1	8.9	12.3	48.7	8.6	11.7	52.7
Servo + Vacuum 1 + Vacuum 2	7.4	12.4	44.8	7.1	11.9	47.3
Servo + Vision	7.9	12.4	48.7	7.5	11.8	52.7
Servo + Vision + Vacuum 1	8.2	12.5	48.1	7.8	11.9	50.7

Detailed mass data - Inertia

Combination	Inertia (kgm ²) without fingers, suction cup(s), and filter(s)			Inertia (kgm ²) of the whole gripper		
	lxx	lyy	lzz	lxx	lyy	lzz
Servo	0.00017	0.00020	0.00008	0.00021	0.00024	0.00009
Servo + Vacuum	0.00017	0.00020	0.00008	0.00021	0.00024	0.00009
Servo + Vacuum 1 + Vacuum 2	0.00020	0.00024	0.00011	0.00025	0.00029	0.00012
Servo + Vision	0.00017	0.00019	0.00008	0.00021	0.00023	0.00008

Continues on next page

2 Installation and commissioning

2.3.1 General

Continued

Combination	Inertia (kgm ²) without fingers, suction cup(s), and filter(s)			Inertia (kgm ²) of the whole gripper		
	lxx	lyy	lzz	lxx	lyy	lzz
Servo + Vision + Vacuum	0.00018	0.00020	0.00009	0.00022	0.00024	0.00009

Tooldata definitions without fingers, suction cup(s), and filter(s)

Combination	Tooldata
Servo	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.215, [8.7, 12.3, 49.2], [1, 0, 0, 0], 0.00017, 0.00020, 0.00008]]
Servo + Vacuum	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.226, [8.9, 12.3, 48.7], [1, 0, 0, 0], 0.00017, 0.00020, 0.00008]]
Servo + Vacuum 1 + Vacuum 2	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.250, [7.4, 12.4, 44.8], [1, 0, 0, 0], 0.00020, 0.00024, 0.00011]]
Servo + Vision	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.229, [7.9, 12.4, 48.7], [1, 0, 0, 0], 0.00017, 0.00019, 0.00008]]
Servo + Vision + Vacuum	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.240, [8.2, 12.5, 48.1], [1, 0, 0, 0], 0.00018, 0.00020, 0.00009]]


Tooldata definitions with fingers, suction cup(s), and filter(s)

Combination	Tooldata
Servo	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.230, [8.2, 11.7, 52.0], [1, 0, 0, 0], 0.00021, 0.00024, 0.00009]]
Servo + Vacuum	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.248, [8.6, 11.7, 52.7], [1, 0, 0, 0], 0.00021, 0.00024, 0.00009]]
Servo + Vacuum 1 + Vacuum 2	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.280, [7.1, 11.9, 47.3], [1, 0, 0, 0], 0.00025, 0.00029, 0.00012]]
Servo + Vision	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.244, [7.5, 11.8, 52.7], [1, 0, 0, 0], 0.00021, 0.00023, 0.00008]]
Servo + Vision + Vacuum	[TRUE, [[0, 0, 0], [1, 0, 0, 0]], [0.262, [7.8, 11.9, 50.7], [1, 0, 0, 0], 0.00022, 0.00024, 0.00009]]

Continues on next page

Mass data, illustration

The following figure shows the mass data of the gripper with one servo module and one vacuum module as an example.



xx1500000826

A	CoG Note: Dimensions of CoG in the brackets are without the fingers and suction tools
B	Getting-started finger length
C	Travel length: 0-50 mm

Continues on next page

2 Installation and commissioning

2.3.1 General

Continued

Airborne noise level

Description	Note
The sound pressure level outside	< 55 dB, measured at a location 0.5 m away from the gripper.

Power consumption


The gripper is powered by 24 V DC and the maximum power consumption of the whole gripper is 9 W.

Air consumption

Maximum air consumption is 15 liters/minute for a single pneumatic module.

Dimensions

The following figure shows the dimension of the gripper with one servo module and two vacuum modules. The dimensions of other gripper options can be obtained by simply removing the dimension data of the suction cups and filters. For the specific dimension of the camera used in the gripper with a vision module, see [Camera, dimensions on page 27](#).



Pos	Description
A	Travel length = 0-50 mm

2.3.2 Servo module

Travel length

Description	Data
Travel length	0-50 mm (max. 25 mm per finger)

Maximum speed

Description	Data
Speed	25 mm/s
Repeatability	±0.05 mm


Gripping force

Description	Data
Gripping direction	Inward or outward
Maximum gripping force	20 N (at the gripping point of 40 mm) ⁱ
External force (not in gripping directions)	15 N (at the gripping point of 40 mm)
Force control accuracy	±3 N

ⁱ The gripping times of getting-started fingers is 10,000 under the maximum gripping force 20 N.

Load diagram

The following figures show the relationship between the maximum allowed gripping force and gripping point to the finger flange.




xx1500000792

Continues on next page

2 Installation and commissioning


2.3.2 Servo module
Continued



xx1500000797


Pos	Description
F	Gripping force, in unit of N
L	Length from the gripping point to the finger flange, in unit of mm

The following figures show the relationship between the maximum allowed external force and gripping point to the finger flange.



xx1500000798

Continues on next page



xx1500000799

Pos	Description
F	External force, in unit of N
L	Length from the gripping point to the finger flange, in unit of mm

Position control and calibration

The servo module has integrated position control with the repeatability of ± 0.05 mm. The servo module is calibrated by RAPID instructions or using the FlexPendant interface. For details, see the section [IRB 14050 gripper FlexPendant application on page 42](#) and chapter [RAPID references on page 113](#).

2 Installation and commissioning

2.3.3 Vacuum module

2.3.3 Vacuum module

Vacuum generator

The vacuum module has an integrated vacuum generator that is designed with a maximum payload of 150 g. The actual payload capacity depends on the following factors:

- Suction tool design and the choice of suction cups
- The surface structure of the object being picked
- The pickup point and the CoG of the object being picked
- Robot motion while the object is picked
- Air pressure input to the robot

Vacuum pressure sensor

The air pressure of the vacuum module can be monitored in real time using an in-built vacuum sensor. This makes it possible to detect whether the object is correctly picked up by the suction tool.

Blow-off actuator

To minimize cycle time and ensure accurate drop-off of the picked objects, a blow-off actuator is integrated in the vacuum module.

2.3.4 Vision module

General


The vision module includes a Cognex AE3 camera and provides powerful and reliable vision and identification tools.

Camera, specification

Description	Data
Resolution	1.3 Megapixel
Lens	6.2 mm f/5
Illumination	Integrated LED with programmable intensity
Software engine	Powered by Cognex In-Sight
Application programming software	ABB Integrated vision or Cognex In-Sight Explorer

Camera, dimensions

The following figure shows the dimension of the Cognex AE3 camera.



xx1500001395

Pos	Description
A	Internal illumination

Continues on next page

2 Installation and commissioning




2.3.4 Vision module

Continued



Pos	Description
B	Lens

Lens focusing

Use the following procedure to focus the lens of the Cognex AE3 camera.

	Action	Note
1	For the gripper also with a vacuum module, twist and remove the filter and suction cup first.	
2	Remove the screws that fasten the shell, and then press the shell sides gently to detach the shell. The shell consists of two parts: • lower shell • upper shell	 xx1500000759  xx1400002152
3	Rotate the focusing ring of the 6.2 mm lens to fit the application.	 xx1500001621

Continues on next page

	Action	Note
4	Put the shell to the base plate by locating the location pins to the location holes on the base plate. Press the two shell parts together. Then, refit the two M1.2 screws.	 xx1400002155  xx1500000759
5	For the gripper also with a vacuum module, refit the filter and suction cup by twisting them.	


2 Installation and commissioning

2.3.5 Fingers

2.3.5 Fingers

Getting-started finger, dimensions

The following figure shows the dimension of the getting-started finger.



xx1500001606

Design requirements for customized fingers

Except for the two getting-started fingers delivered together with the IRB 14050 gripper, it is also possible for users to customize fingers based on actual requirements. The getting-started fingers can grip only up to 10,000 times under the maximum gripper force 20 N; therefore, it is always recommended customized fingers be designed and used.

When designing fingers, the following requirements should be met:

- To enhance the stiffness for gripping and extend lifetime of the fingers, it is recommended that metal is being used as the finger materials.
- The finger size must be designed properly to prevent any collision with the gripper shell during the finger movement or gripping.
- The length of the screws that are used for fastening the fingers to the finger flange must be proper and less than the maximum hole depth on the flange. For details about the maximum hole depth, see [Hole configuration, finger flange on page 39](#).
- Installation direction and position of the fingers should follow those of the getting-started fingers. For details, see [Getting-started finger, dimensions on page 30](#).

2.4 On-site installation

2.4.1 Air and power supply

Requirements

The IRB 14050 gripper is supplied with air and 24 V DC power from the IRB 14050 tool flange.

Before installing the gripper, ensure that air and electric power supply to the tool flange is shut off. The electric power can be shut off from the robot main switch or from a predefined I/O signal that controls power to the tool flange. The air supply cannot be controlled from within the robot, or from the robot main switch, and has to be shut off externally.

The air supply to the robot should be 5.5-6 bar, filtered and non-lubricated. The nominal operating pressure is 6 bar.

Before any installation or service work on the gripper, ensure that the safety instructions in section [Safety on page 11](#) are followed.

2 Installation and commissioning

2.4.2 Recommended standard tightening torque

2.4.2 Recommended standard tightening torque

Standard tightening torque


The table below specifies the recommended standard tightening torque for the screws.

Screw type	Tightening torque (Nm) on metal	Tightening torque (Nm) on plastic
M1.2	N/A	0.05
M1.6 (12.9 class carbon steel screw)	0.25	N/A
M1.6 (stainless steel screw)	N/A	0.05
M2	0.25	0.1
M2.5	0.45	0.45

2.4.3 Mounting the gripper

Mounting flange

Three M2.5 holes and one guide pin are used to assemble the gripper to the arm tool flange.



xx1500000126


Pos	Description
A	Recommended screws, three M2.5 x 8
B	Air hose
C	8-pin connector (spring-loaded)
D	Guide pin

The pins of the connector (shown as C in the preceding figure) are defined as follows.

Continues on next page

2 Installation and commissioning

2.4.3 Mounting the gripper
Continued




xx1500000796

Pin	Description
A	EtherNet RD-
B	EtherNet TD-
C	EtherNet RD+
D	EtherNet TD+
E	PE
F	Spare
G	0V, IO
H	24V, IO

Continues on next page

Hole configuration, mounting base

The following figure shows the hole configuration when assembling the gripper to the arm tool flange.



xx1500000793

Pos	Description
B	Stroke = 1 mm

Installing the gripper

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit on page 153 .

Continues on next page

2 Installation and commissioning

2.4.3 Mounting the gripper


Continued

Required spare part

Spare part	Part No.	Note
SERVO	3HAC054831-001	Used when the Servo gripper is chosen.
SERVO + VISION	3HAC054832-001	Used when the Servo + Vision gripper is chosen.
SERVO + VACUUM 1	3HAC054833-001	Used when the Servo + Vacuum 1 gripper is chosen.
SERVO + VACUUM 1 + VISION	3HAC054834-001	Used when the Servo + Vision + Vacuum 1 gripper is chosen.
SERVO + VACUUM 1 + VACUUM 2	3HAC054835-001	Used when the Servo + Vacuum 1 + Vacuum 2 gripper is chosen.

Procedure




Use the following procedure to install a whole gripper onto the robot arm.

	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 .
2	Position the gripper to the arm tool flange on the axis 6 of the robot.	 xx1500001394 A Arm tool flange B Axis 6 of the robot
3	Use the guide pin and air hose hole to make the gripper align with the arm tool flange.	For the positions of the guide pin and air hose hole, see Mounting flange on page 33 .

Continues on next page

2 Installation and commissioning

2.4.3 Mounting the gripper *Continued*


	Action	Note
4	For the gripper with a vacuum module, fit an O-ring in the air hose hole.	O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625
5	Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw.	Screw: M2.5x8, 3HAC051701-001 (1 pcs)  xx1500001391
6	Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw.	Screw: M2.5x8, 3HAC051701-001 (1 pcs)  xx1500001392

Continues on next page

2 Installation and commissioning

2.4.3 Mounting the gripper

Continued

	Action	Note
7	Rotate the flange with 90 degrees to access the last screw hole and then refit the screw.	Screw: M2.5x8, 3HAC051701-001 (1 pcs)  xx1500001393
8	Turn on the power and air supply to the gripper and then perform commissioning on the gripper.	


2.4.4 Mounting the fingers

General

A pair of getting-started fingers are provided together with the gripper for demo and test purposes. These fingers should be replaced with fingers designed for the actual application by the system integrator and must be included in the final risk assessment done by the system integrator.

Hole configuration, finger flange

The following figures show the hole configuration and main dimensions of the finger flanges.



xx1500000794

Pos	Description
A	Position of the maximum displacement
B	Maximum hole depth

2 Installation and commissioning

2.4.5 Mounting tools to the vacuum module

2.4.5 Mounting tools to the vacuum module


General

The vacuum module is delivered with a first set of suction cups and filters for demo and test purposes. Application-specific suction tools should be designed and chosen by the system integrator. Air filters are required in the suction tools to ensure the long-term performance of the vacuum module. If the vacuum function is not required, passive assembly tools, such as press tools, can also be mounted to the suction tool interface. Any tools mounted to the gripper must be included in the final risk assessment by the system integrator.

Continues on next page

Hole configuration, vacuum tools

The following figure shows the hole configuration and tool interface of the vacuum module.



xx1500000795

Pos	Description
A	Length from the center to the outer shell surface
B	Length from the center to the inner shell surface
C	Shell hole depth

2 Installation and commissioning

2.5 IRB 14050 gripper FlexPendant application

2.5 IRB 14050 gripper FlexPendant application

Overview

The following requirements must be met for the gripper configuration.

Item	Note
Options for manipulator and controller	The gripper option must be chosen.
RobotWare	• RobotWare 7.0 or later • SmartGripper Support option SmartGripper Support is a RobotWare option for ABB smart grippers. All files related to ABB smart grippers will be installed automatically, such as configuration files, RAPID driver and FlexPendant application.

Continues on next page

2.5.1 Installing IRB 14050 gripper FlexPendant application

Installation procedure

- 1 While creating or modifying a robot system using the **Modify Installation** function, select **SmartGripper Support** under **Gripper** in the **System Options** tab page.
- 2 Install the robot system and restart the controller.
The **SmartGripper** icon is displayed in the **Settings** menu on the FlexPendant.

2 Installation and commissioning

2.5.2 Updating IRB 14050 gripper FlexPendant application

2.5.2 Updating IRB 14050 gripper FlexPendant application


Updating procedure

- 1 Since the Smart Gripper is a part of the RobotWare product, the update procedure is same as updating the RobotWare product. See *Operating manual - RobotStudio*.
- 2 Install the robot system and restart the controller.
The **SmartGripper** icon is displayed in the setting menu on the FlexPendant.

2.5.3 IRB 14050 gripper FlexPendant application GUI


Main page

The following figure shows the main page of FlexPendant application.



xx1900000917

If you click on the **Setting** icon, the **SmartGripper** icon will be displayed as shown in the following figure.



xx1800001267

Continues on next page


2 Installation and commissioning

2.5.3 IRB 14050 gripper FlexPendant application GUI

Continued


Configuration page

The following figure shows the configuration page for the IRB 14050 gripper.



xx1800001268

In the configuration page, you can choose the gripper type that has been mounted on the robot.




xx1800001269


Continues on next page

Servo module tab page

The following figure shows the **Servo module** tab page in the hand page, which provides operations related to gripper motion.



xx1800001270




xx1800001478

Continues on next page

2 Installation and commissioning

2.5.3 IRB 14050 gripper FlexPendant application GUI

Continued



xx1800001480


Four function groups are available on the Servo module tab page: **Setup**, **Command**, **Status**, and **Firmware Upgrade**.

Group	Parameter	Description
Setup	Calibrate	Calibrates the gripper at the current position.
	Speed	Sets the movement speed of fingers on the gripper.
	Force	Sets the gripping force of fingers on the gripper.
Command	Jog/Stop/Grip+/Grip-/Move to	If the gripper is not calibrated, only the functions Jog and Stop can be used, and the functions Grip+ , Grip- and Move to are disabled.
Status	Calibration	The calibration status of the robot.
	Current position	Indicates the current position of the gripper.
	Current state	Indicates the state of the gripper. For details about the gripper states, see Returned value on page 141 .
Firmware Upgrade	Current Version	Ver. 5.1

Continues on next page

Pneumatic module tab page

The following figure shows the **Pneumatic module** tab page in the hand page, which is used for instructing the built-in valves to finish vacuum-sucking and blow-off operations.



xx1800001479

Two pneumatic block parts are available for different variants of the gripper. Suction and blow-off functions are exclusive to each other. That is, if one function is turned on, the other will be turned off.

Continues on next page


2 Installation and commissioning

2.5.3 IRB 14050 gripper FlexPendant application GUI

Continued

Camera module tab page

The following figure shows the **Camera module** tab page in the hand page, which can only be set in RobotStudio now. For more information of the camera module, see the *Application manual of Integrated Vision*.



xx1900000709

2.6 Commissioning

2.6.1 Firmware update

Overview

The TFTP method is available for updating the firmware of ABB smart grippers in RobotWare 7.0.

TFTP method

General

The SmartGripper firmware with a version earlier than 4.7 is limited to use the TFTP method for firmware updating.

The TFTP method works after the SmartGripper restarted. It will cost 8s for a new firmware downloading. If the new firmware upgrade fails, the SmartGripper will continue use the TFTP method.

Prerequisites

- PC with a network adapter
The firewall of the PC must be shut down.
- Tftpd client
Tftpd32 developed by Philippe JOUNIN is recommended. For details about Tftpd32, visit <http://tftpd32.jounin.net/>.
- Image binary file
The file must be a BIN file and named like "HandSWx_x.bin". Obtain the proper file by visiting the **ABB Download Center** website and searching with key words "IRB 14050 gripper software".

Update procedure

Use this procedure to update the firmware for the gripper:


- 1 Select **Disable Power To Gripper** to disconnect the flange 24V power to gripper. The TFTP method will be available for updating.

Continues on next page

2 Installation and commissioning

2.6.1 Firmware update

Continued




xx1900000711

- 2 Connect the PC to the Service port of the robot controller.

Ensure that the IP address of the PC is obtained automatically or within the same subnet (192.168.125.xxx) with robot controller.

- 3 Open the Tftpd32 program and click Tftp Client. Then, configure the parameters shown in the following figure.




xx1500000629

- The value of the **Server interfaces** parameter must be the IP address of the network adapter that is used to connect the PC with the robot.

Continues on next page

- The value of the **Host** parameter must be set to the IP address of the target gripper.
192.168.125.30 is the default address for the gripper.
 - The value of the **Port** parameter must be set to 69.
 - In the **Local File** text box, select the image stored on the PC with which the target gripper is to be upgraded.
 - The value of the **Block Size** parameter must be set to 512.
- 4 Power on the target gripper again through the **Enable Power To Gripper** button.



xx1900000712



Note


There is a wait time after pressing the **Enable Power To Gripper** button to enable the Hand device. At this duration, the power on button will be disabled until the Hand turns running.

Continues on next page

2 Installation and commissioning

2.6.1 Firmware update

Continued



xx1900000713

- 5 When the network LED on the target gripper begins blinking, click the **Put** button on the **Tftp Client** tab page.



Note

The **Put** button must be clicked within 8 seconds when you observe the LED blinking. After 8 seconds, the LED stops blinking for a few seconds and then restart blinking. If you click the **Put** button during this re-blinking period, you will experience failures.

- 6 Close the **Tftpd32** program after the transmission is completed.
The gripper is automatically booted with the firmware in the new version. Then, the firmware version of the gripper can be checked using the ABB Smart Gripper Support option.



2.6.2 System commissioning

Servo module

Prerequisites

- The gripper has been installed onto the robot arm correctly.
- Smart Gripper Support option has been selected during installation.
- The gripper has been powered on and the communication is established.

Procedure



	Action	Note
1	Open Smart Gripper and choose the gripper to be tested.	See IRB 14050 gripper FlexPendant application on page 42 .
2	On the Servo module tab page, click the Jog - button until the two fingers of the gripper are in direct contact with each other, which is the zero position used for calibration.	 xx1800001270
3	Click the Calibrate button to perform the calibration.	 xx1900000710

Continues on next page

2 Installation and commissioning

2.6.2 System commissioning

Continued

Action	Note
4 Input value in the text box next to the Move to button and then click the button.	 xx1800001478
5 Check the current position of the gripper, which is shown in Position of the Status area.	 xx1800001481
6 The gripper works properly if all the preceding actions complete normally.	

Vacuum module


Prerequisites

- A gripper with at least one vacuum module has been installed onto the robot arm correctly.
- Suction tools including the suction cup and filter have been installed correctly.
- Smart Gripper Support option has been selected during installation.
- The gripper has been powered on and the communication is established.
- A test object with a smooth surface has been prepared.

Procedure

Action	Note
1 Open Smart Gripper and choose the gripper to be tested.	See IRB 14050 gripper FlexPendant application on page 42 .

Continues on next page

Action	Note
2 Click Pneumatic module to enter the Pneumatic module tab page for commissioning the vacuum module. If any of Pneumatic 1 or Pneumatic 2 is available, the value of Gas pressure should be about 100 KPa. If the value is 0 KPa, no such vacuum module exists or the vacuum sensor of the vacuum module is broken.	 xx1800001479
3 Check the air supply and test object to ensure that the air pressure to the AIR interfaces on the left side panel of the IRB 14050 controller is proper and the test object is in the proper position for the test.	
4 Click the Suction On button.	
5 Verify that the object is picked up successfully. If yes, the value of Gas pressure should be less than 70 kPa.	
6 The vacuum module works properly if all the preceding actions complete normally.	

Vision module

Prerequisites

- A gripper with one vision module has been installed onto the robot arm correctly.
- Smart Gripper Support option has been selected during installation.
- The IV option has been installed to use ABB Integrated Vision for testing the vision module.
- The gripper has been powered on and the communication is normally.
- A PC with the RobotStudio installed has been prepared.



Note

The Cognex In-Sight explorer can also be used for the commissioning of the vision module. In this case, a PC with the Cognex In-Sight software installed must be prepared.



CAUTION

Do not change the firmware of the Cognex AE3 camera; otherwise, communication errors will occur.

Continues on next page

2 Installation and commissioning

2.6.2 System commissioning

Continued

Procedure

See *Application manual - Integrated Vision* for how to perform commissioning on the vision module of the gripper. Verify that:

- The communication between the robot controller/PC and the vision module of the gripper is established.
- The IP address configuration of the vision module is correct. Users can select any available IP address on the subnet 192.168.125.xxx or use the DHCP.
- The vision module can take pictures normally using RobotStudio or Cognex In-Sight.

3 Maintenance

3.1 Inspection activities

Required tools and equipment

Visual inspection, no tools are required.



CAUTION

All power to the manipulator must be shut off when inspecting the gripper. This can be done from the robot main switch on the controller.

Periodicity

Visually inspect the gripper regularly before starting an operation.

Inspecting the gripper

Part	Verify that...
Whole gripper	- The gripper is not loose from the robot arm. - The screws attaching the gripper to the arm flange remain in place and are tightened. - Make sure that there is grease on the spindles and sliders.
Shell/Cover	- The shell/cover is not loose. - No cracks or other mechanical damage.  Note Mechanical damage can only be inspected by removing the cover with appropriate tools and ESD precautions.
Finger	- No finger is loose. - Gripping jaws are correctly mounted on finger and not loose. - Workpiece fit properly in between gripping jaws, no wear. - The screws attaching the fingers to the finger brackets remain in place and are tightened. - No cracks or mechanical damage are in the fingers.
Suction tools	Suction cup(s) and filter(s) are properly fastened and has no mechanical damage.
Camera window	The window is clean and has no damage.
LEDs and lightguides	The LEDs and lightguides are functional.

This page is intentionally left blank

4 Repair

4.1 Introduction

Structure of this chapter

This chapter describes all repair activities recommended for the IRB 14050 gripper. It is made up of separate procedures, each describing a specific repair activity. Each procedure contains all the information required to perform the activity, for example spare parts numbers, required special tools, and materials. The procedures are gathered in sections, divided according to the component location on the IRB 14050 gripper.

Required equipment

The details of the equipment required to perform a specific repair activity are listed in the respective procedures.

The details of equipment are also available in different lists in the chapter [Reference information on page 151](#).

Safety information

There are general safety information and specific safety information. The specific safety information describes the danger and safety risks while performing specific steps in a procedure. Make sure to read through the chapter [Safety on page 11](#) before commencing any service work.



Note

If the robot where the gripper shall be mounted is connected to power, always ensure that the robot is OFF and is connected to protective earth before starting any installation work.

Product manual - IRB 14050

4 Repair

4.2 Replacing the filter and suction cup

4.2 Replacing the filter and suction cup

Location of the filter and suction cup

The filter and suction cup are located as shown in the figure.



xx1500000628

A	Suction cup
B	Filter

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit on page 153 .

Required spare parts

Spare part	Article number	Note
Vacuum filter	3HAC047854-001	
Vacuum rubber cup	3HAC047927-001	


Removing the filter and suction cup

Use this procedure to remove the filter and suction cup.

Continues on next page

4.2 Replacing the filter and suction cup
Continued

Removing the whole gripper

	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 .
2	Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw.	 xx1500001390
3	Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange.	

Removing the filter and suction cup

	Action	Note/Illustration
1	Twist and remove the filter and suction cup.  Note The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them.	 xx1400002624 A Suction cup B Filter

Continues on next page

4 Repair

4.2 Replacing the filter and suction cup

Continued


Refitting the filter and suction cup

Use this procedure to refit the filter and suction cup.

Refit the filter and suction cup

	Action	Note/Illustration
1	Refit the filter and suction cup by twisting them.	Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001  xx1400002624 A Suction cup B Filter




Refitting the whole gripper

	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.
2	Position the gripper to the arm tool flange on the axis 6 of the robot.	 xx1500001394 A Arm tool flange B Axis 6 of the robot

Continues on next page

4.2 Replacing the filter and suction cup

Continued


	Action	Note
3	Use the guide pin and air hose hole to make the gripper align with the arm tool flange.	For the positions of the guide pin and air hose hole, see Mounting flange on page 33 .
4	For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged.	O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625
5	Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001391
6	Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392

Continues on next page

4 Repair

4.2 Replacing the filter and suction cup


Continued

	Action	Note
7	Rotate the flange with 90 degrees to access the last screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393
8	Turn on the power and air supply to the gripper and then perform commissioning on the gripper.	

4.3 Replacing the fingers

Location of the fingers

The fingers are located as shown in the figure.



xx1400002616

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit on page 153 .

Required spare parts

Spare part	Article number	Note
Fingers	3HAC052976-001	Two getting-started fingers are delivered with the gripper. It is also possible to use customized fingers based on actual requirements.
Hex socket head cap screw	3HAC051700-001	

Removing the fingers

Use this procedure to remove the fingers.


Continues on next page

4 Repair

4.3 Replacing the fingers



Continued

Removing the whole gripper

	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 .
2	Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw.	 xx1500001390
3	Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange.	

Continues on next page

Removing the fingers

	Action	Note/Illustration
1	Remove the screws that hold the finger.	 xx1400002617
2	If two pins are used for positioning, remove the pins.	 xx1500000607
3	Pull out the finger from the finger flange.	

Refitting the fingers

Use this procedure to refit the fingers.

Refitting the fingers



	Action	Note/Illustration
1	Place a new finger on the finger flange.	Fingers , 3HAC052976-001

Continues on next page

4 Repair

4.3 Replacing the fingers




Continued

Action	Note/Illustration
2 For metal fingers, insert two pins for positioning.  Note Pins can be designed based on actual requirements. For details about the hole configuration, see Hole configuration, mounting base on page 35.	Pin (2 pcs for each finger) 2x6, h8 ISO 2338  xx1500000607
3 Refit and tighten the screws.	Hex socket head cap screw , 3HAC051700-001: M2x7, class 8.8 (8 pcs) Tightening torque: 0.2 Nm  xx1400002617

Refitting the whole gripper

Action	Note
1  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.

Continues on next page



	Action	Note
2	Position the gripper to the arm tool flange on the axis 6 of the robot.	 xx1500001394 A Arm tool flange B Axis 6 of the robot
3	Use the guide pin and air hose hole to make the gripper align with the arm tool flange.	For the positions of the guide pin and air hose hole, see Mounting flange on page 33 .
4	For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged.	O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625
5	Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001391

Continues on next page

4 Repair

4.3 Replacing the fingers


Continued

	Action	Note
6	Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392
7	Rotate the flange with 90 degrees to access the last screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393
8	Turn on the power and air supply to the gripper and then perform commissioning on the gripper.	

4.4 Replacing the shell

Location of the shell

The shell is located as shown in the figure.



xx1500000638

Required tools and equipment

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit on page 153 .

Required spare parts

Spare part	Article number	Note
Shell complete (with camera window)	3HAC054986-001	Used for the gripper with a camera. Use together with O-ring 1.8x1.8 , 3HAB3772-175

Continues on next page

4 Repair


4.4 Replacing the shell

Continued

Spare part	Article number	Note
Shell complete (without camera window)	3HAC054987-001	Used for the gripper without a camera. Use together with O-ring 1.8x1.8 , 3HAB3772-175
O-ring 1.8x1.8	3HAB3772-175	

Removing the shell

Removing the whole gripper



	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 .
2	Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw.	 xx1500001390
3	Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange.	

Continues on next page

Removing the filter and suction cup

Action	Note/Illustration
1 Twist and remove the filter and suction cup.  Note The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them.	 xx1400002624 A Suction cup B Filter

Removing the shell

Action	Note/Illustration
1 Remove the screws that fasten the shell.	 xx1500000759
2 Press the locations shown in the figure gently to detach the shell. The shell consists of two parts: • lower shell • upper shell	 xx1400002152

Continues on next page



4 Repair

4.4 Replacing the shell


Continued

Refitting the shell

Refitting the shell

	Action	Note/Illustration
1	Put the lower shell to the base plate and insert the locating pins on the lower shell to the location holes on the base plate.	Shell complete (with camera window), 3HAC054986-001 Shell complete (without camera window), 3HAC054987-001  xx1400002155
2	Put the upper shell to the base plate.	 xx1500000769
3	Press the lower shell and upper shell together.	

Continues on next page

Action	Note/Illustration
4 Refit the screws to fasten the shell.	Screw M1.2 (2 pcs)  xx1500000759

Refit the filter and suction cup

Action	Note/Illustration
1 Refit the filter and suction cup by twisting them.	Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001  xx1400002624 A Suction cup B Filter

Refitting the whole gripper




Action	Note
1  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.

Continues on next page



4 Repair

4.4 Replacing the shell

Continued

	Action	Note
2	Position the gripper to the arm tool flange on the axis 6 of the robot.	 xx1500001394 A Arm tool flange B Axis 6 of the robot
3	Use the guide pin and air hose hole to make the gripper align with the arm tool flange.	For the positions of the guide pin and air hose hole, see Mounting flange on page 33 .
4	For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged.	O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625
5	Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001391

Continues on next page

	Action	Note
6	Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392
7	Rotate the flange with 90 degrees to access the last screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393
8	Turn on the power and air supply to the gripper and then perform commissioning on the gripper.	


4 Repair

4.5 Replacing the pneumatic block

4.5 Replacing the pneumatic block

Location of the pneumatic block

The pneumatic block is located as shown in the figure.



xx1400002626

Required tools

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit on page 153 .

Required spare parts


Spare part	Article number	Note
Pneumatic block	3HAC054989-001	
Pneumatic block	3HAC054990-001	
Vacuum sensor	3HAC047823-001	
Pneumatic block connector board	3HAC051609-001	

Continues on next page

Spare part	Article number	Note
FFC for pneumatic block connector board	3HAC051610-002	9 pin; pitch 1.0
FFC for camera	3HAC054157-002	31 pin; 76-mm length

Removing the pneumatic block

Removing the whole gripper

	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 .
2	Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw.	 xx1500001390
3	Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange.	

Continues on next page

4 Repair



4.5 Replacing the pneumatic block

Continued

Removing the filter and suction cup




Action	Note/Illustration
1 Twist and remove the filter and suction cup.  Note The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them.	 xx1400002624 A Suction cup B Filter

Removing the shell

Action	Note/Illustration
1 Remove the screws that fasten the shell.	 xx1500000759
2 Press the locations shown in the figure gently to detach the shell. The shell consists of two parts: • lower shell • upper shell	 xx1400002152

Continues on next page

Removing the pneumatic block




	Action	Note/Illustration
1	Disconnect the connectors from the vacuum sensor and valve.	 xx1400002618
2	Disconnect the motor cable.	 xx1400002619
3	For the left pneumatic block, disconnect the flexible cable for connector board.	 xx1500000608

Continues on next page

4 Repair

4.5 Replacing the pneumatic block



Continued

	Action	Note/Illustration
4	For the gripper with a camera, disconnect the flexible flat cable (FFC) from the camera.	 xx1500000612
5	Remove the screws to detach the main PCB.	 xx1400002621
6	Remove the screws to detach the pneumatic block from the servo base.	 xx1500000610

Continues on next page


4.5 Replacing the pneumatic block

Continued

Action	Note/Illustration
7 For the left pneumatic block, remove the screws to remove the connector board.	 xx1500000609
8 Remove the vacuum sensor.	 xx2100000696

Refitting the pneumatic block

Refitting the pneumatic block




Action	Note/Illustration
1 Refit the vacuum sensor.	Vacuum sensor, 3HAC047823-001  xx2100000696

Continues on next page

4 Repair

4.5 Replacing the pneumatic block


Continued

	Action	Note/Illustration
2	For the left pneumatic block, refit the connector board with screws.	Pneumatic block connector board, 3HAC051609-001  xx150000609
3	Refit the new pneumatic block to the servo base with screws.	Screw M2.5 (3 pcs) Pneumatic block, 3HAC054989-001 Pneumatic block, 3HAC054990-001  xx150000610
4	Refit the main PCB.	 xx1400002621


Continues on next page

4.5 Replacing the pneumatic block

Continued

	Action	Note/Illustration
5	Check the FFC for the pneumatic block connector board and FFC for the camera. Replace if damaged.	FFC for pneumatic block connector board, 3HAC051610-002 FFC for camera, 3HAC054157-002
6	Reconnect the connectors: • Vacuum sensor and valve • motor cable • FFC for the pneumatic block connector board • FFC for the camera	 xx1400002628

Refitting the shell



	Action	Note/Illustration
1	Put the lower shell to the base plate and insert the locating pins on the lower shell to the location holes on the base plate.	Shell complete (with camera window), 3HAC054986-001 Shell complete (without camera window), 3HAC054987-001  xx1400002155

Continues on next page

4 Repair

4.5 Replacing the pneumatic block

Continued


	Action	Note/Illustration
2	Put the upper shell to the base plate.	 xx1500000769
3	Press the lower shell and upper shell together.	
4	Refit the screws to fasten the shell.	Screw M1.2 (2 pcs)  xx1500000759

Continues on next page

Refit the filter and suction cup

	Action	Note/Illustration
1	Refit the filter and suction cup by twisting them.	Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001  xx1400002624 A Suction cup B Filter

Refitting the whole gripper




	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.
2	Position the gripper to the arm tool flange on the axis 6 of the robot.	 xx1500001394 A Arm tool flange B Axis 6 of the robot

Continues on next page


4 Repair

4.5 Replacing the pneumatic block

Continued

	Action	Note
3	Use the guide pin and air hose hole to make the gripper align with the arm tool flange.	For the positions of the guide pin and air hose hole, see Mounting flange on page 33 .
4	For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged.	O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625
5	Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001391
6	Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392

Continues on next page

	Action	Note
7	Rotate the flange with 90 degrees to access the last screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393
8	Turn on the power and air supply to the gripper and then perform commissioning on the gripper.	


4 Repair

4.6 Replacing the camera

4.6 Replacing the camera

Location of the camera

The camera is located as shown in the figure.



xx1500000611

Required tools

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit on page 153 .


Required spare parts

Spare part	Article number	Note
Camera AE3	3HAC051676-001	
Hex socket head cap screw	3HAC051700-001	
FFC for camera	3HAC054157-002	31 pin; 76-mm length

Continues on next page

Removing the camera

Removing the whole gripper

	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 .
2	Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw.	 xx1500001390
3	Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange.	

Removing the filter and suction cup

	Action	Note/Illustration
1	Twist and remove the filter and suction cup.  Note The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them.	 xx1400002624 A Suction cup B Filter



Continues on next page

4 Repair


4.6 Replacing the camera

Continued

Removing the shell


Action		Note/Illustration
1	Remove the screws that fasten the shell.	 xx1500000759
2	Press the locations shown in the figure gently to detach the shell. The shell consists of two parts: • lower shell • upper shell	 xx1400002152

Removing the camera

Action		Note
1	Disconnect the FFC from the camera.	 xx1500000612



Continues on next page

4.6 Replacing the camera Continued

Action	Note
2 Remove the screws to detach the camera with the camera bracket from the servo base.	 xx1500000614

Refitting the camera

Refitting the camera

Action	Note/Illustration
1 Refit the camera with the camera bracket to the servo base.	Camera AE3, 3HAC051676-001 Hex socket head cap screw , 3HAC051700-001: M2x7, class 8.8 (2 pcs)  xx1500000614
2 Check the FFC for the camera. Replace if damaged.	FFC for camera, 3HAC054157-002
3 Connect the FFC to the camera.	 xx1500000612



Continues on next page

4 Repair


4.6 Replacing the camera

Continued

Refitting the shell

	Action	Note/Illustration
1	Put the lower shell to the base plate and insert the locating pins on the lower shell to the location holes on the base plate.	Shell complete (with camera window), 3HAC054986-001 Shell complete (without camera window), 3HAC054987-001  xx1400002155
2	Put the upper shell to the base plate.	 xx1500000769
3	Press the lower shell and upper shell together.	

Continues on next page

Action	Note/Illustration
4 Refit the screws to fasten the shell.	Screw M1.2 (2 pcs)  xx1500000759

Refit the filter and suction cup

Action	Note/Illustration
1 Refit the filter and suction cup by twisting them.	Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001  xx1400002624 A Suction cup B Filter

Refitting the whole gripper




Action	Note
1  CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.

Continues on next page



4 Repair

4.6 Replacing the camera

Continued

	Action	Note
2	Position the gripper to the arm tool flange on the axis 6 of the robot.	 xx1500001394 A Arm tool flange B Axis 6 of the robot
3	Use the guide pin and air hose hole to make the gripper align with the arm tool flange.	For the positions of the guide pin and air hose hole, see Mounting flange on page 33 .
4	For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged.	O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625
5	Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001391

Continues on next page

	Action	Note
6	Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392
7	Rotate the flange with 90 degrees to access the last screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393
8	Turn on the power and air supply to the gripper and then perform commissioning on the gripper.	


4 Repair

4.7 Replacing the servo base

4.7 Replacing the servo base

Location of the servo base

The servo base is located as shown in the figure.



xx1400002623

Required tools

Equipment	Article number	Note
Standard toolkit	-	Content is defined in section Standard toolkit on page 153 .


Required spare parts

Spare part	Article number	Note
Servo base	3HAC054988-001	

Continues on next page

Removing the servo base

Removing the whole gripper

	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46 .
2	Rotate the arm tool flange on the axis 6 of the robot to make one of the three screw holes accessible, and then remove the screw.	 xx1500001390
3	Repeat the preceding step to remove the other two screws to detach the whole gripper from the arm tool flange.	

Removing the filter and suction cup

	Action	Note/Illustration
1	Twist and remove the filter and suction cup.  Note The filter and suction cup are provided as a set and recommended to be replaced together. A built-in screw is mounted on the filter, which enables a simple removal of filter and suction cup by just twisting them.	 xx1400002624 A Suction cup B Filter



Continues on next page

4 Repair


4.7 Replacing the servo base

Continued




Removing the shell

Action	Note/Illustration
1 Remove the screws that fasten the shell.	 xx1500000759
2 Press the locations shown in the figure gently to detach the shell. The shell consists of two parts: • lower shell • upper shell	 xx1400002152

Removing the pneumatic block

Action	Note/Illustration
1 Disconnect the connectors from the vacuum sensor and valve.	 xx1400002618

Continues on next page




	Action	Note/Illustration
2	Disconnect the motor cable.	 xx1400002619
3	For the left pneumatic block, disconnect the flexible cable for connector board.	 xx1500000608
4	For the gripper with a camera, disconnect the flexible flat cable (FFC) from the camera.	 xx1500000612

Continues on next page


4 Repair

4.7 Replacing the servo base



Continued

	Action	Note/Illustration
5	Remove the screws to detach the main PCB.	 xx1400002621
6	Remove the screws to detach the pneumatic block from the servo base.	 xx1500000610
7	For the left pneumatic block, remove the screws to remove the connector board.	 xx1500000609

Continues on next page

Action	Note/Illustration
8 Remove the vacuum sensor.	 xx2100000696

Removing the camera

Action	Note
1 Disconnect the FFC from the camera.	 xx1500000612
2 Remove the screws to detach the camera with the camera bracket from the servo base.	 xx1500000614

Continues on next page



4 Repair

4.7 Replacing the servo base


Continued

Refitting the servo base




Refitting the camera

	Action	Note/Illustration
1	Refit the camera with the camera bracket to the servo base.	Camera AE3, 3HAC051676-001 Hex socket head cap screw , 3HAC051700-001: M2x7, class 8.8 (2 pcs)  xx1500000614
2	Check the FFC for the camera. Replace if damaged.	FFC for camera, 3HAC054157-002
3	Connect the FFC to the camera.	 xx1500000612

Refitting the pneumatic block

	Action	Note/Illustration
1	Refit the vacuum sensor.	Vacuum sensor, 3HAC047823-001  xx2100000696

Continues on next page


	Action	Note/Illustration
2	For the left pneumatic block, refit the connector board with screws.	Pneumatic block connector board, 3HAC051609-001  xx1500000609
3	Refit the new pneumatic block to the servo base with screws.	Screw M2.5 (3 pcs) Pneumatic block, 3HAC054989-001 Pneumatic block, 3HAC054990-001  xx1500000610
4	Refit the main PCB.	 xx1400002621

Continues on next page


4 Repair

4.7 Replacing the servo base



Continued

	Action	Note/Illustration
5	Check the FFC for the pneumatic block connector board and FFC for the camera. Replace if damaged.	FFC for pneumatic block connector board, 3HAC051610-002 FFC for camera, 3HAC054157-002
6	Reconnect the connectors: • Vacuum sensor and valve • motor cable • FFC for the pneumatic block connector board • FFC for the camera	 xx1400002628

Refitting the shell

	Action	Note/Illustration
1	Put the lower shell to the base plate and insert the locating pins on the lower shell to the location holes on the base plate.	Shell complete (with camera window), 3HAC054986-001 Shell complete (without camera window), 3HAC054987-001  xx1400002155

Continues on next page

	Action	Note/Illustration
2	Put the upper shell to the base plate.	 xx1500000769
3	Press the lower shell and upper shell together.	
4	Refit the screws to fasten the shell.	Screw M1.2 (2 pcs)  xx1500000759

Continues on next page

4 Repair


4.7 Replacing the servo base

Continued




Refit the filter and suction cup

	Action	Note/Illustration
1	Refit the filter and suction cup by twisting them.	Vacuum filter , 3HAC047854-001 Vacuum rubber cup , 3HAC047927-001  xx1400002624 A Suction cup B Filter

Refitting the whole gripper

	Action	Note
1	 CAUTION Do not install or remove the gripper when power is on. Otherwise damage to the electronics may occur. Always check the gripper power status before commencing any service work.. Make sure that all supplies for electrical power and air pressure are turned off.	For details about how to check the power status and how to turn off gripper power using FlexPendant, see Configuration page on page 46.
2	Position the gripper to the arm tool flange on the axis 6 of the robot.	 xx1500001394 A Arm tool flange B Axis 6 of the robot

Continues on next page


	Action	Note
3	Use the guide pin and air hose hole to make the gripper align with the arm tool flange.	For the positions of the guide pin and air hose hole, see Mounting flange on page 33 .
4	For the gripper with a vacuum module, check the O-ring in the air hose hole. Replace if damaged.	O-ring 4x2: 3HAC063220-001 (1 pcs)  xx1500001625
5	Rotate the arm tool flange with the gripper to make one of the three screw holes accessible and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001391
6	Rotate the flange with 180 degrees to access the opposite screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001392

Continues on next page

4 Repair

4.7 Replacing the servo base

Continued

	Action	Note
7	Rotate the flange with 90 degrees to access the last screw hole and then refit the screw.	Screw: M2.5 x 8, 3HAC051701-001 (1 pcs)  xx1500001393
8	Turn on the power and air supply to the gripper and then perform commissioning on the gripper.	


5 RAPID references

5.1 Overview

RAPID instruction/function naming

A shorter name is introduced to each RAPID instruction/function, such as, `g_Init` corresponding to the original `Hand_Initialize`. The shorter and longer names of a RAPID instruction/function are totally compatible to each other, that is, having the same usage, arguments and syntax.

The longer names may become invalid in a short future. Users are recommended to use the shorter names that are also easy to remember and use. If the users continue using the longer instruction/function name, the following notification will be displayed to prompt the using of newly shorter ones.



xx1800001482

Continues on next page

5 RAPID references

5.1 Overview

Continued

Program execution on virtual controller

If the following instruction/function is executed on the virtual controller,	Then,
• g_Init • g_JogIn • g_JogOut • g_MoveTo • g_GripIn • g_GripOut • g_Calibrate • g_Stop • g_SetMaxSpd • g_SetForce • g_BlowOn1 • g_BlowOn2 • g_BlowOff1 • g_BlowOff2	the program execution returns immediately to the calling procedure. In this case, the gripper performs no action and no error reports.
• g_VacuumOn1 • g_VacuumOn2 • g_VacuumOff1 • g_VacuumOff2	the program execution returns HIGH after turning on the vacuum channel and returns LOW after turning off the vacuum channel.
• g_GetPos • g_GetSpd • g_GetErrID • g_GetState	the program execution returns 0.
• g_GetPressure1 • g_GetPressure2	the program execution returns 0 if the vacuum channel was turned on before by using g_VacuumOn1 or g_VacuumOn2 and returns 100 if the vacuum channel was turned off before by using g_VacuumOff1 or g_VacuumOff2 . g_GetPressure1 is for the first pneumatic module and g_GetPressure2 is for the second pneumatic module.
• g_IsCalibrated • g_isCamOnline	the program execution returns FALSE.

5.2 Instructions

5.2.1 RAPID instructions for grippers

5.2.1.1 g_Init - Initialize the gripper

Usages

`g_Init` (replacing the original `Hand_Intialize`) is used to initialize the gripper with optionally specified values. For the values that are not specified, the default values will be used.

This instruction can be called before all other gripper-related statements.

Basic examples

Example 1

```
g_Init \maxSpd := 20, \holdForce := 10;
```

In this example, the gripper will be initiated with a maximum speed of 20 mm/s and a holding force of 10 N.

Example 2

```
g_Init \Calibrate;
```

In this example, the gripper will be initiated with default parameter values. The argument `Calibrate` is used to close the fingers and then perform a calibration without holding force.

Example 3

```
g_Init \Calibrate, \Grip;
```

In this example, the gripper will be initiated with default parameter values. The argument `Grip` is used to close the fingers and then perform a calibration with the default holding force of 20 N.

Arguments

```
g_Init [\maxSpd] [\holdForce] [\phyLimit] [\Calibrate] [\Grip]
```

`[\maxSpd]`

Data type: num

The gripper's maximum allowed speed in unit of mm/s. If it is not set, the default maximum speed 25 mm/s will be used.

`[\holdForce]`

Data type: num

The gripper's expected force in unit of N when gripping and holding the target object. If this is not set, the default force 20 N will be used.

`[\phyLimit]`

Data type: num

Continues on next page

5 RAPID references

5.2.1.1 g_Init - Initialize the gripper

Continued

Sometimes, the gripper works in a smaller travel range than the recommended value 25 mmx2. Given this argument, the system will use the value to determine the maximum possible travel range of the gripper.

The value should be within 0-25 mm. If it is not set, the default value 25 will be used.

`[\Calibrate]`

Data type: switch

If this argument is declared, the gripper will undergo a calibrating process without holding force. Note that the gripper will move inward to the limit first.

`[\Grip]`

Data type: switch

If this argument is declared, the gripper will undergo a calibrating process with the default holding force of 20 N. Note that the gripper will move inward to the limit first.

This argument is always used together with the argument `[\Calibrate]`.

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Program execution

If `Calibrate` or `[\Grip]` is declared, the program will pause until the calibration process is completed.

Syntax

```
g_Init
  ['\' maxSpd ':=' ] <expression (IN) of num> ', '
  ['\' holdForce ':=' ] <expression (IN) of num> ', '
  ['\' phyLimit ':=' ] <expression (IN) of num> ', '
  ['\' Calibrate ] ', '
  ['\' Grip ] ';' ;'
```

5.2.1.2 g_JogIn - Jog the gripper to move inward

Usages

g_JogIn (replacing the original Hand_JogInward) is used to move the gripper inward, and does not stop until reaching a mechanical limit or timeout.

Basic examples

```
g_JogIn;
```

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Program execution

The program will pause until the gripper reaches a mechanical limit or timeout. Even if the gripper is stuck mechanically, no error or warning is raised and the program execution will go on.

Syntax

```
g_JogIn ' ; '
```

5 RAPID references

5.2.1.3 g_JogOut - Jog the gripper to move outward

5.2.1.3 g_JogOut - Jog the gripper to move outward

Usages

g_JogOut (replacing the original Hand_JogOutward) is used to move the gripper outward, and does not stop until reaching a mechanical limit or timeout.

Basic examples

```
g_JogOut ;
```

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Program execution

The program will pause until the gripper reaches a mechanical limit or timeout. Even if the gripper is stuck mechanically, no error or warning is raised and the program execution will go on.

Syntax

```
g_JogOut ' ; '
```

5.2.1.4 g_MoveTo - Move the gripper to a target position

Usages

g_MoveTo (replacing the original Hand_MoveTo) is used to move the gripper to a specified position and requires that the gripper must have been calibrated.

Basic examples

Example 1

```
g_MoveTo 15;
```

In this example, the gripper will move to the position that is 15 mm away from the calibrated zero point. The program will pause until the movement is completed.

Example 2

```
g_MoveTo 20, \NoWait;
```

In this example, the gripper will move to the position that is 20 mm away from the calibrated zero point. However, the program will continue to the next statement regardless of whether the movement has completed or not.

Arguments

```
g_MoveTo [targetPos] [\NoWait]
```

[targetPos]

Data type: num

The target position to which the gripper is specified to move with the unit of mm. The value should be within 0-25 mm or 0-phyLimit if phyLimit is set in g_Init.

[\NoWait]

Data type: switch

If NoWait is set, the program will continue to the next statement upon the sending of the command to the gripper, regardless of whether the movement has completed or not.

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Program execution

If NoWait is not set, the program will pause for the movement to complete or raise an error when the movement is not completed within the given time 5 seconds.

If NoWait is set, the program will go directly to the next statement regardless of the movement status. However, the program may need to check the movement result later.

If the specified distance is too small, for example, less than 0.2 mm, the gripper will not move.

Continues on next page

5 RAPID references

5.2.1.4 g_MoveTo - Move the gripper to a target position

Continued

Error handling

If the gripper is not calibrated, an error is raised and the system variable ERRNO will be set to ERR_HAND_NOTCALIBRATED. The error can be handled in the error handler.

If the gripper does not reach the specified target position within the given time 5 seconds, or the movement is mechanically blocked before reaching the target position, an error is raised and the system variable ERRNO will be set to ERR_HAND_FAILEDMOVEPOS. The error can be handled in the error handler. If NoWait is set, ERR_HAND_FAILEDMOVEPOS will not be raised.

If the robot loses the communication with the gripper, the error ERR_NORUNUNIT will be raised.

Syntax

```
g_MoveTo
  [targetPos ':='] <expression (IN) of num> ', '
  ['\ ' NoWait ] ';' ;
```

5.2.1.5 g_GripIn - Jog the gripper to grip inward

Usages

`g_GripIn` (replacing the original `Hand_GripInward`) is used to indicate the gripper to grip inward and requires that the gripper must be calibrated.

Basic examples

Example 1

```
g_GripIn;
```

In this example, the gripper will try to grip inward with the default force. If there is no object, the two fingers of the gripper will move together and press each other tightly.

Example 2

```
g_GripIn \holdForce := 15;
```

In this example, the gripper is instructed to grip the target object with a 15 N force.

Example 3

```
g_GripIn \holdForce :=15, \ targetPos := 10;
```

In this example, the gripper will try to successfully grip around the particular point (10 mm) with a 15 N force. If the gripper does not touch any object in that point, an error is raised.

Example 4

```
g_GripIn \ targetPos:=5, \ posAllowance := 1;
```

In this example, the gripper will try to successfully grip around the particular point (5 mm) with the default force. The gripping position should be at 5 ± 1 mm. Otherwise, an error is raised.

Example 5

```
g_GripIn \NoWait;
```

In this example, the gripper will directly grip inward with the default force. Instead of waiting for the completion of gripping, the RAPID program will go to the next statement directly after sending out the gripping command.

In this case, the user should check the completion of gripping operation themselves. This argument is used to achieve a fast gripping operation without any lag in robot moving. For details, see example 6.

Example 6

```

BOOL GripSuccess:=FALSE;
BOOL GripEvaluated :=FALSE;
MoveL Offs(GripPosition,0,0,50), z10
MoveLSync Offs(GripPosition,0,0,5), z0,"CloseHand";
MoveL GripPosition,z0;
MoveLSync Offs(GripPosition,0,0,50), z10,"EvaluateGrip";
MoveL GripComple, z10
Waituntil GripEvaluated;
IF GripSuccess THEN
! go on with next step.
```

Continues on next page

5 RAPID references

5.2.1.5 g_GripIn - Jog the gripper to grip inward

Continued

```
ELSE
  ! retry to pick the part.
ENDIF
PROC CloseHand()
  g_GripIn\NoWait;
ENDPROC
PROC EvaluateGrip()
  WaitUnit Hand_GetActualSpd()=0;
  IF Hand_GetActualPos() > 10 AND Hand_GetActualPos()<12 THEN
    GripSuccess:=TRUE;
  ELSE
    GripSuccess:=FALSE;
  ENDIF
  GripEvaluated:=TRUE;
ENDPROC
```

In this example, the gripping operation will be executed as an interrupt. That means that even a continuous robot moving without fine point pause is allowed here. After the gripping operation, the program will check whether this gripping is successfully performed.

Arguments

`g_GripIn [\holdForce] [\targetPos] [posAllowance][\NoWait]`

`[\holdForce]`

Data type: num

The force used by the gripper to hold the object. The value should be within 0-20 N. If this argument is not assigned, the default value 20 N will be used.

`[\targetPos]`

Data type: num

If targetPos is set but the gripper does not touch any object within the range from targetPos-posAllowance to targetPos+posAllowance, an error is raised. The value should be within 0-25 mm.

`[posAllowance]`

Data type: num

Ignored if targetPos is not set.

If targetPos is set but posAllowance is not, the default value 2 will be used.

`[\NoWait]`

Without this argument, the program will wait until a completion or failure of gripping operation.

If this argument is declared, the program will go to the next statement directly regardless of how the gripping will be executed.

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Continues on next page

Program execution

If `NoWait` is not declared, the program will pause until the gripper holds the object successfully. Otherwise, an error is raised. If `NoWait` is declared, the call to this instruction will be ended and the program will directly go to the next statement.

If no detection is required, both `targetPos` and `posAllowance` can be omitted.

The gripping is supposed to last less than 5 minutes in normal operations. To avoid overheating of the gripper and other impacts caused by a long time of continuous gripping, the gripping force will be released automatically after an uninterrupted gripping for 30 minutes.

Error handling

If the gripper is not calibrated, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_NOTCALIBRATED`. The error can be handled in the error handler.

If the gripper is not in an expected state, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_WRONGSTATE`. The error can be handled in the error handler.

If `targetPos` is set but the object is not held within the expected range, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_FAILEDGRIPPOS`. The error can be handled in the error handler.

If `targetPos` is set to a larger value than the current position, the gripper cannot grip with an inward force. Then, an error is raised and the system variable `ERRNO` will be set to `FAILEDGRIPINWARD`. The error can be handled in the error handler.

Syntax

```
g_GripIn
  ['\ ' holdForce ':=' ] <expression (IN) of num> ', '
  ['\ ' targetPos ':=' ] <expression (IN) of num> ', '
  ['\ ' posAllowance ':=' ] <expression (IN) of num> ', '
  ['\ ' NoWait ] ';' ;
```

5 RAPID references

5.2.1.6 g_GripOut - Jog the gripper to grip outward

5.2.1.6 g_GripOut - Jog the gripper to grip outward

Usages

`g_GripOut` (replacing the original `Hand_GripOutward`) is used to indicate the gripper to grip outward and requires that the gripper must be calibrated.

Basic examples

Example 1

```
g_GripOut;
```

In this example, the gripper will try to grip outward with the default force. If there is no object to grip, the two fingers of the gripper will press tightly against the mechanic limits.

Example 2

```
g_GripOut \holdForce := 15;
```

In this example, the gripper is instructed to grip the target object with a 15 N outward force.

Example 3

```
g_GripOut \holdForce :=15, \targetPos := 10;
```

In this example, the gripper will try to successfully grip around the particular point (10 mm) with a 15 N force. If the gripper does not touch any object in that point, an error is raised.

Example 4

```
g_GripOut \targetPos:=5, \posAllowance := 1;
```

In this example, the gripper will try to successfully grip around the particular point (5 mm) with the default outward force. The gripping position should be at 5 ± 1 mm. Otherwise, an error is raised.

Example 5

```
g_GripOut \NoWait;
```

In this example, the gripper will directly grip outward with the default force. Instead of waiting for the completion of gripping, the RAPID program will go to the next statement directly after sending out the gripping command.

In this case, the user should check the completion of gripping operation themselves. This argument is used to achieve a fast gripping operation without any lag in robot moving. For details, see example 6.

Example 6

```
BOOL GripSuccess:=FALSE;
BOOL GripEvaluated :=FALSE;
MoveL Offs(GripPosition,0,0,50), z10
MoveLSync Offs(GripPosition,0,0,5), z0,"CloseHand";
MoveL GripPosition,z0;
MoveLSync Offs(GripPosition,0,0,50), z10,"EvaluateGrip";
MoveL GripComple, z10
Waituntil GripEvaluated;
IF GripSuccess THEN
```

Continues on next page

```

! go on with next step.
ELSE
! retry to pick the part.
ENDIF
PROC CloseHand()
g_GripOut\Nowait;
ENDPROC
PROC EvaluateGrip()
WaitUnit Hand_GetActualSpd()=0;
IF Hand_GetActualPos() > 10 AND Hand_GetActualPos()<12 THEN
GripSuccess:=TRUE;
ELSE
GripSuccess:=FALSE;
ENDIF
GripEvaluated:=TRUE;
ENDPROC

```

In this example, the gripping operation will be executed as an interrupt. That means that even a continuous robot moving without fine point pause is allowed here. After the gripping operation, the program will check whether this gripping is successfully performed.

Arguments

g_GripOut [\holdForce] [\targetPos] [\posAllowance][\Nowait]

[\holdForce]

Data type: num

The force used by the griper to hold the object. The value should be within 0-20 N. If this argument is not assigned, the default value 20 N will be used.

[\targetPos]

Data type: num

If targetPos is set but the gripper does not touch any object within the range from targetPos-posAllowance to targetPos+posAllowance, an error is raised.

The value should be within 0-25 mm.

[\posAllowance]

Data type: num

Ignored if targetPos is not set.

If targetPos is set but posAllowance is not, the default value 2 will be used.

[\Nowait]

Without this argument, the program will wait until a completion or failure of gripping operation.

If this argument is declared, the program will go to the next statement directly regardless of how the gripping will be executed.

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Continues on next page

5 RAPID references

5.2.1.6 g_GripOut - Jog the gripper to grip outward

Continued

Program execution

If `NoWait` is not declared, the program will pause until the gripper holds the object successfully. Otherwise, an error is raised. If `NoWait` is declared, the call to this instruction will be ended and the program will directly go to the next statement.

If no detection is required, both `targetPos` and `posAllowance` can be omitted.

The gripping is supposed to last less than 5 minutes in normal operations. To avoid overheating of the gripper and other impacts caused by a long time of continuous gripping, the gripping force will be released automatically after an uninterrupted gripping for 30 minutes.

Error handling

If the gripper is not calibrated, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_NOTCALIBRATED`. The error can be handled in the error handler.

If the gripper is not in an expected state, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_WRONGSTATE`. The error can be handled in the error handler.

If `targetPos` is set but the object is not held within the expected range, an error is raised and the system variable `ERRNO` will be set to `ERR_HAND_FAILEDGRIPPOS`. The error can be handled in the error handler.

If `targetPos` is set to a smaller value than the current position, the gripper cannot grip with an outward force. Then, an error is raised and the system variable `ERRNO` will be set to `FAILEDGRIPOUTWARD`. The error can be handled in the error handler.

Syntax

```
g_GripOut
  ['\ ' holdForce ':=' ] <expression (IN) of num> ', '
  ['\ ' targetPos ':=' ] <expression (IN) of num> ', '
  ['\ ' posAllowance ':=' ] <expression (IN) of num> ', '
  ['\ ' NoWait ] ';' ;
```

5.2.1.7 g_Calibrate - Calibrate the gripper

Usages

g_Calibrate (replacing the original Hand_DoCalibrate) is used to calibrate the gripper in a particular position. Only after the gripper is calibrated, it can be instructed to perform movement or gripping.

Basic examples

Example 1

```
g_Calibrate;
```

In this example, the gripper will set the current position as the zero point.

Example 2

```
g_Calibrate \Jog;
```

In this example, the two fingers of the gripper will move together at the middle point first and then that point will be set as the zero point.

Example 3

```
g_Calibrate \Grip;
```

In this example, the gripper will undergo a calibrating process with the default holding force of 20 N and set the current position as the zero point.

Argument

```
[\Jog] [\Grip]
```

[\Jog]

Data type: switch

With this argument is declared, the gripper fingers will move to the middle point first and then that point will be set as the zero point.

[\Grip]

Data type: switch

If this argument is declared, the gripper will undergo a calibrating process with the default holding force of 20 N and set the current position as the zero point.

Limitations

This instruction is allowed only in gripper tasks T_ROB1.

Program execution

The program does not continue to the next statement until the calibrating process is completed.

Syntax

```
g_Calibrate
  ['\ ' Jog] ', '
  ['\ ' Grip] ';'
```

5 RAPID references

5.2.1.8 g_Stop - Stop the gripper

5.2.1.8 g_Stop - Stop the gripper

Usages

g_Stop (replacing the original Hand_Stop) is used to stop any action of the gripper. Especially, the motor will lose power.

Basic examples

```
g_Stop;
```

Program execution

The instruction will stop any movement or gripping operation of the gripper. Then, the program will continue.

Syntax

```
g_Stop ';' ;
```

5.2.1.9 g_SetMaxSpd - Set the maximum speed

Usage

g_SetMaxSpd (replacing the original Hand_SetMaxSpeed) is used to set the maximum allowed speed of the gripper. Note that the actual maximum speed may be limited by the acceleration time.

Basic examples

```
g_SetMaxSpd 15;
```

In this example, the gripper is configured with a maximum allowed speed of 15 mm/s.

Arguments

```
g_SetMaxSpd maxSpd
```

maxSpd

Data type: num

The maximum allowed speed of the gripper in unit of mm/s.

The value should be within 0-25 mm/s.

Program execution

This instruction will give the gripper a new maximum speed. The new setting will be kept until you change it again or restart the robot system.

Error handling

If the robot loses the communication with the gripper, the error ERR_NORUNUNIT will be raised.

Syntax

```
g_SetMaxSpd  
[maxSpd ':='] <expression (IN) of num> ';' ;
```

5 RAPID references

5.2.2.1 g_BlowOn1 - Turn on blowing channel 1

5.2.2 RAPID instructions for pneumatic modules

5.2.2.1 g_BlowOn1 - Turn on blowing channel 1

Usage

g_BlowOn1 (replacing the original Hand_TurnOnBlow1) is used to turn on the blowing channel in gripper pneumatic module 1.

Basic examples

```
g_BlowOn1;
```

In this example, whether vacuum channel 1 is turned on will be inspected first and then is closed if necessary. Then, blow channel 1 will be turned on.

Program execution

The program will turn on the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_BlowOn1 ' ; '
```

5.2.2.2 g_BlowOff1 - Turn off blowing channel 1

Usage

g_BlowOff1 (replacing the original Hand_TurnOffBlow1) is used to turn off the blowing channel in gripper pneumatic module 1.

Basic examples

```
g_BlowOff1;
```

In this example, blow channel 1 will be turned off.

Program execution

The program will turn off the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_BlowOff1 ';' ;'
```

5 RAPID references

5.2.2.3 g_BlowOn2 - Turn on blowing channel 2

5.2.2.3 g_BlowOn2 - Turn on blowing channel 2

Usage

g_BlowOn2 (replacing the original Hand_TurnOnBlow2) is used to turn on the blowing channel in gripper pneumatic module 2.

Basic examples

```
g_BlowOn2;
```

In this example, whether vacuum channel 2 is turned on will be inspected first and then is closed if necessary. Then, blow channel 2 will be turned on.

Program execution

The program will turn on the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_BlowOn2 ';' ;
```

5.2.2.4 g_BlowOff2 - Turn off blowing channel 2

Usage

g_BlowOff2 (replacing the original Hand_TurnOffBlow2) is used to turn off the blowing channel in gripper pneumatic module 2.

Basic examples

```
g_BlowOff2;
```

In this example, blow channel 2 will be turned off.

Program execution

The program will turn off the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_BlowOff2 ';' ;'
```

5 RAPID references

5.2.2.5 g_VacuumOn1 - Turn on vacuum channel 1

5.2.2.5 g_VacuumOn1 - Turn on vacuum channel 1

Usage

g_VacuumOn1 (replacing the original Hand_TurnOnVacuum1) is used to turn on the vacuum channel in hand pneumatic module 1. After turning on the vacuum channel, the vacuum pressure in the pneumatic module will also be verified with the given threshold. If there is not enough vacuum, an error is raised.

Basic examples

Example 1

```
g_VacuumOn1;
```

In this example, whether blowing channel 1 is turned on will be checked first and then is closed if necessary. Then, vacuum channel 1 will be turned on.

Example 2

```
g_VacuumOn1 \threshold := 30;
```

After turning on the vacuum valve, the program will also read the vacuum pressure from the interior sensor. If the pressure is larger than 30 kpa, an error is raised.

Arguments

```
g_VacuumOn1 \threshold;
```

\threshold

Data type: num

Expected upper limit of the vacuum pressure. Normally, the value should be within 0-110 kpa.

Program execution

The program will turn on the corresponding I/O signal. It will also read the vacuum pressure from the interior sensor and compare it with the given threshold. The vacuum has 1s to reach the expected pressure.

Error handling

If threshold is set but the reading value of the pressure sensor is larger than the threshold, an error is raised and the system variable ERRNO will be set to ERR_HAND_FAILEDVACUUM. The error can be handled in the error handler.

Syntax

```
g_VacuumOn1  
['\ ' threshold ':='] <expression (IN) of num> ';' ;
```

5.2.2.6 g_VacuumOff1 - Turn off vacuum channel 1

Usage

g_VacuumOff1 (replacing the original Hand_TurnOffVacuum1) is used to turn off the vacuum channel in hand pneumatic module 1.

Basic examples

```
g_VacuumOff1;
```

In this example, vacuum channel 1 will be turned off.

Program execution

The program will turn off the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_VacuumOff1 ' ';
```

5 RAPID references

5.2.2.7 g_VacuumOn2 - Turn on vacuum channel 2

5.2.2.7 g_VacuumOn2 - Turn on vacuum channel 2

Usage

g_VacuumOn2 (replacing the original Hand_TurnOnVacuum2) is used to turn is used to turn on the vacuum channel in hand pneumatic module 2. After turning on the vacuum channel, the vacuum pressure in the pneumatic module will also be verified with the given threshold. If there is no enough vacuum, an error is raised.

Basic examples

Example 1

```
g_VacuumOn2;
```

In this example, whether blowing channel 2 is turned on will be inspected first and then is closed if necessary. Then, vacuum channel 2 will be turned on.

Example 2

```
g_VacuumOn2 \threshold := 15;
```

After turning on the vacuum valve, the program will also read the vacuum pressure from the interior sensor. If the pressure is larger than 15 kpa, an error is raised.

Arguments

```
g_VacuumOn2 \threshold;
```

\threshold

Data type: num

Expected upper limit of the vacuum pressure. Normally, the value should be within 0-110 kpa.

Program execution

The program will turn on the corresponding I/O signal. It will also read the vacuum pressure from the interior sensor and compare it with the given threshold. The vacuum has 1s to reach the expected pressure.

Error handling

If threshold is set but the reading value of the pressure sensor is larger than the threshold, an error is raised and the system variable ERRNO will be set to ERR_HAND_FAILEDVACUUM. The error can be handled in the error handler.

Syntax

```
g_VacuumOn2  
['\ ' threshold ':='] <expression (IN) of num> ';' ;'
```

5.2.2.8 g_VacuumOff2 - Turn off vacuum channel 2

Usage

g_VacuumOff2 (replacing the original Hand_TurnOffVacuum2) is used to turn off the vacuum channel in hand pneumatic module 1.
is used to turn off the vacuum channel in hand pneumatic module 2.

Basic examples

```
g_VacuumOff2;
```

In this example, vacuum channel 2 will be turned off.

Program execution

The program will turn off the corresponding I/O signal. If there is no actual valve, this instruction has no meaning.

Syntax

```
g_VacuumOff2 ' ; '
```

5 RAPID references

5.3.1.1 g_IsCalibrated - Get gripper calibration status

5.3 Functions

5.3.1 RAPID functions for servo module

5.3.1.1 g_IsCalibrated - Get gripper calibration status

Usages

`g_IsCalibrated` (replacing the original `Hand_IsCalibrated`) is used to retrieve the calibration status of the gripper.

Basic examples

```
VAR bool isRightHandCalibrated;  
isRightHandCalibrated := g_IsCalibrated();
```

Returned value

Data type: `bool`

The function will return `TRUE` if the gripper has been calibrated, while `FALSE` if not calibrated.

Syntax

```
g_IsCalibrated '('  
  [ Value ':= ' ] <expression (IN) of num>  
' )'
```

5.3.1.2 g_GetPos - Get current gripper position

Usages

g_GetPos (replacing the original Hand_GetActualPos) is used to retrieve the current position of the gripper, based on the previous calibrated zero point. Note that this result may have no sense if the gripper is not calibrated.

Basic examples

```
VAR num nRightHandPos;  
nRightHandPos:= g_GetPos();
```

Returned value

Data type: num

The function will return the value of the current position in unit of mm.

Error handling

If the communication to the corresponding gripper fails, the error ERR_NORUNUNIT will be raised.

If the gripper has not been calibrated, the error ERR_NOTCALIBRATED will be raised.

Syntax

```
g_GetPos '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

5 RAPID references

5.3.1.3 g_GetSpd - Get current gripper speed

5.3.1.3 g_GetSpd - Get current gripper speed

Usages

g_GetSpd (replacing the original Hand_GetActualSpd) is used to retrieve the current speed of the gripper.

Basic examples

```
VAR num nRightHandSpd;  
nRightttHandSpd:= g_GetSpd();
```

Returned value

Data type: num

The function will return the value of the current speed in unit of mm/s.

Error handling

If the communication to the corresponding gripper fails, the error ERR_NORUNUNIT will be raised.

Syntax

```
g_GetSpd '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

5.3.1.4 g_GetState - Get current gripper status

Usages

g_GetState (replacing the original Hand_GetFingerState) is used to retrieve the current state of the gripper.

Basic examples

```
VAR num nRightHandState;
nRightHandState:= g_GetState();
```

Returned value

Data type: num

The function will return the value of the current state. The following table describes the gripper states.

Code	State	Description
0x0	Ready	The gripper is in free state and ready for receiving new commands.
0x1	Error	The gripper is in error state. Check what the error is based on the error ID. For details about the error IDs, see Error handling on page 143 .
0x2	Free_Move_Outward	The gripper is moving outward.
0x3	Free_Move_Inward	The gripper is moving inward.
0x4	Grip_Move_Inward	The gripper is moving inward and the movement stops only after the gripper reaches the target object or mechanical limit.
0x5	Grip_Move_Outward	The gripper is moving outward. The moving will stop only after the gripper reaches the target object or mechanical limit.
0x6	Action_Completed	The command is executed successfully.
0x7	Grip_Forcing_Inward	The gripper is adjusting its inward gripping force.
0x8	Grip_Forcing_Outward	The gripper is adjusting its outward gripping force.
0x9	Keep_Object	The gripper has completed the gripping operation and is holding the object.
0xA	Calibration	The gripper is under calibration.
0xB	Jog_Open	The gripper is jogged to move outward.
0xC	Jog_Close	The gripper is jogged to move inward.
0x10	Agile_Gripping_Inward	The gripper is moving inward with limited force (less than the assigned gripping force). The movement stops only after the gripper reaches the target object or mechanical limit.
0x11	Agile_Gripping_Outward	The gripper is moving outward with limited force (less than the assigned gripping force). The movement stops only after the gripper reaches the target object or mechanical limit.

Continues on next page

5 RAPID references

5.3.1.4 g_GetState - Get current gripper status

Continued

Error handling

If the communication to the corresponding gripper fails, the error ERR_NORUNUNIT will be raised.

Syntax

```
g_GetState '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

5.3.1.5 g_GetErrID - Get current gripper error ID

Usages

g_GetErrID (replacing the original Hand_GetFingerErrID) is used to retrieve the current error ID of the gripper. The error ID indicates the error type and designed to store the last error. Note that even if the gripper is recovered from an error state, the error ID does not reset automatically.

Basic examples

```
VAR num nRightHandLastError;
nRightHandLastError:= g_GetErrID();
```

Returned value

Data type: num

The function returns the value of current error ID.

Error handling

If the communication to the corresponding gripper fails, the error ERR_NORUNUNIT will be raised.

The following table provides some common hardware exceptions and related handling actions.

Error ID (HEX)	Error ID (BCD)	Description	Action
0x00	0	The system runs properly.	N/A
0x51	81	A wrong Hall sensor feedback is found in clockwise movement.	Check the connection between the Hall sensor output of the motor and the main board.
0x52	82	A wrong Hall sensor feedback is found in counter-clockwise movement.	Check the connection between the Hall sensor output of the motor and the main board.
0x58	88	There is an unexpected Hall sensor reading.	- Check the motor cable connection. - Check the motor or PCB.
0x63	99	The gripper is not calibrated.	Calibrate the gripper and try again.
0x64	100	The gripper is blocked.	Check whether there is anything blocking the gripper.
0x65	101	The object grasped by the gripper drops.	Increase the gripping force.
0xF0	240	The internal voltage is abnormal.	- Check the power supply of the gripper. - Check the MPB.
0xF1	241	The CPU temperature is over-high.	- Check the cooling system. - Check the MPB.

Continues on next page

5 RAPID references

5.3.1.5 g_GetErrID - Get current gripper error ID

Continued

Error ID (HEX)	Error ID (BCD)	Description	Action
0xF2	242	The DC bus voltage is abnormal.	Check the power supply of the gripper.
0xF3	243	The DC bus current is too large.	Check the power supply of the gripper.

Syntax

```
g_GetErrID '('  
  [ Value ':' '=' ] <expression (IN) of num>  
  ')'
```

5.3.2 RAPID functions for pneumatic module

5.3.2.1 g_GetPressure1 - Get vacuum pressure 1

Usages

g_GetPressure1 (replacing the original Hand_GetVacuumPressure1) is used to retrieve the current vacuum pressure of pneumatic module 1. If the value 0 is returned, it means that no corresponding pneumatic module is included for this gripper or means there is no successful communication to the pressure sensor.

Basic examples

```
VAR num nRightHandPressure1;  
nRightHandPressure1:= g_GetPressure1();
```

Returned value

Data type: num

The function will return the value of that sensor in unit of kpa.

Error handling

If the communication to the corresponding gripper fails, the error ERR_NORUNUNIT will be raised.

Syntax

```
g_GetPressure1 '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

5 RAPID references

5.3.2.2 g_GetPressure2 - Get vacuum pressure 2

5.3.2.2 g_GetPressure2 - Get vacuum pressure 2

Usages

g_GetPressure2 (replacing the original Hand_GetVacuumPressure2) is used to retrieve the current vacuum pressure of pneumatic module 2. If the value 0 is returned, it means that no corresponding pneumatic module is included for this gripper or means there is no successful communication to the pressure sensor.

Basic examples

```
VAR num nRightHandPressure2;  
nRightHandPressure2:= g_GetPressure2();
```

Returned value

Data type: num

The function will return the value of that sensor in unit of kpa.

Error handling

If the communication to the corresponding gripper fails, the error ERR_NORUNUNIT will be raised.

Syntax

```
g_GetPressure2 '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

5.3.3 RAPID functions for camera module

5.3.3.1 g_IsCamOnline - Get handheld camera connection status

Usages

g_IsCamOnline (replacing the original Hand_IsCamConnected) is used to retrieve the connection status of the handheld camera.

Basic examples

```
VAR bool isRighthCamConnected;  
isRightCamConnected:= g_IsCamOnline();
```

Returned value

Data type: bool

The function will return the connection status of the handheld camera. The value TRUE is for connected, while FALSE for unconnected.

Error handling

If the communication to the corresponding gripper fails, the error ERR_NORUNUNIT will be raised.

Syntax

```
g_IsCamOnline '('  
  [ Value ':= ' ] <expression (IN) of num>  
  ')'
```

This page is intentionally left blank

6 Decommissioning


6.1 Environmental information

Introduction

ABB robots contain components in different materials. During decommissioning, all materials shall be dismantled, recycled, or reused responsibly, according to the relevant laws and industrial standards. Robots or parts that can be reused or upcycled helps to reduce the usage of natural resources.

Disposal symbol

The following symbol indicates that the product must not be disposed of as common garbage. Handle each product according to local regulations for the respective content (see table below).



xx1800000058

Materials used in the product

The table specifies some of the materials in the product and their respective use throughout the product.

Dispose components properly according to local regulations to prevent health or environmental hazards.

Material	Example application
Aluminium	Other parts
Copper	Cables and motor
Magnesium	Base plate
Oil, grease	Linear guide, pinion and rack
Plastic/rubber	Cables, connectors, fingers, shell and vacuum units
Steel	Slide plates

Oil and grease

Where possible, arrange for oil and grease to be recycled. Dispose of via an authorized person/contractor in accordance with local regulations. Do not dispose

Continues on next page

6 Decommissioning

6.1 Environmental information

Continued

of oil and grease near lakes, ponds, ditches, down drains, or onto soil. Incineration must be carried out under controlled conditions in accordance with local regulations.

Also note that:

- Spills can form a film on water surfaces causing damage to organisms. Oxygen transfer could also be impaired.
- Spillage can penetrate the soil causing ground water contamination.

7 Reference information

7.1 Introduction

General

This chapter includes general information, complementing the more specific information in the different procedures in the manual.

7 Reference information

7.2 Unit conversion

7.2 Unit conversion

Converter table

Use the following table to convert units used in this manual.

Quantity	Units		
Length	1 m	3.28 ft.	39.37 in
Weight	1 kg	2.21 lb.	
Weight	1 g	0.035 ounces	
Pressure	1 bar	100 kPa	14.5 psi
Force	1 N	0.225 lbf	
Moment	1 Nm	0.738 lbf-ft	
Volume	1 L	0.264 US gal	

7.3 Standard toolkit

General

All service (repairs, maintenance, and installation) procedures contains lists of tools required to perform the specified activity.

All special tools required are listed directly in the procedures while all the tools that are considered standard are gathered in the standard toolkit and defined in the following table.

This way, the tools required are the sum of the standard toolkit and any tools listed in the instruction.

Contents, standard toolkit

Qty	Tool	Rem.
1	Slot screwdriver for M1.2	
1	Socket head cap screwdriver for M1.6	
1	Socket head cap screwdriver for M2	
1	Socket head cap screwdriver for M2.5	
1	Plus screwdriver M2	
1	Torx screwdriver M2	
1	Tweezer	

This page is intentionally left blank

8 Spare parts

8.1 Introduction

General

This chapter include spare part lists and spare part illustrations for the IRB 14050 gripper and all its variants.

Spare part level

ABB spare parts are categorized into three levels, L1, L2 and L3. Always check the part level before conducting a service work on a spare part.

- **L1 spare parts**

The L1 parts can be replaced in the field. The maintenance and replacement instructions given in the related product manuals must be strictly followed. If there are any problems, contact your local ABB for support.

- **L2 spare parts**

To replace the L2 parts require specialized training and might need special tools. Only ABB field service personnel or qualified personnel trained by ABB can replace L2 parts.

- **L3 spare parts**

L3 spare parts shall only be replaced or repaired by qualified ABB service technician with knowledge of the application due to reduce risk of injury or damage to equipment. Improper installation may void warranty.


8 Spare parts

8.2.1 Parts

8.2 Spare part lists and illustrations

8.2.1 Parts

Spare part list and exploded view for servo with vacuum and vision



xx1500000640

Pos	Article number	Description	Spare part level	Qty
A	3HAC051608-001	Main PCB	L1	1
B	3HAC063220-001	O-ring 4x2	L1	1
C	3HAB3772-175	O-ring 1.8x1.8	L1	1
D	3HAC051610-002	FFC for pneumatic block connector board	L1	1
E	3HAC051609-001	Pneumatic block connector board	L1	1

Continues on next page


Pos	Article number	Description	Spare part level	Qty
F	3HAC047823-001	Vacuum sensor	L1	1
G	3HAC054989-001	Pneumatic block	L1	1
H	3HAC051676-001	Camera AE3	L1	1
J	3HAC047854-001	Vacuum filter	L1	2
K	3HAC047927-001	Vacuum rubber cup	L1	2
L	3HAC054157-002	FFC for camera	L1	1
M	3HAC054988-001	Servo base	L1	1
N	3HAC051700-001	Hex socket head cap screw (M2x7)	L1	8
P	3HAC052976-001	Fingers  Note Gripper fingers are wear parts.	L1	1
Q	3HAB3772-173	O-ring 7x1	L1	1
R	3HAC054986-001	Shell complete (with camera window)	L1	1

8 Spare parts

8.2.1 Parts

Continued

Spare part list and exploded view for servo with vacuum1 and vacuum2



xx1500000641

Pos	Article number	Description	Spare part level	Qty
A	3HAC051608-001	Main PCB	L1	1
B	3HAB3772-175	O-ring 1.8x1.8	L1	1
C	3HAC052976-001	Fingers	L1	1
		 Note Gripper fingers are wear parts.		
D	3HAC047823-001	Vacuum sensor	L1	2
E	3HAC054989-001	Pneumatic block	L1	1

Continues on next page

Pos	Article number	Description	Spare part level	Qty
F	3HAC051610-002	FFC for pneumatic block connector board	L1	2
G	3HAC054988-001	Servo base	L1	1
H	3HAB3772-173	O-ring 7x1	L1	1
K	3HAC054990-001	Pneumatic block	L1	1
J	3HAC051609-001	Pneumatic block connector board	L1	2
L	3HAC054987-001	Shell complete (without camera window)	L1	1
M	3HAC047854-001	Vacuum filter	L1	2
N	3HAC047927-001	Vacuum rubber cup	L1	2

This page is intentionally left blank

Index

A

air consumption, 22
aluminum
 disposal, 149
ambient humidity
 operation, 18
 storage, 18
ambient temperature
 operation, 18
 storage, 18

C

copper
 disposal, 149

E

environmental information, 149

G

g_BlowOff1, 131
g_BlowOff2, 133
g_BlowOn1, 130
g_BlowOn2, 132
g_Calibrate, 127
g_GetErrID, 143
g_GetPos, 139
g_GetPressure1, 145
g_GetPressure2, 146
g_GetSpd, 140
g_GetState, 141
g_GripIn, 121
g_GripOut, 124
g_Init, 115
g_IsCalibrated, 138
g_IsCamOnline, 147
g_JogIn, 117
g_JogOut, 118
g_MoveTo, 119
g_SetMaxSpd, 129
g_Stop, 128
g_VacuumOff1, 135
g_VacuumOff2, 137
g_VacuumOn1, 134
g_VacuumOn2, 136
grease

disposal, 149

H

hazardous material, 149
humidity
 operation, 18
 storage, 18

M

magnesium
 disposal, 149

O

oil
 disposal, 149

P

plastic
 disposal, 149
pneumatic module
 air consumption, 22
protection classes, 18
protection type, 18

R

RAPID function, 138–141, 143, 145–147
RAPID instruction, 115, 117–119, 121, 124, 127–137
recycling, 149
robot
 protection class, 18
 protection types, 18
rubber
 disposal, 149

S

safety
 introduction, 11
steel
 disposal, 149
storage conditions, 18

T

temperatures
 operation, 18
 storage, 18

U

upcycling, 149



ABB Robotics Sweden AB
S-721 71 VÄSTERÅS, Sweden
Telephone +46 10-732 50 00

ABB Robotics Norway AS
Nordlysvegen 7, N-4340 BRYNE, Norway
Box 265, N-4349 BRYNE, Norway
Telephone: +47 22 87 2000

ABB Robotics (Shanghai) Limited
No. 39, 99 Miaoqiao Road,
Pudong New Area,
Shanghai, 201315, China
Telephone: +86 21 6105 6666

ABB Robotics LLC
1250 Brown Road
Auburn Hills, MI 48326
USA
Telephone: +1 248 391 9000

abb.com/robotics