## **SEPARATOR**

### **MRPX 318TGV-44C**



In letters, telegrams, telex messages and calls, please state type and manufacturing No. of the machine.

Product No.: 4260-23

(SG4260-02:01)

Reg. 33436

**Book No.:** 

SV4260-23:01E

1/9306

ALFA-LAVAL SEPARATION AB - S-147 80 TUMBA - SWEDEN

AIFA & LAVAL (OID). water 1800 300 Rod. 300 CIPLW CIPIL 600 180C Stop 60 DISLK WFSH -DS 60 3 IN-DLY V6-PROD 20 Ub-DRN 20 V7 - PROD 20 V7 - DRN 20

(5/5/7)

(New)


Water  $\bigcirc$ 240 PROD 300 CIPW 600 CIPLL 1800 STOP DISILK 60 WFSH-DS 180 IN-DLY V6-PROD 3 300 V6-DRN 5 47 - PROD. 300 V7 - DRN

11:19

30/29/94

AL SEP AB CUSTOMER SERVICE AVI

992




BEFORE USE

TOOL SHOULD BE PUMPED AS ABOVE

STORAGE OF TOOL

TOOL SHOULD BE STORED STANDING UP-RIGHT IN BOX





)


|                | Supplier    |         | SattControl, Malmo, Sweden | Demense Eng. Supplies, Dublin, Ireland | F.E.C. (Irl) Ltd., Dublin, Ireland | Demense Eng. Supplies, Dublin, Ireland | A.P. Haslam Ltd, Dublin, Ireland | A.P. Hestem Ltd, Dublin, Ireland | F.E.C. (Irl) Ltd., Dublin, Ireland | A.P. Hoslom Ltd, Dublin Ireland | Demense Eng. Supplies, Dublin, Ineland | A.P. Haslam Ltd, Dublin Ireland | Demense Eng. Supplies, Dublin, Ireland | Alfa-Lavel Separation, Tumba, Sweden | Cabawa Calaba        |                        | SattControl, Malmo, Sweden | Esta, Klimeade, Attu, Co. Nilaare |   |         |  |                          | 5            | מי                           | Charles of the control of the contro |
|----------------|-------------|---------|----------------------------|--|------------------------------------|--|----------------------------------|----------------------------------|------------------------------------|---------------------------------|--|---------------------------------|--|--------------------------------------|----------------------|------------------------|----------------------------|-----------------------------------|---|---------|--|--------------------------|--------------|------------------------------|--|
| EQUIPMENT LIST | Part Number | 233-781 | SCOP455B / 492-7055-02     | Zurc, 8-188%, 1A F.S.D.                | 188-758                            |  | SAK25mm                          | Sursum, 10A, 380Y, 2 Pole        | 179-878                            | Sursum, 6A,2A,4A, 380V, 2 Pole  | Metal Clad RCD 13A Socket              | Klippon ASK1                    | IN 1AA C4X2 OAP                        | 558-587-01                           | 40.0339.004.W.000001 |                        | SD24RS / 492-6211-82       | 688nnX888nnX218nn                 |   |         |  | EXPRESS FOODS MAGHERALIN |              | Separator ( $1 \times TGV$ ) | Tue of the Circuit Drawing   |
| PANEL EQUIPA   | Description |         | Electronic Beacon (New)    |  | 24Vdc Supply, 2Amp regulated       | 248Vac/48Vac Supply 588VA              | Terminals, DIN nail              | Main MCB, MCB1                   | Surge Suppressor                   | MCB 2-4                         | 220Vac, 3 pin/square) Sacket           | Control Fuses                   | Current Relaus                         | Toe!                                 |                      | V0 bus cable + bracket | I/O Unit                   | Stainless Steel Enclosure         |   |         |  |                          |              |                              |  |
|                | Oventity    | •       | → •                        | • •                                    |                                    |  |                                  |                                  |                                    | m                               | <b>~</b>                               | on.                             |  |                                      |                      |                        | 7                          | 2                                 |   | <br>~~~ |  |                          |              |                              |  |
| -              | Item        | ,       | <b>-</b> (1                | <b>ا</b> ر                             | , 32                               | TRAFO                                  | TERMS                            | MCB1                             | SP                                 | MCB2-4                          | Θ                                      | F1-13                           | η 4-90<br>Π 4-90                       | 1 5                                  | i<br>i               | 4-                     | ın                         |                                   | • |         |  | Date and sett.           | <del> </del> |                              | المستدين   |


| EXPRESS FOODS  Separator ( 1 × TG  Separator ( 1 × TG   |  | Preumatic Regulators AR2       | Quentity Description | PANEL EQUIPMENT LIST |
|---|--|--------------------------------|----------------------|----------------------|
| EXPRESS  A B Circuit  |  | AR:                            |                      | QUIPMENT             |
|   |  | AR2000-02BG SMC                | Part Number          | LIST                 |
| FOODS MAGHERALIN  18 Cont on start  1 × TCV )  2 × TCV    3 × TCV    4 × TCV    4 × TCV    6 × TCV    7 × TCV |  | Holl and Pyke, Dublin, Instand | Supplier             |                      |


.,,


























# INSTRUCTION BOOK

Upgracle

SEPARATOR

MRPX 318TGV-44C

A Alfa Laval

|                                | General information         | •   | A |
|--------------------------------|-----------------------------|-----|---|
|                                | Technical information       |     | В |
|                                | Data                        |     | С |
| PART 1                         | Installation                | 8   | G |
|                                | Lubrication                 |     | Н |
|                                | Operation                   |     | Κ |
|                                | Cleaning. Maintenance       |     | L |
|                                | Set of tools. Set of spares | oʻʻ | F |
|                                | Inlet. Bowl (Drum). Outlet  |     |   |
|                                | Power transmission          |     | Р |
| PART 2  Parts list Dismantling | Mounting the motor          |     | R |
| Assembly                       | Frame parts                 |     | S |
|                                | Accessories                 |     | X |

Supplement

ALFA-LAVAL

#### INTRODUCTION

Correct installation, suitable treatment of the liquid before and after processing in the machine, correct servicing and handling of the machine according to the directions given in this book, cleanliness, carefulness and methodical overhaul are essential to achieve best machine functioning and wanted results.

In all centrifugal separators the bowl is running at high speed, and thus great forces are generated. It is necessary, therefore, to study the instruction book carefully and to follow strictly all safety regulations.

Observe that, as a rule, the book contains no safety stipulations which are commanded by special properties of the process liquid, e.g. inflammability, toxicity, corrosiveness.

The instruction book is intended for the machine whose manufacturing number is stamped on the title page of the book. The instructions, which are given under the assumption that no reconstructions or alterations have been made without manufacturer's knowledge, shall not imply any obligations on the part of the manufacturer beyond those stipulated in the delivery agreement.

The manufacturer reserves the right to make changes in design or add any improvements on its products without any obligations to provide notice thereof or to install same on units previously delivered by it.

# △ SAFETY PRECAUTIONS FOR CENTRIFUGAL SEPARATORS △



The bowl of a centrifugal separator rotates at a very high speed and great forces are generated.

To ensure your own safety, always carefully follow the instruction book(s) concerning installation, assembly of the components, operation and regular maintenance.

Always use Alfa-Laval spare parts and tools supplied with the machine.

#### **OPERATION**




Never start the machine before the lock rings of the bowl inlet, outlet and other fastenings have been securely tightened. Note that the assembly marks Q (arrowed) must be aligned or pass each other (due to thread wear) when the lock ring is fully tightened.

#### MAINTENANCE




Never heat the bowl body, bowl hood or lock ring with a naked flame.


Never carry out any welding work on the components that rotate.




If excessive vibration occurs, IMME-DIATELY fill and keep the bowl full of liquid whilst stopping. Switch off and apply brakes, if fitted. After the bowl has stopped; dismantle, clean and check all parts carefully.



Never operate the machine when the Ø assembly mark on the lock ring can pass the corresponding mark on bowl body/bowl hood by more than 25 degrees. Consult your AL representative.



Never loosen any part of the machine until the bowl has completely stopped.




Check at regular intervals for damage due to corrosion and/or erosion. If in doubt, consult your AL representative.

- Switch off and disconnect the power supply to the machine before starting any dismantling work.
- Never use the machine for separating a liquid that is more corrosive or has a higher density, temperature, different characteristics of the solids, etc. than that for which the machine has been purchased.

In case of doubt, consult your AL representative.

- A separator bowl is balanced as a complete unit. Do not interchange the components of a bowl with those of any other machine, even if it is the same type. Make sure that no parts are left out at assembly.
- Follow the safety instructions concerning inflammable, toxic or corrosive process media and cleaning agents. Affix information and warning notices in prominent places.

S 95300E





### GENERAL DEFINITIONS

Throughput This means the quantity of liquid supplied per unit

time. The throughput is given in m<sup>3</sup>/h or 1/h.

Solids ejection Emptying of the bowl during operation by uncovering

and closing slots in the bowl wall.

Total ejection Total emptying of the bowl with the feed (as a rule)

turned off.

Partial ejection Total or partial emptying of the solids space in the

bowl but without emptying the rest of the bowl. The


feed need not be interrupted.

Combined A combination of total and partial ejections in succes-

programme sion.



SLUDGE DISCHARGE



Total or partial discharge


The sludge discharge takes place through a number of sludge ports in the bowl wall. Between discharges theses ports are closed by a large valve slide (a), the sliding bowl bottom, which constitutes an inner, sliding bottom in the reparating space. The sliding bowl bottom is forced upwards against a seal ring (b) by the liquid pressure acting on its underside. During rotation, this pressure increases with the distance from the axis of rotation because of the centrifugal force. The operating liquid exerts an upward pressure exceeding the counter-acting downward pressure from the process liquid, because the underside of the sliding bowl bottom has a larger pressure surface (radius R<sub>1</sub>) than its upper side (radius R<sub>2</sub>).

Operating liquid is supplied on the underside of the bowl through a paring disc device. Leakage or evaporation of operating liquid is made up for automatically by the paring disc, which maintains a constant horizontal operating liquid level (radius R3), as its pumping effect neutralizes the static pressure from the supply.


This feed of operating liquid which is of inferior size (low-pressure liquid) is going on also during the discharge cycle shown in the following illustrations but has not been indicated in the latter, as it is of minor effect in this connection.

B

(Sludge Discharge, page 2)




Operating liquid (high-pressure liquid) is now supplied in such quantites that it flows over the lower edge of the paring chamber (radius R4) and continues through a channel out to the space above an operating slide (c). Between discharges the operating slide is pressed upwards by coil springs. It is now forced downwards by the liquid pressure, thereby opening discharge valves (d) from the space below the sliding bowl bottom so that the operating liquid in this space flows out.




When the pressure exerted by the operating liquid against the underside of the sliding bowl bottom diminishes, the latter is forced downwards and opens so that the sludge is ejected from the bowl through the sludge ports in the bowl wall. The operating liquid on the upper side of the operating slide flows out through a nozzle (g). This nozzle is always open but so small that the outflow is negligible in view of the rapid inflow shown in the foregoing illustration.

B


(Sludge Discharge, page 3)



The coil springs force the operating slide (c) upwards again, which closes the discharge valves (d) from the space below the sliding bowl bottom (a). Operating liquid (low-pressure liquid) is supplied, flows to the space below the sliding bowl bottom (a) and forces the latter upwards so that the bowl is closed.



The paring disc device now counterbalances the static pressure from the operating liquid supply. The situation is identical with that shown in the first illustration of the series but for the difference that the sludge discharge cycle is now accomplished.



The paring disc has for its object to discharge the liquid under pressure.

The liquid rotates, driven by the rotating paring chamber, in the form of a ring around the stationary paring disc. This dips radially, to a greater or smaller depth, into the rotating liquid ring, which exerts a pressure rising rapidly with increasing diameter. The pressure produced by the paring disc is composed partly of the "centrifugal pressure" prevailing at the periphery, partly of the kinetic energy of the rotating liquid ring which is converted more or less completely into pressure energy.

When the throughput is small and there is no back pressure in the discharge line, the inner diameter of the liquid ring will practically equal the outer diameter of the paring disc. If the liquid must overcome a back pressure, such as a high delivery head or presssure-absorbing apparatuses, the diameter of the liquid ring in the paring chamber will diminish until the back pressure is neutralized. Thus the paring disc will pump out all liquid fed to the paring chamber (nothwithstanding the back pressure) up to the highest pressure the paring disc can produce at this liquid quantity.



#### DATA

Supplementary particulars (such as weight data) are contained in the technical information supplied in connection with the purchase of the machine.

Abbreviations

h = hour

r.p.m. = revolutions per minute

c/s = Hz = cycles per second

Ø = diameter

SAE-class = indication of oil viscosity according to Society of Automotive Engineers, USA

SSU = Saybolt Seconds Universal: indication of oil viscosity

<sup>o</sup>E = degree Engler: indication of oil viscosity

EP = Extreme Pressure: lubricants made capable of resisting high contact pressures through admixture of additives.

ASTM = American Society for Testing Materials.

NLGI-classes = classification of lubricating grease by means of penetration after processing according to National Lubricating Grease Institute, USA.

ISO = standards of processing according to International Organization for Standardizing.

Suitable motor power: 30 kW (40 HP); POWER REQUIREMENT

OBS. Special motor required.

Starting current: approx. 1.5 times the rated current. Working power (= motor output) at rated throughput:

approx. 25 kW.

SPEED

The prescribed speed of the worm wheel shaft, which must be strictly maintained, is stamped on the type plate of the machine.

The speed table refers to r.p.m.

| WORM WHEEL SHAFT   | 1420-1500 | 1700-1800 |
|--------------------|-----------|-----------|
| Drive (motor)      | 1420-1500 | 1700-1800 |
| Tachometer         | 1420-1500 | 1700-1800 |
| Revolution counter | 118-125   | 142-150   |

RUN-UP TIME (Time relay setting)

Approx. 15 minutes.

BRAKING TIME

Approx. 21 minutes.

WORM GEAR OIL

For oil type and quantity see chapter H.

RATED THROUGHPUT

For whey separation:  $20-25 \text{ m}^3/\text{h}$ .

BACK PRESSURE (at rated throughput) Suitable pressure (in whey outlet): 4.5 - 5 bar.

Overflow pressure: approx. 5.5 bar.

INTERVAL between SOLIDS EJECTIONS

For whey separation: approx. 15 minutes.

CREAM FLOW METER

Approximate flow through the flow meter at the various


graduations - see Flow meter, chapter X.

OPERATING LIQUID

Operating liquid system and pressure — see chapter G.

COOLING COIL for

Water quantity and temperature - see chapter G. OIL BATH





INSTALLATION

This chapter deals with the mounting of the machine and with the actions to be taken before the first start. The ALFA-LAVAL representative is always glad to provide further advice and information.

DIMENSIONED DRAWING All measurements needed for the installation are given in the dimensioned drawing, the reference numbers of which are explained below. (The table applies to several types of separator and thus comprises more reference numbers than are found in the drawing.)

| 1   | Feed                             | 40         | Inlet                           | 80  | Condensation wat   | er            |
|-----|----------------------------------|------------|---------------------------------|-----|--|---------------|
| 2   | From heater                      | 41         | Outlet                          | 81  | Interface control  |               |
|     | To heater                        | 42         | Concentrate                     | 82  | Pump for feed and  | discharge     |
| 3   |                                  | 43         | Operating liquid                | 83  | Discharge pump   |               |
| 4   | Light effluent                   | 44         | Ventilation                     | 84  | Three-way valve  |               |
| 5   | Heavy effluent                   | 45         | Air or other gas (except steam) | 85  | Plate heat exchar  | nger          |
| 6   | Solid effluent                   | 46         | Waste liquid                    | 86  | Skimmilk   | - T           |
| 7   | Overflow liquid                  | 47         | Constant pressure valve         | 87  | Whey   |               |
| 8   | Drain                            | 48         | Flow meter                      | 88  | Bowl emptying  |               |
| 9   | Auxiliary liquid for liquid seal | 49         | Shut-off valve                  | 89  |  |               |
|     |                                  | <b>T</b> 7 | Bildt-Oil valve                 |     |  |               |
|     |                                  |            | ner Th                          |     |  |               |
|     |                                  |            |                                 |     |  | - 1 to 1 to 1 |
|     |                                  |            |                                 |     |  |               |
|     |                                  |            |                                 |     |  |               |
|     | A                                | 50         | Control valve                   | 90  | Nozzle flow  |               |
| 10  | Auxiliary liquid for liquid seal | 51         | Flow indicator                  | 91  | Flow-control valv  | /e            |
| 11  | Auxiliary liquid                 | 52         | Sight glass                     | 92  | The same of the sa |               |
| 12  | Flushing liquid                  |            | Electric connection             |     | Barrier liquid   |               |
| 13  | Self-emptying                    | 53         | Brake handle                    | 94  | •  |               |
| 14  | Air or other gas (except steam)  | 54         |                                 | 95  |  | or            |
| 15  | Operating liquid                 | 55         | Revolution counter              | 96  |  | •             |
| 16  | Operating liquid                 | 56         | Oil filling screw               | 97  | Fixed throttling   |               |
| 17  | Cooling air                      | 57         | Oil gauge glass                 | 98  | Pilot liquid   |               |
| 18  | Cooling air                      | .58        | Oil drain screw                 | 99  |  |               |
| 19  | Ventilation                      | 59         | Waste liquid                    | 77  | Indicator gas  |               |
|     |                                  |            |                                 |     |  |               |
|     |                                  |            |                                 |     |  |               |
|     |                                  |            |                                 |     |  |               |
|     |                                  |            |                                 |     |  |               |
|     |                                  |            |                                 | 100 | Cooling liquid   |               |
| 20  | Ventilation                      | 60         | Shut-off valve                  | 100 | <u> </u>   |               |
| 21  | Return flow                      | 61         | Feed pump                       | 101 | Compressed air   |               |
| 22  | Electric connection              | 62         | Strainer                        | 102 | Vibration switch   |               |
| 23  | Effluent                         | 63         | Light liquid feed               | 103 |  |               |
| 24  | Raw material                     | 64         | Heavy liquid feed               |     | Protective gas   |               |
| 25  | Treated raw material             | 65         | Light effluent                  | 105 | Protective gas   |               |
| 26  | Steam                            | 66         | Heavy effluent                  |     |  |               |
| 27  | Waste liquid                     | 67         | Barrier liquid                  |     |  |               |
| 28  | Flushing liquid                  | 68         | Air or other gas (except steam) | )   |  |               |
| 29  | Reagent                          | 69         | Protective gas                  |     |  |               |
|     | -                                |            |                                 |     |  |               |
|     |                                  |            |                                 |     |  |               |
|     |                                  |            |                                 |     |  |               |
|     |                                  |            |                                 |     |  |               |
|     |                                  |            |                                 |     |  |               |
| 30  | Flushing liquid                  | 70         | Protective gas                  |     |  |               |
| 31  | Barrier liquid                   | 71         | Electric connection             |     |  |               |
| 2.2 | Darrier liquid                   | 72         |                                 |     |  |               |

72

73

74

75

76 77

78

Cream

Strainer

Thermometer

Sludge tank

Sludge pump

Softening filter

Steam preheater

Operating water tank

33

35

32 Barrier liquid

Barrier liquid

Barrier liquid

37 Air or other gas (except steam)


39 Outlet for bowl emptying


Waste liquid


Ventilation

Water feed

### ALFA-LAVAL








530148 (v.sid) (9.11.71)


ALFA-LAVAL


G




## G

## VIBRATION DAMPER (3) and FOUNDATION PLATE











Set screw (3)

Adjusting washer (6)



Foundation foot





INSTALLATION G

UNPACKING

When unpacking take care not to scratch metallic or painted surfaces.

Check by means of the packing list that all parts have been unpacked.

FOUNDATION

This must be plane, solid and vibrationless. The measurement to the nearest wall must not be smaller than the minimum stated in the dimensioned drawing. Make sure that pipes, pumps and other apparatuses are installed so as to be easily accessible for inspection.

FOUNDATION PLATE

The foundation plate of the machine must be embedded in a level and solid base. For measurements see dimensioned drawing.

Slip the caps over the foundation feet before embedding the plate in the base. Level out the plate properly.

ERECTION

Check that frame feet and rubber washers are attached to the frame. If they are loose, tighten the screws firmly, but not so much that the elasticity of the rubber washers is neutralized.


Lubricate the thread of the foundation feet. Screw down the holders until they rest rigidly against the foundation feet. Slip the protecting rings over the holders. Lift the frame, fit the frame feet carefully into the holders and lower the frame. Check the levelness of the frame by means of a spirit level placed on the outer frame rim. If the latter is horizontal, tighten the set screws of the holders and push up the protecting rings over the holders.

If the frame is not horizontal, lift it a trifle so that the holders can be screwed so as to compensate for the inclination. There will now be a gap between holder and frame foot, which must be filled with one or more washers, the frame must be lifted again and the holders unscrewed. LUBRICATION

Pour oil into worm gear housing - see chapter H.



INLET. BOWL OUTLET



See chapter I.

The bowl is assembled but not mounted when delivered. It will be necessary to dismantle the bowl and to check, lubricate and reassemble it in the machine.

Make sure the O-rings are fitted (in some cases they are packed separately in the pack box).




Place bowl parts on a soft base, such as wood or rubber. Be special careful of the seal ring in the lower edge of the bowl hood.

HEIGHT ADJUSTMENT

Check as described in chapter L.

MOTOR MOUNTING

See chapter R.





CONNECTION TO MAINS

Connect the motor to mains so that the bowl will rotate CLOCKWISE. For machine with fixed coupling — see special wiring diagram.



The machine must never be started unless the bowl is placed on the spindle and the worm gear housing contains lubricating oil in the precribed quantity and of the proper quality. If the machine is to be run up to full speed the covers must, besides, be fastened.





The machine has rigid coupling and is, therefore, equipped with a special motor provided with built-in thermocontacts (e l) or thermistors (f l), which are to be connected to the control circuit of the starter according to the above diagram. When thermistors are provided, they must be combined with a special tripping device (u l). If connected in the same way as the thermocontacts, the thermistors will burn out.


The motor must not be started direct but via an Y/D starter and should be Y-connected throughout the running-up time.


The time relay in the starter (for changing over from Y to D) should be set in the first place to the value stated in chapter C. In case of voltage variations (running-up time changes) it may become necessary to reset the time relay.

The overload protector in the starter is connected to the D-circuit. During running-up (with motor Y-connected) the protector is non-operative.

Due to the great heat generation during running-up the thermal protectors will normally cut out the current when more than two subsequent (and accomplished) starts are performed. Prior to a third start the motor should, therefore, be left to rest for an hour.

### COOLING COIL for LUBRICATING OIL BATH






In order to bring down the oil temperature, a cooling coil is installed in the worm gear housing.

The distribution arrangement for the cooling water can be solved in a number of ways depending on the existing facilities.

- The feed flow should be measured on the outlet portion.
- If a throttling arrangement is necessary to maintain given feed data, that should be installed before the inlet.
- Ensure that there is an apparent flow of cooling water through the cooling coil by making frequent checks on the outlet during both the running-up and processing periods.

FLOW CHART; programmed operation



\*) In MRPX 418SGV-34C (for bactofugation) = treated liquid

1231080

(Flow chart, page 2)

For parts incorporated in the discharge programme equipment (control equipment) see supplementary instruction book. Observe that this equipment may differ from the disclosure of the diagram.

A general programme for the discharges during separation as well as for those during cleaning appears from chapter K.

Legend

- 1 Timing unit (control unit). To be placed in electric centre or other suitable place.
- 2 Transformer
- 3 Switches, signal lamps etc. mounted in a panel near the machine (for remote control).
- 4\* Opening liquid total discharge. Flushing liquid to sludge cover. Pressure: approx. 2.6 bar; 37 psi (= the pressure indicated by the pressure gauge during the opening time of the solenoid valve item V I).
- 5\* Opening and closing liquid partial discharge. Pressure: approx. 1.8 bar; 26 psi (= the pressure indicated by the pressure gauge during the opening time of the solenoid valve item V II). This gives a discharge quantity of 15-20 lit (3.3-4.4 UK gal).

Note The size of the liquid flow and thus the degree of partial discharge can be regulated by means of the pressure regulator item 9.

- 6 Make-up liquid during operation. Closing liquid when starting and after a total discharge. Pressure: 0.15—0.25 bar: 2.2-3.6 psi.
- 7 Manual valve (shut-off valve, by-pass valve).
- 8 Pressure gauge
- 9 Pressure regulator
- 10 Strainer (filter)
- 11 Dehardening filter; not necessary when clean and soft water is used as operating liquid see also below
- 12 Non-return valve (check valve)
- V I up to and including V IV = Solenoid valves
- V T Feed pump
- V VIII Pneumatic valve. For suitable liquid and air pressure see instructions for the valve in question.
- \* Liquid consumption during a total scharge: opening liquid approx. 1.3 lit/sec. (0.28 UK gal/sec.) for about 4 seconds.

Consumption during a partial discharge: opening and closing liquid approx. 1.1 lit/sec. (0.24 UK gal/sec.) for about 1.5 second; flushing liquid to sludge cover approx 1.5 lit/sec. (0.33 UK gal/sec.) for about 25 seconds.

INSTALLATION G

(Flow chart ..., page 3)

Operating liquid system

This system should be placed near the machine (preferably in a box of stainless material) in order to avoid pressure losses and to facilitate any adjustment of the pressure. If the system is placed elsewhere remember to check that the pressures have the prescribed values near the machine.

Install the pipe for opening liquid — total discharge (V I) — so that it is in straight connection with the inlet pipe on the machine. A straight pipe gives a more distinct discharge. Place the by-pass valves, which are intended for use in an emergency, e.g. when the automatic system is out of operation, so that they are readily accessible.

Operating liquid

Clean; soft water can be used as operating liquid. Hard water involves a risk of lime deposits which can obstruct the channels in the operating liquid system with operation trouble as a result.

The demands upon the softness of the water increase with rising operation temperature, since lime is easier precipitated at higher temperatures.

Lime deposition can be prevented by adding a desoftening agent or by providing a dehardening filter in the operating liquid line.

REMOTE SPEED INDICATION

See chapter T.

INSTALLATION G

### **PIPINGS**

Fit the pipes and hoses so that the inlet and outlet connections of the machine are not subjected to strain. Tightweld (hard-solder) internal pipe ends in connection sleeves so as to avoid dirtcollecting pockets. This is particularly important in plants on which high hygienic demands are made, such as in food industry. Grind and polish all welding seams (hard-solderings) carefully.

All attachements should be made so as to allow variations in length and to prevent transmission of strains and vibrations.

Blow or flush out each section of the piping after mounting. Also flush out the whole pipe system after installation so that metallic ashes and other impurities are removed entirely and cannot get into the machine, pumps or other apparatuses.

### CHECKING

Examine the installation before putting the machine into service. Check particularly:

- o That the worm wheel shaft rotates at prescribed speed and that the bowl rotates clockwise
- o That the directions given under the heading BEFORE STARTING in chapter K have been observed.

#### CLEANING PLACE

A table, a stand or the like affording sufficient place for the bowl and the special tools for the latter should be provided, preferably in the immediate proximity of the machine.



#### LUBRICATION

It should be understood that the mentioning of certain brands as examples of a suitable lubricant does not involve an exclusion of other brands with equivalent properties.

The machine is delivered without oil in the worm gear housing. It must NOT be started unless oil in the quantity and of the quality prescribed has been supplied. A change of the separating temperature can make it necessary to replace the oil by oil of a different type.

Lubricants, oil as well as grease, must be kept in clean, closed cans to prevent penetration of dust and moisture and to reduce the oxidizing effect of the air as far as possible. The storing place should be dry and cool.


| _   | _ |
|-----|---|
|     |   |
| 4.1 |   |
|     |   |

| LUBRICATION POINT LUBRICANT WHEN                                | a a  |
|---|--|
|   |  |
| housing to 100°C; ambient temp. starting                        |  |
| SYNTHETIC OIL of then aft                                       | il exchange after<br>irs' operation,<br>ter every period<br>hours' operation.      |
|   | onal operation be-<br>ery operating  |
|   | g before exchange.   |
| approx. 13 lit. Oil leve of gaug                                | el in upper half<br>e glass.   |
|   | before putting<br>ol body on the   |
| slipping to avoid cate the                                      | sparsely to avoid y but sufficiently d seizing (lubrie tapered end be with a clean |
|   |  |
| Other machine Molybdenum disulfide grease or equivalent. Before | every mounting.  |
|   |  |
| Motor Follow motor supplier's recommendations. Follow           | motor supplier's mendations.   |
|   |  |
|   |  |
|   | 122140   |

S91011E (STL 7103-01) 1231695

Bow1


Before every assembly wipe clean the threads of lock rings, bowl body and bowl hood as well as the contact surfaces between these parts. If necessary, they should be cleaned with a clean cloth moistened with cleaning agent (see chapter L). After wiping, lubricate them according to one of the alternatives below.



### Alternative 1

When the bowl lock ring is made of stainless steel or monel metal and the bowl body and/or the bowl hood are of stainless steel, the lock ring carries the symbol shown in the adjoining drawing. The following lubrication procedure is recommended:

- 1. PRIMING with molybdenum disulfide paste. Rub or brush in the paste sparsely all over the surface follow the directions printed on the wrapping, if any. Always prime new parts as well as parts which have lost their previously applied primer due to e.g. thorough cleaning or machining.
- 2. LUBRICATION with molybdenum disulfide grease after priming, and before assembly after routine dismantling as well. Polyethylene-castor oil paste, polytetrafluoroethylene-castor oil paste or some other equivalent lubricant can be used for machines emploied in the food industry or where dark-coloured lubricants are unsuitable.



## Alternative 2


When the lock ring is made of carbon steel priming is normally unnecessary, lubrication alone will do — for lubricant see above.

If practical experience shows that no inconveniences occur, consistent grease, oil as prescribed for the worm gear housing, castor oil, tallow or liquid paraffin may be used as lubricant.

However, if a tendency to seizing is observed, alternative 1 must be applied.

(Lubrication Directions)


Bowl (cont.)



Lock ring

Lock ring

Bowl hood




All surfaces marked must be cleaned and lubricated before the parts are mounted. Such surfaces or parts indicated by are to be lubricated according to alternative 1 on the foregoing page, whereas those lacking such indication may be lubricated according to alternative 2.



SUPPLEMENT for BOWL BODY, BOWL HOOD and LARGE LOCK RING. NACHTRAG für TROMMELKÖRPER, TROMMELDECKEL und GROSSEN VERSCHLUSSRING.

SUPPLEMENT pour FOND DE BOL, CHAPEAU DE BOL et GRAND ANNEAU DE SERRAGE.

TILLÄGG för KULKROPP, KULHUV samt STOR LÅSRING.



Bowl body, bowl hood and large lock ring differ somewhat from the drawings on the foregoing pages. Their actual design and lubrication points are shown in the adjoining illustration, in which the lubrication points are indicated by arrows.

Trommelkörper, Trommeldeckel und grosser Verschlussring unterscheiden sich etwas von den Zeichnungen auf den vorstehenden Seiten. Wirkliche Form und Schmierstellen sind aus dem nebenstehenden Bild ersichtlich, in welcher die Schmierstellen durch Pfeile angegeben sind.

Le fond et le chapeau du bol de même que le grand anneau de serrage diffèrent un peu des illustrations des pages antérieures. Leurs formes réelles et leurs points à lubrifier sont montrés par l'illustration en marge, où les points à lubrifier sont indiqués par des flèches.

Kulkropp, kulhuv samt stor låsring skiljer sig något från figurerna på föregående sidor. Deras verkliga utseende samt smörjställen framgår av vidstående bild, där smörjställena angivits med pilar.



Lubricating oil for worm gear housing Synthetic polyglycol type oil with the following properties:

| The second secon |   |
|--|---|
| Viscosity at 100°C   | 20-25 cSt<br>(2,9-3,5°E)                                      |
| Viscosity at 0 °C  | maximum 2000 cSt<br>(260 <sup>o</sup> E)                      |
| Viscosity index  | minimum 140   |
| Pour point   | maximum -30°C   |
| Heat resistance  | must stand utilization<br>for at least 1000 hours<br>at 120°C |

Suitable oils (examples)

BP ENERGOL GRS 260 SHELL TIVELA OIL 75

Synthetic oils of this type are not miscible with mineral lubricating oils.

Molybdenum disulfide paste Examples:
Molykote Paste G
Rocol Anti-Scuffing Paste

Molybdenum disulfide grease Examples: Molykote BR-2 Molykote BR-3

Polyethylene-castor oil paste or polytetrafluoroethylene-castor oil paste is recommended for machines used in the food industry or where dark-coloured lubricants are unsuitable.

Ball bearing grease

Always use a high grade lithium-soap type ball bearing grease according to NLGI-class 2 or 3 and usable at temperatures above 100°C. Drop point about 180°C according to ASTM D 566-44.

Examples: BP Energrease 2 or 3, Caltex Starfak Premium Grease 2 or 3, Castrol Spheerol AP Grease 2 or 3, Esso Beacon Grease 2 or 3, Gulfcrown Grease 2 or 3, Mobilux Grease 2 or 3, Shell Alvania Grease 2 or 3.



## SAFETY REGULATIONS

In all centrifugal separators the bowl rotates at a very high speed, normally between 100 and 150 revolutions per SECOND. Thus, very great forces are released and it is essential, therefore, to follow strictly the directions given in the Instruction Book concerning assembly of parts, starting, stopping and overhaul.

In this connection remember particularly...

- ... to tighten the bowl lock ring (lock rings).
- ... to fasten carefully the frame hood as well as the inlet and outlet parts.
- ... to check the speed.
- ... that no machine part must be loosened until the bowl has stopped rotating.
- ... that bowl parts marked "\*" in chapter I must never be exchanged without subsequent rebalancing of the bowl.
- ... that bowl body, bowl hood and lock ring must never be heated by means of a flame.
- ... that the machine must never be used for processing liquids with a higher density (temperature, solids nature etc.) than that for which it was originally intended. Thus, always consult an ALFA-LAVAL representative before using the machine beyond its proper range of separation.

## Special recommendations

### CREAM SEPARATION

Cream flow meter

The scale of the cream flow meter is neither graduated in percent nor in volume per hour. Such a graduation would — since the deviation is influenced by the viscosity — only apply to a certain fat content and temperature. The accurate values for the fat content or the fat contents must be determined by tests. To ensure that the fat content of the cream remains constant, the output, the fat content of the milk and temperature should of course be almost constant.

Regulating the cream fat content

The cream quantity and thus the cream fat content depend on the pressure in both outlets.

To facilitate regulation, which is effected by means of the regulating valve of the cream flow meter, the pressure in the skim milk outlet should be kept as constant as possible.

Variations in cream percentage

If the resistance in the skim milk outlet changes, e.g. the skim milk is conveyed to a tank placed at a higher level, this will involve a change of the cream percentage, i.e. the cream will get thinner with increasing resistance in the skim milk pipe and vice versa. In such cases the pressure in the skim milk outlet must be restored to the original value (by means of the skim milk valve). If required, a final adjustment can be made by means of the cream regulating valve.

If the change in cream percentage is caused by resistance variations in the cream outlet, adjust by means of the cream regulating valve.

Sampling

For checking the clean skimming, draw a skim milk sample from the pipe next to machine. It may happen that samples which are taken out simultaneously at the machine and in the skim milk tank show a different fat content. This can be due to the fact that whole milk or cream has leaked into the skim milk somewhere after the machine.

MILK CLEANING

Cleaning of kettle milk or consumption milk involves the use of a remixing device — see chapter X — which makes it possible to return all the cream to the skim milk.


STANDARDIZATION

For standardization, i.e. when milk with a prescribed fat content is wanted, a device (see chapter X) is necessary that makes it possible to remix a suitable quantity of the cream with the skim milk while the rest of the cream is discharged separately.

Always check the fat content of the standardized milk.

Keep the throughput constant.

FLOW CHART; programmed operation



\*) In MRPX 418SGV-34C (for bactofugation) = treated liquid

1231080

PROGRAMME EQUIPMENT — see supplementary instruction book. Observe that this book is finally decisive for the details of the equipment, programme etc.

For machine equipped for REMOTE SPEED INDICATION— see chapter T.

BEFORE STARTING

The bowl must be well cleaned and assembled according to directions given in chapter I.


Check particularly: that the brake is released—that the frame hood and discharge cover are clamped with the hinged bolts—that the oil level in the worm gear housing reaches somewhat above the middle of the oil gauge glass\*—the operating liquid pressures—that the valves in the outlets are open.

\* Note

With idle machine the oil level must never be allowed to sink below the lower edge of the gauge glass; in operation the oil level will drop slightly.

If the glass is provided with corrugations they must be vertical. Keep the gauge glass clean, otherwise a line, which could be mistaken for the oil level, will in time build up on the inside of the glass.

If the machine has been idle for some time, screw out the drain screw some turns and drain off any water.



START and ACCEL-ERATION TIME Start the motor. Observe directions given in chapter G.

Shortly after starting it may occur that the bowl begins to vibrate more than normal. The general cause is lack of balance due to bad cleaning (washing). Stop the machine and clean the bowl by hand if the vibrations are very heavy.

During acceleration the power consumption is higher than in normal operation.

ALFA-LAVAL

operation **K** 

CLOSING the BOWL

The bowl is to be closed when it has attained full speed. Before starting the closing procedure compare the reading of the speed indicating means with the speed table in chapter C. The closing is performed by starting the timing unit (control unit), whereupon the solenoid valve V III will open and low pressure liquid (make-up liquid) is fed to the paring disc device of the bowl. The bowl will now close in 10-15 seconds.

If desired, the bowl can be closed (and be kept closed) by opening the by-pass valve in the low pressure liquid line.

When the timing unit (control unit) is started, also the pneumatic valve V VIII opens (provided it is of the pressure-opening type).

When the bowl has closed, supply water in the same quantites as one will later supply process liquid, and adjust to suitable back pressure in the outlet for heavy phase. Then adjust to suitable throughput in the flow meter. If this affects the back pressure in the heavy phase outlet, readjust according to the above.

Shift to process liquid. Observe that the throughput must be suited to the separability of the process liquid.

SLUDGE DISCHARGE during OPERATION

The time relay in the timing unit (control unit) intended for partial discharges during operation initiates the discharges cycle. Generally, the following programme is performed: Discharge and closing of the bowl (V II) and flushing of the sludge cover (V IV).

FILLING

CLEANING (CIP)

The bowl need not be dismantled after each operating period provided it can be cleaned satisfactorily by circulation washing before being stopped, i.e. by circulating various rinsing and cleaning liquids through the machine according to a fixed programme. During the various different washing stages the bowl must be emptied several times, either partially or totally—see below.

As the washing procedure can vary from case to case depending on the type of detergent, temperatures, and the sludge content in the process liquid, the washing programme cannot be determined in advance but must be found out through practical experiments in each particular case. A suitable sequence of the various stages appears from the following example of a programme, in which the indicated times can of course be shortened if considered suitable.

To save detergent, it may be preferable to execute only partial discharges during the washing stages proper, whereas only total discharges should, as a rule, be performed during the rinsing stages.

# Example:

- 1. Flushing with warm water, approx. 50°C (122°F), for 15 minutes with a total discharge every 3rd minute loose sludge is removed.
- 2. Washing with caustic soda, approx. 50°C (122°F), for 40 minutes with a partial discharge every 10th minute fat and proteins are removed.
- 3. Rinsing with warm water see paragraph 1.
- 4. Washing with acid solution, approx. 50°C (122°F), for 40 minutes with a partial discharge every 10th minute any milkstone is removed.
- 5.\*) Rinsing with cold water for 15 minutes with a total discharge every 3rd minute this also cools down the machine.
- \*) In some cases preceded by sterilization with hot water, about 90°C (194°F).

OPERATION K

(Cleaning, page 2) Total discharge

The time relay in the timing unit (control unit) intended for total discharges during the washing period (water) initiates the discharge cycle. Generally, the following programme is performed:

- 1. Flushing of frame hood inside and bowl outside V VIII): the liquid flow in the discharge pipe is throttled so that liquid overflows at the bowl top (paring chamber).
- -2. Water flow shut-off (V V); the pump stops.
- 3. Flushing according to point 1 ceases. 4. Discharge and closing of bowl (V I, VIII). 5 Water flow turned on (V V); the pump starts.

Partial discharge

The time relay intended for partial discharges during the washing period (acid - lye) initiates the discharge cycle. Generally, the following programme is performed:

1. Flushing of sludge cover (V IV). - 2. Flushing of frame hood inside and bowl outside (V VIII). - 3. Discharge and closing of bowl (V II). - 4. The flushing according to points 1 and 2 ceases.

In an emergency, e.g. when the automatic system fails,

the bowl can be discharged by opeaning the by-pass valve

MANUAL CLEANING

See chapter L.

MANUALLY OP-ERATED DISCHARGE

for the solenoid valve VII. After discharge close the valve. The bowl will now be closed automatically (and kept close) by the make-up liquid.

With the operating liquid pressures maintained unchanged (as in automatic operation) the above procedure will result in a partial discharge. If a total discharge is wanted, the pressure must be increased (with the pressure regulator item 9) to the recommended value. During discharge the bowl speed drops slightly. Do not repeat the discharge until correct speed is recovered.

Always shut off the feed to the bowl before a total discharge.

STOPPING



Keep the bowl closed and filled with liquid during the stopping period. This serves to prevent the bowl from getting out of balance in case residues of solids are still left in it.

:: Wait until the bowl has been filled with liquid after the last ejection. Stop the timing unit — the feed to the bowl is interrupted (the pump stops), valves V III and V VIII close.

:: Stop the motor, apply the brake and let the bowl run down to standstill. Release the brake (handle downward).

A small quantity of liquid will collect in the bottom of the bowl after the machine has stopped. To expel this liquid proceed as follows: Start the motor and let the bowl accelerate until the tachometer indicates about 10% of full speed — the liquid is now thrown out through the slots in the bowl body. Stop the motor and apply the brake. Release the brake when the bowl has stopped running.

Note. If the machine must be stopped temporarily during separation, it must at least be flushed out with water and emptied according to point 1 of the cleaning programme.

|   | 4 | 1 | 7 |
|---|---|---|---|
| ı | 1 | K |   |
|   |   | ч | A |
|   |   |   | ٠ |
|   |   |   |   |

| Indication          | Cause  | Remedy                                   |
|---------------------|--|--|
| Indication          |  |  |
| CREAM               |  |  |
| SEPARATION          |  | Find out a new cleaning programme.       |
| Fat content in skim | :: Cleaning programme is unsatisfactory                | Find out a new cleaning programmer       |
| milk abnormally     | (bowl badly cleaned). :: Extracted cream is too thick. | Open up the regulating valve of cream    |
| high.               | :: Extracted Cream is too mick.                        | flow meter.                              |
|                     | :: Unsuitable operating temperature.                   | The temperature should lie at approx.    |
|                     |  | 50-55°C (122-130°F).                     |
|                     | :: Sourish milk.                                       | Reduce throughput.                       |
|                     | :: Throughput too high.                                | Check that the pump is regulated on      |
|                     | :: Fat globules split.                                 | delivery side.                           |
|                     | :: Back pressure too low.                              | Suitable pressure - see chapter C.       |
|                     | :: Incorrect analysis.                                 |  |
|                     | :: Whole milk or cream has leaked in                   | Check any change-over connections and    |
|                     | after machine.   | the setting of the valves.               |
|                     |  |  |
|                     | Extracted cream is too thick.                          | Shut off the milk feed and shift to      |
| Cream blockage.     | Extracted cream is too tiles.                          | water. Readjust the cream flow meter.    |
|                     |  |  |
|                     |  |  |
| Cream too thin.     | [2017년 4] (등) 12 (2017년 <u>급</u> 합                     | Throttle with regulating valve of cream  |
|                     |  | flow meter.                              |
|                     |  |  |
| Cream too thick.    |  | Open up the regulating valve of cream    |
| Cream too mick.     |  | flow meter.                              |
|                     |  | Throttle the skim milk pipe if the regu- |
|                     |  | lating valve of the cream flow meter     |
|                     |  | is already fully open.                   |
|                     |  |  |
| Remixing fails when | Skim milk pressure higher than cream                   | Skim milk pressure too high at the       |
| clarifying or stan- | pressure in the outlets.                               | remixing point.                          |
| dardizing.          |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |
|                     |  |  |



| DOWL DISCHARGE Bowl fails to close  1. Operating liquid lines wrongly connected to the control valve 2. None or unsufficient operating liquid feed due to: a. Obstructed strainers, closed or throttled valves, unsufficient pipe dimension, too low pressure  b. Electrical or mechanical defects in solenoid valves or programming components. Wrongly set cam time (on cam shaft in programme timing unit) 3. Control paring disc device obstruc- ted or wrongly mounted  4. Leakage: at distributing cover (see "Control paring disc device"), valve plug (in operating alide) — sealing surface (in bowl body) 5. Operating slide of bowl jams due to imperfect habrication, defective seal ring, burrs or deformation 6. Operating slide springs are defective 7. Sliding bowl bottom jams — the seal ring defective 8. Nozzle in bowl body for draining the space between bowl body and operating slide is obstructed (only for closing after discharge) 9. Obstructed channels to space under sliding bowl bottom (in screw/nozzle)  Bowl fails to open  1. See paragraphs 1-2, 5-7 under "Bowl fails to close" 2. Leakage: at distributing cover, distributing ring — bowl body, operating slide — bowl body 3. Nozzle in bowl body for draining the space between bowl body and operating slide = bowl body 3. Nozzle in bowl body of ordarining the space between bowl body and upper slide of operating slide are obstructed 4. Channels to space between bowl body and upper slide of operating slide are obstructed  Observe directions in chapter G. Check pressure (with pressure gauge) at the inlet to the machine. Check cheapter is the inlet to the machine. Measure the quantity of outflowing liquid per unit time (undo connections in chapter G. Check the fine the inlet to the machine. Measure the quantity of outflowing liquid per unit time (undo connections in chapter S. Check the am time (such pressure gauge) at the inlet to the machine. Check the cam time. See Dicharge programme Fquipment. Check the flow according to directions in the programme faulting of the chapter I. "Disc | Indication         | Cause   | Remedy   |
|--|--------------------|---|--|
| 4. Leakage: at distributing cover (see  "Control paring disc device"), valve plug (in operating slide) — sealing surface (in bowl body)  5. Operating slide of bowl jams due to imperfect lubrication, defective seal ring, burrs or deformation  6. Operating slide springs are defective 7. Sliding bowl bottom jams — the seal ring defective 8. Nozzle in bowl body and operating slide is obstructed (only for closing after discharge)  9. Obstructed channels to space under sliding bowl bottom (in screw/nozzle)  Bowl fails to open  1. See paragraphs 1-2, 5-7 under "Bowl fails to close" 2. Leakage: at distributing cover, distributing ring — bowl body, operating slide — bowl body 3. Nozzle in bowl body and operating slide not inserted 4. Channels to space between bowl body and upper side of operating slide are  Check. Clean seals and sealing surfaces.  Check. Clean and lubricate carefully. Compare chapter I "Discharge mechanism".  Check and renew. Renew the seal ring. Lubricate carefully. Clean. Compare chapter I "Discharge mechanism".  Clean. Compare chapter I "Discharge mechanism".  Check. Clean seals and sealing surfaces.  | BOWL DISCHARGE     | 1. Operating liquid lines wrongly connected to the control valve 2. None or unsufficient operating liquid feed due to: a. Obstructed strainers, closed or throttled valves, unsufficient pipe dimension, too low pressure  b. Electrical or mechanical defects in solenoid valves or programming components. Wrongly set cam time (on cam shaft in programme timing unit)  3. Control paring disc device obstruc-                               | Observe directions in chapter G.  Check pressure (with pressure gauge) at the inlet to the machine. Measure the quantity of outflowing liquid per unit time (undo connection at machine).  Adjust the cam time. See Dicharge Programme Equipment.  Check the flow according to directions in chapter L "Discharge mechanism".  Dissolution of any deposits, see chapter L "Cleaning agents". |
| Bowl fails to open  1. See paragraphs 1-2, 5-7 under "Bowl fails to close"  2. Leakage: at distributing cover, distributing ring — bowl body, operating slide — bowl body  3. Nozzle in bowl body for draining the space between bowl body and operating slide not inserted  4. Channels to space between bowl body and upper side of operating slide are mechanism".  Mechanism".  See corresponding paragraphs.  Check. Clean seals and sealing surfaces.  Check.  Check.  Clean. Compare chapter I "Discharge mechanism".   |                    | "Control paring disc device"), valve plug (in operating slide) — sealing surface (in bowl body)  5. Operating slide of bowl jams due to imperfect lubrication, defective seal ring, burrs or deformation  6. Operating slide springs are defective  7. Sliding bowl bottom jams — the seal ring defective  8. Nozzle in bowl body for draining the space between bowl body and operating slide is obstructed (only for closing after discharge) | Paring disc device — see chapter S. Check. Clean seals and sealing surfaces.  Check. Clean and lubricate carefully. Compare chapter I "Discharge mechanism".  Check and renew. Renew the seal ring. Lubricate carefully.  Clean. Compare chapter I "Discharge mechanism".  Clean. Compare chapter I "Discharge mechanism".   |
|  | Bowl fails to open | 1. See paragraphs 1-2, 5-7 under "Bowl fails to close"  2. Leakage: at distributing cover, distributing ring — bowl body, operating slide — bowl body  3. Nozzle in bowl body for draining the space between bowl body and operating slide not inserted  4. Channels to space between bowl body and upper side of operating slide are   | See corresponding paragraphs.  Check. Clean seals and sealing surfaces.  Check.  Clean. Compare chapter I "Discharge   |



| Indication  | Cause   | Remedy   |
|---|---|--|
| (Bowl discharge,  |   |  |
| page 2)  The bowl opens and closes but reopens ("double discharge") | The solenoid valve remains open too long (cam time too long)  | Reduce the cam time for the relevant solenoid valve.  See Discharge Programme Equipment. |
| The bowl opens unintentionally during operation                     | <ol> <li>Liquid losses are not compensated.</li> <li>See paragraphs 2-4, 6, 9 under "Bowl fails to close"</li> <li>Pressure in make-up liquid line is too high</li> </ol> | See corresponding paragraphs.  Reduce pressure.  |
| Discharge quantity (at partial discharge) is too large/small        | Pressure in partial discharge liquid line is too high/low   | Reduce/increase pressure.  |
|   |   |  |
|   |   |  |
|   |   |  |
|   |   |  |
|   |   |  |
|   |   |  |
|   |   |  |



| Indication  | Cause   | Remedy   |
|---|---|--|
| Machine vibrates  | :: Moderate vibrations normally occur at the critical number of revolutions during the running-up and retardation periods. :: Bowl out of balance due to: bad cleaning — wrong assembling — badly tightened lock ring — disc set insufficiently clamped — bowl asembled with parts from | None  Stop immediately and establish cause.  Badly tightened lock ring involves fatal danger.  |
|   | different machines. :: Vibration damping rubber washers have lost elasticity. :: Top bearing spring broken. :: Foundation too weak.   | Renew rubber washers every second year. Exchange all springs. Reinforce foundation.  |
| Speed too high  | :: Tachometer reading wrong.<br>:: Wrong transmission.  | Check by means of revolution counter. Stop immediately. Check that proper transmission is used in view of motor speed.                           |
|   | :: The motor speed is not appropriate.  | Stop immediately and exchange motor.   |
| Speed too low<br>Running-up time<br>too long                            | <ul> <li>:: Brake applied.</li> <li>:: Voltage drop in mains.</li> <li>:: Ball bearing damage.</li> <li>:: Other machine defects.</li> <li>:: Motor defect.</li> </ul>  | Release the brake.  Locate and exchange defective bearing.  Stop immediately. Check that bowl can be rotated by hand.  Exchange or repair motor. |
| Running-up time<br>shorter than normal<br>(starting current to<br>high) | :: Overvoltage  |  |
| Retardation time too long   | :: Brake lining worn or oily.   | Exchange or clean lining.  |
| Motor stops during running-up   | :: Probably more than two successive (accomplished) starts have been performed, resulting in overheating of motor (thermocontacts in motor have cut out the current).   |  |
| Water in worm gear housing  | :: Condensation. :: Axial seals not tight or turned wrongly. :: Leakage at hood over top bearing.   | Drain water. Exchange rings and turn correctly. Tighten the hood.  |
| Noise from worm gear housing  | <ul><li>:: Oil quantity wrong.</li><li>:: Worm wheel or worm worn.</li><li>:: Ball bearing worn or damaged.</li></ul>   | Check quantity and quality. Exchange worn parts. Exchange of complete gear is generally advisable. Exchange bearing.                             |
| Noise from coupling   | <ul><li>:: Wrong play between coupling pulley and elastic plate.</li><li>:: Speed too low</li></ul>   | Adjust - see chapter R.  See - Speed too low.  |
| Smell   | :: Bearing running hot  | Feel over machine and locate spot. Exchange bearing.   |
| "Scraping" noise  | Wrong height position   | Stop and adjust — see chapter L.   |
|   |   |  |
|   |   |  |



### CLEANING. OVERHAUL

It has proved very difficult in practice to prescribe how often cleaning should be carried out and how thorough the overhaul should be. However, aided by the directions given in this chapter it should not be difficult to make up a suitable working routine with regard paid to special local conditions.

The ALFA-LAVAL representative will always be glad to provide further advice and information.

When cleaning and overhauling always follow strictly the directions given in this book concerning the dismantling, lubrication and assembling.

Make it a habit to inspect and replenish the set of spare parts (and tools) once a year. It pays to keep the consuming parts in stock.

OVERHAUL CHART

The time intervals stated below relate to continuous operation. If the mentioned number of operating hours is not obtained during the period, the latter can be extended, but a thorough overhaul at least once every third year is imperative.

| OPER | ATING | HOURS |
|------|-------|-------|
|      |       |       |

Every 24th (every day\*)

Operation check
Machine run (speed).
Power consumption.
Oil level in worm gear housing.
Observation of discharged liquids.
Temperature

Throughput
Sludge tank
Pressure
Automatic control device, if
any (signal lamps).

Every 200th (every week\*)

Worm gear housing Check and if necessary replenish oil. Further actions
Speed check
Leakage tracing

Every 750th (every month\*)

Bowl
Dismantling of bowl
and thorough cleaning
of bowl inset parts.
Thorough cleaning
and lubrication of
lock rings and oiling
of bowl body nave bore.
Check on seals.

Power transmission Cleaning and oiling of bowl spindle cone.

Control system
Check flow of operating liquid.
Check sludge discharge interval of automatic control device.

Strainers and filters Cleaning and checking.

Every 1500th (every second month\*)

Worm gear housing
Cleaning and oil change.
(In case of new installation, however, after 300 operating hours and in seasonal operation before every working period).

Bowl
Dismantle and clean sludge
discharge mechanism of bowl.
Check springs, seals and
sludge ports. Check erosion.

Frame Renew brake lining.

Every 9000th (every year\*)

Thorough overhaul, cleaning and lubrication.

Bowl check
Pressure in set of discs.
Lock ring joint.

Corrosion and other material attacks.

Power transmission
Dismantle bowl spindle,
coupling and worm wheel
shaft.

Check particularly ball bearings and gear as well as top bearing springs and buffers. Control system
Check pipes and valves.

Height positions Check and adjust.

Frame Check elasticity of vibration dampers and mounting of machine.

Motor - see special manual for motor.

<sup>\*</sup> In continuous operation.

CLEANING AGENTS Metallic machine parts

Use Cleaning kerosene, White spirit, Mineral spirits or another solvent with equivalent properties. If the cleaning agent is unsuitable in view of the product of the process, the bowl, inlet and outlet parts in contact with liquid can normally be cleaned with a soda or trisodiumphosphate solution, or with current technical defatting agent on an alkaline basis. A certain care should be exercised when cleaning light metal parts, as these may be attacked by strong

Benzine or benzol may also be used for the metal parts, but if so, the cleaning should be done in the open air due to the risk of explosion, and because benzol vapours are dangerous to inhale.

alkaline solutions.

Seal rings

Wipe seal rings with a cloth moistened with some of the above cleaning agents.

Coupling pads and brake lining

Trichlorethylene should be used for cleaning these parts and the corresponding friction surfaces. Note that it should be done under safe control (ventilation), and preferably in the open air.

Discharge mechanism

Any deposits on the parts of the control device are to advantage dissolved in an approx. 10 percent solution of acetic acid heated to about 80°C (175°F).

WASHING AGENTS for DAIRY MACHINES Lye solution

1% alkaline solution, for instance of the following composition: 90% caustic soda (NaOH), 9% sodium tripolyphosphate (Na<sub>5</sub>P<sub>3</sub>O<sub>10</sub>), 1% wetting agent (nonionic ethylenediaminoacetate)

Acid solution

0,5-0,8% nitric acid solution.

MANUAL CLEANING of BOWL

During the first time the bowl should be dismantled and, when necessary, cleaned after every automatic washing until a suitable washing programme has been established. Thereafter the intervals between dismantlings can be extended successively. Observe that defective or wrongly fitted strainers letting through particles that are too large to pass between the bowl discs can cause sludge blockage. If this occurs, the bowl discs must be cleaned one by one.

Any tendency of the lock ring to stick to the bowl body must also be considered when determining the intervals between dismantlings. It is difficult to prescribe how often the lock ring threads must be lubricated, as this depends both on the lubricant used and on the care with which the lubrication is performed.

Discharge mechanism The hardness of the water decides how often cleaning must be done. However, as a rule the parts should be cleaned every time the bowl body is removed from the spindle.

Clean all channels and nozzles in bowl body, operating slide and control paring disc.

Check on liquid flow


- :: Turn on the feed of operating water.
- : Open the valve for high-pressure water. Water should now spurt out through the holes in the paring discs in powerfull jets.
- :: Open the valve for low pressure water. Water should now spurt out through the holes, but in weak jets.

BOWL OVERHAUL

Exchange of parts

Bowl parts marked "\*" on the perspective drawing in chapter I can be exchanged only in an authorized ALFA-LAVAL/DE LAVAL workshop, as the exchange necessitates rebalancing — thus the COMPLETE bowl must be sent in. Other parts can be exchanged on the spot.

Thread check



Lock ring with external thread

In a new bowl, the guide marks ( $\phi$ ) should be right in front of each other. In time, these marks can be drawn past each other due to wear of the threads. When the  $\phi$ -mark of the lock ring can be drawn past the other  $\phi$ -mark by more than 25-30°, an authorized ALFA-LAVAL/DE LAVAL representative should be consulted.

Thread checking should be done at least once a year.


The checking is carried out as follows:


Unscrew the large lock ring, remove the distributor with disc set. Put on the hood and screw on the lock ring.

Tighten the large lock ring anti-clockwise till tight contact is obtained between the contact surfaces of bowl body and bowl hood.

Clamping of disc See chapter I, Bowl. set

Seal ring of bowl hood





When exchanging the seal ring drive it out by means of the tool, which should be inserted alternately in the holes provided for this purpose.

The seal ring is pressed into the groove in the lower edge of the bowl hood by means of a planed board (1"x5"), which should be placed across the ring. Knock carefully on the board right above the ring, first on one side and then on the other. Turn the board around successively and drive the ring into the groove as evenly as possible.

If a new seal ring of nylon (polyamide) turns out to be too wide when mounted, this is due to absorption of moisture — it will recover correct dimensions after drying for about 24 hours at a temperature of 175°-195°F (80°-90°C) in heating chamber.

If the ring is too narrow, put it in hot water, 160°-175°F (70°-80°C), for about 8 hours.


MAINTENANCE

HEIGHT ADJUSTMENT

Checking should be done both in connection with the yearly overhaul and after exchange or mounting of parts which can affect the height position.


The tolerances are narrow and it is essential, therefore, that all parts are clean and free from burrs.

Control paring disc



The distance between the upper rim of the distributing cover and the spindle top should be as indicated in the figure. The height position of the paring disc is adjusted by means of height adjusting rings under the distributing cover. See also chapter S "Paring disc device".

Paring discs of bowl



Check


Assemble the bowl. Put on the frame hood and clamp it with the hinged bolts. Insert the height adjusting ring.

The distance between the height adjusting ring and the upper edge of the upper paring disc should be as indicated in the figure. If this is not the case, replace the inserted height adjusting ring by a ring with more suitable thickness. For height adjusting rings see chapter I "Inlet. Outlet".

After every height adjustment of the control paring disc the bowl spindle should be revolved by hand (with bowl body put on the spindle). If scraping noise is audible, the adjustment is probably wrong — readjust.

If a scraping noise is audible in the inlet and outlet after the machine has been started, stop the machine at once and recheck the adjustment. The listening for scraping noise must be done as near the inlet and outlet as possible and in immediate connection with the start.

GENERAL HINTS
Bearing overhaul



How often the bearings should be overhauled depends chiefly on the working conditions. Where the load on the bearings is heavy it is advisable once a year to clean them thoroughly and examine their rings, cages, and rolling bodies. In many cases, however, a much longer interval than 12 months can safely be allowed between overhauls, especially if the condition of the bearings can be ascertained during operation for instance by listening, checking the bearing temperature, observing the lubricant colour or the like.

Storing

Always keep spare bearings in stock, storing them in a place where they are protected against moisture and dust. Never remove a bearing from its wrapping until it is to be mounted.

Dismantling and mounting

Never dismantle a bearing unless it is necessary. A dismantling always involves certain risks: the bearing could suffer damage, dirt might enter it, and it might be wrongly remounted.

Before dismantling it should be found out, from a drawing or otherwise, how the bearing is fitted. To avoid mistakes, the dismantled parts should be so laid out or marked as to make completely clear how bearing, spacing sleeves, seal rings etc. were originally placed.

A satisfactory result of the bearing overhaul cannot be obtained unless the utmost cleanliness is exercised.


In dismantling and mounting it is essential to apply the force to the appropriate ring. Only seldom the two rings of a bearing have equally tight fits. In most cases one ring is mounted with a tight fit and the other one with a reasonably loose fit. When for dismantling of e.g. the tight-fit-ring the power is applied to the loose-fit-ring, the pressure must proceed through ball races and rolling bodies to the former ring. This can easily cause a denting of the ball races that will shorten the lifetime of the bearings. Particularly vulnerable in this respect are bearings of a type which is not constructed for axial loading.


When for instance the inner ring is to be removed from the shaft, the dismounting power should be applied to this ring.

On the other hand, if the outer ring is to be removed from the bearing housing or the bearing seat, this ring should be subjected to the dismantling power.

What is said above also goes for thrust bearing washers. Never fit or remove a shaft washer by exerting a pressure against a housing washer.

Blows are the least lenient form of dismantling and mounting power and should be avoided. A pressure or pull (cont.)






1231704

(Dismantling and mounting, page 2) from a press or puller is preferable. If blows are the only possibility, never knock directly on the bearing. The rings are hardened and can burst, and the wrong ring or the cage could be hit with denting of the ball races or the cage as a result. To avoid this, place a mounting sleeve between the bearing and the hammer.

ball bearing



Angular-contact The single-row angular-contact ball bearing is capable of resisting an axial load in one direction only, and thus it is essential to mount it so that the axial load will act toward the stamped side of the inner ring.

Heating


Bearings with cylindrical bore which are to be mounted with tight inner-ring fit should be heated in oil. However, the temperature should not be so high or the heating be carried on for so long a time as to affect the properties of the steel. As only a short heating is needed for mounting purposes, the bearing can safely be heated to a temperature of maximum 120°C (248°F).

Cleaning

Used bearings which have been removed from the machine must be washed in clean kerosen. After washing, the bearings must be oiled or greased immediately to protect them against corrosion.

Never wash completely new bearings. The rust preventive with which they are coated has no detrimental effect on the lubricant and thus need not be removed.

Test run and final check



With the mounting accomplished test-run the bearings. Observe the sounds emitted by the bearing, and the temperature rise. The sound can be observed by placing one end of a wooden stick or a screw driver against the ear and its other end against the bearing housing. Normally the bearing should emit a regular, spinning sound. A whistling sound indicates insufficient lubrication. Irregular and noisy running sounds are mostly due to the presence of foreign matter in the bearing, or to damage done to it during mounting.

PARTS LIST DISMANTLING ASSEMBLY

| Set of tools. Set of spares | O!  | F |
|-----------------------------|-----|---|
| Inlet. Bowl (Drum). Outlet  |     | 1 |
| Power transmission          | JC. | Ρ |
| Mounting the motor          |     | R |
| Frame parts                 |     | S |
| Accessories                 |     | X |
|                             |     |   |

**Supplement** 

## SPARE PART ORDERING

A

Instruction book

Each machine is accompanied by an instruction book carrying the type denomination and manufacturing number of the machine on its title page.


Type denomination and manufacturing number

Always base spare parts orders on the instruction book which is marked with the manufacturing number of the machine.

All machines are subjected to continuous constructional modification, and thus the type denomination alone is not enough for adequate identification of the book. To be usable as a spare parts catalogue for a given machine the instruction book must, besides, carry the manufacturing number of the machine in question. If not, this number must be quoted in the spare parts order.

Differing manufacturing numbers

If different manufacturing numbers are indicated on the bowl and the type plate, state both of them.



Rebuilds

If the machine has been rebuilt or completed after delivery, specify such modifications when ordering spares. Besides, full particulars as mentioned above are absolutely necessary in this case.

Example of spare parts order

| Quantity                                 | Part number | Part name       |
|--|-------------|-----------------|
| 2  | 00000       | Nmnmnmnmnmnmnmn |
| 10                                       | 00000-00    | Nmomomomomomomo |
| 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1 |             | e ar sessabilit |



| Ref.   | Part No.<br>Delnr. | Qty.<br>Ant. | Part name                           | Benämning               |
|--------|--------------------|--------------|-------------------------------------|-------------------------|
|        | Denn.              | ,            | (Pressing and lifting tool)         | (Press-och lyftverktyg) |
| 1      | 221891-19          | 1            | Lock nut                            | Låsmutter               |
| 2      | 223101-55          | 1            | Washer                              | Bricka                  |
| 3      | 226314-27          | 14           | Cup spring                          | Tallriksfjäder          |
| 4      | 530035-80          | 1            | Yoke                                | Bygel                   |
| 5      |                    | 1            | Spindle with ball nut and           | Spindel med kulmutter   |
| اد     | •                  |              | thrust washer:                      | och tryckbricka:        |
|        | 535728-82          |              | for BRPX 217, 317 and               | för BRPX 217, 317 och   |
|        | 333120-02          |              | MRPX 217, 317                       | MRPX 217, 317           |
|        | 536242-83          |              | for MRPX 218, 318 and               | för MRPX 218, 318 och   |
|        | 33041,- 33         | 1 1          | 418                                 | 418                     |
| 6      | 535731-01          | 1            | Seal ring                           | Tätningsring            |
| 7a     | 260189-01          | 2            | Bearing                             | Lager                   |
| 7b     | 260189-02          | 4            | Washer                              | Bricka                  |
| 10     | 200107-02          | -            |                                     |                         |
| 0      | 535726-01          | 1            | Thrust washer                       | Tryckbricka             |
| 8<br>9 | 535720-01          | ı            | Washer                              | Bricka                  |
| 100    | 223406-66          | 1            | Seal ring                           | Tätningsring            |
| 10     | 530028-01          | 2            | Round nut                           | Rundmutter              |
| 11     | 550020-01          | "            |                                     | *                       |
| 12     |                    | 4            | Lifting lugs:                       | Lyftklackar:            |
| 12     | 530029-02          | -            | for BRPX 217, 317 and               | för BRPX 217, 317 och   |
|        | 530029-02          |              | MRPX 217, 317                       | MRPX 217, 317           |
|        | E24227 02          |              | for MRPX 218, 318 and               | för MRPX 218, 318 och   |
|        | 536237-02          | 1            | 418                                 | 418                     |
|        |                    | ,            |                                     | Spiralring:             |
| 13     | 50/550 00          | 1            | Coil ring:<br>for BRPX 217, 317 and | för BRPX 217, 317 och   |
|        | 536552-02          |              | MRPX 217, 317                       | MRPX 217, 317           |
|        |                    |              | for MRPX 217, 317                   | för MRPX 218, 318 och   |
| 5      | 536552-01          | 1            | 418                                 | 418                     |
|        | 001501 10          | ,            |                                     | Stoppskruv              |
| 14     | 221581-12          | 1            | Grub screw                          | Fjäder                  |
| 15     | 226211-02          | 1            | Spring                              |                         |
| 16     | 64416              | 1            | Cylindrical pin                     | Cylindrisk pinne        |
| 17     | 221230-10          | 2            | Screw                               | Skruv                   |
| 18     | 530033-01          | lī           | Lock plate                          | Låsbricka               |
| 19     | 536791-01          | lî           | Roller                              | Rulle                   |
| 17     | 330171-01          | 1 *          |                                     |                         |
|        |                    |              |                                     |                         |
|        | 20.0               |              |                                     |                         |
|        |                    | 1            |                                     |                         |
|        |                    | -            |                                     |                         |
|        |                    |              |                                     |                         |
|        |                    |              |                                     |                         |
|        |                    |              |                                     |                         |
| 1      |                    |              |                                     |                         |
| 1      |                    |              |                                     |                         |
|        |                    |              |                                     |                         |
|        |                    |              |                                     |                         |
|        |                    |              |                                     |                         |
|        |                    |              |                                     |                         |
|        |                    |              |                                     |                         |
|        |                    |              |                                     |                         |
|        |                    | 1            |                                     |                         |
|        | 1                  |              |                                     | ,                       |
| 1      | 1                  | i            | 1                                   | 1                       |

SET OF SPARES

| BOWL (comp. chapter I)  | Ball bearings for:   |
|---|--|
| 515133-03 Nozzle<br>528165-02 Valve plug (3)<br>226214-74 Spring (6)<br>Bowl disc (5) - see Bowl                  | 233211-49 top bearing (2)<br>233215-03 top bearing<br>65187 worm<br>69850 worm (2)<br>69843 bottom bearing |
| Seal rings for:   | Springs for:   |
| 223412-55 operating slide (2)<br>223416-35 bowl body (3)<br>523116-04 sliding bowl bottom (2)                     | 70340 axial buffer (20)<br>66191 top bearing (12)  |
| 521863-02 bowl hood (2)<br>528086-01 bowl hood  | Seal rings for:  |
| Packings for:   | 223412-42 cover for spring casing 223412-17 throw-off collar   |
| 528167-01 spring support (2)<br>528087-01 paring chamber cover (2)  | 223412-51 protecting cap   |
| 516281-25 cyclone nut (2)<br>528220-2 lower paring disc<br>516281-24 upper paring disc (2)                        | FRAME PARTS (comp. chapter S)  |
| nm Ouri ET (comp chapter I)   | 65227 Brake lining with 3 screws 38685 Oil gauge glass 223521-08 Lipseal ring for revolution               |
| INLET. OUTLET (comp. chapter I)   | counter and tachometer (2)   |
| 74384 Membrane for pressure gauge<br>522808-05 Sealing strip for frame hood<br>223324-04 Seal ring for inlet pipe | 528746-01* Protecting glass for tachometer   |
| Spare parts for regulating  | Seal rings for:  |
| valve and flow meter - see chapter X  | 74067 inlet bend — operating liquid  |
| Packings:   | 38411 bottom bearing housing<br>74634 paring disc device (2)<br>223406-27** for pneumatic brake (2)        |
| 71068 (4)<br>190608 for flow meter  | 223406-27** for pheditatic brake (2)   |
| 1,0000 101 120 0  | Packings for:  |
| COUPLING. WORM WHEEL SHAFT (comp. chapter P)  | 516281-16 cyclone<br>71068 drain tube<br>516281-10 flushing nozzle<br>68937 flushing nozzle                |
| 223408-09 Seal ring for seal washer<br>43626 Packing for bearing shield   | 223316-05 oil drain screw<br>528723-01 oil gauge glass<br>37167 oil gauge glass<br>71068 ventilation bend  |
| BOWL SPINDLE (comp. chapter P)  | 223434-02 revolution counter 223316-05 oil filling screw — see Revolution counter                          |
| 72473 Washer for screw plug (12)  | 528732-01 protecting cap (2) - see Brake and Revolution counter  |
|   | * Not for machine equipped for remote speed indication.  |
|   | ** Only for remotely controlled machine.   |
|   |  |



### INLET. BOWL. OUTLET

Satisfactory functioning cannot be ensured unless the parts in contact with liquid are carefully cleaned before assembly. This applies particularly to seal rings, sliding surfaces, guiding and contact surfaces, and threads. Also take care that no burrs are knocked up on the metal parts when handling them.

Exchange of parts

Each bowl constitutes a balanced unit which will get out of balance if any parts having an "\* or ▼ "added to their name in the general drawing are exchanged without the bowl being rebalanced. To prevent confusion of parts, for instance when a plant consists of several machines of the same type, these main parts are stamped either with the complete manufacturing number or its three last digits.

#### Guides

When assembling make sure that the bowl parts are placed in the position defined by the guides. Be careful not to damage the guides when handling the parts.

Seal rings. Packings

Check seal rings and packings for defects and make sure that the corresponding grooves and sealing surfaces are well cleaned.

After mounting check...

- ... that the ring lies properly (not twisted) in the groove.
- ... that it fills the groove evenly all around.


Threads. Pressure in disc set

Check the lock ring threads and the pressure in the


disc set at regular intervals — see chapter L.


Corrosion. Erosion

Aggressive liquids as well as liquids containing very hard particles may cause corrosion and erosion damage. If rapidly growing or advanced damage is noticed, consult an ALFA-LAVAL representative.



Ì





#### ALFA-LAVAL


· Just

| Ref.                       | Part No.<br>Delnr.  | Qty.<br>Ant.                                     | Part name   | Benämning  |
|----------------------------|---|--|---|--|
| 1<br>2<br>3<br>4           | 522808-05<br>528104-02<br>233281-01   | $\begin{bmatrix} 1 \\ 1 \\ 4 \\ 4 \end{bmatrix}$ | Frame hood<br>Sealing strip<br>Hinged bolt<br>Ball                                  | Stativhuv<br>Tätningsli <b>st</b><br>Länkskruv<br>Kula               |
| 5<br>6<br>7<br>-<br>-<br>- | 785865-02<br>72956<br>528191-01<br>528191-02<br>528191-03<br>528191-04<br>528191-05 | 4<br>4<br>1-2*                                   | Clamping shoe Cap nut Height adjusting ring 12.0 mm 13.5 mm 15.0 mm 16.5 mm 18.0 mm | Låsklack Hattmutter Höjdring 12,0 mm 13,5 mm 15,0 mm 16,5 mm 18,0 mm |
| .8<br>.9<br>.10<br>.11     | 530008-80<br>71066<br>74656<br>71068  | 1<br>1<br>1                                      | Discharge cover Packing Sealing plug Packing  | Utloppslock Packning Täckbr  |
|                            | 535288-82<br>5223324-04<br>528188-01<br>530384-01                                   |  | Outlet piece<br>Seal ring<br>Inlet pipe<br>Nozzle                                   | Utloppskr<br>Tätningsring<br>Tilloppspip<br>Munstycke                |
| 15<br>16<br>13<br>18<br>19 | ,190616<br>71068<br>190630<br>533395-84<br>190608                                   | 1<br>1<br>1<br>1                                 | Coupling nut Packing Sleeve Cream flow meter ** (450 1/h) Packing                   | Kopplingsmutter  Packman  Hyls  Graddmätare  (450 1/h)  Packning     |
| <b>A</b>                   |   |  | Manual back-pressure<br>regulation  | Manuell/mottryck <b>s</b><br>reglering                               |
| 20<br>21<br>22<br>23       | 517697-80<br>71068<br>532345-80<br>74384  | 1<br>3<br>1<br>1                                 | Regulating valve ** Packing T-piece Membrane  | Regleringsventik<br>Packning<br>T-ror<br>Membran                     |
| 24<br>25<br>26             | 74386<br>190630<br>190616   | 1<br>1<br>2 1                                    | Pressure gauge(0-10bar)<br>Sleeve<br>Coupling nut                                   | Tryckmätare (0-10 Bar)<br>Hylsa<br>Kopplingsmutter                   |
| В                          |   | -  | Automatic back-pressure regulation  | reglering  |
| 27<br>28<br>29<br>430      | 71068<br>31317-0870-1<br>74384<br>74386   | 2<br>1<br>1<br>1                                 | Packing Pipe cross Membrane Pressure gauge(0-10bar)                                 |  |
| 31 3<br>32<br>33           | SPCL-SMS-<br>51-Kv 51<br>71066<br>31801-1057-1                                      | . 1<br>1<br>1                                    | SPCL-valve Packing Pressure transmitter   | SPCL-ventil Packning Tryckgivare                                     |

One ring is mounted before delivery, another one of the next smaller thickness is supplied unmounted.

<sup>\*</sup> Included parts - see chapter X.

<sup>\*</sup> En ring monteras vid leverans in; en ring med tjockleken närmast ui der den monterade ringens, medföljer lös. \*\* Ingående delar — se kapitel X.



Note that the bowl must be at rest before starting the dismantling - check by means of the revolution counter.

Dismantle the parts in the sequence appearing from the illustration. Use a hook spanner for unscrewing the inlet pipe from the lower paring disc (see also vertical section).


ASSEMBLY

Clean all parts. Carefully lubricate threads and contact surfaces, and particularly the thread of the inlet pipe.

Screw in the pipe firmly.

Check the height position of the paring discs before the first start and after exchange of parts that could affect the height position — see also chapter L " Height adjustment".

**ISÄRTAGNING** 




Observera att kulan måste stå stilla innan isärtagningen får påbörjas – kontrollera mot varvräknaren.

Tag isär delarna i den ordning som framgår av figuren. Använd haknyckel för att skruva loss tilloppsröret från den undre skalskivan (se även vertikalsnitt).


HOPSÄTTNING

Gör ren samtliga delar. Smörj noggrant gängor och anliggningsytor. Se särskilt till att tilloppsrörets gänga blir väl smord och att röret blir ordentligt draget.

Kontrollera skalskivornas läge före första start och efter utbyte av delar som kan påverka höjdläget – se vidare i kapitel L, "Höjdinställning".



536618-Z (4260-14) P



| Ref.                 | Part No.  Delnr.                                     | Qty.<br>Ant.     | Part name  | Benämning   |
|----------------------|--|------------------|--|---|
| 1                    | 528018-01  | 1                | Lock ring, small (left-hand thread)                                  | Låsring, liten (vänster-<br>gänga)  |
| 2 3                  | 528016-02<br>536359-02*                              | 1<br>1           | Paring chamber cover Lock ring, large (left- hand thread             | Skalkammarlock<br>Låsring, stor (vänster-<br>gänga)                             |
| 4                    | 516281 -24**   | 1                | Packing  | Packning  |
| 5<br>6<br>7<br>8     | 528221 - 01** 528229 - 01** 528087 - 01 536372 - 01* | 1<br>1<br>1<br>1 | Paring disc, top part Paring disc, bottom part Packing Bowl hood     | Skalskiva, överdel<br>Skalskiva, underdel<br>Packning<br>Kulhuv                 |
| 9                    | 521863-02  | 1                | Seal ring Seal ring Top disc Packing                                 | Tätningsring  |
| 10                   | 528086-01  | 1                |  | Tätningsring  |
| 11                   | 530118-01*   | 1                |  | Överplåt  |
| 12                   | 528220-01**  | 1                |  | Packning  |
| 13                   | 528218-80**  | 1                | Paring disc, top part Paring disc, bottom part Bowl disc Bottom disc | Skalskiva, överdel  |
| 14                   | 528217-01**  | 1                |  | Skalskiva, underdel   |
| 15                   | 530091-05  | 152              |  | Insatsplåt  |
| 15a                  | 530091-06  | 1                |  | Underplåt   |
| 15b                  | the many are that they are the same and              | 36               | Bowl disc  | Insatsplåt  |
| 15c                  |  | 1                | Bottom disc  | Underplåt   |
| 16                   |  | 1                | Distributing disc  | Fördelningsplåt   |
| 17                   |  | 1                | Distributor  | Fördelare   |
| 18<br>19<br>20<br>21 | 535258-01** 516281-25 533283-80* 523116-04           | 1<br>1<br>1<br>1 | Cap nut (left hand thread)  Packing Distributing cone Seal ring      | Kapselmutter (vänster-<br>gänga)<br>Packning<br>Fördelningskona<br>Tätningsring |
| 22                   | 528044-01  | 1                | Sliding bowl bottom Seal ring Screw/nozzle Bowl body                 | Slidtallrik   |
| 23                   | 223416-35  | 1                |  | Tätningsring  |
| 24                   | 526648-01**  | 3                |  | Skruv/munstycke   |
| 25                   | 536252-80*   | 1                |  | Kulkropp  |
| 26                   | 528168-01  | 6                | Screw Spring support Spring Screw                                    | Skruv   |
| 27                   | 528166-01*   | 1                |  | Fjäderhållare   |
| 28                   | 226214-74  | 24               |  | Fjäder  |
| 29                   | 2211722-25   | 3                |  | Skruv   |
| 30                   | 528169-02  | 1                | Wing rim Packing Operating slide Valve plug                          | Vingkrans   |
| 31                   | 528167-01  | 1                |  | Packning  |
| 32                   | 528164-01*   | 1                |  | Manöverslid   |
| 33                   | 528165-02  | 3                |  | Ventilpropp   |
| 34                   | 223412-55  | 1                | Seal ring  | Tätningsring  |
| 35                   | 515133-03  | 1                | Nozzle   | Munstycke   |

<sup>\*</sup> Exchange necessitates rebalancing — send the COMPLETE bowl to an authorized ALFA-LAVAL representative.

<sup>\*\*</sup> Not included in the complete-unit number of the bowl.

<sup>\*</sup> Utbyte nödvändiggör ombalansering – skicka in HELA kulan till en auktoriserad ALFA-LAVAL representant.

<sup>\*\*</sup> Ingår ej i kulans komplettnummer.

# DISMANTLING. ASSEMBLY

Dismantle and assemble the bowl in the sequence appearing from the perspective drawing, observing any directions given in the following text. Use the special tools — see chapter F. Place the parts on a soft base (such as wood or rubber).

Observe that the bowl MUST be at rest before dismantling of inlet and outlet is commenced. After assembly check manually that the bowl rotates unimpeded.

# OFF

# Left-hand thread

The bowl rotates clockwise. For this reason, the threads of the rotating parts are left-handed. This is always mentioned in the text. Where right-hand threads are concerned, no special note is made.



## Lubrication (see chapter H)

Clean and lubricate the threads of the lock rings and their contact surfaces with bowl hood and bowl body before every assembly. Seizing may be the result, especially in new machines, if this lubrication is neglected or an unsuitable lubricant is used. Careful lubrication of these surfaces will prevent unnecessary wear and severe seizing.

Small lock ring

The lock ring is provided with left-hand thread and unscrews CLOCKWISE. It is loosened by hitting the spanner handle with a lead mallet or the like. When assembling screw it down firmly so that a tight joint is obtained at the paring chamber cover. Lubricate the thread before mounting.

#### Large bowl lock ring. Disc set pressure


The lock ring has left-hand thread and thus unscrews CLOCKWISE.

The ring must be tightened until tight contact is obtained between bowl hood and bowl body. The hood now should press the distributor against the bottom of the bowl body while FIRMLY clamping the disc set.

Insufficient disc set pressure may cause rough bowl running and even heavy vibration (danger).

Note that the lock ring must turn easily in the corresponding thread of the bowl body to ensure correct disc set pressure according to the method below.


Check this by screwing on the lock ring with bowl hood placed on the bowl body but disc set removed.



Before fitting the pressing tool check that lifting loop and lugs are positioned as above.

To check and adjust the disc set pressure proceed as follows:

- l Add one or more extra discs to the top of the ordinary disc set. Fit the solids indication disc, if any, and the bowl hood.
- 2 Fit the tool as illustrated above.
- 3 Push stop into locking position.
- 4 Retain the ball nut and turn lifting loop ANTI-CLOCKWISE until lifting lugs are fully pressed out and well engaged.
- 5 Tighten ball nut CLOCKWISE with spanner until a force of 20-25 kp is obtained (this will give a pressing power of 6-7 tons).




(Lock ring..)

6 Lubricate the lock ring thread and tighten the ring as far as possible by hand, using the bowl spanner. The mark φ of the lock ring should now, as viewed in the direction of tightening, lie before the mark φ of the stationary part (the bowl body, and for lock ring with internal thread, the bowl hood respectively).

If the marks  $\phi$  are aligned, a <u>further</u> disc or more must be added and the procedure 1-6 be repeated.

When the requirement according to paragraph 6 has been complied with, unscrew the lock ring. Relieve the disc set of pressure by screwing the ball nut slightly CLOCKWISE so that the stop can be released and the ball nut be turned ANTI-CLOCKWISE. Remove the tool as well as the bowl hood, and the top disc, if any.




- Correct pressure is now obtained as follows: Remove the smallest number of discs that will allow the lock ring, with disc set compressed, to be tightened by hand with the bowl spanner until the marks of are aligned. The force aplied to the spanner of the pressing tool must not exceed 25 kp.
- 9 With marks  $\phi$  aligned, hit the bowl spanner handle lightly a few times with the tin hammer.

# Note

In a new bowl marks  $\phi$  will thus line up. In time it may become possible to draw mark  $\phi$  of the ring past the stationary mark due to wear of the threads. When thread wear has been established scribe stationary part at new position of the mark on the ring. For check on thread wear see chapter L.

(Dismantling. Assembly)

Bowl hood




The bowl hood lifting tool is screwed ANTI-CLOCK-WISE (left-hand thread) onto the bowl hood.

Put on the bowl hood so that the guide lug of the


Put on the bowl hood so that the guide lug of the bowl body enters the recess in the hood. If the bowl hood does not drop properly into its seat when the disc set is compressed as described above check whether some part has been wrongly fitted.

The seal ring in the lower edge of the hood should be removed for exchange only — see chapter L, Bowl Overhaul. Lubricate the thread and the surfaces in contact with the large lock ring before screwing on the latter.

Solids indication disc When mounting make sure that the bore mark on the solids indication disc neck comes right in front of the bowl body guide lug. The recesses in the underside of the disc will now fit over the distributor ribs.



# Mounting



- 1. Fit the tool as appears from illustration.
- 2. Push stop into locking position.
- Retain ball nut and turn lifting loop ANTI-CLOCKWISE until lugs are fully pressed out and well engaged.
- 4. Tighten ball nut lightly CLOCK-WISE using the spanner.
- 5. Lift distributor with disc set.

Three of the distributor wings are provided with guide ribs. When mounting, position the guide rib pointed out in illustration slightly to one side of the bowl body guide lug. Now turn the distributor until the recesses in its underside will fit over the guide pins of the distributing cone.

(Dismantling. Assembly)

Cap nut (cyclone nut)

The nut has left-hand thread and thus unscrews CLOCKWISE. Use a hook spanner. Lubricate the thread before mounting. Tighten the nut firmly.

Distributing cone

At assembly the recesses in the underside of the distributing cone must fit over the corresponding guides on the bowl body.

Sliding bowl bottom

When mounting make sure that the sliding bowl bottom drops into the proper position, i.e. with its upper rim approximately flush with the lower edge of the discharge openings in the bowl body.


Before assembly lubricate the sliding surfaces of the sliding bowl bottom — nave bore and peripheral surface.

Bowl body


For dismantling screw the screws out of the bowl body bottom and mount the lifting tool. Detach the bowl body from the spindle by screwing down the eye nut. When mounting lubricate the three screws, place them in the holes in the bowl body bottom and rotate the bowl body slowly until the screws enter the holes in the distributing ring. Tighten the screws evenly and firmly. Distributing ring — see Paring Disc Device in chapter S. If the bowl body must be turned upside down use the special tool.


Discharge mechanism The operating slide must be handled with great care. Oblique and uneven mounting or dismantling and use of force will in most cases result in deformation with operation trouble as a consequence.

The valve plugs should be removed only for exchange. Nozzle and channels should be cleaned with soft iron wire. When assembling lubricate the sliding surface of the operating slide (facing the spring support) and the bowl body surface against which the slide glides. Tighten the spring support screws evenly and firmly.



534202-Z (4225-1, 4226-1)





1231688A -2 (4226-1)



#### POWER TRANSMISSION

Dismantle and assemble the parts in the sequence shown in the illustrations on the following pages, using the special tools supplied.

In addition to the specific instructions, remember the following points at all times ...


- ... cleanliness and neatness are essential.
- ... make sure that all seal rings and gaskets are intact.
- ... exchange spring washers whenever necessary.
- ... avoid unnecessary dismantling of ball bearings.
- ... follow the directions given in chapter L for assembly of ball and roller bearings.
- ... round nuts should be tightened with a spanner and locked with lock washers.
- ... the worm-gear housing should be cleaned and filled with clean oil after any work that may have introduced dirt.
- ... follow the directions for cleaning and overhaul in chapter L and the directions for lubrication in chapter H.

| ng        |
|-----------|
| <b>a</b>  |
|           |
| llager    |
| plett     |
|           |
|           |
| ıllager   |
|           |
| plett     |
|           |
|           |
|           |
| igt lager |
|           |

S91001E,S-3 (4226-1; 3720-3960 r/m)

P

DISMANTLING. ASSEMBLY



Exchange of worm wheel only

- 1. Drain off the oil.
- 2. Remove the tachometer cap.

Remove the protecting cap (if any), bearing shield etc. according to illustration on foregoing page. Observe any directions in the following text.


Note. The motor need not be removed.

Complete dismantling

- 1. Drain off the oil.
- 2. Remove the tachometer cap.
- 3. Disconnect the electric wires from the terminal block in the frame.
- 4. Remove the motor (together with the motor adapter).

Remove the protecting cap (if any), bearing shield etc. according to illustration on foregoing page. Observe any directions in the following text.

Bearing shield



To detach the bearing shield from the frame use two of its screws, screwing them into the two threaded holes of the shield.


P

# (Dismantling. Assembly)

Angular contact ball bearings



The bearings for worm wheel and spacing sleeve are single-row angular-contact ball bearings. When mounting them it is essential that they should be turned in the direction shown in the illustration below. The symbol  $\otimes$  indicates the stamped side of the inner ring. Heat the bearings in oil before fitting them on the worm wheel, and on the spacing sleeve respectively.




Seal washer

The seal washer is pulled out by means of two special screws included in the set of tools.


To retain the springs of the washer during mounting apply a little consistent grease to them.

Exchange of conveyor pulley or worm wheel shaft Spacing sleeve

The spacing sleeve (with the bearing) is pulled off from the worm wheel shaft by means of a special screw included in the set of tools.




Dismantling



Exchanging the gear rim of worm wheel nave


#### Dismantling



Put the worm wheel on a wooden base. Remove the screws.


Using a piece of wood as an intermediary, knock the gear rim off the nave with powerful blows distributed evenly all around the rim.

#### Assembly



Fit one guiding screw as above.


Heat the gear rim in a heating cabinet.




Fit the rim on the nave.

Tighten the screws Remove the guiding screw. while the rim is hot.

Test-tighten screws when rim has cooled down.



534201-Z (4225-1,4226-1)





| Ref.   | Part No.<br>Deinr.     | Qty.<br>Ant. | Part name                                   | Benämning                |
|--------|------------------------|--------------|---|--------------------------|
|        | 2211722-24             | 3            | Screw                                       | Skruv                    |
| 1 2    | 526198-03              | 1            | Top shield                                  | Skyddsplåt               |
| 3      | 2211724-22             | 6            | Screw                                       | Skruv                    |
| 4      | 526196-02              | 1            | Protecting cap                              | Skyddskåpa               |
|        | 000410 51              | 1            | Seal ring                                   | Tätningsring             |
| 5      | 223412-51              | 6            | Screw                                       | Skruv                    |
| 6      | 2210947-23             |              | Washer                                      | Bricka                   |
| 7<br>8 | 223101-50<br>223412-17 | 1            | Seal ring                                   | Tätningsring             |
| 0      | Majara.                |              | [m-1] 하 - [m-14 4+ [1941] 남양교육하             | Skyddskrage              |
| 9      | 526197-03              | 1            | Throw-off collar                            | Lock                     |
| 10     | 533512-02              | 1            | Cover                                       | Oljefläkt (vänstergänga) |
| 11     | 533414-02              | 1            | Oil deflector (left-h.thr.)                 |                          |
| 12     | 223412-42              | 2            | Seal ring                                   | Tätningsring             |
| 1,0    | 70346                  | 12           | Buffer                                      | Buffert                  |
| 13     | 180                    | 12           | Spring                                      | Fjäder                   |
| 14     | 66191<br>72473         | 12           | Washer                                      | Bricka                   |
| 15     | 528776-01              | 12           | Plug  | Propp                    |
| 16     | 528770-01              | 12           | * 148 a 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 |                          |
| 1,,,   | 71072                  | 1            | Conveyor                                    | Medbringare              |
| 17     | 71973                  | i            | Self-aligning ball                          | Sfäriskt kullager        |
| 18     | 69843                  | 1            | bearing (SKF 2309M)*                        | (SKF 2309M)*             |
|        | <b>72000</b>           | 1            | Intermediate washer                         | Mellanläggsbricka        |
| 19     | 73988                  | 1 1          | Lock washer                                 | Låsbricka                |
| 20     | 66076                  | •            | (SKF MB9)                                   | (SKF MB9)                |
|        |                        |              | Round nut                                   | Rundmutter               |
| 21     | 67476                  | 1            | (SKF KM9)                                   | (SKF KM9)                |
|        |                        | 1            | Wear ring                                   | Slitring                 |
| 22     | 533417-01              | 1 1          | Spring support                              | Fjäderhållare            |
| 23     | 533418-01              | 20           |   | Fjäder                   |
| 24     | 70340                  | 20           | Spring                                      |                          |
| 25     | 66312                  | 1            | Round nut                                   | Rundmutter               |
|        |                        |              | (SKF KM14)                                  | (SKF KM14)               |
| 26     | 66313                  | 1            |   | Låsbricka                |
|        |                        |              | (SKF MB 14)                                 | (SKF MB 14)              |
| 27     | 223642-45              | 1            | Snap ring                                   | Spårring                 |
| 28     | 69850                  | 2            | Angular contact ball                        | Vinkelkontaktkullager    |
| 29     |                        |              | bearing (SKF 7214BM)*                       | (SKF 7214BM)*            |
| 30     | 534143-01              | 1            | Spring casing                               | Fjäderhus                |
| 31     | 534143-01              | i            |   | Distanshylsa             |
| 32     | 65187                  | li           | Rigid ball bearing                          | Spårkullager             |
| 1 34   | 02101                  | _            | (SKF 6014M)*                                | (SKF 6014M)*             |
| 33     | 50 Hz:                 | 1            | Worm  | Snäcka                   |
|        | 534275-09              |              |   |                          |
|        | 60 Hz:                 |              |   |                          |
|        | 534275-13              | _            |   | 12.1. 아 독취 시기 중 가능함      |
|        | 52555/ 01              | 1            | Spindle                                     | Spindel                  |
| 34     | 535556-01              | 1            | Dpinate                                     |                          |
|        |                        |              |   |                          |
|        |                        |              | * or equivalent bearing                     | * eller likvärdigt lager |
|        |                        |              | of other make.                              | av annat fabrikat.       |
| 1      |                        |              | 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0. 0    | 41221/70                 |

S91008E,S -2 (4226-1; 3720-3960 r/m) (1231678)




| Ref.     | Part No.<br>Delnr.     | Qty.<br>Ant. | Part name   | Benämning  |
|----------|------------------------|--------------|---|--|
| 35<br>36 | 533413-01<br>233211-49 | 1            | Lock ring Rigid ball bearing (SKF 6315M)*                 | Låsring<br>Spårkullager<br>(SKF 6315M)*                  |
| 37<br>38 | 533415-01<br>62763     | 1<br>12      | Spacing sleeve<br>Spring                                  | Distanshylsa<br>Fjäder                                   |
| 39<br>40 | 533412-01<br>233215-03 | 1<br>1       | Spring support Angular contact ball bearing (SKF 7315BM)* | Fjäderhållare<br>Vinkelkontaktkullager<br>(SKF 7315 BM)* |
| 41<br>42 | 533411-01<br>533416-01 | 1            | Ball bearing housing Stop ring                            | Kullagerhus Stoppring                                    |
| 43       | 221545-02              | 2            | Set screw   | Stoppskruv   |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              |   |  |
|          |                        |              | * or equivalent bearing of other make.                    | * eller likvärdigt lager<br>av annat fabrikat.           |

BOWL SPINDLE

DISMANTLING ASSEMBLY Always dismantle and assemble the bowl spindle parts in the sequence shown in the preceding perspective drawing, observing any directions given below. Use the special tools.


After assembly check the height positions - see chapter L.



The bearings shown in the adjoining illustration are single-row angular-contact ball bearings.

They must absolutely be mounted so as to face in direction shown in the figures.


The symbol  $\bigotimes$  in the illustration indicates the stamped side of the inner ring.





Before lifting the bowl spindle out of the frame, preferably loosen the plugs in the bearing housing as well as the bearing housing lock ring.


When mounting tighten the plugs and lock ring firmly.

P











Assembly




(Dismantling, assembly)

Bearings of spring casing

Dismantling




Assembly




Top bearing

Dismantling



Assembly



To be heated in oil



#### MOUNTING THE MOTOR

The speed prescribed for the ingoing shaft of the machine (the worm wheel shaft) and which must on no conditions be exceeded, is stamped on the type plate of the machine. The worm gear ratio is suited to this speed.

Check the number of revolutions by means of the revolution counter after installation and after exchange of motor.

For particulars concerning power requirement and speed see chapter C.

#### Coupling pulley

When the machine is delivered with motor, the pulley has been fastened in its correct position on the motor shaft. Score the position of the pulley before loosening it from the motor shaft. The axial play for the elastic plate — measurement "a" in illustration — should be about 2 mm (5/64").

When finishing a predrilled coupling pulley, the tolerance H7-J6 according to ISO should be applied.

## Connection to mains


Connect the motor to mains so that the bowl will rotate CLOCKWISE:

The machine must never be started unless the bowl is placed on the spindle and the worm gear housing contains the prescribed quantity and quality of lubricating oil.


#### MOTOR

See separate instruction book.

Wiring diagrams for machine with rigid coupling and special motor are shown in chapter G.



(Mounting the motor)



Stud bolt (6)
-- 2216261-02

Guide ring \_\_ 529531-02 Sealing strip -- 532072-01 Coupling pulley\* \_\_ 534184-80 /534183-01 × Set screw \_\_ 221585-18 Motor adapter -- 529522-02 Washer (6) -- 223101-50 Nut (6) -- 72946 Stud bolt (4)

Nut (4)
-- 2218043-05

-- 2216321-16

Motor (make Brook, type C365D, three-phase motor)\*\*


Washer (4)
-- 223134-01
Attachment
-- 529532-80
Washer (2)
Nut (2)

Motor hood -- 529529-80

Cap nut -- 72947

Dismantling. Assembly
When dismantling first disconnect
the electric cables from the terminal block in the frame, then
dismantle the parts according to
the figure. If the coupling pulley
should be loosened — see "Coupling pulley" in this chapter.

After assembly remove the brake cap and check that there is a play at the elastic plate.



The part No. refers to the solely prebored pulley. If a ready-bored pulley is wanted, state also, besides the above part No., the motor shaft measurements b, c and D.

\*\*


When ordering state also the output, frequency and voltage.

\* For MRPX 418TGV


#### FRAME PARTS



- 1 Cyclone
- 2 Paring disc device for operating liquid
- 3 Flushing device for solids cover
- 4 Drain tube
- 5 Ventilation bend
- 6 Bottom bearing housing
- 7 Foundation plate and vibration dampers
- 8 Oil drain
- 9 Oil gauge glass
- 10 Electric connection
- 11 Revolution counter and
   tachometer\*. Oil filling.
- 12 Brake
- 13 Inlet bend for operating liquid
- \* For machine equipped for remote speed indication:
  Revolution counter and speed sensor (pulse transmitter).



FRAME PARTS S



# FLUSHING DEVICE for SLUDGE COVER



Nozzle -- 785868-1



Packing -- 516281-10



Frame ring



Nut -- 785877-1



Packing -- 68937



Hose nipple -- 252613-12



Nut -- 521136-1

# VENTILATION BEND



Packing -- 71068



Bend



Stud bolt --2216241-17



Washer -- 223101-34



# OIL DRAIN



Packing -- 223316-5



Screw -- 526189-1


#### OIL GAUGE GLASS




Packing -- 528723-01



Glass -- 38685





Fixing ring -- 523215-02

Screw (3) -- 2211722-28

### HINGED BOLT (12)



Cap nut -- 72956




Clamping shoe -- 785865-2



Hinged bolt -- 528104-1


Ball

\_\_ 233281-1



# S

# PARING DISC DEVICE for OPERATING LIQUID



♠ = Holes for operating liquid


The distributing ring rotates, the other parts are non-moving.


Dismantling
For dismantling the bowl
see chapter I. The distributing ring is fastened to
the bowl body by screws.
These screws must be removed before the bowl body
can be lifted off from the
spindle.

Take out the distributing cover and dismantle the parts in the sequence appearing from the illustration.

Cleaning
Make sure the parts (particularly all holes and channels) are carefully cleaned — for cleaning agents see chapter L.


Assembling
Check the height position
of the paring disc after
assembling — see chapter L.
Supply operating liquid and
check throughflow according to directions in
chapter L.





Exchange of lining
Release the brake and remove the cap. Note that
the screws are slotted at
both ends (use an angle
driver). Fasten the cap to
the machine with the handle
pointing downward.

Dismantling. Assembling




Clamp the cap in a screw vice, apply the brake, and remove the handle. See that cap, handle, and brake shoe are turned as shown by the arrows in the figure. Fasten the cap to the machine with the handle pointing downward.

(Revolution Counter and Tachometer, page 2)

REVOLUTION COUNTER

Speed checking



Speed particulars — see chapter C. Count the number of revolutions during one minute.

Assembling

When mounting lubricate shaft and gear wheel with oil of the type used in the gear housing. Direct the gear wheel correctly — pin an hole are tapered. In case of play ream the hole (conicity 1:50).

Make sure the lipseal ring is directed according to the illustration and knock it carefully into its seat.

TACHOMETER Dismantling


Speed particulars — see chapter C.

Unscrew the lock ring and remove the protecting glass. Lift out the tachometer. Remove the gear wheel and knock out the shaft towards the tachometer side.

Assembling

Lubricate shaft and gear wheel with oil of the same type as used in the gear housing. Push home the shaft and secure the gear wheel with the taper pin. Direct the gear wheel correctly — pin and hole are tapered. In case of play ream the hole (conicity 1:50).

Direct the lipseal ring according to the illustration, slip it onto the shaft and knock it carefully into its seat.



| Ref. | Part No.<br>Delnr.   | Qty.<br>Ant. | Part name                   | Benämning   |
|------|----------------------|--------------|-----------------------------|---|
|      |                      |              | REVOLUTION COUNTER          | VARVRÄKNARE och   |
| -    |                      | -            | and SPEED SENSOR            | VARVTALSGIVARE (för                                       |
|      |                      | 1.55         | (for machine intended for   | maskin avsedd för fjärr-                                  |
|      |                      |              | remote indication)          | indikering)   |
| 1    | 528747-01            | 1            | Lock ring                   | Låsring   |
| 2    | 536956-01            | 1            | Cover                       | Lock  |
| - 3  | 221115-12            | 2            | Screw                       | Skruv   |
| 4    | 536961 - 02          | 1            | Terminal strip              | Kopplingssprint   |
| 5    | 536955-01            | 1            | Sensor (with electric wire) | Givare (med elledning)                                    |
| 6    | 536954-01            | 1            | Disc                        | Bricka  |
| 6a   | 980874-02            | 1            | Sealing sleeve              | Tätningshylsa   |
| 7    | 221893-01            | 1            | Nut                         | Mutter  |
| 8    | 536953-01            | 1            | Cog wheel                   | Tandhjul  |
| 9    | 223521-08            | 1            | Lipseal ring                | Läpptätningsring  |
| 10   | 518474-01            | 1            | Stop ring                   | Stoppring   |
| 11   | 222116-07            | 1            | Slotted pin                 | Räffelpinne   |
| 12   | 532119-01            | 1            | Shaft                       | Axel  |
| 1.3  | 536952-01            | 1            | Bushing                     | Bussning  |
| 14   | 18085                | 1            | Sealing sleeve              | Tätningshylsa   |
| 15   | 2234121 - 37         | 1            | Seal ring                   | Tätningsring  |
| 16   |                      | 1            | Cap                         | Kåpa  |
| 16a  | 2210942-37           | 6            | Screw                       | Skruv   |
| 17   | 528732-01            | 1            | Packing                     | Packning (SKE KMO)  |
| 18   | 67476                | 1            | Round nut (SKF KM9)         | Rundmutter (SKF KM9)                                      |
| 19   | 526698-01            | 1            | Gear wheel                  | Kugghjul  |
| 20   | 69226                | 1            | Taper pin                   | Konisk pinne  |
| 21   | 526694-03            | 1            | Collar                      | Krage   |
| 22   | 223521 - 08          | 1            | Lipseal ring                | Läpptätningsring  |
| 23   | 526693-04            | 1            | Shaft                       | Axel  |
| 24   | 67542                | 1            | Snap ring                   | Spårring  |
| 25   | 528743-01            | 1            | Bushing                     | Bussning  |
| 26   | 223434-02            | 1            | Packing                     | Packning  |
| 27   | 67473                | 1            | Round nut (SKF KM6)         | Rundmutter (SKF KM6)                                      |
| 28   | 69214                | 1            | Gear wheel                  | Kugghjul  |
| 29   | 69226                | 1            | Taper pin                   | Konisk pinne  |
| 30   | 526189-01            | 1            | Screw (oil supply)          | Skruv (oljepåfyllning)<br>  Packning                      |
| 31   | 223316-05            | 1            | Packing                     | Packing   |
|      |                      |              |                             | 마이트 이 전 경험을 보고하다 왔어요요? 기록<br>  현실 이 기를 기록 보았다. 기급이 되고 있다. |
|      |                      |              |                             |   |
|      |                      |              |                             |   |
|      |                      |              |                             |   |
|      |                      |              |                             |   |
|      |                      |              |                             |   |
|      | Lillian val. Attoina |              |                             |   |


S93084E,S-3 (536962-80) (Ref. 1231981)

S

(Revolution counter and speed sensor)

REVOLUTION COUNTER

Speed checking




Speed particulars — see chapter C. Count the number of revolutions during one minute.

Assembling

When mounting lubricate shaft and gear wheel with oil of the type used in the gear housing. Direct the gear wheel correctly — pin an hole are tapered. In case of play ream the hole (conicity 1:50).

Make sure the lipseal ring is directed according to the illustration and knock it carefully into its seat.

SPEED SENSOR Assembling



Lubricate shaft and gear wheel with oil of the same type as used in the gear housing. Push home the shaft and secure the gear wheel with the taper pin. Direct the gear wheel correctly — pin and hole are tapered. In case of play ream the hole (conicity 1:50).


Direct the lipseal ring according to the illustration, slip it onto the shaft and knock it carefully into its seat.

After any dismantling which can affect the play indicated in the figure, the play must be readjusted. An impression of the play can be made in modelling clay. PNEUMATIC BRAKE (for machine designed for remote control).


The piston 6 presses the brake shoe lining 11 against the coupling pulley when compressed air is fed to the cylinder 2. Suitable air pressure is 5-6 bar (72-87 psi).

PNEUMATISK BROMS (för maskin avsedd för fjärrstyrning).


Då tryckluft tillföres cylindern 2 pressar kolven 6 skoningen 11 mot medbringar - skivan. Lämpligt lufttryck 5-6 bar.



| Ref.             | Part No.<br>Delnr.  | Qty.<br>Ant. | Part name  | Benämning   |
|------------------|---|--------------|--|---|
| 1<br>2<br>3<br>4 | 2210942-37<br><br>528732-01<br>535207-01                      | 6 1 1 2      | Screw Cap/cylinder Packing Set screw                         | Skruv<br>Kåpa/cylinder<br>Packning<br>Stoppskruv              |
| 5<br>6<br>7<br>8 | 223406-27<br>535202-01<br>2×6×14-83<br>535206-01              | 1 1 1 1 1 1  | O-ring<br>Piston<br>Spring<br>Gland                          | O-ring<br>Kolv<br>Fjäder<br>Gland                             |
| 9<br>10<br>11    | 535200-01<br>535204-01<br>67960<br>65227<br>8341<br>537602-81 | 1 1 2        | Brake shoe Slotted pin Lining (with screws) Screw Brake shoe | Bromsplatta Räffelpinne Skoning (med skruvar) Skruv Bromsback |








| Ref.              | Part No.<br>Delnr.                        | Qty.<br>Ant.     | Part name  | Benämning   |
|-------------------|---|------------------|--|---|
| -                 | 532420-82                                 | 1                | REMIXING DEVICE, complete                                | ATERBLANDNINGS-<br>ANORDNING, komplett                        |
| 1<br>2<br>3<br>3a | 190608<br>526749-81<br>191631<br>190613   | 4<br>1<br>1<br>1 | Packing<br>Return pipe<br>Three-way cock<br>Coupling nut | Packning<br>Återledningsrör<br>Trevägskran<br>Kopplingsmutter |
| 3b<br>4<br>5<br>6 | 190627<br>31317-0869-1<br>71068<br>191011 | 1<br>1<br>2<br>1 | Sleeve<br>T-piece<br>Packing<br>Nipple                   | Hylsa<br>T-rör<br>Packning<br>Nippel                          |
| 1<br>5            | 190608<br>71068                           | 4 2              | Spare parts Packing Packing                              | Reservdelar Packning Packning                                 |
|                   |   |                  |  |   |







|                                 | 533395-80<br>533395-81 |      |     |                | 0 |
|---------------------------------|------------------------|------|-----|----------------|---|
| FLOW METER                      | 533395-82<br>533395-83 | 6500 | 1/h | (SMS)<br>(SMS) |   |
| (FOI connection to animal of it | 533395-84              | 450  | 1/h | (SMS)          |   |
|                                 | 533395-85<br>533395-86 | 300  | -/  | (IDF)          |   |

| Pos. | Part No. Description Detalj nr. |                | Benämning         | Qty.<br>Ant. |  |
|------|---------------------------------|----------------|-------------------|--------------|--|
| 1    |                                 | Hand nut       | Rattmutter        |              |  |
| la   | 223406-16                       | Seal ring      | Tätningsring      |              |  |
| 2    | 11705                           | Rubber packing | Gummipackning     | 2            |  |
| 3    |                                 | Scale holder   | Skalhållare       |              |  |
| 4    | 43402                           | Scale          | Skala             |              |  |
| 5    | 221121-48                       | Screw          | Skruv             | 2            |  |
| 6    | 533407-01                       | Glass tube     | Glasrör           |              |  |
| 7    | 11707                           | Packing screw  | Packningsskruv    |              |  |
| 8    | 785933-01                       | Washer         | Bricka            |              |  |
| 9    |                                 | Gland          | Gland             | Topic of     |  |
| 10   |                                 | Outlet piece   | Utloppsvinkel     |              |  |
| 11   | See table<br>Se tabell          | Measuring rod  | Mätstång          |              |  |
| 12   | 516281-13                       | Packing        | Packning          |              |  |
| 13   | 2211722-13                      | Screw          | Skruv             |              |  |
| 14   | See table                       | Packing        | Packning          |              |  |
| 15   | Se tabell                       | Nipple         | Nippel            |              |  |
| 16   |                                 | Inlet piece    | Inloppsvinkel     |              |  |
| 17   | 223537-02                       | Packing collar | Tätningsmanschett |              |  |
| 18   | 533546-80                       | Valve spindle  | Ventilspindel     |              |  |
| 18a  | 223404-04                       | Seal ring      | Tätningsring      |              |  |
|      |                                 | Spare parts    | Reservdelar       |              |  |
| 2    | 11705                           | Packing        | Packning          | 2            |  |
| 6    | 533407-01                       | Glass tube     | Glasrör           | 2            |  |
| 12   | 516281-13                       | Packing        | Packning          | _            |  |
| 14   |                                 | Packing        | Packning          | 2            |  |
| 17   | 223537-02                       | Packing collar | Tätningsmanschett | 2            |  |

| Assembly No.<br>Komplettnummer | Pos ll    | Pos 14       | Pos 15       |
|--------------------------------|-----------|--------------|--------------|
| 533395-80                      | 528345-80 | 190608       | 190641       |
| 533395-81                      | 528345-81 | 190608       | 190641       |
| 533395-82                      | 528345-82 | 190608       | 190641       |
| 533395-83                      | 528345-83 | 190608       | 190641       |
| 533395-84                      | 11823     | 190608       | 190641       |
| 533395-85                      | 528345-80 | 31319-0031-1 | 31319-0007-1 |
| 533395-86                      | 528345-81 | 31319-0031-1 | 31319-0007-1 |

## Replacements:

| Meter, No. (mätare nr.) | Replaces meter No. (ersätter mätare nr) |
|-------------------------|---|
| 533395-80, -81          | 526729-80, -81                          |
| 533395-82               | 526729-82                               |
| 533395-83, -84          | 526729-83,-84                           |
| 533395-85,-86           | 785900-80, -81                          |



The table shows the approximate flow through the meter in tests with water. Values for the fat content or contents in question must be established on the spot.


Tabellen visar den ungefärliga volymströmmen genom mätaren vid försök med vatten. Värden för den eller de fetthalter som kommer i fråga, måste fastställas på platsen.

| Meter     | Graduation | Flow    | Flöde    |
|-----------|------------|---------|----------|
| Mätare    | Gradering  | liter/h | UK gal/h |
| 533395-80 |            | 860     | 190      |
| 533395-85 | 2          | 1100    | 240      |
|           | 3          | 1500    | 330      |
|           | 4          | 1900    | 420      |
| 533395-81 | <b>1</b>   | 100     | 22       |
| 533395-86 | 2          | 180     | 40       |
|           | 3          | 280     | 62       |
|           | 4          | 340     | 75       |
| 533395-83 |            | 1500    | 330      |
|           | 2          | 2000    | 440      |
|           | 3          | 2500    | 550      |
|           | 4          | 2900    | 640      |
| 533395-84 | 1          | 200     | 44       |
|           | 2          | 260     | 57       |
|           | 3.00       | 330     | 73       |
|           | 4          | 380     | 84       |

X

REGULATING VALVE without connecting parts REGLERINGSVENTIL utan kopplingsdelar

74414 517697-80




| Pos. | Part No.<br>Detalj nr. | Description             | . Benämning            | Qty.<br>Ant. |
|------|------------------------|-------------------------|------------------------|--------------|
| 1.   |                        | Valve housing           | Ventilhus              |              |
| 2.   | 74421                  | Valve cone              | Ventilkägla            |              |
| 3.   | 74494                  | Packing collar          | Tätningsmanschett      |              |
| 4.   | 74425                  | Valve bushing           | Ventilbussning         |              |
| 5.   | 190613                 | Coupling nut            | Kopplingsmutter        |              |
| 6.   | 518469-03              | Hand wheel              | Vred                   |              |
|      |                        | Connecting parts        | Anslutningsdelar       |              |
| 7.   | 71068                  | Packing                 | Packning               | 2            |
| 8.   | 190630                 | Sleeve (even pipes)     | Hylsa (släta rör)      |              |
|      |                        | 51 mm, 2"               | 51 mm, 2 <sup>11</sup> |              |
| 9.   | 190644                 | Nipple (even pipes)     | Nippel (släta rör)     |              |
|      |                        | 51 mm, 2"               | 51 mm, 2"              |              |
| 10.  | 72234                  | Sleeve (threaded pipes) | Hylsa (gängade rör)    |              |
|      |                        | R 1 1/2"                | R 1 1/2"               |              |
| 11.  | 72226                  | Nipple (threaded pipes) | Nippel (gängade rör)   |              |
|      |                        | R 1 1/2"                | R 1 1/2"               |              |
| 12.  | 190616                 | Coupling nut            | Kopplingsmutter        |              |
|      |                        | Spare part              | Reservdel              |              |
| 3.   | 74494                  | Packing collar          | Tätningsmanschett      |              |


S90822S, E-2 (3969, 4030)


1231648

## SUPPLEMENT



\* Not delivered if visual indication only is wanted.






Installation

Mount the sensor on the machine or in its proximity. Observe that the screened wire between sensor and amplifier must be drawn in a steel tube with the steel spiral nearest to the sensor. Other wires must not be drawn through the same tube. Amplifier and wires must not be mounted near high current cables or other magnetic fields.

(Remote speed indication equipment, page 3)

Electric connection



\* Change-over of the starter from star(Y) connection to delta (D) connection takes place by means of the terminals 4 and 5. The contact between the terminals is then broken.

Trimming

Amplifier unit

## Connecting - up:


- 1. Voltage (220V) terminals 1 and 2.
- 2. Speed indicator terminals 6 and 7.
- 3. Sound generator terminals 15 and 16.
- 4. If oscilloscope is provided, connect it over R4

   see diagram for circuit card 530639-80.

  Note. Output voltage from sound generator is
  30-50 mV. Oscilloscope set to 5 V/cm.

(Remote speed indication equiment, page 4)

Speed indicator




Adjust the voltage by turning the screw for the potentiometer (P11) so that the speed indicator shows 1420 - 1460 r.p.m. (for 50 Hz) or 1700 - 1750 r.p.m. (for 60 Hz).at a frequency of 290 Hz for the sound generator — see type plate of motor.

Observe that the speed indicator will show slightly more than 0 r.p.m. when the machine is at rest, due to leakage current in the amplifier.

Note. The frequency of the local oscillator is reduced by turning the adjusting screw on the potentiometer clockwise and increased by turning the screw anti-clockwise.

Impulse (e.g. for YD switch)




## Action:

- Short-circuit the terminals 8-9 (starting contact) and 12-13 (K3 is alive).
- 2. Set the sound generator to 280-285 Hz = 93-94% of full speed.
- 3. Adjust the local oscillator by turning the screw for potentiometer P4 until K1 is dead. If there is no reaction, screw P5 some turns anti-clockwise and repeat the adjustment with P4.

AMPLIFIER UNIT - Connection diagram for mounting plate. The illustration.

shows the soldering side.



AMPLIFIER UNIT - Dimensioned sketch.

