

Technician's Handbook





Safety Notices

Read these precautions to prevent personal injury:

- Read this manual thoroughly before operating, installing or performing maintenance on the equipment. Failure to follow instructions in this manual can cause property damage, injury or death.
- Routine adjustments and maintenance procedures outlined in this manual are not covered by the warranty.
- Proper installation, care and maintenance are essential for maximum performance and trouble-free operation of your equipment.
- Visit our website www.manitowocice.com for manual updates, translations, or contact information for service agents in your area.
- Installation and repairs are to be performed by properly trained technicians aware of the dangers of dealing with high voltage electricity and refrigerant under pressure. The technician must also be certified in proper refrigerant handling and servicing procedures. All lockout and tag out procedures must be followed when working on this equipment.
- This equipment is intended for indoor use only. Do not install or operate this equipment in outdoor areas.
- As you work on this equipment, be sure to pay close attention to the safety notices in this handbook.
 Disregarding the notices may lead to serious injury and/or damage to the equipment.
- Never use a high-pressure water jet for cleaning on the interior or exterior of this unit. Do not use power cleaning equipment, steel wool, scrapers or wire brushes on stainless steel or painted surfaces.

Follow these electrical requirements during installation of this equipment.

- All field wiring must conform to all applicable codes of the authority having jurisdiction. It is the responsibility of the end user to provide the disconnect means to satisfy local codes. Refer to rating plate for proper voltage.
- This appliance must be grounded.
- This equipment must be positioned so that the plug is accessible unless other means for disconnection from the power supply (e.g., circuit breaker or disconnect switch) is provided.
- Check all wiring connections, including factory terminals, before operation. Connections can become loose during shipment and installation.
- For a cord-connected appliance, the following must be included:
 - Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
 - Unplug from outlet when not in use and before servicing or cleaning.
 - Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner.
 Contact the nearest authorized service facility for examination, repair, or electrical or mechanical adjustment.

Follow these precautions to prevent personal injury during installation of this equipment:

- Installation must comply with all applicable equipment fire and health codes with the authority having jurisdiction.
- To avoid instability the installation area must be capable of supporting the combined weight of the equipment and product. Additionally the equipment must be level side to side and front to back.
- Remove all removeable panels before lifting and installing and use appropriate safety equipment during installation and servicing. Two or more people are required to lift or move this appliance to prevent tipping and/or injury.
- Do not damage the refrigeration circuit when installing, maintaining or servicing the unit.
- Connect to a potable water supply only.
- This equipment contains refrigerant charge.
 Installation of the line sets must be performed by a properly trained and EPA certified refrigeration technician aware of the dangers of dealing with refrigerant charged equipment.

Follow these precautions to prevent personal injury while operating or maintaining this equipment.

- Legs or casters must be installed and the legs/casters
 must be screwed in completely. When casters
 are installed the mass of this unit will allow it to
 move uncontrolled on an inclined surface. These
 units must be tethered/secured to comply with all
 applicable codes. Swivel casters must be mounted
 on the front and rigid casters must be mounted on
 the rear. Lock the front casters after installation is
 complete.
- Refer to nameplate to identify the type of refrigerant in your equipment.
- Only trained and qualified personnel aware of the dangers are allowed to work on the equipment.
- Read this manual thoroughly before operating, installing or performing maintenance on the equipment. Failure to follow instructions in this manual can cause property damage, injury or death.
- Crush/Pinch Hazard. Keep hands clear of moving components. Components can move without warning unless power is disconnected and all potential energy is removed.
- Moisture collecting on the floor will create a slippery surface. Clean up any water on the floor immediately to prevent a slip hazard.
- The on-site supervisor is responsible for ensuring that operators are made aware of the inherent dangers of operating this equipment.
- Do not store or use electrical appliances inside the ice machine or ice storage areas.

Follow these precautions to prevent personal injury while operating or maintaining this equipment.

- Objects placed or dropped in the bin can affect human health and safety. Locate and remove any objects immediately.
- Do not damage the refrigeration circuit when installing, maintaining or servicing the unit. Never use sharp objects or tools to remove ice or frost.
- Do not use mechanical devices or other means to accelerate the defrosting process.
- When using cleaning fluids or chemicals, rubber gloves and eye protection (and/or face shield) must be worn.

A DANGER

Do not operate equipment that has been misused, abused, neglected, damaged, or altered/modified from that of original manufactured specifications. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision concerning use of the appliance by a person responsible for their safety. Do not allow children to play with, clean or maintain this appliance without proper supervision.

A DANGER

Follow these flammable refrigeration system requirements during installation, use or repair of this equipment:

- Refer to nameplate ice machine models may contain up to 500 grams of R290 (propane) refrigerant. R290 (propane) is flammable in concentrations of air between approximately 2.1% and 9.5% by volume (LEL lower explosion limit and UEL upper explosion limit). An ignition source at a temperature higher than 470°C is needed for a combustion to occur.
- To minimize the risk of ignition due to improper installation, replacement parts or service procedures, only refrigeration technicians with flammable refrigerant training who are aware of the dangers of dealing with high voltage electricity and refrigerant under pressure are allowed to work on this equipment.
- All replacement parts must be like components obtained from the equipment manufacturers authorized replacement part network.
- This equipment must be installed in accordance with the ASHRAE 15 Safety Standard for Refrigeration Systems.
- This equipment can not be installed in corridors or hallways of public buildings.
- This equipment contains high voltage electricity and refrigerant charge. Shorting electrical wires to refrigeration tubing may result in an explosion. All electrical power must be disconnected from the system before servicing the system. Refrigerant leaks, can result in serious injury or death from explosion, fire, or contact with refrigerant or lubricant mists.

A DANGER

Follow these precautions to prevent personal injury during use and maintenance of this equipment:

- It is the responsibility of the equipment owner to perform a Personal Protective Equipment Hazard Assessment to ensure adequate protection during maintenance procedures.
- Do Not Store Or Use Gasoline Or Other Flammable Vapors Or Liquids In The Vicinity Of This Or Any Other Appliance. Never use flammable oil soaked cloths or combustible cleaning solutions for cleaning.
- All covers and access panels must be in place and properly secured when operating this equipment.
- Risk of fire/shock. All minimum clearances must be maintained. Do not obstruct vents or openings.
- Failure to disconnect power at the main power supply disconnect could result in serious injury or death. The power switch DOES NOT disconnect all incoming power.
- All utility connections and fixtures must be maintained in accordance with the authority having jurisdiction.
- Turn off and lockout all utilities (gas, electric, water) according to approved practices during maintenance or servicing.
- Units with two power cords must be plugged into individual branch circuits. During movement, cleaning or repair it is necessary to unplug both power cords.

We reserve the right to make product improvements at any time. Specifications and design are subject to change without notice.

Additional Safety Notices for Arctic Pure® Pro Water Filtration Systems

Arctic Pure® Pro Water Filters are manufactured by Pentair Everpure for Manitowoc, 1040 Muirfield Drive, Hanover Park, IL 60133. PH: 630.307.3000

A Warning

DO NOT use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used on disinfected waters that may contain filterable cysts.

DO NOT use a torch or other high temperature sources near filter or cartridge. DO NOT solder plumbing connections.

Notice

Passing hot water through the water filter may seriously damage housings and/or cartridges and affect warranty coverage.

Do not disassemble manifold head. No user serviceable parts are available. The entire manifold head is the only available replacement part.

Caution

If the cartridge is dropped from a height greater than 3 feet (1 m), inspect the outer casing. DO NOT USE if the cartridge case is cracked or if there is any evidence of cracking.

Not for residential use. For foodservice applications only.

The Arctic Pure® Pro water filtration systems are designed to reduce coarse and fine particulate matter from the incoming potable water supply. Chlorine will be reduced in the water so as not to adversely affect the ice produced or the equipment components. Scale inhibitor is automatically fed into the water to inhibit the formation of scale on water solenoids and evaporator plates. The NSF mark indicates that these products have met certification requirements under the NSF/ANSI & CSA standards listed on the Performance Data Sheet.

Check for compliance with state and local laws and regulations. NSF/ANSI Standard 53 certified to reduce cysts such as Cryptosporidium and Giardia by mechanical means. EPA Est. No. 002623-IL-002.

'Bacteriostatic' indicates that the system limits the passage or growth of bacteria that may already exist in the incoming water. It does not mean that water leaving the system is safer to drink than water entering the system.

The contaminants or other substances removed or reduced by this water treatment system are not necessarily in your water.



Arctic Pure® Pro systems are tested and certified by NSF International against; NSF/ANSI 42, 53, 401, and/or CSA B483.1 for the reduction of claims specified on the Performance Data Sheet.




Table of Contents

General Information Model Numbers How to Read a Model Number Model/Serial Number Location Warranty LuminIce® II	. 22 . 22 . 23
Installation	
Location of Ice Machine	. 25
Installation Requirements	. 26
Ice Machine Clearance Requirements	. 27
Ice Machine Heat of Rejection	. 27
Leveling the Ice Machine	
Electrical Requirements	
Electrical Specifications	. 30
Water Service/Drains	
Water Supply	
Cooling Tower Applications	
Water Filter	
Installation	
Removal	. 37
Maintenance	
140/190/240/310 Series	
De-scaling and Sanitizing	. 39
Ice Machine Inspection	
Exterior Cleaning	
Cleaning Cycle Touch Pad Operation	. 40
De-scaling Procedure	. 42
Sanitizing Procedure	. 44
Remedial De-scaling Procedure	. 50
Air Filter and Air Condenser Maintenance	. 51
LuminIce® Bulb Maintenance	. 53
Bulb Replacement	
Water Filter Replacement	
Bin Removal	
Removal from Service/Winterization	. 56

	UDE0065/UDP0065 Series	
	De-scaling and Sanitizing Procedure	. 58
	De-scaling Procedure	. 58
	Sanitizing Procedure	
	Exterior Cleaning & Inspection	. 63
	Air Filter and Air Condenser Maintenance	
	Removal from Service/Winterization	. 65
	UDE0080/UDP0080 Series	
	De-scaling and Sanitizing Procedure	
	De-scaling procedure	
	Sanitizing Procedure	
	Exterior Cleaning & Inspection	
	Air Filter and Air Condenser Maintenance	. 76
	Removal from Service/Winterization	. 77
Oper	ation	
	140/190/240/310 Series - Operation	
	Touch Pad Operation	. 79
	U/UF Series	. 79
	UP Series	. 80
	Buttons & Icons	. 81
	Control Board Revisions	. 83
	Firmware Revisions	. 83
	U/UF Series	
	Ice Making Sequence of Operation	. 84
	Service Limits	
	Energized Parts Chart	. 89
	UP Series	
	Ice Making Sequence of Operation	. 91
	Service Limits	
	Energized Parts Chart	
	Operational Checks	
	Ice Thickness Check	
	Ice Thickness Adjustment	
	Minimum/Maximum Slab Weight	

UDE0065/UDP0065 Series - Operation	. 98
Ice Making Sequence of Operation	. 98
Energized Parts Chart	
Ice Thickness Control Dial Adjustment	101
Minimum/Maximum Slab Weight	
UDE0080/UDP0080 Series - Operation	103
Ice Making Sequence of Operation	103
Energized Parts Chart	105
Siphon System Check	107
Float Valve Check	108
Water Level Check	108
Water Level Check	109
Ice Thickness Probe Adjustment	110
Minimum/Maximum Slab Weight	. 111
Troubleshooting	
140/190/240/310 Series - Troubleshooting	113
Problem Checklist	
Control Board Test Mode	
Operating Ice Machine with Bin and	
Touch Pad Removed	116
Low Production, Long Freeze Cycle	121
Refrigeration Analysis Chart	
Ice Production Check	
Installation/Visual Inspection Checklist	132
Water System Checklist	
Ice Formation Pattern	135
Analyzing Discharge Pressure	137
Analyzing Suction Pressure	139
Harvest Valve	
Comparing Evaporator Inlet/Outlet	
Temperatures	147
Discharge Line Temperature Analysis	
Ice Machine Will Not Harvest	151

UDE0065/UDP0065 Series - Troubleshooting 155
Problem Checklist
Ice Machine Will Not Run159
Refrigeration Diagnostics
Ice Production Check161
Installation/Visual Inspection Checklist 163
Water System Checklist
Refrigeration Diagnostics 166
Flooding Expansion Valve Symptoms 167
Starving Expansion Valve/Low Refrigerant
Charge Symptoms167
Overcharged System Symptoms 167
Analyzing Ice Formation Pattern 168
Analyzing Discharge Line Temperature 168
Analyzing Suction Line Temperature 172
Comparing Evaporator Inlet/Outlet
Temperatures
Discharge Line Temperature Analysis 176
Harvest Valve178
UDE0080/UDP0080 Series - Troubleshooting 182
UDE0080/UDP0080 Series - Troubleshooting 182 Problem Checklist
Problem Checklist
Problem Checklist
Problem Checklist 182 Service Limits 184 Ice Machine Will Not Run 185 Safety Limit Feature 186
Problem Checklist 182 Service Limits 184 Ice Machine Will Not Run 185 Safety Limit Feature 186 Diagnosing Ice Thickness Control 191
Problem Checklist

Component Check Procedures

	Main Fuse	215
	Bin Switch	216
	Touch Pad	218
	Float Switches	220
	Water Trough Thermistor	222
	Bin Thermostat	
	Liquid Line Thermistor	225
	ON/OFF/WASH Toggle Switch	227
	Compressor Electrical Diagnostics	228
	Fan Cycle Control	230
	High Pressure Cutout Control	231
	Filter Driers	232
Refri	igerant Recovery/Evacuation	233
	Refrigerant Re-use Policy	235
	140/190/240/310 Series	236
	65/80 Series	239
	System Contamination Cleanup	242
Tota	System Refrigerant Charge	248
	UDE0065/UDP0065 & UDE0080/UDP0080.	248
	U0140/U0190/U0240/U0310	248
	UF0140/UF0190/UF0240/UF0310	249
	UP0140/UP0190/UP0240/UP0310	249

Charts

Cycle Times, 24 Hr. Ice Production and	
Refrigerant Pressure Charts25	51
UDE0065A 25	52
UDP0065A 25	54
UDE0080A	56
UDP0080A	59
U0140A/UF0140A 26	51
UP0140A26	55
U0190A/UF0190A 26	57
UP0190A26	59
U0240A/UF0240A	71
UP0240A27	73
U0240W/UF0240W	75
UP0240W	77
U0310A/UF0310A 27	79
UP0310A28	31
U0310W/UF0310W	33
11002101//	0 5

Diagrams

Wiring Diagrams 289
UP0140/UP0190/UP0240, UP0310 (50Hz) . 290
UP0310 (60 Hz)292
U0140/U0190/U0240
With J4 Thermistor Terminal 294
Before Thermistor Terminal
U0310 Wiring Diagram
With J4 Thermistor Terminal 298
Before J4 Thermistor Terminal 300
UDE0065/UDP0065302
UDE0080/UDP0080304
Electronic Control Boards 306
UF / UP Models306
U Models
With J4 Thermistor Terminal 308
Before J4 Thermistor Terminal 310
UDE0065/UDP0065312
UDE0080/UDP0080314
Tubing Schematics316
65 Series
80 Series &140 Series
190/240/310 Series

THIS PAGE INTENTIONALLY LEFT BLANK

General Information

Model Numbers


This manual covers the following models:

Self-contained	Self-contained	
Air-cooled	Water-cooled	
UD0065A	-	
UDE0065A	-	
UDP0065A	-	
UD0080A	-	
UDE0080A	-	
UDP0080A	-	
U0140A	U0140W	
U0140AE	U0140WE	
UF0140A	-	
UP0140A	-	
U0190A	-	
U0190AE	-	
UF0190A	-	
UP0190A	-	
U0240A	U0240W	
U0240AE	U0240WE	
UF0240A	UF0240W	
UP0240A	UP0240W	
U0310A	U0310W	
U0310AE	U0310WE	
UF0310A	UF0310W	
UP0310A	UP0310W	

POWER CORD OPTION:

- Z Cord without Plug
- B NEMA Plug (USA)
- F Schuko Plug (EU)
- G- 13A Blade (GBR)
- I Oblique V Blade (AUS)

How to Read a Model Number



A Warning

An ice machine contains high voltage electricity and refrigerant charge. Repairs are to be performed by properly trained refrigeration technicians aware of the dangers of dealing with high voltage electricity and refrigerant under pressure.

Model/Serial Number Location

These numbers are required when requesting information from your local Manitowoc Distributor, Service Representative, or Manitowoc Ice.

The model/serial number data plate is located in the refrigeration compartment and on the back of the ice machine.

Warranty

For warranty information visit:

www.manitowocice.com/Service/Warranty

- Warranty Coverage Information
- Warranty Registration
- Warranty Verification

Warranty coverage begins the day the ice machine is installed.

WARRANTY REGISTRATION

Completing the warranty registration process is a quick and easy way to protect your investment.

Scan the QR code with your smart device or enter the link in a web browser to complete your warranty registration.



WWW.MANITOWOCICE.COM/SERVICE/WARRANTY#WARRANTY-REGISTRATION

Registering your product insures warranty coverage and streamlines the process if any warranty work is required.

To obtain a printed copy of warranty terms, please contact Manitowoc Ice at 800-545-5720.

LuminIce® II

The LuminIce® growth inhibitor recirculates the air in the ice machine foodzone over a UV bulb. This process will inhibit the growth of common micro-organisms on all exposed foodzone surfaces.

LuminIce® bulbs require replacement on a yearly basis.

NOTE: LuminIce® and LuminIce® II bulbs are not interchangeable; verify your model before ordering a replacement bulb.

Cleanup Procedure for Accidental Bulb Breakage

The cleanup procedure is identical to the procedure used to clean up compact fluorescent (CFL) or fluorescent tube lights. These lights contain a small amount of mercury sealed within a glass tube. Breaking these types of lights will release mercury and mercury vapor. The broken bulb can continue to release mercury vapor until it is cleaned up and removed.

The latest EPA procedures can be viewed on their website at www.epa.gov/cfl/cflcleanup.html.

NOTE: LuminIce® and LuminIce® II bulbs are not interchangeable; verify your model before ordering a replacement bulb. LuminIce® bulbs have a white base and LuminIce® II bulbs have a blue base.

Installation

Location of Ice Machine

The location selected for the ice machine must meet the following criteria. If any of these criteria are not met, select another location.

- The location must be indoors and must be free of airborne and other contaminants.
- The location must not be near heat-generating equipment or in direct sunlight and protected from weather.
- Air temperature:
 - 65 Series: Must be at least 50°F (10°C) but must not exceed 110°F (43°C)
 - 80 Series: Must be at least 35°F (2°C) but must not exceed 110°F (43°C)
 - 140/190/240/310 Series: Must be at least 50°F (10°C) but must not exceed 100°F (38°C)
 - The location must not be near heat-generating equipment or in direct sunlight.
- The location must be capable of supporting the weight of the ice machine and a full bin of ice.
- The location must allow enough clearance for water, drain, and electrical connections in the rear of the ice machine.
- The location must not obstruct airflow through or around the ice machine (condenser airflow is in and out the front). Refer to the chart below for clearance requirements.
- The location must not be near garbage or other contaminants.
- The ice machine must be protected if it will be subjected to temperatures below 32°F (0°C). Failure caused by exposure to freezing temperatures is not covered by the warranty.

- Minimum room size required, refer to ice machine label.
- The ice machine must use legs or be sealed to the floor. Before sealing to the floor, the rubber bumpers on the bottom of the ice machine must be removed.
- UP Models: Front Water Filter Panel & Air Filter The water filter panel must be able to open and swing freely. The air filter and water filter must be able to be replaced from the front. Recommended front clearance of 36" (92 cm) to swing open and replace filters. Do not obstruct.

Installation Requirements

- The ice machine must be level.
- Vent the ice machine drains separately.
- Bin drain termination must have an air gap.
- The ice machine and bin must be de-scaled and sanitized after installation.
- The drain line must contain a union or other suitable means of disconnection at the ice machine.
- The water inlet and electrical connection must contain a service loop to allow future access.
- The location must not allow exhaust fan heat and/or grease to enter the condenser.

Ice Machine Clearance Requirements

	Self-contained	Self-contained
	Air-cooled	Water-cooled
Top/Sides	5" (13 cm)*	5" (13 cm)*
Back	5" (13 cm)*	5" (13 cm)*
Front	36" (165 cm)*	36" (165 cm)*

^{*}The ice machine may be built into a cabinet. There is no minimum clearance requirement for the top or left and right sides of the ice machine. The listed values are recommended for efficient operation and servicing only.

Ice Machine Heat of Rejection

Series	Heat of Rejection*	
Ice Machine	Air Conditioning**	Peak
UDE0065	1600	2350
UDP0065	1600	2350
UDE0080	1750	2600
UDP0080	2050	2500
U0140/UF0140	2400	2900
UP0140	2500	2900
U0190/UF0190	2200	2600
UP0190	3200	3800
U0240/UF0240	2800	3300
UP0240	3700	4400
U0310/UF0310	3800	6000
UP0310	5500	6500

^{*} B.T.U./Hour

Use this information when:

- Sizing air conditioning equipment where self-contained air-cooled ice machines are installed.
- Determining the load on a cooling tower. Use the peak figure for sizing the load.

^{**} Because the heat of rejection varies during the ice making cycle, the figure shown is an average.

Leveling the Ice Machine

- 1. Screw the legs onto the bottom of the ice machine.
- 2. Screw the foot of each leg in as far as possible.

A Caution

The legs must be screwed in tightly to prevent them from bending.

- 3. Move the ice machine into its final position.
- 4. Level the ice machine to ensure that the drain system functions correctly. Use a level on top of the ice machine. Turn each foot as necessary to level the ice machine from front to back and side to side.

Electrical Requirements

Voltage

The maximum allowable voltage variation is +10%/-5% of the rated voltage at ice machine start-up (when the electrical load is highest).

The 115/1/60 ice machines are factory pre-wired with an 8' (2.5 m) power cord and NEMA 5-15P-plug configuration.

The 208-230/1/60 and 230/1/50 ice machines are factory pre-wired with an 8' (2.5 m) power cord only, no plug is supplied.

Fuse/Circuit Breaker

A separate electrical disconnect, which disconnects all poles and has 1/8" (3 mm) contact separation, must be provided for fixed wiring. Circuit breakers must be H.A.C.R. rated in USA.

Minimum Circuit Ampacity

The total circuit ampacity (MCA) is the minimum main power wire size needed to ensure that wiring won't overheat under any operating conditions.

The wire size (or gauge) also depends on location, materials used, length of run, etc., so it must be determined by a qualified electrician.

Ground Fault Circuit Interrupter

We do not recommend the use of a GFCI/GFI circuit protection with our equipment. If a GFCI/GFI is required by code, use a GFCI/GFI breaker rather than an outlet, which is more prone to intermittent nuisance trips than panel circuit breakers.

Electrical Specifications

Air-cooled Ice Machines

Ice Machine	Voltage Phase	Max. Fuse/	Total Amps
ice Machine	Cycle	Circuit Breaker	iotai Amps
UDE0065	115/1/60	15	5.3
000005	230/1/50	15	5.3
UDP0065	115/1/60	15	2.65
	115/1/60	15	6.2
UDE0080	230/1/50	15	6.2
	230/1/60	15	-
UDP0080	115/1/60	15	4.2
U0140	115/1/60	15	5.0
UF0140	208-230/1/60	15	2.5
UFU140	230/1/50	15	2.5
UP0140	115/1/60	15	5.0
070140	230/1/50	15	2.5
U0190	115/1/60	15	6.0
UF0190	208-230/1/60	15	3.0
010190	230/1/50	15	2.5
UP0190	115/1/60	15	6.0
070190	230/1/50	15	2.5
U0240	115/1/60	15	7.0
UF0240	208-230/1/60	15	3.5
010240	230/1/50	15	4.0
	115/1/60	15	7.0
UP0240	208-230/1/60	15	3.5
	230/1/50	15	3.5
110210	115/1/60	15	10.0
U0310 UF0310	208-230/1/60	15	4.5
010310	230/1/50	15	4.5
	115/1/60	15	8.0
UP0310	208-230/1/60	15	5.0
	230/1/50	15	5.0

 $\ensuremath{\mathsf{NOTE}}\xspace$: Model/serial plate information overrides all data listed in this chart.

Water-cooled Ice Machines

Ice Machine	Voltage Phase Cycle	Max. Fuse/ Circuit Breaker	Total Amps
U0240	115/1/60	15	7.0
UF0240	208-230/1/60	15	4.0
UF0240	230/1/50	15	4.0
	115/1/60	15	6.0
UP0240	208-230/1/60	15	3.5
	230/1/50	15	3.0
110310	115/1/60	15	10.0
U0310	208-230/1/60	15	4.5
UF0310	230/1/50	15	4.5
UP0310	115/1/60	15	7.0
	208-230/1/60	15	-
	230/1/50	15	-

NOTE: Model/serial plate information overrides all data listed in this chart.

AWarning

All wiring must conform to local, state and national codes.

AWarning

The ice machine must be grounded in accordance with national and local electrical code.

Water Service/Drains

WATER SUPPLY

Plumbing must conform to state and local codes.

Important

If you are installing a Manitowoc water filter system, refer to the Installation Instructions supplied with the filter system for ice making water inlet connections.

Water Inlet Lines

Follow these guidelines to install water inlet lines:

- Local water conditions may require treatment of the water to inhibit scale formation, filter sediment, and remove chlorine odor and taste.
- All water and drains must conform to all applicable codes of the authority having jurisdiction. It is the responsibility of the end user to satisfy all local codes.
- Connect ice making water inlet to potable water only.
- Do not connect the ice machine to a hot water supply.
 Be sure all hot water restrictors installed for other equipment are working. (Check valves on sink faucets, dishwashers, etc.)
- If water pressure exceeds the maximum recommended pressure, 80 psig (5.5 bar) obtain a water pressure regulator.
- Install a water shut-off valve for ice making potable water.
- Insulate water inlet lines to prevent condensation.

Drain Connections

Follow these guidelines when installing drain lines to prevent drain water from flowing back into the ice machine and storage bin:

- Drain lines must have a 1.5-inch drop per 5 feet of run (2.5 cm per meter), and must not create traps.
- The floor drain must be large enough to accommodate drainage from all drains.
- Run separate bin and ice machine drain lines. Insulate them to prevent condensation.
- Install a tee at the ice making water drain outlet and install an 8.0" (20 cm) vent above the ice making water drain line.
- Drain termination must have an air gap that meets local code.

COOLING TOWER APPLICATIONS

Water-cooled Models Only

A water-cooling tower installation does not require modification of the ice machine. The water regulator valve for the condenser continues to control the refrigeration discharge pressure.

It is necessary to know the amount of heat rejected, and the pressure drop through the condenser and water valves (inlet to outlet) when using a cooling tower on an ice machine.

- Water entering the condenser must not exceed 90°F (32.2°C).
- Water flow through the condenser must not exceed 5 gallons (19 liters) per minute.
- Allow for a pressure drop of 7 psig (.48 bar) between the condenser water inlet and the outlet of the ice machine.
- Water exiting the condenser must not exceed 110°F (43.3°C).

Water Temperature & Pressure

140/190/210/310

Landina	Water	Water	
Location	Temperature	Pressure	
Ice Making	40°F (4°C) min.	20 psi (1.4 bar) min.	
Water Inlet	90°F (32°C) max.	80 psi (5.5 bar) max.	
Condenser	40°F (4°C) min. 20 psi (1.4 bar) mi		
Water Inlet	90°F (32°C) max. 150 psi (10.3 bar) m		
Condenser	110% (12.3%)		
Water Drain	110°F (43.3°C) max.	_	

UDE0065/UDP0065

Location	Water	Water	
Location	Temperature	Pressure	
Ice Making 50°F (10°C) min.		35 psi (2.4 bar) min.	
Water Inlet	86°F (30°C) max.	90 psi (6.2 bar) max.	

UDE0080/UDP0080

Location	Water	Water	
Location	Temperature	Pressure	
Ice Making	king 33°F (0.6°C) min. 20 psi (1.4 bar) m		
Water Inlet	90°F (32°C) max. 80 psi (5.5 bar) ma		

Water Connection Sizes

140/190/210/310

Location	Ice Machine Fitting - Female Pipe Thread	Tubing Size to Ice Machine Fitting Inside Diameter	
Ice Making Water Inlet	3/8" (9.5 mm)	3/8" (9.5 mm) min.	
Ice Making Water Drain	1/2" (13 mm)	1/2" (13 mm)	
	3/8" (9.5 mm)	3/8" (9.5 mm) min.	
Condenser Water Inlet	<i>U310 only</i> : 1/2" (13 mm)	<i>U310 only:</i> 1/2" (13 mm) min.	
Condenser Water Drain	1/2" (13 mm) min.	1/2" (13 mm) min.	
Bin Drain	1/2" (13 mm) min.	1/2" (13 mm) min.	

UDE0065/UDP0065

Location	Ice Machine Fitting	Tubing Size to Ice Machine Fitting Inside Diameter	
Ice Making Water Inlet	3/4" (9.5 mm)	3/8" (9.5 mm) min.	
Ice Making Water Drain	5/8" (16 mm)	5/8" (16 mm) min.	
Bin Drain	5/8" (16 mm)	5/8" (16 mm) min.	

UDE0080/UDP0080

Location	Ice Machine Fitting	Tubing Size to Ice Machine Fitting Inside Diameter	
Ice Making Water Inlet	3/8" (9.5 mm)	3/8" (9.5 mm) min.	
Ice Making Water Drain	5/8" (16 mm)	5/8" (16 mm) min.	
Bin Drain	5/8" (16 mm)	5/8" (16 mm) min.	

Water Filter

UP0140/UP0190/UP0240/UP0310

SPECIFICATIONS

Pressure: 10 - 125 psi (69 - 862 kPa)

Temperature: 35 - 100°F (1.6 - 38°C)


Replacement Cartridges:

Model	Rated	Sediment	Reduction
	Flow	Reduction	Capacity
K00530	0.32 gpm	5.0 micron	4,000 g
K00532	(1.2 lpm)		(15,142 l)
K00531	0.32 gpm (1.2 lpm)	0.5 micron	4,000 g (15,142 l)

Incoming water does not need to be turned off for installation and/or removal of the water filter. This system is equipped with a built-in bypass when the water filter is removed.

INSTALLATION

- Press the On/Off button for 3 seconds to turn off the ice machine.
- Open the water filter panel. Remove water filter manifold plug by turning left. The plug is factory installed to keep dirt out of the machine. Do not discard.




Water Filter Manifold Plug

- 3. Remove cap from top of new cartridge.
- Insert new cartridge into water filter manifold. Turn cartridge to the right, until it firmly stops to lock the water filter into position.
- 5. Close the Water Filter panel and power on the unit.
- Press the Water Filter button for 4 seconds to initiate a flush sequence. This will energize the water inlet valve and dump valve for 5 minutes and reset the water filter replacement light.
- 7. Power off unit and restart to begin a new fill sequence and ice making cycle.

REMOVAL

- Turn cartridge slowly to the left, until it releases. At this position, both inlet and outlet ports are closed and water pressure has been relieved.
- Remove and discard the cartridge. There may be a small amount of residual water drainage after pressure is relieved and during cartridge removal.



Water Filter Removal

- Follow Water Filter Installation to install a new water filter.
- If a new water filter is not immediately available, install water filter manifold plug until a new water filter is available.

THIS PAGE INTENTIONALLY LEFT BLANK

Maintenance

De-scaling and Sanitizing

GENERAL

You are responsible for maintaining the ice machine in accordance with the instructions in this manual.

Maintenance procedures are not covered by the warranty.

Sanitizing for Exterior, Remedial, and Detailed procedures can be performed independently and more frequently than de-scaling when needed.

De-scale and sanitize the ice machine every six months for efficient operation. If the ice machine requires more frequent de-scaling and sanitizing, consult a qualified service company to test the water quality and recommend appropriate water treatment.

An extremely dirty ice machine must be taken apart for de-scaling and sanitizing.

Manitowoc Ice Machine De-scaler and Sanitizer are the only products approved for use in Manitowoc ice machines.

Using non Manitowoc de-scalers, sanitizers, cleaners or solutions may result in bodily harm and/or cause damage to the ice machine that is not covered under the warranty.

ICE MACHINE INSPECTION

Check all water fittings and lines for leaks. Also, confirm the refrigeration tubing is not rubbing or vibrating against other tubing, panels, etc.

Do not put anything (boxes, etc.) in front of the ice machine. There must be adequate airflow through and around the ice machine to maximize ice production and ensure long component life.

EXTERIOR CLEANING

Clean the area around the ice machine as often as necessary to maintain cleanliness and efficient operation.

Wipe surfaces with a damp cloth rinsed in water to remove dust and dirt from the outside of the ice machine. If a greasy residue persists, use a damp cloth rinsed in a mild dish soap and water solution. Wipe dry with a clean, soft cloth.

The exterior panels have a clear coating that is stain resistant and easy to clean. Products containing abrasives will damage the coating and scratch the panels.

- · Never use steel wool or abrasive pads for cleaning.
- Never use chlorinated, citrus based or abrasive cleaners on exterior panels and plastic trim pieces.

REMEDIAL DE-SCALING PROCEDURE

 This procedure de-scales all components in the water flow path, and is used between the bi-yearly detailed de-scaling and sanitizing procedure.

DETAILED DE-SCALING/SANITIZING PROCEDURE

This procedure must be performed a minimum of once every six months.

- The ice machine and bin must be disassembled descaled and sanitized.
- All ice produced during the de-scaling and sanitizing procedures must be discarded.

/ Caution

Use only Manitowoc approved Ice Machine De-scaler and Sanitizer for this application (Manitowoc De-scaler part number 9405463 and Manitowoc Sanitizer part number 9405653). Do not use de-scaler or sanitizer quantities that exceed the amounts listed in this manual. It is a violation of Federal law to use these solutions in a manner inconsistent with their labeling. Read and understand all labels printed on bottles before use.

TOUCH PAD OPERATION

140/190/240/310

When the ice machine is Off, press and hold the Clean button for 3 seconds starts the clean cycle. The Clean and On/Off lights energize indicating the clean cycle has started and ice making will automatically start when the clean cycle is complete.

- Setting the ice machine to stop after the clean cycle:
 Press the On/Off button. The On/Off light will
 de-energize, indicating the ice machine will stop after
 the clean cycle.
- Pausing the clean cycle: Press the Clean button. The clean light will flash indicating the clean cycle has paused. Pressing the Clean button again will restart the clean cycle.

NOTE: If the ice damper is open for 2 seconds, the clean cycle will pause. If the damper is open for 30 seconds, the clean cycle will be canceled.

Detailed De-scaling and Sanitizing Procedure

140/190/240/310

(See page 58 for UD0065 Series and page 66 for UD0080 Series)

Ice machine De-scaler is used to remove lime scale and mineral deposits. Ice machine sanitizer disinfects and removes algae and slime.

NOTE: Although not required and dependent on your installation, removing the ice machine top cover may allow easier access.

Step 1 Open the bin door to access the evaporator compartment. Ice must not be on the evaporator during the de-scaling/sanitize cycle. Follow one of the methods helow:

- Press the On/Off button for 3 seconds at the end of a harvest cycle after ice falls from the evaporator.
- Press the On/Off button for 3 seconds and allow the ice to melt.

! Caution

Never use anything to force ice from the evaporator. Damage may result.

Step 2 Remove all ice from the bin.

▲Warning

Wear rubber gloves and safety goggles (and/or face shield) when handling Ice Machine De-scaler or Sanitizer.

∴ Caution

Do not mix Ice Machine De-scaler and Sanitizer solutions together. It is a violation of Federal law to use these solutions in a manner inconsistent with their labeling.

DE-SCALING PROCEDURE

Step 3 Press the Clean button. Water will flow through the water dump valve and down the drain. Wait approximately 1 minute until the water trough refills. Add the proper amount of ice machine de-scaler to the water trough.

Model	Amount of De-scaler #9405463
140	2 ounces (60 ml)
190/240/310	5 ounces (150 ml)

Step 4 Wait until the cycle is complete (approximately 24 minutes). Then press the On/Off button and disconnect power to the ice machine.

A Warning

Disconnect the electric power to the ice machine at the electric service switch box.

Step 5 Remove parts for de-scaling. Refer to the proper parts removal for your machine. Continue with step 6 when the parts have been removed.

Step 6 Mix a solution of de-scaler and lukewarm water. Depending upon the amount of mineral buildup, a larger quantity of solution may be required. Use the ratio in the table below to mix enough solution to thoroughly de-scale all parts.

Solution Type	Water	Mixed with
De-scaler	1 (2) (4.1)	16 oz (475 ml)
#9405463	1 gal (4 L)	de-scaler

A Caution

Do not immerse electrical connectors or motors for any components in water, de-scaler or sanitizer solutions.

Step 7 Use half of the de-scaler & water mixture to de-scale all components. Use caution not to expose electrical connectors to liquid and soak parts for 5 minutes (15 - 20 minutes for heavily scaled parts). The solution will foam when it contacts lime scale and mineral deposits; once the foaming stops, use a soft-bristle nylon brush, sponge or cloth (NOT a wire brush) to carefully de-scale the parts. When de-scaling is complete rinse all removed components with clean water.

Step 8 While components are soaking, use half of the solution to de-scale all food zone surfaces of the ice machine and bin (or dispenser). Use a nylon brush or cloth to thoroughly de-scale the following ice machine areas:

- Side walls
- Base (area above water trough)
- Evaporator plastic parts including top, bottom and sides
- Bin

Rinse all areas thoroughly with clean water.

SANITIZING PROCEDURE

NOTE: Sanitizing can be performed independently and more frequently than de-scaling when needed.

Step 9 Mix a solution of sanitizer and warm water.

Solution Type	Water	Mixed With
Sanitizer	3 gal (12 L)	2 oz (60 ml)
#9405653	3 gai (12 L)	sanitizer

Step 10 UUse half of the sanitizer/water solution to sanitize all removed components. Fill a spray bottle and use caution not to expose electrical connectors to liquid and liberally apply the solution to all surfaces of the removed parts or soak the removed parts in the sanitizer/water solution.

Do not rinse parts after sanitizing.

Step 11 Use half of the sanitizer/water solution to sanitize all food zone surfaces of the ice machine and bin. Use a spray bottle to liberally apply the solution. When sanitizing, pay particular attention to the following areas:

- Side walls
- Base (area above water trough)
- Evaporator plastic parts including top, bottom and sides
- Bin

Do not rinse the sanitized areas.

Step 12 Replace all removed components back into their original configuration and wait 20 minutes.

Step 13 Reapply power and press the Clean button. Water will flow through the water dump valve and down the drain. Wait approximately 1 minute until the water trough refills. Add the proper amount of ice machine sanitizer to the water trough.

Model	Amount of Sanitizer
	Part Number 9405653
140	1 oz (30 ml)
190/240/310	2 oz (60 ml)

Step 14 Close and secure all panels and bin door. The ice machine will automatically start ice making after the sanitize cycle is complete (approximately 24 minutes).

Remove Parts for De-scaling and Sanitizing

AWarning


Disconnect electric power to the ice machine at the electric switch box before proceeding.

NOTE: Electrical connectors must never be exposed to any liquids.

A. Remove the ice thickness and harvest float switch.

- Pull forward on the bottom of the bracket until clear of the tab.
- Slide bracket upward to remove the bracket and float switch as an assembly.
- At this point, the component can easily be cleaned.
- If complete removal is desired, follow the wires to the bulkhead grommet (exit point) in the back wall. Pull the wire connector through the bulkhead grommet, then disconnect the wire leads from the connector.

WIRE CONNECTORS ARE LOCATED BEHIND BULKHEAD PULL THROUGH GROMMET TO DISCONNECT




Notice

Reversing the mounting location of the ice thickness & harvest floats will result in a Service Limit #3 failure since the harvest float will never go up.

- The ice thickness float (black wire) must be mounted to the front of the water trough and the electrical connection must be in the top bulkhead grommet.
- The harvest float (red wire) must be mounted to the side of the water trough and the electrical connection must be in the bottom bulkhead grommet.
- The wire connectors for each float are different and will not allow incorrect electrical bulkhead connection.


A Caution

Do not disassemble the float switches for de-scaling and/or sanitizing - incorrect reassembly will result in an ice machine that will not harvest.



Remove the water trough thermistor and water В. trough.

- While supporting the water trough, remove the upper thumbscrew and lift off the thermistor.
- Continue supporting the water trough and remove the thumbscrew from beneath the water trough.
- Remove the water trough from the bin area.
- At this point, the component can easily be cleaned.
- If complete removal is desired, follow the wires to the bulkhead grommet (exit point) in the back wall. Pull the wire connector through the bulkhead grommet, then disconnect the wire leads from the connector.



C. Remove the ice damper.


- Remove thumbscrew from bin switch cover.
- Support ice damper and then pull bin switch cover and ice damper forward to remove.

D. Remove the water distribution tube.

NOTE: Thumbscrews for the distribution tube are retained to prevent loss. Loosen thumbscrews, but do not pull thumbscrews out of distribution tube.

- Loosen the two outer screws (do not remove screws, they are retained to prevent loss) and pull forward on the distribution tube to release from slip joint.
- Disassemble distribution tube by loosening the two (2) middle thumbscrews and dividing the distribution tube into two pieces.

NOTE: When reinstalling, install top edge first.



Remove Thumbscrew from Bin Switch Cover, Support The Damper, and Remove

REMEDIAL DE-SCALING PROCEDURE

This procedure de-scales all components in the water flow path, and is used to de-scale the ice machine between the bi-yearly detailed de-scaling and sanitizing procedure.

Ice machine de-scaler is used to remove lime scale and mineral deposits. Ice machine sanitizer disinfects and removes algae and slime.

NOTE: Although not required and dependent on your installation, removing the ice machine top cover may allow easier access.

Step 1 Ice must not be on the evaporator during the de-scale/sanitize cycle. Follow one of the methods below:

- Press the On/Off button for 3 seconds at the end of a harvest cycle after ice falls from the evaporator.
- Press the On/Off button for 3 seconds and allow the ice to melt.

Notice

Never use anything to force ice from the evaporator. Damage may result.

Step 2 Open the bin door to access the evaporator compartment.

Step 3 Press the Clean button. Water will flow through the water dump valve and down the drain. Wait approximately 1 minute until the water trough refills. Add the proper amount of ice machine de-scaler to the water trough.

Model	Amount of De-scaler #9405463
140	2 oz (60 ml)
190/240/310	5 oz (150 ml)

Step 4 Close and secure the bin door. The ice machine will automatically start ice-making after the clean cycle is complete (approximately 24 minutes).

Air Filter and Air Condenser Maintenance

It is recommended to check the air filter and air condenser during De-scaling & Sanitizing Procedure.

AIR FILTER


All Models

The washable air filter on self-contained ice machines is designed to catch dust, dirt, lint and grease.

- Clean the air filter once a month.
- Wash with mild soap and water.



UP Models: Air Filter Location (insert mesh end first)



Other Models: Air Filter located behind Front Grill

AIR CONDENSER

All Models

A dirty air condenser restricts airflow, resulting in excessively high operating temperatures. This reduces ice production and shortens component life.

AWarning

Disconnect electric power to the ice machine at the electric service switch before cleaning the air filter or the condenser. The condenser fins are sharp; Use care when removing or installing the air filter.

- Clean the condenser at least every six months.
- Shine a flashlight through the condenser to check for dirt between the fins.
- Blow compressed air or rinse with water from the inside out (opposite direction of airflow).
- If dirt still remains, call a service agent to clean the condenser.

NOTE: Cleaning the air condenser will require the removal of the bin.

LuminIce® Bulb Maintenance

When Installed

It is recommended to check the LuminIce bulb during De-scaling & Sanitizing Procedure.

LuminIce bulbs require replacement on a yearly basis. The bulb will still illuminate after 12 months, the effectiveness of the bulb diminishes as operational hours increase. To retain maximum effectiveness, replace the bulb on a 12 month schedule.

BULB REPLACEMENT

LuminIce II has an indicator light on the device that will illuminate blue when operating normal or red when the bulb needs replacement.

 Replace with a Luminice II bulb with white bulb base: K00528.

CLEAN-UP PROCEDURE

Accidental Bulb Breakage

The clean up procedure is identical to the procedure used to clean up compact fluorescent (CFL) or fluorescent tube lights. These lights contain a small amount of mercury sealed within a glass tube. Breaking these types of lights will release mercury and mercury vapor. The broken bulb can continue to release mercury vapor until it is cleaned up and removed.

The latest EPA procedures can be viewed on their website at: www.epa.gov/cfl/cflcleanup.html.

Water Filter Replacement

UP MODELS ONLY

It is recommended to check the Water Replacement light during De-scaling & Sanitizing Procedure.



Red Light = Replace Water Filter

When the ice machine completes 4,000 freeze/harvest cycles the water filter light will energize to indicate the filter needs replacement.


- Pressing the Water Filter Replacement button for 4 seconds will reset the counter. Once the 5 minute Flush Sequence is complete the light will de-energize.
- Pressing the Water Filter Replacement button once will de-energize the light for 24 hours but will not reset the water filter reminder.

NOTE: Arctic Pure® Pro water filter cartridges **must be replaced every 6 months** or when water pressure through the system drops below 20 psi (138 kPa), whichever occurs first.

Bin Removal

NOTE: Although not required and dependent on your installation, removing the bin may allow easier access.

- Disconnect power and remove all ice from bin.
- Remove air filter and louvered front panel/grill from lower front of machine.
- Loosen screws and rotate clips to release bin from base.
- Disconnect bin drain line clamp and remove bin drain line.
- Disconnect touch pad communication cable from the control board harness.
- Slide bin forward to remove.



The bin seal gasket must seal tightly to the cabinet. Confirm the bin seal gasket is not pinched or folded. A water tight seal is required to prevent future condensation and/or water leakage from entering the ice machine base and damaging the unit.

Removal from Service/Winterization

GENERAL

Special precautions must be taken if the ice machine is to be removed from service for an extended period of time or exposed to ambient temperatures of 32°F (0°C) or below.

Notice

If water is allowed to remain in the ice machine in freezing temperatures, severe damage to some components could result. Damage of this nature is not covered by the warranty.

- 1. De-scale and sanitize the ice machine.
- Press the On/Off button for 3 seconds to turn off the ice machine.
- Turn off the water supply, disconnect and drain the incoming ice-making water line at the rear of the ice machine, and drain the water trough.
- 4. Remove water filter (UP models only).
- Energize the ice machine, wait one minute for the water inlet valve to open, and blow compressed air in both the incoming water and the drain openings in the rear of the ice machine to remove all water.
- Press the On/Off button for 3 seconds to turn off the ice machine. Disconnect the electric power at the circuit breaker or the electric service switch.
- Fill spray bottle with sanitizer and spray all interior food zone surfaces. Do not rinse and allow to air dry.
- 8. Install water filter manifold plug (UP models only).
- 9. Replace all panels.

Water-cooled Models Only

- 1. Perform steps 1-6.
- 2. Disconnect the incoming water and drain lines from the water-cooled condenser.
- Insert a large screwdriver between the bottom spring coils of the water regulating valve. Pry upward to open the valve.
- Hold the valve open and blow compressed air through the condenser until no water remains.
- 5. Replace all panels.

Detailed De-scaling and Sanitizing Procedure

UDE0065/UDP0065

Ice machine de-scaler is used to remove lime scale and mineral deposits. Ice machine sanitizer disinfects and removes algae and slime.

Step 1 Set the toggle switch to Off after ice falls from the evaporator at the end of a Harvest cycle. Or, set the toggle switch to Off and allow the ice to melt off the evaporator.

/ Caution

Never use anything to force ice from the evaporator. Damage may result.

Step 2 Remove all ice from the bin.

AWarning

Wear rubber gloves and safety goggles (and/or face shield) when handling Ice Machine De-scaler or Sanitizer.

∴ Caution

Do not mix Ice Machine De-scaler and Sanitizer solutions together. It is a violation of Federal law to use these solutions in a manner inconsistent with their labeling.

DE-SCALING PROCEDURE

Step 3 To start a cycle, set the toggle switch to Wash.

Step 4 Wait until water flows over the evaporator (about three minutes) then add the proper amount of Ice Machine De-scaler (9405463) to the water trough.

Model	Amount of De-scaler
	#9405463
UDE0065/UDP0065	1.5 oz (45 ml)

Step 5 Wait until the cycle is complete (approximately 45 minutes) then set the toggle switch in the Off position and disconnect power and water supplies to the ice machine.

A Warning


Disconnect electric power to the ice machine at the electric switch box before proceeding.

Step 6 Remove parts for de-scaling.

Remove the Overflow Tube

 To remove the tube, lift it up while using a slight back and forth motion to loosen it from the drain hole.

NOTE: When installing the tube, be sure it is completely inserted into the drain hole to prevent water leakage during normal operation.




Remove Vinyl Hose

 Disconnect the water pump discharge hose from the distribution tube and water pump.

Remove the Water Pump

- Remove the two thumbscrews and the water pump cover.
- Disconnect the water pump power cord.
- Loosen the screws that hold the water pump in place.
- Lift the water pump and bracket assembly up and off the screws.



Remove the Water Trough

 Remove the screws holding the water trough to the walls of the cabinet.

Step 7 Mix a solution of de-scaler and warm water. Depending on the amount of mineral buildup, a larger quantity of solution may be required. Use the ratio in the table below to mix enough solution to thoroughly de-scale all parts.

Solution Type	Water	Mixed with
De-scaler	1 col (41)	16 oz (500 ml)
#9405463	1 gal. (4 l)	de-scaler

Step 8 Use ½ of the de-scaler and water solution to de-scale all components. The solution will foam when it contacts lime scale and mineral deposits; once the foaming stops use a soft bristle brush, sponge or cloth (not a wire brush) to carefully de-scale the parts. Soak the parts for 5 minutes (15 – 20 minutes for heavily scaled parts). Rinse all components with clean water.

Step 9 While components are soaking, use ½ of the de-scaler and water solution to de-scale all foodzone surfaces of the ice machine and bin. Use a nylon brush or cloth to thoroughly de-scale the following ice machine areas:

- Evaporator plastic parts including top, bottom and sides.
- Bin bottom, sides and top

Rinse all areas thoroughly with clean water.

SANITIZING PROCEDURE

NOTE: Sanitizing can be performed independently and more frequently than de-scaling when needed.

Step 10 Mix a solution of sanitizer part number 9405653 and warm water.

Solution Type	Water	Mixed With
Sanitizer #9405653	6 gal. (23 l)	4 oz (120 ml) sanitizer

Step 11 Use 1/2 of the sanitizer/water solution to sanitize all removed components. Use a cloth or sponge to liberally apply the solution to all surfaces of the removed parts or soak the removed parts in the sanitizer/water solution. **Do not rinse parts after sanitizing**.

Step 12 Use 1/2 of the sanitizer/water solution to sanitize all foodzone surfaces of the ice machine and bin. Use a cloth or sponge to liberally apply the solution. When sanitizing, pay particular attention to the following areas:

- Evaporator plastic parts including top, bottom and sides
- Bin bottom, sides and top

Do not rinse the sanitized areas.

Step 13 Replace all removed components.

Step 14 Reapply power and water to the ice machine and set the toggle switch in the WASH position.

Step 15 Add the proper amount of Ice Machine Sanitizer to the water trough.

Model	Amount of Sanitizer #9405653
UDE0065/UDP0065	1.5 oz (45 ml)

Step 16 Wait until the sanitize cycle is complete (approximately 45 minutes) then set the toggle switch in the OFF position, disconnect power and water supplies to the ice machine.

AWarning

Disconnect electric power to the ice machine at the electric switch box before proceeding.

Step 17 Repeat step 6 to remove parts for hand sanitizing.

Step 18 Mix a solution of sanitizer and warm water.

Solution Type	Water	Mixed With
Sanitizer #9405653	6 gal (23 L)	4 oz (120 ml) sanitizer

Step 19 Use 1/2 of the sanitizer/water solution to sanitize all removed components. Use a cloth or sponge to liberally apply the solution to all surfaces of the removed parts or soak the removed parts in the sanitizer/water solution. **Do not rinse parts after sanitizing**.

Step 20 Use 1/2 of the sanitizer/water solution to sanitize all foodzone surfaces of the ice machine and bin. Use a cloth or sponge to liberally apply the solution. When sanitizing, pay particular attention to the following areas:

- Evaporator plastic parts including top, bottom and sides.
- Bin bottom, sides and top.

Do not rinse the sanitized areas.

- **Step 21** Replace all removed components.
- **Step 22** Reapply power and water to the ice machine and set the toggle switch in the ICE position.

Exterior Cleaning

Clean the area around the ice machine as often as necessary to maintain cleanliness and efficient operation.

Sponge any dust and dirt off the outside of the ice machine with mild soap and water. Wipe dry with a clean, soft cloth.

Treat all exterior stainless steel surfaces with a commercial grade stainless steel polish.

Ice Machine Inspection

Check all water fittings and lines for leaks. Also, make sure the refrigeration tubing is not rubbing or vibrating against other tubing, panels, etc.

Do not put anything (boxes, etc.) in front of the ice machine. There must be adequate airflow through and around the ice machine to maximize ice production and ensure long component life.

Air Filter and Air Condenser Maintenance

It is recommended to check the air filter and air condenser during De-scaling & Sanitizing Procedure.

AIR FILTER

The washable air filter on self-contained ice machines is designed to catch dust, dirt, lint and grease.

- · Clean the air filter once a month
- Wash with mild soap and water

CLEANING THE AIR CONDENSER

A dirty air condenser restricts airflow, resulting in excessively high operating temperatures. This reduces ice production and shortens component life. Clean the air condenser at least every six months. Follow the steps below.

- The washable aluminum filter on self-contained ice machines is designed to catch dust, dirt, lint and grease. This helps keep the condenser clean. Clean the filter with a mild soap and water solution.
- Clean the outside of the condenser with a soft brush or a vacuum with a brush attachment. Clean from top to bottom, not side to side. Be careful not to bend the condenser fins.
- Shine a flashlight through the condenser to check for dirt between the fins. If dirt remains: Blow compressed air through the condenser fins from the inside. Be careful not to bend the fan blades.
- Use a commercial condenser coil cleaner. Follow the directions and cautions supplied with the cleaner.
- 5. Straighten any bent condenser fins with a fin comb.
- Carefully wipe off the fan blades and motor with a soft cloth. Do not bend the fan blades. If the fan blades are excessively dirty, wash with warm, soapy water and rinse thoroughly.

REMOVAL FROM SERVICE/WINTERIZATION

Self-contained Air-cooled ice machines

Special precautions must be taken if the ice machine is to be removed from service for an extended period of time or exposed to ambient temperatures of 32°F (0°C) or below.

- Disconnect the electric power at the circuit breaker or the electric service switch.
- 2. Turn off the water supply.
- 3. Remove the water from the water trough.
- 4. Disconnect the drain and the incoming ice-making water line at the rear of the ice machine.
- Make sure no water is trapped inside the ice machine incoming water lines, drain lines, distribution tubes, etc.

Detailed De-scaling and Sanitizing Procedure UDE0080/UDP0080

Ice machine de-scaler is used to remove lime scale and mineral deposits. Ice machine sanitizer disinfects and removes algae and slime.

Step 1 Set the toggle switch to Off after ice falls from the evaporator at the end of a Harvest cycle. Or, set the toggle switch to Off and allow the ice to melt off the evaporator.

∴ Caution

Never use anything to force ice from the evaporator. Damage may result.

Step 2 Remove all ice from the bin.

A Warning

Wear rubber gloves and safety goggles (and/or face shield) when handling Ice Machine De-scaler or Sanitizer.

/ Caution

Do not mix Ice Machine De-scaler (9405463) and Sanitizer (9405653) solutions together. It is a violation of Federal law to use these solutions in a manner inconsistent with their labeling.

DE-SCALING PROCEDURE

Step 3 To start a cycle set the toggle switch to Wash.

Step 4 Wait until water flows over the evaporator (about three minutes) then add the proper amount of Ice Machine De-scaler to the water trough.

Model	Amount of De-scaler
	Part Number 9405463
UDE0080/UDP0080	1.5 ounces (45 ml)

Step 5 Wait until the cycle is complete (approximately 22 minutes) then set the toggle switch in the Off position and disconnect power and water supplies to the ice machine.

A Warning


Disconnect electric power to the ice machine at the electric switch box before proceeding.

Step 6 Remove parts for de-scaling.

- A. Remove Two Thumbscrews and Water Pump
 Cover.
- B. Remove the Vinyl Hose Connecting the Water Pump and Water Distribution Tube.


Remove Water Pump

- Disconnect the water pump power cord.
- Loosen the screws securing the pump mounting bracket to the bulkhead.
- Lift the pump and bracket assembly off the mounting screws.



Remove the Ice Thickness Probe

 Compress the side of the ice thickness probe near the top hinge pin and remove it from the bracket.



NOTE: At this point, the ice thickness probe can easily be de-scaled. If complete removal is desired follow the ice thickness probe wire to the bulkhead grommet (exit point) in the back wall. Pop the bulkhead grommet out of the back wall by inserting fingernails or a flat object between the back wall and the grommet and prying forward. Pull the bulkhead grommet and wire forward until the connector is accessible, then disconnect the wire lead from the connector.


Ice Thickness Probe De-scaling

- Mix a solution of Ice Machine De-scaler and water (2 ounces of de-scaler to 16 ounces of water) in a container.
- Soak the ice thickness probe a minimum of 10 minutes.

De-scale all ice thickness probe surfaces and verify the ice thickness probe cavity is de-scaled. Rinse thoroughly with clean water, then dry completely. Incomplete rinsing and drying of the ice thickness probe can cause premature harvest.


Remove the Water Distribution Tube

- Loosen the two thumbscrews, which secure the distribution tube.
- Lift the distribution tube up off the thumbscrews.




Disassembly

- Twist the barbed end until the tab lines up with the key way.
- Pull the inner tube end outward




Remove the Float Valve

- Turn the splash shield counterclockwise one or two turns.
- Pull the float valve forward and off the mounting bracket.
- Disconnect the water inlet tube from the float valve at the compression fitting.
- Remove the cap and filter screen for de-scaling.




Remove the Water Trough

- Apply downward pressure on the siphon tube and remove from the bottom of the water trough.
- Remove the upper thumbscrew.
- While supporting the water trough remove the two thumbscrews from beneath the water trough.
- Remove the water trough from the bin area.



Remove the Ice Damper

- Grasp left side of ice damper and apply pressure against the right-hand ice damper mounting bracket.
- Pull forward on the ice damper until the left hand mounting pin disengages.




Installation

- Grasp the right side of ice damper and place left hand pin in the mounting bracket.
- While applying pressure against the left-hand mounting bracket push the damper until the righthand mounting pin engages.

Remove the Bin Door

- Grasp the rear of the bin door and pull bin door forward approximately 5".
- Slide bin door to the rear while applying upward pressure (The rear door pins will ride up into the track slot and slide backward to the stop tab).
- While applying pressure against the bin door pull down on the rear of each bin door track until the door pins clear the stop tabs.
- Slide the rear door pins off the end and then below the door track. Slide bin door forward allowing the back of the door to lower into the bin. Continue forward with the bin door until the front pins bottom out in the track.
- Lift right side of door until the front pins clear the track, then remove door from bin.
- Remove rollers (4) from all door pins.



Step 7 Mix a solution of de-scaler and warm water. Depending on the amount of mineral buildup, a larger quantity of solution may be required. Use the ratio in the table below to mix enough solution to thoroughly de-scale all parts.

Solution Type	Water	Mixed with
De-scaler	1 col (41)	16 oz (500 ml)
# 9405463	1 gal. (4 l)	de-scaler

Step 8 Use 1/2 of the de-scaler and water solution to de-scale all components. The solution will foam when it contacts lime scale and mineral deposits; once the foaming stops use a soft bristle brush, sponge or cloth (not a wire brush) to carefully de-scale the parts. Soak the parts for 5 minutes (15 - 20 minutes for heavily scaled parts). Rinse all components with clean water.

Step 9 While components are soaking, use 1/2 of the de-scaler and water solution to de-scale all foodzone surfaces of the ice machine and bin. Use a nylon brush or cloth to thoroughly de-scale the following ice machine areas:

- Evaporator plastic parts including top, bottom and sides.
- · Bin bottom, sides and top.

Rinse all areas thoroughly with clean water.

SANITIZING PROCEDURE

NOTE: Sanitizing can be performed independently and more frequently than de-scaling when needed.

Step 10 Mix a solution of sanitizer and warm water.

Solution Type	Water	Mixed With
Sanitizer #9405653	6 gal. (23 l)	4 oz (120 ml) sanitizer

Step 11 Use 1/2 of the sanitizer/water solution to sanitize all removed components. Use a cloth or sponge to liberally apply the solution to all surfaces of the removed parts or soak the removed parts in the sanitizer/water solution.

Do not rinse parts after sanitizing.

Step 12 Use 1/2 of the sanitizer/water solution to sanitize all foodzone surfaces of the ice machine and bin. Use a cloth or sponge to liberally apply the solution. When sanitizing, pay particular attention to the following areas:

- Evaporator plastic parts including top, bottom and sides.
- Bin bottom, sides and top.

Do not rinse the sanitized areas.

- **Step 13** Replace all removed components.
- **Step 14** Reapply power and water to the ice machine and set the toggle switch in the WASH position.

Step 15 Add the proper amount of Ice Machine Sanitizer to the water trough.

Model	Amount of Sanitizer Part Number 9405653
UDE0080/UDP0080	1.5 ounces (45 ml)

Step 16 Wait until the sanitize cycle is complete (approximately 22 minutes) then set the toggle switch in the OFF position, disconnect power and water supplies to the ice machine.

▲ Warning

Disconnect electric power to the ice machine at the electric switch box before proceeding.

Step 17 Repeat step 6 to remove parts for hand sanitizing.

Step 18 Mix a solution of sanitizer and warm water.

Solution Type	Water	Mixed With
Sanitizer	6 (22 /22)	4 oz (120 ml) sanitizer
Samuzer	6 gal. (23 l)	part number 9405653

Step 19 Use 1/2 of the sanitizer/water solution to sanitize all removed components. Use a cloth or sponge to liberally apply the solution to all surfaces of the removed parts or soak the removed parts in the sanitizer/water solution. **Do not rinse parts after sanitizing**.

Step 20 Use 1/2 of the sanitizer/water solution to sanitize all foodzone surfaces of the ice machine and bin. Use a cloth or sponge to liberally apply the solution. When sanitizing, pay particular attention to the following areas:

- Evaporator plastic parts including top, bottom and sides
- Bin bottom, sides and top

Do not rinse the sanitized areas.

Step 21 Replace all removed components.

Step 22 Reapply power and water to the ice machine and set the toggle switch in the ICE position.

EXTERIOR CLEANING

Clean the area around the ice machine as often as necessary to maintain cleanliness and efficient operation.

Sponge any dust and dirt off the outside of the ice machine with mild soap and water. Wipe dry with a clean, soft cloth.

Treat all exterior stainless steel surfaces with a commercial grade stainless steel polish.

ICE MACHINE INSPECTION

Check all water fittings and lines for leaks. Also, make sure the refrigeration tubing is not rubbing or vibrating against other tubing, panels, etc.

Do not put anything (boxes, etc.) in front of the ice machine. There must be adequate airflow through and around the ice machine to maximize ice production and ensure long component life.

Air Filter and Air Condenser Maintenance

It is recommended to check the air filter and air condenser during De-scaling & Sanitizing Procedure.

AIR FILTER

The washable air filter on self-contained ice machines is designed to catch dust, dirt, lint and grease.

- · Clean the air filter once a month
- Wash with mild soap and water

CLEANING THE AIR CONDENSER

A dirty air condenser restricts airflow, resulting in excessively high operating temperatures. This reduces ice production and shortens component life. Clean the air condenser at least every six months. Follow the steps below.

- The washable aluminum filter on self-contained ice machines is designed to catch dust, dirt, lint and grease. This helps keep the condenser clean. Clean the filter with a mild soap and water solution.
- Clean the outside of the condenser with a soft brush or a vacuum with a brush attachment. Clean from top to bottom, not side to side. Be careful not to bend the condenser fins.
- Shine a flashlight through the condenser to check for dirt between the fins. If dirt remains: Blow compressed air through the condenser fins from the inside. Be careful not to bend the fan blades.
- Use a commercial condenser coil cleaner. Follow the directions and cautions supplied with the cleaner.
- 5. Straighten any bent condenser fins with a fin comb.
- Carefully wipe off the fan blades and motor with a soft cloth. Do not bend the fan blades. If the fan blades are excessively dirty, wash with warm, soapy water and rinse thoroughly.

REMOVAL FROM SERVICE/WINTERIZATION

Self-contained Air-cooled ice machines

Special precautions must be taken if the ice machine is to be removed from service for an extended period of time or exposed to ambient temperatures of 32°F (0°C) or below.

- Disconnect the electric power at the circuit breaker or the electric service switch.
- 2. Turn off the water supply.
- 3. Remove the water from the water trough.
- 4. Disconnect the drain and the incoming ice-making water line at the rear of the ice machine.
- Make sure no water is trapped inside the ice machine incoming water lines, drain lines, distribution tubes, etc.

THIS PAGE INTENTIONALLY LEFT BLANK

Operation

Touch Pad

140/190/240/310 Series

The NEO touch pad offers a series of pressure-sensitive buttons to control ice machine operation and provide operational status.

LIGHTS (WITHOUT WATER FILTER - U/UF SERIES)



On/Off - Blue

On = Machine Is On
Off = Machine Is Off

Delay - BLUE

On = Delay Mode Is On

Off = Delay Mode Is Off

Clean - YELLOW

On = Clean Cycle Is On

Off = Cleaning Is Off

Flashing = Cleaning Is Paused

Rin - BIUF

On = Bin Is Full

Off = Bin Is Not Full

Service - RED

On = Service Limit

Off = Does Not Need Service

NOTE: Touch pad is to be activated with finger tips only. Do not disassemble touch pad.

LIGHTS (WITH WATER FILTER - UP SERIES ONLY)



On/Off - BLUE
On = Machine Is On
Off = Machine Is Off

Delay - BLUE
On = Delay Mode Is On
Off = Delay Mode Is Off

Clean - YELLOW
On = Clean Cycle Is On
Off = Cleaning Is Off
Flashing = Cleaning Is Paused

Water Filter Replacement - RED Flashing = Change Water Filter

Bin - BLUE
On = Bin Is Full
Off = Bin Is Not Full

Service - RED On = Service Limit

Off = Does Not Need Service

NOTE: Touch pad is to be activated with finger tips only. Do not disassemble touch pad.

BUTTONS & ICONS

On/Off Button

The On/Off button is used to start and stop ice making.

 Pressing the On/Off button for 3 seconds will power off the unit.

The blue light indicates whether the ice machine is Ice Making (light on) or Off (light off).

NOTE: If ice is on the evaporator (during the freeze or harvest cycle) and the On/Off button is pressed, the next cycle will have a thick slab of ice. Press the On/Off button and allow the ice to melt off the evaporator, then start a new freeze cycle.

Delay Button

Pressing the Delay button will start a delay period. The ice machine will finish the freeze and harvest cycle and then start the delay period.

U/UF Models

- Pressing the button once will start a 4 hour delay.
- Pressing the button twice will start a 12 hour delay.
- Pressing the button three times will start a 24 hour delay.
- Pressing the button four times will cancel the delay.

UP Models

- Pressing the button once will start an 8 hour delay.
- Pressing the button twice will start a 16 hour delay.
- Pressing the button three times will cancel the delay or by pressing the button once during a delay.
- Press and hold the delay button for 3 seconds to set the delay to repeat daily.

NOTE: The delay period will be canceled if power is interrupted to the ice machine. When power is restored, the ice machine will remain Off.

Clean Button

Pressing the Clean button for 3 seconds with the machine off will start a clean cycle. After the clean cycle is complete, the ice machine will automatically start an ice making cycle.

- Pressing the Clean button again within 45 seconds of the clean cycle starting will abort the clean cycle.
- Pressing the On/Off button anytime during the clean cycle will de-energize the On/Off light and the ice machine will stop after the clean cycle is complete.
- Pressing the Clean button will pause the clean cycle. The On/Off and Clean lights will flash On/Off to indicate pause mode. Pressing the Clean button again will continue the clean cycle from the point of interruption.

NOTE: Opening the ice damper for 30 seconds will cancel the clean cycle.

Water Filter Replacement Button - UP Models Only

When the ice machine completes 4,000 freeze/harvest cycles the water filter light will energize to indicate the water filter needs replacement.

- Pressing the Water Filter button for 4 seconds will reset the counter and initiate a flush sequence. Once the 5 minute flush sequence is complete the light will de-energize.
- Pressing the Water Filter button once will de-energize the light for 24 hours but will not reset the change water filter reminder.

Bin Full Icon

The Bin Full light energizes when the bin is full or is de-energized if the bin is not full.

Service Icon

The Service light indicates the machine needs attention.

Refer to service limits if this light is energized.

CONTROL BOARD REVISIONS

- 1. Original control board
- Control board with J4 terminal, which can utilize a thermistor to control when/if a water pump delay occurs in the freeze cycle.
- Control board with the addition of J8 & J9 terminals.
 The J8 terminal can control an EC fan motor.

NOTE: The replacement control board is backward compatible and can be used without thermistors or EC fan motors.

FIRMWARE REVISIONS

In addition to the primary sequence of operation the following firmware changes have been added.

Control boards with water trough thermistor and firmware version before 2.70

The water trough thermistor performs the following function in the freeze cycle:

- When the temperature of the water reaches 34° F the water pump de-energizes for 25 seconds, then re energizes.
- When the water pump restarts the water inlet solenoid energizes for 7 seconds..

2.70 and Higher

 120 second prechill cycle on initial start and 60 second prechill cycles thereafter.

ICE MAKING SEQUENCE OF OPERATION

U/UF Series

NOTE: The On/Off button must be powered On - light blue and the ice damper must be closed before the ice machine will start.

The following is the primary sequence of operation. Firmware revisions will alter some of the timing sequences and are noted in firmware revisions.

Initial Start-up From Shutoff

The dump valve energizes to purge any water in the water trough down the drain. The harvest valve energizes to equalize refrigerant pressures before the compressor starts.

Freeze Cycle

Prechill - The refrigeration system chills the evaporator before water flow over the evaporator starts. The water inlet valve energizes during the prechill and remains on until the ice thickness float switch is satisfied.

Freeze - Water flowing across the evaporator cools as the freeze cycle progresses. (Firmware version 2.58 or higher: The water pump turns off for 25 seconds and the water inlet valve energizes for 7 seconds when the pump restarts) Water flowing across the evaporator will start to freeze and build ice on the evaporator. After a sheet of ice has formed, the harvest float switch signals the control board to start a harvest cycle.

Harvest Cycle

Every third cycle the remaining water is purged down the drain. The refrigerant gas warms the evaporator and the sheet of cubes slides off the evaporator and into the storage bin. If all cubes fall clear of the ice damper the ice machine starts another freeze cycle. The maximum harvest time is a total of 7 minutes.

If the bin switch does not activate within 3.5 minutes, the harvest cycle extends another 3.5 minutes.

Full Bin Cycle

If the ice damper is held open by ice cubes the ice machine shuts off. When the ice damper closes the ice machine starts a new cycle at Initial Start-up From Shutoff. The ice machine will remain off for a 3 minute delay period.

Thaw Cycle

The maximum harvest time is a total of 7 minutes. If the bin switch does not activate within 7 minutes a thaw cycle initiates using the following sequence:

- 1. The compressor de-energizes.
- The water inlet valve energizes and fills the water trough.
- 3. The water pump energizes for 2 minutes and circulates water over the evaporator.

If the bin switch did not open & close.

- The water dump valve energizes and drains water from the water trough.
- 5. Step 1 through 4 repeat.
- If the damper does not open/close after step 5, the control board assumes no ice is on the evaporator and an initial startup cycle starts.
- If the bin switch opens & closes anytime during the thaw cycle the ice machine starts a new freeze cycle.
- If the bin switch opens and remains open for 30 seconds at any point in the thaw cycle the ice machine will enter an automatic shutoff cycle.
- The maximum water fill time for the thaw cycle is 105 seconds for each of the two possible thaw cycles.

CONTROL BOARD TIMERS

U/UF Series

- The ice machine is locked into the freeze cycle for 6 minutes before a harvest cycle can be initiated.
- The freeze time lock in feature is bypassed on the initial cycle (manual start or after a full bin/service limit condition).
- **Firmware version before 2.58:** The water fill valve is de-energized 1 minute after the freeze cycle starts. The control board will energize the water inlet valve one more time 3 minutes into the freeze cycle.
- If the harvest float switch is in the down position for 10 continuous seconds during the start of a freeze cycle, a harvest sequence is initiated.
- The maximum freeze time is 35 minutes at which time the control board automatically initiates a harvest sequence.
- The maximum harvest time is a total of 7 minutes.
 If the bin switch does not activate within 3.5 minutes,
 the harvest cycle extends another 3.5 minutes.
 If 7 minutes is exceeded a thaw cycle starts.
- After the initial harvest cycle from either an automatic shut off or initial start the dump valve solenoid will only energize and purge the water in the water trough every third cycle.

Control boards with thermistor and firmware version before 2.70

The water trough thermistor performs the following function in the freeze cycle:

- When the temperature of the water reaches 34° F the water pump de-energizes for 25 seconds, then re energizes.
- When the water pump restarts the water inlet solenoid energizes for 7 seconds.

SERVICE LIMITS

U/UF Series

Service limits are stored and indicated by the control board. The number of cycles required to stop the ice machine varies for each service limit.

Service limits can be reset by pressing the On/Off button and starting a new ice making cycle.

A service limit shutdown is indicated by the red Service light on the touch pad.

Service Limit 1

If the freeze time reaches 35-60 minutes*, the control board automatically initiates a harvest cycle.

- After 3 consecutive 35-60 minute* cycles control board light SL#1 along with the touch pad Service (wrench) light will flash on/off at 1 second intervals.
- If 6 consecutive 35-60 minute* freeze cycles occur, the ice machine stops and the SL#1 light on the control board and the Service (wrench) light on the touch pad will be on continuously.

NOTE: *Verify your firmware version (label on the control board) for freeze time.

Firmware	Freeze
Version	Time
V1.0 to V2.53	60 minutes
V2.54 to V2.9	45 minutes
UF Models: V3.0 to current	35 Minutes

Service Limit 2

- If the harvest time reaches 3.5 minutes, the control board automatically energizes the water pump and extends the harvest cycle another 3.5 minutes (7 minutes total).
- If the ice damper does not open and close within the 7 minute harvest cycle the ice machine enters a water thaw cycle for 170 seconds.
- If the damper does not open/close within the 170 second thaw cycle, a second thaw cycle starts.
- The control board automatically initiates a freeze sequence when the thaw cycle(s) is complete.
- If 3 consecutive 7 minute harvest/thaw cycles occur, the ice machine stops.

Service Limit 3

If the freeze time reaches 4 minutes and water is not sensed (float remains down for 10 continuous seconds) the ice machine stops.

- Service Limit 3 is bypassed on the initial cycle (manual start or after a full bin/service limit condition). For all subsequent cycles if the freeze time reaches 4 minutes and water is not sensed, the ice machine stops and initiates a 30 minute delay period. Control board lights SL#1 and SL#2 along with the touch pad Service (wrench) light will flash on/off at 1 second intervals.
- The ice machine automatically restarts at the end of the 30 minute delay period and stops flashing the control board and Service (wrench) lights.
- If 100 consecutive failures occur the ice machine stops and the touch pad Service (wrench) light remains energized.

ENERGIZED PARTS CHART

U/UF Series

Length of Time	20 seconds	5 seconds	60 Seconds 120 Seconds Initial Cycle After Automatic Shutoff	Until Harvest Float Switch closes for 10 continual seconds
Ice Thickness Float Switch	Closed	Closed	Closed	Closed Then Open
Harvest Float Ice Thickness Switch Float Switch	Closed	Closed	Open	Open Then Closed
Compressor & Condenser Fan Motor *	JJO	uO	uO	On
Dump Valve	On	Off	Off	Off
Harvest Water Inlet Valve Valve	Off	Off	O	% u O
Harvest Valve	On	On	ЭŲ	Off
Water Pump	JJO	JJO	ДO	0n**
ICE MAKING SEQUENCE OF OPERATION	Initial Start-up 1. Water purge	2. Refrigeration System Start-up	Freeze Sequence 3. Prechill	4. Freeze

20 seconds Water purge initial cycle, then every 3rd cycle thereafter	Closed Bin switch activation	Closed switch re-closure
Closed	Closed	Closed
O	On	JJO
Initial cycle, then every 3rd	***JJO	JJO
Off	***#O	μо
On	On	μо
Off	***JJO	ЭŲ
Harvest Sequence 5. Water Purge	6. Harvest	7. Automatic Shutoff
	Off On Off then On Closed Closed every 3rd	Off On Off then On Closed Closed Closed Off*** On Off*** On Off***

* Condenser Fan Motor: The fan motor is wired through a fan cycle pressure control; therefore, it may cycle on and off.

Firmware prior to 2.58 - The water fill valve is de-energized by the control board 1 minute after the freeze cycle starts - The control board will energize the ** Firmware 2.58 with thermistor - When the water temperature reaches 34°F the water pump de-energizes for 25 seconds. When the pump restarts the water inlet valve energizes for 7 seconds. Firmware 2.58 without thermistor - At 3.75 minutes the water pump de-energizes for 25 seconds. When the water inlet valve for 7 seconds one last time, 3 minutes into the freeze cycle, regardless of float position. pump restarts the water inlet valve energizes for 7 seconds.

^{***} Will be energized during harvest when time exceeds 3.5 minutes.

ICE MAKING SEQUENCE OF OPERATION

UP Series

NOTE: The On/Off button must be powered On - light blue and the ice damper must be closed before the ice machine will start.

Water Purge Cycle

The ice machine purges any remaining water from the water trough down the drain.

Freeze Cycle

Pre-chill - The refrigeration system chills the evaporator before water flow over the evaporator starts. The water inlet valve energizes during the pre-chill and remains on until the ice thickness float switch is satisfied.

- When the water temperature reaches 34°F (1°C), the water pump will de-energize for 25 seconds, then re-energizes.
- When the water pump restarts the water inlet solenoid energizes for 7 seconds.
- Water flowing across the evaporator will start to freeze and build ice on the evaporator. After a sheet of ice has formed, the harvest float switch signals the control board to start a harvest cycle.

Harvest Cycle

Every fourth cycle, any remaining water is purged down the drain as refrigerant gas warms the evaporator. When the evaporator warms, the sheet of cubes slides off the evaporator and into the storage bin. If all cubes fall clear of the ice damper, the ice machine starts another freeze cycle.

Full Bin Cycle

If the ice damper is held open by ice cubes, the ice machine shuts off. When the ice damper closes, the ice machine starts a new cycle at the water purge.

Control Board Timers

UP Series

The control board has the following non-adjustable timers:

- The ice machine is locked into the freeze cycle for 6 minutes before a harvest cycle can be initiated.
- The maximum freeze time is 45 minutes, at which time the control board automatically initiates a harvest sequence.
- The maximum harvest time is 7 minutes. When harvest is complete the control board automatically initiates a freeze sequence.
- If the ice damper does not open and close within
 the 7 minute harvest cycle, the ice machine enters
 a water thaw cycle for 170 seconds. If the damper
 does not open and close within the 170 second thaw
 cycle, a second thaw cycle starts. The control board
 automatically initiates a freeze sequence when the
 thaw cycle(s) is complete.

Service Limits

UP Series

Service limits are stored and indicated by the control board. The number of cycles required to stop the ice machine varies for each service limit.

Service limits can be reset by pressing the On/Off button and starting a new ice making cycle.

A service limit is indicated by an energized Service Light on the touch pad.

- Service Limit 1 If the freeze time reaches 45 minutes, the control board automatically initiates a harvest cycle. After 6 consecutive 45-minute freeze cycles occur, the ice machine stops.
- Service Limit 2 If the harvest time reaches 3.5 minutes, the control board automatically energizes the water pump and extends the harvest cycle another 3.5 minutes (7 minutes total). If the ice damper does not open and close within the 7 minute harvest cycle, the ice machine enters a water thaw cycle for 170 seconds. If the damper does not open and close within the 170 second thaw cycle, a second thaw cycle starts. The control board automatically initiates a freeze sequence when the thaw cycle(s) is complete. If 3 consecutive 7 minute harvest and thaw cycles occur, the ice machine stops.
- Service Limit 3 Harvest Float Only: If the freeze time reaches 4 minutes and water is not sensed, the ice machine stops and initiates a 30 minute delay period. The ice machine will automatically restart at the end of the 30 minute delay period. If 100 consecutive failures occur, the ice machine stops.

ENERGIZED PARTS CHART

S
a
:=
~
۳,
٠,
Δ.
$\overline{}$

ICE MAKING SEQUENCE OF OPERATION	Water	Harvest Valve	Water Harvest Water Inlet Pump Valve Valve	Dump Valve	Compressor & Condenser Fan Motor *	Harvest Float Ice Thickness Switch Float Switch	Ice Thickness Float Switch	Length of Time
Initial Start-up 1. Water purge	ЭJO	uO	Off	On	JJO	Closed	Closed	20 seconds
2. Refrigeration System Start-up	JJO	uO	Off	Off	uO	Closed	Closed	5 seconds
Freeze Sequence 3. Prechill	ΉΟ	ДO	On	Off	uO	Open	Closed	60 Seconds 120 Seconds Initial Cycle After Automatic Shutoff
4. Freeze	**n0	JJ0	** **	Off	On	Open Then Closed	Closed Then Open	Until Harvest Float Switch closes for 10 continual seconds

ICE MAKING SEQUENCE OF OPERATION	Water	Harvest Valve	Water Harvest Water Inlet Dump Pump Valve Valve Valve	Dump Valve	Compressor & Condenser Fan Motor *	Harvest Float Ice Thickness Switch Float Switch	Ice Thickness Float Switch	Length of Time
Harvest Sequence	5	Č	i,	Initial cycle,	d	7	-	20 seconds Water purge initial cycle,
5. Water Purge	5	5	5	tnen every 3rd	S O	Closed	Closed	then every 3rd cycle thereafter
6. Harvest	***#O	On	***#O	***JJO	On	Closed	Closed	Bin switch activation
7. Automatic Shutoff	μο	ЩO	Off	Off	ΉΟ	Closed	Closed	3 Minute delay and bin switch re-closure

** Firmware 2.58 with thermistor - When the water temperature reaches 34°F the water pump de-energizes for 25 seconds * Condenser Fan Motor: The fan motor is wired through a fan cycle pressure control; therefore, it may cycle on and off

When the pump restarts the water inlet valve energizes for 7 seconds

*** Every fourth cycle and will energize during harvest when time exceeds 3.5 minutes

**** The water pump de-energizes for 25 seconds then re-energizes

Operational Checks

140/190/240/310 Series


ICE THICKNESS CHECK

After a harvest cycle, inspect the ice cubes in the ice storage bin. The ice bridge connects the ice cubes and must be set to maintain an ice bridge thickness of 1/8" (3.2 mm). To adjust the thickness of the bridge refer to ice thickness adjustment.

ICE THICKNESS ADJUSTMENT

The ice thickness can be adjusted to three levels.

- Pull forward on the bottom of the bracket until clear of the tab.
- 2. Slide the bracket over the desired tab and release.
 - The center position is the normal factory setting.
 - To increase bridge thickness, raise the water level.
 - To decrease bridge thickness, lower the water level.



MINIMUM/MAXIMUM SLAB WEIGHT

140/190/240/310 Series

Model	Minimum Ice Weight Per Cycle Ibs Grams	Maximum Ice Weight Per Cycle Ibs Grams
U0140 UF0140 UP0140	1.1 lbs 513 grams	1.4 lbs 617 grams
U0190 UF0190 UP0190	2.3 lbs 1025 grams	2.9 lbs 1329 grams
U0240 UF0240 UP0240	2.3 lbs 1025 grams	2.9 lbs 1329 grams
U0310 UF0310 UP0310	2.3 lbs 1025 grams	2.9 lbs 1329 grams

Optional Cycle Bypass - Water Purge

140/190/240/310 Series

To bypass this feature and purge every harvest cycle:

- Press & hold the Clean button for
 3 seconds while in the ice making cycle.
- 2. Press the Delay button.
- The Service light will flash red, 5 times to indicate bypass. The machine will purge water every cycle.
- 4. Repeat steps to reinstate fourth cycle water purge.
- 5. The Service light will flash red, 6 times to indicate fourth cycle water purge.

NOTE: Bypassing the Water Purge will increase water usage.

UDE0065/UDP0065

ICE MAKING SEQUENCE OF OPERATION Initial Startup or Startup After Automatic Shut-off

1. Water Purge

The water fill valve and the hot gas valve are energized for 2.9 minutes (175 seconds). This ensures that the ice making cycle starts with fresh water, and that the refrigerant pressures are equalized prior to refrigeration system start-up.

2. Refrigeration System Start-up

The compressor starts 2.9 minutes (175 seconds) after the water fill valve and hot gas valve are energized. (The water fill valve and hot gas valve remain energized for 5 seconds during compressor start-up, and then shut off.) The compressor remains on throughout the entire freeze and harvest cycles.

3. Freeze Cycle

The condenser fan motor and water pump are energized and remain on throughout the entire freeze cycle. An even flow of water is directed across the evaporator and into each cube cell, where it freezes. The control system automatically determines the length of the freeze cycle by monitoring the temperature of the refrigeration system liquid line.

4. Harvest Cycle

The condenser fan motor and water pump de-energize.

The water fill valve energizes to purge the water in the water trough. The hot gas valve also energizes at the beginning of the harvest cycle to divert hot refrigerant gas into the evaporator. The hot refrigerant gas warms the evaporator, causing the cubes to slide, as a sheet, off the evaporator and into the ice storage bin.

The control system automatically determines the length of the harvest cycle, based on the temperature of the refrigeration system liquid line at the end of the freeze cycle. At the end of the harvest cycle, the ice machine returns to another freeze cycle (step 3).

5. Automatic Shut-off

The level of ice in the ice storage bin controls the ice machine shut-off. When the bin is full, ice cubes contact the bin thermostat bulb holder, which cools down and opens to stop the ice machine. The ice machine remains off until enough ice has been removed from the bin. This causes the thermostat bulb holder to warm and close, restarting the ice machine.

When the ice machine restarts, it returns to the startup sequence (steps 1-2).

ENERGIZED PARTS CHART

UDE0065/UDP0065

Length of Time		
	3	Water Birms
Control Board Relays	2	Hot Gar Walto
	1	Comprocor
Ice Making Sequence Of Operation		

Ice Making Sequence Of Operation		Control Board Relays		Length of Time
	1	7	æ	
	Compressor	Hot Gas Valve	Water Pump	
		Water Fill Valve	Fan Motor	
Initial Start-up	ЭJO	uo	JJo	175 Seconds (2.9 minutes)
1. Water Purge 2. Refrigeration Start-up	uo	uo	off	5 Seconds
3. Freeze Cycle	on	JJo	on	Automatically Determined
4. Harvest cycle	on	no	off	Automatically Determined
5. Automatic Shut-off	off	off	off	Until Bin Thermostat Closes


ICE THICKNESS CONTROL DIAL ADJUSTMENT UDE0065/UDP0065

It is normal to have a dimple in the ice cube (a concave indentation in the cube). Cube size is determined by measuring the slab weight (the combined weight of all cubes from one harvest cycle). To determine proper slab weight follow the instructions listed below.



- Ensure the air filter, front, and back panels are installed properly and close the bin door.
- During the third harvest cycle open the bin door and catch the entire slab of ice.
- 3. Weigh the ice slab. The combined weight of all cubes from one harvest should weigh between 200 - 270g (7 - 9-oz). If the slab weight is within this range, the ice machine is working properly and no further action is needed. If the slab weight is not within this range or you desire a slightly thicker or thinner cube, continue to step four.
- 4. Remove the air filter, the two screws holding the front panel in place and remove the front cover.

 Locate the ice thickness control dial on the control board (see below). Turn the dial clockwise for a thicker cube or counter clockwise for a thinner cube.



Assure all panels and the air filter are reinstalled properly and the bin door is closed. Repeat steps one through three.

MINIMUM/MAXIMUM SLAB WEIGHT UDE0065/UDP0065

Adjust ice thickness to meet chart specifications.

Minimum	Maximum
Ice Weight Per Cycle	Ice Weight Per Cycle
0.44 lbs	0.60 lbs
(200 g)	(272g)

Notice

Routine adjustments and maintenance procedures are not covered by the warranty.

UDE0080/UDP0080

ICE MAKING SEQUENCE OF OPERATION

Initial start-up or start-up after automatic shut-off

1. Pressure Equalization

Before the compressor starts the hot gas valve is energized for 15 seconds to equalize pressures during the initial refrigeration system start-up.

2. Refrigeration System Start-up

The compressor starts after the 15-second pressure equalization, and remains on throughout the entire Freeze and Harvest Sequences. The hot gas valve remains on for 5 seconds during initial compressor start-up and then shuts off. At the same time the compressor starts, the condenser fan motor (air-cooled models) is supplied with power throughout the entire Freeze and Harvest Sequences. The fan motor is wired through a fan cycle pressure control, therefore it may cycle on and off. (The compressor and condenser fan motor are wired through the relay. As a result, any time the relay coil is energized, the compressor and fan motor are supplied with power.)

3. Prechill Cycle

The compressor is on for 30 seconds prior to water flow to prechill the evaporator.

4. Freeze Cycle

The water pump starts after the 30-second prechill. An even flow of water is directed across the evaporator and into each cube cell, where it freezes. When sufficient ice has formed, the water flow (not the ice) contacts the ice thickness probe. After approximately 7 seconds of continual water contact, the Harvest Sequence is initiated. The ice machine cannot initiate a Harvest Sequence until a 6-minute freeze time has been surpassed.

5. Harvest Cycle

The water pump de-energizes stopping flow over the evaporator. The rising level of water in the sump trough diverts water out of the overflow tube, purging excess minerals from the sump trough. The hot gas valve also opens to divert hot refrigerant gas into the evaporator.

The refrigerant gas warms the evaporator causing the cubes to slide, as a sheet, off the evaporator and into the storage bin. The sliding sheet of cubes contacts the ice damper, opening the bin switch.

The momentary opening and re-closing of the bin switch terminates the Harvest Sequence and returns the ice machine to the Freeze Sequence.

6. Automatic Shut-Off

When the storage bin is full at the end of a Harvest Sequence, the sheet of cubes fails to clear the ice damper and will hold it down. After the ice damper is held open for 7 seconds, the ice machine shuts off. The ice machine remains off for 3 minutes before it can automatically restart.

The ice machine remains off until enough ice has been removed from the storage bin to allow the ice to fall clear of the damper. As the ice damper swings back to the operating position, the bin switch re-closes and the ice machine restarts (steps 1 - 2), provided the 3-minute delay period is complete.

ENERGIZED PARTS CHART

UDE0080/UDP0080

ICE MAKING		Control Board Relays	S	Relay	lay	Length of
SEQUENCE OF OPERATION	1 Water Pump	2 Hot Gas Valve	3 Relay Coil	3A Compressor	3B Compressor Fan Motor*	Time
Initial Start-up 1. Water purge	off	uo	у	off	ЭJO	15 seconds
2. Refrigeration System Start-up	off	uo	uo	uo	uo	5 seconds
Freeze Sequence 3. Prechill	off	JJo	uo	uo	uo	30 seconds
4. Freeze	on	off	uo	on	on	Until 7 sec. Water contact w/ice thickness probe

ICE MAKING	0	Control Board Relays	S	Re	Relay	Length of
SEQUENCE OF OPERATION	1 Water Pump	2 Hot Gas Valve	3 Relay Coil	3A Compressor	3B Compressor Fan Motor*	Time
Harvest Sequence 5. Harvest	ДO	uo	uo	uo	uo	Bin switch activation
Automatic Shut-off 6. Auto Shut-off	JJo	off	JJo	JJo	off	Until bin switch re-closes


SIPHON SYSTEM CHECK

UDE0080/UDP0080

To reduce mineral build-up and cleaning frequency, the water in the sump trough must be purged during each harvest cycle.

When the water pump de-energizes the level in the water trough rises above the standpipe starting a siphon action. The siphon action stops when the water level in the sump trough drops. When the siphon action stops, the float valve refills the water trough to the correct level.


Follow steps 1 through 6 under water level check to verify the siphon system functions correctly.



WATER FLOAT VALVE CHECK

UDE0080/UDP0080


Before water will flow into the water trough the float valve shut-off must be in the OPEN position.



WATER LEVEL CHECK

UDE0080/UDP0080

Check the water level while the ice machine is in the ice mode and the water pump is running. The correct water level is 1/4" (6.3 mm) to 3/8" (9.5 mm) below the top of the standpipe, a line in the water trough indicates the correct level.



WATER LEVEL CHECK

UDE0080/UDP0080

The float valve is factory-set for the proper water level.

If adjustments are necessary:

- 1. Verify the ice machine is level.
- 2. Remove the siphon cap from the standpipe.
- Place the main ON/OFF/WASH toggle switch to the ON position, and wait until the float valve stops adding water.
- 4. Adjust the water level to [1/4" to 3/8" (6.3 to 9.5 mm) below the standpipe] the line in the water trough:
 - A. Loosen the two screws on the float valve bracket.
 - B. Raise or lower the float valve assembly as necessary, then tighten the screws.
 - C. Move the main ON/OFF/WASH toggle switch to the OFF position. The water level in the trough will rise above the standpipe and run down the drain.
- Replace the siphon cap on the standpipe, and verify water level and siphon action by repeating steps 3 through 5.

ICE THICKNESS PROBE ADJUSTMENT


UDE0080/UDP0080

The ice thickness probe is factory-set to maintain the ice bridge thickness at 1/8" (3.2 mm).

NOTE: Make sure the Ice Damper is in place when performing this check. It prevents water from splashing out of the water trough.

- After a harvest cycle, inspect the bridge connecting the cubes. It should be about 1/8" (3.2 mm) thick.
- If adjustment is necessary, turn the ice thickness probe adjustment screw clockwise to increase bridge thickness, or counterclockwise to decrease bridge thickness.

NOTE: Turning the adjustment 1/3 of a turn will change the ice thickness about 1/16" (1.5 mm).



Ice Thickness Check

Make sure the ice thickness probe wire and the bracket do not restrict movement of the probe.

MINIMUM/MAXIMUM SLAB WEIGHT UDE0080/UDP0080

Adjust ice thickness to meet chart specifications.

Minimum	Maximum
Ice Weight Per Cycle	Ice Weight Per Cycle
1.2 lbs	1.4 lbs
(544 g)	(635g)

Notice

Routine adjustments and maintenance procedures are not covered by the warranty.

THIS PAGE INTENTIONALLY LEFT BLANK

Troubleshooting

140/190/240/310 Series

See "Troubleshooting" on page 155 for U0065 Series and "Troubleshooting" on page 182 for U0080 Series

PROBLEM CHECKLIST

Problem	Possible Cause	Correction
Ice machine does	No electrical power to the ice machine.	Replace the fuse/reset the breaker/turn on the main switch/plug power cord into receptacle.
Ice machine does not operate.	Ice machine needs to be turned on.	Press the On/Off button to start ice making.
	Damper in open position (down).	Damper must be in upright position and capable of swinging freely.
Ice machine stops, and can be restarted by turning the ice machine OFF/ ON.	Service limit feature stopping the ice machine.	Refer to Service Limit Feature U/UF: page 87 UP: page 93
	Ice machine is dirty.	Descale and sanitize the ice machine. page 42
Ice machine does not release	Ice machine is not level.	Level the ice machine. page 28
ice or is slow to harvest.	Low air temperature around ice machine (air-cooled models).	Air temperature must be at least 40° F (4°C).
	Water regulating valve leaks in harvest mode (water-cooled models).	Replace water regulating valve.
	The six-minute freeze time lock-in has not expired yet.	Wait for freeze lock-in to expire.
Ice machine does not cycle into harvest mode.	Harvest float switch is dirty.	Descale and sanitize the ice machine. page 42
	Harvest float switch wire is disconnected.	Connect the wire.
	Harvest float switch is out of adjustment.	Adjust the harvest float switch. page 220
	Uneven ice fill (thin at top of evaporator).	Refer to Shallow or Incomplete Cubes.

Problem	Possible Cause	Correction
	Poor incoming water quality.	Test the quality of the incoming water and make appropriate filter recommendations.
Ice quality is poor (soft or not	Water filtration is poor.	Replace the filter. page 51
clear).	Ice machine is dirty.	Descale and sanitize the ice machine. page 42
	Water softener is working improperly (if applicable).	Repair the water softener. (if applicable).
Ice machine produces shallow	Ice thickness switch is out of adjustment.	Adjust the ice thickness switch. page 96
	Water trough level is too high or too low.	Check the water level.
or incomplete	Water filtration is poor.	Replace the filter. page 51
ubes, or the ice ill pattern on he evaporator is ncomplete.	Hot incoming water.	Connect the ice machine to a cold water supply.
	Incorrect incoming water pressure.	Water pressure must be 20-80 psi (137.9 -551.5 kPa).
	Ice machine is not level.	Level the ice machine. page 28
	The condenser is dirty.	Clean the condenser. page 52
	High air temperature around ice machine (air-cooled models).	Air temperature must not exceed 110° F (43°C).
	Inadequate clearance around the ice machine.	Provide adequate clearance.
Low ice capacity.	Objects stacked around ice machine, blocking condenser airflow.	Remove items blocking airflow.
	Hot incoming water.	Connect to cold water.
	Incorrect incoming water pressure. Water pressure is too low or	Water pressure must be 20-80 psi (137.9 -551.5 kPa).
	water filter is restricted.	Replace water filter.

Problem	Possible Cause	Correction
	Water trough level is too high.	Adjust ice thickness float. page 96
	Power button was turned off/on during the freeze cycle and ice remained on the evaporator.	Allow ice to thaw and release from the evaporator, then restart.
Ice sheet is thick.	Ice damper was opened and closed in the harvest cycle before the ice released	Allow ice to thaw and release from the evaporator, then restart
	Long harvest cycles with repeated service limit indication.	Descale the ice machine & perform diagnostic procedures as required.
	Incoming water pressure is over 80 psig (5 bar, 552 kPa).	Verify incoming water pressure.

CONTROL BOARD TEST MODE

140/190/240/310 SERIES

NOTE: The ice damper/bin switch can be open or closed and does not effect the operation of the test mode.

To enter the test mode press and hold the test switch on the control board for 3 seconds. Refer to "Electronic Control Boards" on page 306 for test button location. The control board test mode performs the following functions for a 2 minute time period:

- Energizes all control board relays
- Energizes all control board lights
- · Energizes all touch pad control lights

After the 2 minute test period the control board will complete 500 ice making cycles, then stop.

Canceling a test cycle:

To cancel a test cycle press the test button a second time.

Restarting a test cycle:

The test cycle will restart each time the test button is pressed for a 3 second time period.

OPERATING ICE MACHINE WITH BIN AND TOUCH PAD REMOVED

The ice machine is designed to allow diagnostic procedures to be performed with the bin removed or to run ice making cycles if a touch pad is defective. The touch pad is attached to the bin and is disconnected during the removal process. Use the control board test mode to operate the ice machine without connecting the touch pad. Refer to "Electronic Control Boards" on page 306 for test button location

NOTE: Firmware versions before 2.70 operate for 1 cycle in test mode. Firmware versions after 2.70 operate for 500 cycles in test mode.

Troubleshooting By Symptom

140/190/240/310 SERIES

The troubleshooting procedures follow diagnostic charts. There are four symptoms, the symptom that you are experiencing will determine which diagnostic chart to use. The chart asks yes and no questions to determine the problem. The diagnostic chart will direct you to a procedure to correct the problem.

SYMPTOM #1

Ice Machine Stops Running

Ice machine is in Ice Making cycle

or

Has a History of Shutting Down

Refer to Ice Machine Stops Running diagnostic chart

SYMPTOM #2

Ice Machine has a Long Freeze Cycle

Ice Formation is Thick

or

Thin Ice Fill on Inlet or Outlet of Evaporator

or

Low Production

Service Fault (possible)

 Refer to Freeze Cycle Refrigeration System Operational Analysis Table

SYMPTOM #3

Ice Machine Will Not Harvest - Freeze Cycle is Normal and Ice Cubes are Not Melted After Harvest

Long Harvest (possible)

• Refer to Refrigeration Harvest Flow Chart


SYMPTOM #4


Ice Machine Will Not Harvest - Freeze Cycle is Normal and Ice Cubes are Melted After Harvest


Refer to Ice Meltout Flow Chart

SYMPTOM #1

Ice Machine stops running or has history of shutting down







#2 - LOW PRODUCTION, LONG FREEZE CYCLE 140/190/240/310 Series

Ice Machine has a Long Freeze Cycle Ice Formation is Thick

or

Thin on Inlet or Outlet of Evaporator

or Low Production

How to Use the Freeze Cycle Refrigeration System Operational Analysis Table

GENERAL

These tables must be used with charts, checklists and other references to eliminate refrigeration components not listed on the tables and external items and problems which can cause good refrigeration components to appear defective.

The tables list five different defects that may affect the ice machine's operation.

NOTE: A low-on-charge ice machine and a starving expansion valve have very similar characteristics and are listed under the same column.

NOTE: Before starting, see "Before Beginning Service" for a few questions to ask when talking to the ice machine owner.

PROCEDURE

Step 1 Complete the "Operation Analysis" column.

Read down the left "Operational Analysis" column.
Perform all procedures and check all information listed.
Each item in this column has supporting reference material to help analyze each step.

While analyzing each item separately, you may find an "external problem" causing a good refrigerant component to appear bad. Correct problems as they are found. If the operational problem is found, it is not necessary to complete the remaining procedures.

Enter Checkmarks ($\sqrt{}$). Step 2

Each time the actual findings of an item in the "Operational Analysis" column matches the published findings on the table, enter a Checkmark.

Example: Freeze cycle suction pressure is determined to be low Enter a Checkmark in the "low" column

Step 3 Add the Checkmarks listed under each of the four columns. Note the column number with the highest total and proceed to "Final Analysis."

NOTE: If two columns have matching high numbers, a procedure was not performed properly, supporting material was not analyzed correctly or the problem component is not covered by the analysis table.

Before Beginning Service

Ice machines may experience operational problems only during certain times of the day or night. A machine may function properly while it is being serviced, but malfunctions later. Information provided by the user can help the technician start in the right direction, and may be a determining factor in the final diagnosis.

Ask these questions before beginning service:

- When does the ice machine malfunction? (night, day, all the time, only during the Freeze cycle, etc.)
- When do you notice low ice production? (one day a week, every day, on weekends, etc.)
- Can you describe exactly what the ice machine seems to be doing?
- Has anyone been working on the ice machine?
- During "store shutdown," is the circuit breaker, water supply or air temperature altered?
- Is there any reason why incoming water pressure might rise or drop substantially?

\vdash
\sim
7
-
÷.
O
S
-
S
>
_
⋖
_
5
۹
_
_
0
=
5
٧.
~
ш
G
=
œ
ш
ш
~
_

Operational Analysis	1	2	8	4
Ice Production	Cal NOTE: The ice machine is c	Published 24 hour ice production	uction	production is within 10%
Installation and Water System	Alli	All installation and water related problems must be corrected before proceeding with chart.	d problems must be correct ing with chart.	pə
Ice Formation Pattern	Ice formation is extremely thin on outlet of thin on outlet of thin on outlet of evaporator or-or- No ice formation on entire evaporator evaporator	Ice formation is extremely thin on outlet of thin on outlet of thin on outlet of evaporator or-or- No ice formation on entire evaporator evaporator		Ice formation is normal Ice formation is normal -or- Ice formation is extremely No ice formation on entire evaporator evaporator -or- No ice formation on evaporator

Operational Analysis	1	2	3	4
Service Limits Refer to "Analyzing Service Limits" to eliminate all non- refrigeration problems.	Stops on service limit: 1 or 2	Stops on service limit:	Stops on service limit:	Stops on service limit:
Ice Formation Pattern	Ice formation is extremely thin on outlet of evaporator -or-	Ice formation is extremely thin on outlet of thin on outlet of evaporator or evaporator or evaporator or evaporator or evaporator evaporator evaporator evaporator	_	Ice formation is normal -or -or ce formation is extremely thin on the bottom of evaporator -or No ice formation on evaporator evaporator evaporator
Service Limits Refer to "Analyzing Service Limits" to eliminate all non- refrigeration problems.	Stops on service limit: 1 or 2	Stops on service limit:	Stops on service limit: 1 or 2	Stops on service limit:

Operational Analysis	1	2	3	4
Freeze Cycle Discharge Pressure	If discharge pressure is Hig eliminate pro	If discharge pressure is High or Low, refer to freeze cycle high or low discharge pressure problem checklist to eliminate problems and/or components not listed on this table before proceeding.	cle high or low discharge pre	ssure problem checklist to e proceeding.
1 minute Middle End				
Freeze Cycle Suction Pressure	If suction pressure is Hig eliminate pro	If suction pressure is High or Low refer to freeze cycle high or low suction pressure problem checklist to eliminate problems and/or components not listed on this table before proceeding.	le high or low suction pressu not listed on this table befor	ure problem checklist to e proceeding.
1 minute Middle End	Suction pressure is High	Suction pressure is Low	Suction pressure is High	Suction pressure is High

Operational Analysis	1	2	3	4
Harvest Valve	The harvest valve inlet is HOT and and The compressor discharge line is HOT	The harvest valve inlet is COOL and The compressor discharge line is HOT	The harvest valve inlet is COOL and The compressor discharge line is COOL	The harvest valve inlet is COOL and The compressor discharge line is HOT
Discharge Line Temp. Record freeze cycle discharge line temp at the end of freeze cycle.	Discharge line temp 150°F (66°C) or higher at the end of freeze cycle	Discharge line temp 150°F (66°C) or higher at the end of freeze cycle	Discharge line temp less than 150°F (66°C) at the end of freeze cycle	Discharge line temp 150°F (66°C) or higher at the end of freeze cycle
Final Analysis Enter total number of boxes checked in each column.	Harvest Valve Leaking	Low On Charge -or- TXV Starving	TXV Flooding	Compressor

ICE MACHINE DOES NOT CYCLE INTO HARVEST WHEN THE HARVEST FLOAT IS DOWN/CLOSED

140/190/240/310 Series

NOTE: The ice machine will make a thick or double slab when a new freeze cycle is started with ice already present on the evaporator.

 The ice damper/bin switch is opened/closed in the harvest cycle before the ice releases.

Remove all ice from the evaporator before starting diagnostic procedures.

Freeze Time Lock-In Feature

The ice machine control system incorporates a freeze time lock-in feature. This prevents the ice machine from short cycling in and out of harvest. The control board locks the ice machine in the freeze cycle for six minutes. After six minutes a harvest cycle can be initiated. To allow the service technician to initiate a harvest cycle without delay, this feature is not used on the first cycle after pressing the power button OFF and back to ON.

Step 1 Disconnect power to the ice machine, remove the electrical panel to allow viewing of the control board lights and pull the wire connector for the harvest float switch through the bulkhead and disconnect. Attach a jumper wire to the wire terminals connected to the control board.

Step 2 Bypass the freeze time lock-in feature by pressing the power button to cycle the ice machine on. Wait until water flows over the evaporator, then refer to chart.


Result	Correction
10 seconds into the freeze cycle	The ice thickness float
the ice machine cycles from freeze	switch, connectors or
to harvest and the control board	wiring is causing the
harvest light energizes.	malfunction.
The harvest light comes on, but the	The ice machine is in a 6
ice machine remains in the freeze	minute freeze lock - Cycle
cycle.	on/off and retest.
The harvest light stays off and the ice	Replace the control
machine remains in freeze.	board

ICE MACHINE CYCLES INTO HARVEST BEFORE THE HARVEST FLOAT IS DOWN/CLOSED

140/190/240/310 Series

Step 1 Disconnect power to the ice machine, remove the electrical panel to allow viewing of the control board lights and pull the wire connector for the harvest float switch through the bulkhead and disconnect.

WIRE CONNECTORS ARE LOCATED BEHIND BULKHEAD PULL THROUGH GROMMET TO DISCONNECT



/ Caution

Do not disassemble a float for descaling/sanitizing or troubleshooting. The float magnet is not located in the center of the float and incorrect reassembly will result in an ice machine that will not harvest.

Step 2 Reapply power and press the power button to cycle the ice machine off/on and bypass the freeze time lock-in feature. Wait until water flows over the evaporator, then refer to chart.

Result	Correction
The harvest light does not come on	The ice thickness float
and the ice machine stays in freeze.	switch, connectors or
	wiring is causing the
	malfunction.
10 seconds into the freeze cycle	Replace the control board.
the ice machine cycles from freeze	
to harvest and the control board	
harvest light energizes.	

ICE PRODUCTION CHECK

140/190/240/310 Series

The amount of ice a machine produces directly relates to the operating water and air temperatures. This means an ice machine with a 70°F (21°C) ambient temperature and 50°F (10°C) water produces more ice than the same ice machine with 90°F (32°C) ambient and 70°F (21°C) water.

1.	Determine the ice machine operating conditions
	Air temp entering condenser:°
	Air temp around ice machine:°
	Water temp entering sump trough:°

- Refer to the appropriate "Cycle Times, 24 Hr. Ice Production and Refrigerant Pressure Charts" on page 251. Use the operating conditions determined in Step 1 to find published 24-Hour Ice Production:
 - Times are in minutes.
 Example: 1 min. 15 sec. converts to 1.25 min.
 (15 seconds ÷ 60 seconds = .25 minutes)
 - Weights are in pounds.
 Example: 2 lb. 6 oz. converts to 2.375 lb.
 (6 oz. ÷ 16 oz. = .375 lb.)
- Perform an ice production check using the formula below.

1.	Freeze Time	+	Harvest Time	=	Total Cycle Time
2.	Minutes in 24 Hrs.	÷	Total Cycle Time	=	Cycles per Day
3.	Weight of One Harvest	х	Cycles per Day	=	Actual 24-Hour Production

Weighing the ice is the only 100% accurate check.

- 4. Compare the results of step 3 with step 2. Ice production is normal when these numbers match closely. If they match closely, determine if:
 - Another larger ice machine is required.
 - Relocating the existing equipment to lower the load conditions is required.

Contact the local Manitowoc distributor for information on available options and accessories.

INSTALLATION/VISUAL INSPECTION CHECKLIST 140/190/240/310 Series

Ice machine is not level

Level the ice machine

Condenser is dirty

Clean the condenser

Water filtration is plugged (if used)

Install a new water filter

Water drains are not run separately and/or are not vented

· Run and vent drains according to the Install Manual

WATER SYSTEM CHECKLIST

A water-related problem often causes the same symptoms as a refrigeration system component malfunction.

Example: A water dump valve leaking during the freeze cycle, a system low on charge, and a starving TXV have similar symptoms.

Water system problems must be identified and eliminated prior to replacing refrigeration components.

Water area (evaporator) is dirty

Descale as needed

Water inlet pressure not between 20 and 80 psig (1–5 bar, 138–552 kPa)

 Install a water regulator valve or increase the water pressure

Incoming water temperature is not between 40°F (3°C) and 90°F (32°C)

 If too hot, check the hot water line check valves in other store equipment

Water filtration is plugged (if used)

Install a new water filter

Vent tube is not installed on water outlet drain

See Installation Instructions

Hoses, fittings, etc., are leaking water

• Repair/replace as needed

Water valve is stuck open, closed or is leaking

Descale/replace as needed

Water is spraying out of the sump trough area

Stop the water spray

Uneven water flow across the evaporator

Descale the ice machine

Water is freezing behind the evaporator

Correct the water flow

Plastic extrusions and gaskets are not secured to the evaporator

· Remount/replace as need

Water trough will not drain, Clean LED is flashing


- Verify drain line is installed correctly and unrestricted
- Verify Harvest and Ice Floats are clean
- Refer to float diagnostics

ICE FORMATION PATTERN

140/190/240/310 Series

Evaporator ice formation pattern analysis is helpful in ice machine diagnostics.

Analyzing the ice formation pattern alone cannot diagnose an ice machine malfunction. However, when this analysis is used along with Manitowoc's Refrigeration System Operational Analysis Table, it can help diagnose an ice machine malfunction.



Examples of Evaporator Tubing Routing

Normal Ice Formation

Ice forms across the entire evaporator surface.

At the beginning of the Freeze cycle, it may appear that more ice is forming on the inlet of the evaporator than at the outlet. At the end of the Freeze cycle, ice formation at the outlet will be close to, or just a bit thinner than, ice formation at the inlet. The dimples in the cubes at the outlet of the evaporator may be more pronounced than those at the inlet. This is normal.

If ice forms uniformly across the evaporator surface, but does not do so in the proper amount of time, this is still considered a normal ice fill pattern.

Extremely Thin at Evaporator Outlet

There is no ice, or a considerable lack of ice formation on the outlet of the evaporator.

Examples: No ice at all at the outlet of the evaporator, but ice forms at the inlet half of the evaporator. Or, the ice at the outlet of the evaporator reaches the correct thickness. but the outlet of the evaporator already has 1/2" to 1" of ice formation.

Possible cause: Water loss, low on refrigerant, starving TXV, hot water supply, faulty float valve, etc.

Extremely Thin at Evaporator Inlet

There is no ice, or a considerable lack of ice formation at the inlet of the evaporator, Examples: The ice at the outlet of the evaporator reaches the correct thickness, but there is no ice formation at all at the inlet of the evaporator.

Possible cause: Insufficient water flow, flooding TXV, etc.

Spotty Ice Formation

There are small sections on the evaporator where there is no ice formation. This could be a single corner, or a single spot in the middle of the evaporator. This is generally caused by loss of heat transfer from the tubing on the backside of the evaporator.

No Ice Formation

The ice machine operates for an extended period, but there is no ice formation at all on the evaporator.

Possible cause: Water float valve, water pump, starving expansion valve, low refrigerant charge, compressor, etc.

ANALYZING DISCHARGE PRESSURE

140/190/240/310 Series

1.	Determine the ice machine operating conditions:				
	Air temperature entering condenser				
	Air temperature around ice machine				
	Water temperature entering sump trough				
2.	 Refer to "Installation/Visual Inspection Checklist" of page 133 for ice machine being checked. 				
Use the operating conditions determined in step 1 to find the published normal discharge pressures.					
	Freeze Cycle				
	Harvest Cycle				
3.	Perform an actual discharge pressure check.				

5. Terrorm an actual discharge pressure check.						
	Freeze Cycle	Harvest Cycle				
	PSIG	PSIG				
Beginning of						
Cycle						
Middle of						
Cycle						
End of						
Cycle						

4. Compare the actual discharge pressure (Step 3) with the published discharge pressure (Step 2).

The discharge pressure is normal when the actual pressure falls within the published pressure range for the ice machine's operating conditions. It is normal for the discharge pressure to be higher at the beginning of the freeze cycle (when load is greatest), then drops throughout the freeze cycle.

Discharge Pressure High Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 133

Restricted Condenser Air Flow

- High inlet air temperature
- Condenser discharge air re-circulation
- · Dirty condenser fins
- Defective fan cycling control
- Defective fan motor

Improper Refrigerant Charge

- Overcharged
- Non-condensible in system
- Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- High side refrigerant lines/component restricted (before mid-condenser)

Freeze Cycle Discharge Pressure Low Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 133

Improper Refrigerant Charge

- Undercharged
- Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- High side refrigerant lines/component restricted (before mid-condenser)
- Defective fan cycle control

ANALYZING SUCTION PRESSURE

140/190/240/310 Series

The suction pressure gradually drops throughout the freeze cycle. The actual suction pressure (and drop rate) changes as the air and water temperature entering the ice machine changes. These variables also determine the freeze cycle times.

To analyze and identify the proper suction pressure drop throughout the freeze cycle, compare the published suction pressure to the published freeze cycle time.

NOTE: Analyze discharge pressure before analyzing suction pressure. High or low discharge pressure may be causing high or low suction pressure.

Procedure

Step

 Determine the ice machine operating conditions. Example:

Air temperature entering condenser: 90°F/32.2°C Air temperature around ice machine: 80°F/26.7°C

Water temperature entering water fill valve: 70°F/21.1°C
2A. Refer to "Cycle Time" and "Operating Pressure" charts for ice

machine model being checked. Using operating conditions from Step 1, determine published freeze cycle time and published freeze cycle suction pressure.

Example:

Published freeze cycle time: 14.8 - 15.9 minutes
Published freeze cycle suction pressure: 65 - 26 psiq

2B. Compare the published freeze cycle time and published freeze cycle suction pressure. Develop a chart.

Example:

Published Freeze Cycle Time (minutes)

<u>Published Freeze Cycle Suction Pressure (psig)</u> In the example, the proper suction pressure should be approximately 39 psig at 7 minutes; 30 psig at 12 minutes; etc.

Step

Perform an actual suction pressure check at the beginning, middle and end of the freeze cycle. Note the times at which the readings are taken.

Example:

Manifold gauge set was connected to the example ice machine and suction pressure readings taken as follows: _______PSIG

Beginning of freeze cycle: 79 (at 1 min.) Middle of freeze cycle: 48 (at 7 min.) End of freeze cycle: 40 (at 14 min.)

4. Compare the actual freeze cycle suction pressure (Step 3) to the published freeze cycle time and pressure comparison (Step 2B). Determine if the suction pressure is high, low or acceptable.

Example:

In this example, the suction pressure is considered high throughout the freeze cycle. It should have been: Approximately 65 psig (at 1 minute) – not 79 Approximately 39 psig (at 7 minutes) – not 48

Approximately 26 psig (at 14 minutes) – not 40

Suction Pressure High Checklist

140/190/240/310 Series

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 133

Discharge Pressure

 Discharge pressure is too high, and is affecting suction pressure, refer to "Discharge Pressure High Checklist" on page 138.

Improper Refrigerant Charge

- Overcharged
- Wrong type of refrigerant
- Non-condensible in system

Other

- Non-Manitowoc components in system
- · Harvest valve leaking
- TXV flooding (check bulb mounting)
- Defective compressor

Suction Pressure Low Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 133

Discharge Pressure

 Discharge pressure is too low, and is affecting suction pressure, refer to "Freeze Cycle Discharge Pressure Low Checklist" on page 138.

Improper Refrigerant Charge

- Undercharged
- Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- Improper water supply over evaporator refer to "Water System Checklist" on page 133.
- Loss of heat transfer from tubing on back side of evaporator
- Restricted/plugged liquid line drier
- Restricted/plugged tubing in suction side of refrigeration system
- TXV starving

NOTE: Do not limit your diagnosis to only the items listed in the checklists.

HARVEST VALVE

140/190/240/310 Series

The harvest valve is an electrically operated valve that opens when energized, and closes when de-energized.

Normal Operation

The valve is de-energized (closed) during the freeze cycle and energized (open) during the harvest cycle. The valve is positioned between the receiver and the evaporator and performs two functions:

- Prevents refrigerant from entering the evaporator during the freeze cycle.
 - The harvest valve is not used during the freeze cycle. The harvest valve is de-energized (closed) preventing refrigerant flow from the receiver into the evaporator.
- Allows refrigerant vapor to enter the evaporator in the harvest cycle.

During the harvest cycle, the harvest valve is energized (open) allowing refrigerant gas from the discharge line of the compressor to flow into the evaporator. The heat is absorbed by the evaporator and allows release of the ice slab.

Exact pressures vary according to ambient temperature and ice machine model. Harvest pressures can be found in the "Cycle Times, 24 Hr. Ice Production and Refrigerant Pressure Charts" on page 251.

Harvest Valve Analysis

The valve can fail in two positions:

- Valve will not open in the harvest cycle.
- Valve remains open during the freeze cycle.

VALVE WILL NOT OPEN IN THE HARVEST CYCLE

Although the circuit board has initiated a harvest cycle, the evaporator temperature remains unchanged from the freeze cycle.

VALVE REMAINS OPEN IN THE FREEZE CYCLE:

Symptoms of a harvest valve remaining partially open during the freeze cycle can be similar to symptoms of an expansion valve, float valve or compressor problem. Symptoms are dependent on the amount of leakage in the freeze cycle.

A small amount of leakage will cause increased freeze times and an ice fill pattern that is "Thin at the Outlet", but fills in at the end of the cycle.

As the amount of leakage increases the length of the freeze cycle increases and the amount of ice at the outlet of the evaporator decreases.

Refer to the Parts Manual for proper valve application. If replacement is necessary, use only "original" Manitowoc replacement parts.

Use the following procedure and table to help determine if a harvest valve is remaining partially open during the freeze cycle.

- 1. Wait five minutes into the freeze cycle.
- 2. Feel the inlet of the harvest valve(s).

Important

Feeling the harvest valve outlet or across the harvest valve itself will not work for this comparison.

The harvest valve outlet is on the suction side (cool refrigerant). It may be cool enough to touch even if the valve is leaking.

3. Feel the compressor discharge line.

A Warning

The inlet of the harvest valve and the compressor discharge line could be hot enough to burn your hand. Just touch them momentarily.

 Compare the temperature of the inlet of the harvest valves to the temperature of the compressor discharge line.

Findings	Comments	
The inlet of the harvest valve	This is normal as the discharge	
is cool enough to touch and	line should always be too hot to	
the compressor discharge	touch and the harvest valve inlet,	
line is hot.	although too hot to touch during	
	harvest, should be cool enough	
Cool & Hot	to touch after 5 minutes into the	
	freeze cycle.	
The inlet of the harvest	This is an indication something is	
valve is hot and approaches	wrong, as the harvest valve inlet	
the temperature of a hot	did not cool down during the	
compressor discharge line.	. freeze cycle. If the compressor	
	dome is also entirely hot, the	
Hot & Hot	problem is not a harvest valve	
	leaking, but rather something	
	causing the compressor (and the	
	entire ice machine) to get hot.	
Both the inlet of the harvest	This is an indication something is	
valve and the compressor	wrong, causing the compressor	
discharge line are cool	discharge line to be cool to the	
enough to touch.	touch. This is not caused by a	
	harvest valve leaking.	
Cool & Cool		

5. Record your findings on the table.

COMPARING EVAPORATOR INLET/OUTLET TEMPERATURES 140/190/240/310 Series

The temperatures of the suction lines entering and leaving the evaporator alone cannot diagnose an ice machine. However, comparing these temperatures during the freeze cycle, along with using Manitowoc's Refrigeration System Operational Analysis Table, can help diagnose an ice machine malfunction.

The actual temperatures entering and leaving the evaporator vary by model, and change throughout the freeze cycle. This makes documenting the "normal" inlet and outlet temperature readings difficult. The key to the diagnosis lies in the difference between the two temperatures five minutes into the freeze cycle. These temperatures must be within 7°F (4°C) of each other.

Use this procedure to document freeze cycle inlet and outlet temperatures.

- Use a quality temperature meter, capable of taking temperature readings on curved copper lines.
- Attach the temperature meter sensing device to the copper lines entering and leaving the evaporator.

Important

Do not simply insert the sensing device under the insulation. It must be attached to and reading the actual temperature of the copper line.

- 3. Wait five minutes into the freeze cycle.
- 4. Record the temperatures below and determine the difference between them.

Difference must be within	Outlet
7°F (4°C) at 5 minutes into the freeze cycle	Temperature
the freeze cycle	

 Use this with other information gathered on the Refrigeration System Operational Analysis Table to determine the ice machine malfunction.

DISCHARGE LINE TEMPERATURE ANALYSIS 140/190/240/310 Series

Knowing if the discharge line temperature is increasing, decreasing or remaining constant can be an important diagnostic tool. Maximum compressor discharge line temperature on a normally operating ice machine steadily increases throughout the freeze cycle. Comparing the temperatures over several cycles will result in a consistent maximum discharge line temperature.

Ambient air temperatures affect the maximum discharge line temperature.

Higher ambient air temperatures at the condenser = higher discharge line temperatures at the compressor.

Lower ambient air temperatures at the condenser = lower discharge line temperatures at the compressor.

Regardless of ambient temperature, the freeze cycle discharge line temperature will be higher than 150°F (66°C) on a normally operating ice machine.

PROCEDURE

Connect a temperature probe on the compressor discharge line within 6" (15.2 cm) of the compressor. Observe the discharge line temperature for the last three minutes of the freeze cycle and record the maximum discharge line temperature.

Discharge Line Temperature Above 150°F (66°C) at End of Freeze Cycle:

Ice machines that are operating normally will have consistent maximum discharge line temperatures above 150°F (66°C).

Verify the expansion valve sensing bulb is positioned and secured correctly.

Discharge Line Temperature Below 150°F (66°C) at End of Freeze Cycle

Ice machines that have a flooding expansion valve will have a maximum discharge line temperature that decreases each cycle.

Verify the expansion valve sensing bulb is 100% insulated and sealed airtight. Condenser air contacting an incorrectly insulated sensing bulb will cause overfeeding of the expansion valve.

Final Analysis

The column with the highest number of check marks identifies the refrigeration problem.

Column 1 - Harvest Valve Leaking

A leaking harvest valve must be replaced.

Column 2 - Low Charge/TXV Starving

Normally, a starving expansion valve only affects the freeze cycle pressures, not the harvest cycle pressures. A low refrigerant charge normally affects both pressures. Verify the ice machine is not low on charge before replacing an expansion valve.

Add refrigerant charge in 2 oz. increments as a diagnostic procedure to verify a low charge. (Do not add more than the total charge of refrigerant). If the problem is corrected, the ice machine is low on charge. Find the refrigerant leak.

The ice machine must operate with the nameplate charge. If the leak cannot be found, proper refrigerant procedures must still be followed. Change the liquid line drier, evacuate the system and weigh in the proper charge.

If the problem is not corrected by adding charge, the expansion valve is faulty.

Column 3 – TXV Flooding


A loose or improperly mounted expansion valve bulb causes the expansion valve to flood. Check bulb mounting, insulation, etc., before changing the valve.


Column 4 - Compressor

Replace the compressor and start components. To receive warranty credit, the compressor ports must be properly sealed by crimping and soldering them closed. Old start components must be returned with the faulty compressor.

SYMPTOM #3


Ice Machine Will Not Harvest – Freeze Cycle Is Normal and Ice Cubes Are Not Melted After Harvest






SYMPTOM #4

Ice Machine Will Not Harvest – Freeze Cycle is Normal and Ice Cubes Are Not Melted After Harvest





*A damaged evaporator may not be repairable. For example: the top molding assembly is replaceable however the side moldings and/or the evaporator grid is not repairable.

Troubleshooting

UDE0065/UDP0065

PROBLEM CHECKLIST

Problem	Possible Cause	Correction	
Ice machine does	No electrical power to the ice machine.	Replace the fuse/reset the breaker/turn on the main switch/plug power cord into receptacle.	
not operate	Toggle switch set improperly.	Move the toggle switch to the ON position.	
	Low air temperature around ice machine.	Air temperature must be at least 50°F (10°C).	
Ice machine	Ice machine is dirty.	Descale and sanitize the ice machine. (page 46)	
does not release	Ice machine is not level.	Level the ice machine. (page 23)	
harvest.	Low air temperature around ice machine (air-cooled models).	Air temperature must be at least 50° F (10°C).	
	Poor incoming water quality.	Test the quality of the incoming water and make appropriate filter recommendations.	
Ice quality is poor (soft or not	Ice machine is dirty.	Descale and sanitize the ice machine. (page 46)	
clear).	Water inlet valve filter screen is dirty.	Remove the water inlet valve and clean the filter screen.	
	Water softener is working improperly (if applicable).	Repair the water softener.	
	Water level is low.	Confirm the overflow tube is fully seated to prevent water leakage.	
Ice machine produces shallow or incomplete	Water inlet valve filter screen is dirty.	Remove the water inlet valve and clean the filter screen.	
	Hot incoming water.	Connect the ice machine to a cold water supply.	
cubes, or the ice fill pattern on the evaporator is	Ice thickness adjustment dial is not set properly.	Adjust the ice thickness adjustment dial. (page 97)	
incomplete.	Incorrect incoming water pressure.	Water pressure must be 34.8 psi - 89.9 psi (240 kPa - 620 kPa).	
	Ice machine is not level.	Level the ice machine. (page 23)	

Problem	Possible Cause	Correction
	Water inlet valve filter screen is dirty.	Remove the water inlet valve and clean the filter screen.
	Incoming water supply is off.	Open the water service valve.
	The air filter is dirty.	Clean the air filter. (page 65)
Low ice capacity.	The condenser is dirty.	Clean the condenser. (page 65)
	Inadequate airflow at the front of the ice machine.	Remove items blocking airflow at the front of the ice machine.
	Ice thickness adjustment dial is not set properly.	Adjust the ice thickness adjustment dial. (page 97)

DIAGNOSING AN ICE MACHINE THAT WILL NOT RUN

AWarning

High (line) voltage is applied to the control board (terminals #2 and #8) at all times. Removing control board fuse or moving the toggle switch to OFF will not remove the power supplied to the control board.

- Verify primary voltage is supplied to ice machine and the fuse/circuit breaker is closed.
- Verify the jumper wire is installed and control board fuse is okay. If the bin switch light functions, the jumper wire and fuse are okay.
- 3. Verify the bin switch functions properly. A defective bin switch can falsely indicate a full bin of ice.
- Verify ON/OFF/WASH toggle switch functions properly. A defective toggle switch may keep the ice machine in the OFF mode.
- Verify low DC voltage is properly grounded. Loose DC wire connections may intermittently stop the ice machine.
- Replace the control board Be sure Steps 1 5 were followed thoroughly. Intermittent problems are not usually related to the control board.

NOTE: If replacing control board, the jumper wire from the old control board must be installed on the new control board.

REFRIGERATION DIAGNOSTICS OVERVIEW UDE0065/UDP0065

65 Series ice machines have a very small refrigerant charge and we do not recommend diagnosing the ice machine using refrigerant pressures. For this reason refrigeration access fittings are not installed during production and the ice machine is diagnosed with temperatures.

Verify that your water flow is even across the entire evaporator before diagnosing the refrigeration system. Mineral build-up on the evaporator assembly can cause water tracking and an erratic ice fill pattern. Descale with Manitowoc Ice Machine cleaner/descaler to remove any mineral buildup before diagnosing the refrigeration system.

The following can be used for diagnostics:

- Install a temperature lead on the compressor suction line within 6" of the compressor.
- Install a temperature lead on the compressor discharge line within 6" of the compressor
- Refer to the "Cycle Times, 24 Hr. Ice Production and Refrigerant Pressure Charts" on page 251 to determine the correct temperature operating range for your air and water temperature.
- Record the temperatures throughout the freeze and harvest cycles.

NOTE: First cycle is not used for refrigeration system diagnostics. Run a minimum of two cycles to allow the system to stabilize and record the second cycle.

Normal Operation

Example below is for normal operation at 86°F (30°C) air temperature 68°F (20°C) water temperature.

FREEZE CYCLE

- Normal suction line temperature at the compressor will range from 86°F (30°C) three minutes into the cycle to 8°F (-13°C) at the end of the freeze cycle.
- Normal discharge line temperature at the compressor will range from 168°F (76°C) to 140°F (60°C) through the freeze cycle.

HARVEST CYCLE

Suction line temperature at the compressor will range from 64°F (18°C) to 111°F (44°C) through the harvest cycle. An obstructed capillary tube will not effect suction line temperature range during the harvest cycle. Low refrigerant charge will have a lower temperature than normal.

Discharge line temperature at the compressor will range from 180°F (82°C) to 150°F (60°C) through the harvest cycle.

Ice fill pattern will vary depending on severity of the obstruction or refrigeration loss. Ice fill patterns will range from no ice on the entire evaporator to thin only at the evaporator outlet (thin at the bottom, thick at the top of the evaporator).

Abnormal temperatures

Higher than normal freeze cycle temperatures.

- A dirty filter or condenser will result in higher than normal temperatures. Always clean the filter and condenser before diagnosing the refrigeration system.
- Hot water entering the ice machine will result in high suction and discharge line temperatures in the freeze cycle.

Capillary tube failures or low refrigerant charge will always result in a starving evaporator.

- An obstructed capillary tube or low refrigerant charge will have a suction line temperature higher than normal.
- An obstructed capillary tube or low refrigerant charge will have a discharge line temperature lower than normal.
- An obstructed capillary tube will not effect the discharge line temperature during the harvest cycle.
 A low freeze and discharge line temperature in the freeze cycle with a normal harvest cycle discharge line temperature indicates an obstructed capillary tube.
- Low refrigerant charge will have both the suction and discharge line temperatures lower than normal in the freeze and harvest cycles.

ICE PRODUCTION CHECK

UDE0065/UDP0065

The amount of ice a machine produces directly relates to the operating water and air temperatures. This means an ice machine with a 70°F (21°C) ambient temperature and 50°F (10°C) water produces more ice than the same ice machine with 90°F (32°C) ambient and 70°F (21°C) water.

1.	Determine the ice machine operating conditions
	Air temp entering condenser:°
	Air temp around ice machine:°
	Water temp entering sump trough:°

- Refer to the appropriate "Cycle Times, 24 Hr. Ice Production and Refrigerant Pressure Charts" on page 251. Use the operating conditions determined in Step 1 to find published 24-Hour Ice Production:
 - Times are in minutes.
 Example: 1 min. 15 sec. converts to 1.25 min.
 (15 seconds ÷ 60 seconds = .25 minutes)
 - Weights are in pounds.
 Example: 2 lb. 6 oz. converts to 2.375 lb.
 (6 oz. ÷ 16 oz. = .375 lb.)
- Perform an ice production check using the formula below.

1.	Freeze	+	Harvest Time	=	Total Cycle
2	Time				Time
2.	1440	÷		=	
	Minutes in		Total Cycle		Cycles per Day
	24 Hrs.		Time		
3.		Χ		=	
	Weight		Cycles per		Actual 24-Hour
	of One		Day		Production
	Harvest				

Weighing the ice is the only 100% accurate check.

- 4. Compare the results of step 3 with step 2. Ice production is normal when these numbers match closely. If they match closely, determine if:
 - Another larger ice machine is required.
 - Relocating the existing equipment to lower the load conditions is required.

Contact the local Manitowoc distributor for information on available options and accessories.

INSTALLATION/VISUAL INSPECTION CHECKLIST UDE0065/UDP0065

Ice machine is not level

· Level the ice machine

Condenser is dirty

• Clean the condenser

Water filtration is plugged (if used)

Install a new water filter

Water drains are not run separately and/or are not vented

 Run and vent drains according to the Installation Manual

WATER SYSTEM CHECKLIST

UDE0065/UDP0065

A water-related problem often causes the same symptoms as a refrigeration system component malfunction.

Water system problems must be identified and eliminated prior to replacing refrigeration components.

Water area (evaporator) is dirty

Descale as needed

Water inlet pressure not between 20 and 80 psig (1–5 bar, 138–552 kPa)

 Install a water regulator valve or increase the water pressure

Incoming water temperature is not between 40°F (3°C) and 90°F (32°C)

 If too hot, check the hot water line check valves in other store equipment

Water filtration is plugged (if used)

Install a new water filter

Vent tube is not installed on water outlet drain

See Installation Instructions

Hoses, fittings, etc., are leaking water

• Repair/replace as needed

Water valve is stuck open, closed or is leaking

Descale/replace as needed

Continued Next Page

Water is spraying out of the sump trough area

Stop the water spray

Water is leaking through the sump trough overflow

• Set the water level 1/4"-3/8" below standpipe

Uneven water flow across the evaporator

Descale the ice machine

Water is freezing behind the evaporator

Correct the water flow

Plastic extrusions and gaskets are not secured to the evaporator

• Remount/replace as needed.

Refrigeration Diagnostics UDE0065/UDP0065

Perform the procedures on the preceding pages before performing refrigeration diagnostics. The first pages cover an overview of the diagnostic procedures followed by diagnostics checklists.

Install thermometer thermocouples on Suction and Discharge line:

- Digital thermometers with remote thermocouples must be used to obtain temperatures.
- Suction and Discharge line thermocouples must be within 3" (76.2 mm) of the compressor.
- Thermocouples must be insulated.
- Doors and all panels must be in place.
- Initial freeze cycle is not used for diagnostics.
- Start monitoring temperatures 3 minutes into the second freeze cycle.

Compare Suction and Discharge temperatures to your model in the charts starting on page 251.

The charts list normal suction and discharge temperatures.

Analysis

Discharge Line	Suction Line	Ice Fill Pattern	Refer to
Temp	Temp		Diagnostics
			for:
Normal	Normal	Less fill on the	This is normal
		left side of the	operation
		evaporator	
Low (20°F	Low 20°F (-7°C)	Less fill on the	Expansion
[-7°C] or more)	or more)	left side of the	Valve Flooding
		evaporator	
Normal or	High 10°F	Less fill on the	Low on
High	(-12°C) or	left side and	Refrigerant
	more)	top 2 rows of	or Expansion
		the evaporator	Valve Starving
Normal	Low 5°F (-15°C)	Less fill on the	Refrigerant
	or less)	left side of the	Overcharge
		evaporator	

FLOODING EXPANSION VALVE SYMPTOMS

A flooding expansion valve will have discharge and suction line temperatures 20°F (-7°C) lower than normal freeze cycle temperatures. Normal suction line temperature and low discharge line temperature DO NOT verify a flooding valve. Both discharge line temperature and suction line temperature must be low to verify a flooding expansion valve. Ice fill pattern is thin on the left hand side of the evaporator.

STARVING EXPANSION VALVE/LOW REFRIGERANT CHARGE SYMPTOMS:

- A. Ice Fill Pattern
- Thin on top two rows of the evaporator
- Thin on entire left side of the evaporator
- Thick on the bottom of the evaporator
 - B. Freeze time longer than normal

Diagnosis can be confirmed by adding installing a temporary access valve and adding 2 oz (56.7 g) of refrigerant: If the suction line temperature drops or the ice fill pattern on the top two rows fills in, the ice machine is low on refrigerant. Refer to charging procedures for access valve installation/removal procedure.


OVERCHARGED SYSTEM SYMPTOMS

Suction line temperature will be slightly low during freeze cycle 5°F (-15°C). Discharge line temperature is normal. Actual amperage readings will be higher than nameplate rating.

ANALYZING ICE FORMATION PATTERN

Evaporator ice formation pattern analysis is helpful in ice machine diagnostics.

Analyzing the ice formation pattern alone cannot diagnose an ice machine malfunction. However, when this analysis is used along with Manitowoc's Refrigeration System Operational Analysis Table, it can help diagnose an ice machine malfunction.



Normal Ice Formation

Ice forms across the entire evaporator surface.

At the beginning of the Freeze cycle, it may appear that more ice is forming on the inlet of the evaporator than at the outlet. At the end of the Freeze cycle, ice formation at the outlet will be close to, or just a bit thinner than, ice formation at the inlet. The dimples in the cubes at the outlet of the evaporator may be more pronounced than those at the inlet. This is normal.

If ice forms uniformly across the evaporator surface, but does not do so in the proper amount of time, this is still considered a normal ice fill pattern.

Extremely Thin at Evaporator Outlet

There is no ice, or a considerable lack of ice formation on the outlet of the evaporator.

Examples: No ice at all at the outlet of the evaporator, but ice forms at the inlet half of the evaporator. Or, the ice at the outlet of the evaporator reaches the correct thickness, but the outlet of the evaporator already has 1/2" to 1" of ice formation.

Possible cause: Water loss, low on refrigerant, starving TXV, hot water supply, faulty float valve, etc.

Extremely Thin at Evaporator Inlet

There is no ice, or a considerable lack of ice formation at the inlet of the evaporator. Examples: The ice at the outlet of the evaporator reaches the correct thickness, but there is no ice formation at all at the inlet of the evaporator.

Possible cause: Insufficient water flow, flooding TXV, etc.

Spotty Ice Formation

There are small sections on the evaporator where there is no ice formation. This could be a single corner, or a single spot in the middle of the evaporator. This is generally caused by loss of heat transfer from the tubing on the backside of the evaporator.

No Ice Formation

The ice machine operates for an extended period, but there is no ice formation at all on the evaporator.

Possible cause: Water float valve, water pump, starving expansion valve, low refrigerant charge, compressor, etc.

ANALYZING DISCHARGE LINE TEMPERATURE UDE0065/UDP0065

1.	Determine the ice machine operating conditions:
	Air temperature entering condenser
	Air temperature around ice machine
	Water temperature entering sump trough
2.	Refer to "Installation/Visual Inspection Checklist" on page 163 for ice machine being checked.
	the operating conditions determined in step 1 to find published normal discharge temperatures.
	Freeze Cycle
	Harvest Cycle

3. Perform an actual discharge temperature check.

	· ·	
	Freeze Cycle	Harvest Cycle
	Temperature	Temperature
Beginning of		
Cycle		
Middle of		
Cycle		
End of		
Cycle		

4. Compare the actual discharge temperature (Step 3) with the published discharge temperature (Step 2).

The discharge temperature is normal when the actual temperature falls within the published temperature range for the ice machine's operating conditions. It is normal for the discharge temperature to be lower at the beginning of the freeze cycle, then climb through out the freeze cycle.

Discharge Line Temperature High Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 163

Restricted Condenser Air Flow

- High inlet air temperature
- · Condenser discharge air re-circulation
- Dirty condenser fins
- · Defective fan cycling control
- Defective fan motor

Improper Refrigerant Charge

- Overcharged
- Non-condensible in system
- Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- High side refrigerant lines/component restricted (before mid-condenser)

Freeze Cycle Discharge Temperature Low Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 163

Improper Refrigerant Charge

- Undercharged
- · Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- High side refrigerant lines/component restricted (before mid-condenser)
- Defective fan cycle control

ANALYZING SUCTION LINE TEMPERATURE

UDE0065/UDP0065

The suction line temperature gradually drops throughout the freeze cycle. The actual suction temperature (and drop rate) changes as the air and water temperature entering the ice machine changes. These variables also determine the freeze cycle times. To analyze and identify the proper suction temperature drop throughout the freeze cycle, compare the published suction temperature to the published freeze cycle time.

NOTE: Analyze discharge temperature before analyzing suction temperature. High or low discharge temperature may be causing high or low suction temperature.

Determine the ice machine energting conditions

Ι.	Determine the ice machine operating conditions:	
	Air temperature entering condenser	_
	Air temperature around ice machine	_
	Water temperature entering sump trough	_
	the operating conditions determined in step 1 to fi published normal suction temperatures.	nd
	Freeze Cycle	
	Harvest Cycle	
2.	Perform an actual suction temperature check.	

	Freeze Cycle Temperature	Harvest Cycle Temperature
Beginning of Cycle		
Middle of Cycle		
End of Cycle		

3. Compare the actual suction temperature (Step 3) with the published suction temperature (Step 2).

The suction temperature is normal when the actual temperature falls within the published temperature range for the ice machine's operating conditions. It is normal for the suction temperature to be higher at the beginning of the freeze cycle, then drop through out the freeze cycle.

Suction Temperature High Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 163

Discharge Pressure

 Discharge temperature is too high, and is affecting suction temperature, refer to "Discharge Line Temperature High Checklist" on page 171.

Improper Refrigerant Charge

- Overcharged
- Wrong type of refrigerant
- Non-condensible in system

Other

- Non-Manitowoc components in system
- Harvest valve leaking
- TXV flooding (check bulb mounting)
- Defective compressor

Suction Temperature Low Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 163

Discharge Pressure

 Discharge temperature is too low, and is affecting suction temperature, refer to "Freeze Cycle Discharge Temperature Low Checklist" on page 171.

Improper Refrigerant Charge

- Undercharged
- Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- Improper water supply over evaporator refer to "Water System Checklist" on page 164.
- Loss of heat transfer from tubing on back side of evaporator
- Restricted/plugged liquid line drier
- Restricted/plugged tubing in suction side of refrigeration system
- TXV starving

NOTE: Do not limit your diagnosis to only the items listed in the checklists.

COMPARING EVAPORATOR INLET/OUTLET TEMPERATURES

UDE0065/UDP0065

The temperatures of the suction line entering and leaving the evaporator alone cannot diagnose an ice machine. However, comparing these temperatures during the freeze cycle can help diagnose an ice machine malfunction.

The actual temperatures entering and leaving the evaporator vary by model, and change throughout the freeze cycle. This makes documenting the "normal" inlet and outlet temperature readings difficult. The key to the diagnosis lies in the difference between the two temperatures five minutes into the freeze cycle. These temperatures must be within 7°F (4°C) of each other.

Use this procedure to document freeze cycle inlet and outlet temperatures.

- Use a quality temperature meter, capable of taking temperature readings on curved copper lines.
- Attach the temperature meter sensing device to the copper lines entering and leaving the evaporator.

Important

Do not simply insert the sensing device under the insulation. It must be attached to and reading the actual temperature of the copper line.

- 3. Wait five minutes into the freeze cycle.
- 4. Record the temperatures below and determine the difference between them.

Inlet Temperature	Difference must be within	Outlet
	7°F (4°C) at 5 minutes into	Temperature
	the freeze cycle	

5. Use this with other information gathered on the Refrigeration System Operational Analysis Table to determine the ice machine malfunction.

DISCHARGE LINE TEMPERATURE ANALYSIS UDE0065/UDP0065

Knowing if the discharge line temperature is increasing, decreasing or remaining constant can be an important diagnostic tool. Maximum compressor discharge line temperature on a normally operating ice machine steadily increases throughout the freeze cycle. Comparing the temperatures over several cycles will result in a consistent maximum discharge line temperature.

Ambient air temperatures affect the maximum discharge line temperature.

Higher ambient air temperatures at the condenser = higher discharge line temperatures at the compressor.

Lower ambient air temperatures at the condenser = lower discharge line temperatures at the compressor.

Regardless of ambient temperature, the freeze cycle discharge line temperature will be higher than 150°F (66°C) on a normally operating ice machine.

PROCEDURE

Connect a temperature probe on the compressor discharge line within 6" (15.2 cm) of the compressor. Observe the discharge line temperature for the last three minutes of the freeze cycle and record the maximum discharge line temperature.

Discharge Line Temperature Above 150°F (66°C) at End of Freeze Cycle:

Ice machines that are operating normally will have consistent maximum discharge line temperatures above 150°F (66°C).

Verify the expansion valve sensing bulb is positioned and secured correctly.

Discharge Line Temperature Below 150°F (66°C) at End of Freeze Cycle

Ice machines that have a flooding expansion valve will have a maximum discharge line temperature that decreases each cycle.

Verify the expansion valve sensing bulb is 100% insulated and sealed airtight. Condenser air contacting an incorrectly insulated sensing bulb will cause overfeeding of the expansion valve.

HARVEST VALVE

UDE0065/UDP0065

The harvest valve is an electrically operated valve that opens when energized, and closes when de-energized.

Normal Operation

The valve is de-energized (closed) during the freeze cycle and energized (open) during the harvest cycle. The valve is positioned between the and the evaporator and performs two functions:

- Prevents refrigerant from entering the evaporator during the freeze cycle.
 - The harvest valve is not used during the freeze cycle. The harvest valve is de-energized (closed) preventing refrigerant flow from the receiver into the evaporator.
- Allows refrigerant vapor to enter the evaporator in the harvest cycle.

During the harvest cycle, the harvest valve is energized (open) allowing refrigerant gas from the discharge line of the compressor to flow into the evaporator. The heat is absorbed by the evaporator and allows release of the ice slab

Exact temperatures vary according to ambient temperature and ice machine model.

Harvest Valve Analysis

The valve can fail in two positions:

- Valve will not open in the harvest cycle.
- Valve remains open during the freeze cycle.

VALVE WILL NOT OPEN IN THE HARVEST CYCLE

Although the circuit board has initiated a harvest cycle, the evaporator temperature remains unchanged from the freeze cycle.

VALVE REMAINS OPEN IN THE FREEZE CYCLE:

Symptoms of a harvest valve remaining partially open during the freeze cycle can be similar to symptoms of an expansion valve, float valve or compressor problem. Symptoms are dependent on the amount of leakage in the freeze cycle.

A small amount of leakage will cause increased freeze times and an ice fill pattern that is "Thin at the Outlet", but fills in at the end of the cycle.

As the amount of leakage increases the length of the freeze cycle increases and the amount of ice at the outlet of the evaporator decreases.

Refer to the Parts Manual for proper valve application. If replacement is necessary, use only "original" Manitowoc replacement parts.

Use the following procedure and table to help determine if a harvest valve is remaining partially open during the freeze cycle.

- 1. Wait five minutes into the freeze cycle.
- 2. Feel the inlet of the harvest valve(s).

Important

Feeling the harvest valve outlet or across the harvest valve itself will not work for this comparison.

The harvest valve outlet is on the suction side (cool refrigerant). It may be cool enough to touch even if the valve is leaking.

3. Feel the compressor discharge line.

AWarning

The inlet of the harvest valve and the compressor discharge line could be hot enough to burn your hand. Just touch them momentarily.

 Compare the temperature of the inlet of the harvest valves to the temperature of the compressor discharge line.

- : ::		
Findings	Comments	
The inlet of the harvest valve	This is normal as the discharge	
is cool enough to touch and	line should always be too hot to	
the compressor discharge	touch and the harvest valve inlet,	
line is hot.	although too hot to touch during	
	harvest, should be cool enough	
Cool & Hot	to touch after 5 minutes into the	
	freeze cycle.	
The inlet of the harvest	This is an indication something is	
valve is hot and approaches	wrong, as the harvest valve inlet	
the temperature of a hot	did not cool down during the	
compressor discharge line.	freeze cycle. If the compressor	
	dome is also entirely hot, the	
Hot & Hot	& Hot problem is not a harvest valve	
	leaking, but rather something	
	causing the compressor (and the	
	entire ice machine) to get hot.	
Both the inlet of the harvest	This is an indication something is	
valve and the compressor	wrong, causing the compressor	
discharge line are cool	discharge line to be cool to the	
enough to touch.	touch. This is not caused by a	
	harvest valve leaking.	
Cool & Cool		

Troubleshooting

UDE0080/UDP0080

PROBLEM CHECKLIST

Problem	Possible Cause	Correction
Ice machine does	No electrical power to the ice machine.	Replace the fuse/reset the breaker/turn on the main switch/plug power cord into receptacle.
not operate	ON/OFF/WASH toggle switch set improperly.	Move the toggle switch to the ON position.
	Damper in open position (down).	Damper must be in upright position and capable of swinging freely.
Ice machine stops, and can be restarted by turning the ice machine OFF/ ON.	Service Limit stopping the ice machine.	Refer to "Service Limits". (page 184)
Ice machine	Ice machine is dirty.	De-scale and sanitize the ice machine. (page 66)
does not release ice or is slow to	Ice machine is not level.	Level the ice machine. (page 23)
harvest.	Low air temperature around ice machine.	Air temperature must be at least 35° (2°C).
	The six-minute freeze time lock-in has not expired yet.	Wait for the freeze lock-in to expire.
	Ice thickness probe is dirty.	De-scale and sanitize the ice machine. (page 66)
Ice machine does	Ice thickness probe wire is disconnected.	Connect the probe wire to the control board.
not cycle into harvest mode.	Ice thickness probe is out of adjustment.	Adjust the ice thickness probe. (page 110)
	Uneven ice fill (thin at the top of evaporator).	Verify sufficient water level in sump trough. Contact a qualified service company to check refrigeration system.

Problem	Possible Cause	Correction
leo queliturio	Poor incoming water quality.	Contact a qualified service company to test the quality of the incoming water and make appropriate water filter recommendations.
Ice quality is poor (soft or not	Ice machine is dirty.	De-scale and sanitize the ice machine. (page 66)
clear).	Water siphon is not working.	Check the water siphon system.
	Water softener is working improperly (if applicable).	Repair the water softener.
	Ice thickness probe is out of adjustment.	Adjust the ice thickness probe. (page 110)
Ice machine	Water trough level is too high or too low.	Check the water level probe position.
produces shallow	Water float valve filter screen is dirty.	Remove and clean the filter screen.
or incomplete cubes, or the ice	Hot incoming water.	Connect the ice machine to a cold water supply.
fill pattern on the evaporator is	Water float valve is not working.	Remove the water float valve and clean it.
incomplete.	Incorrect incoming water pressure.	Water pressure must be 20 psi - 80 psi (140 kPa - 550 kPa)
	Ice machine is not level.	Level the ice machine. (page 28)
	Water float valve filter screen is dirty.	Remove and clean the filter screen.
	Incoming water supply is off	Open the water service valve.
	Water float valve stuck open or leaking.	Remove the water float valve and clean it.
	The condenser is dirty.	Clean the condenser.
Low ice capacity.	High air temperature entering condenser	Air temperature cannot exceed 110° (43°C).
	Inadequate cleaarance around ice machine.	Provide adequate clearance.
	Objects stacked around ice machine, blocking airflow to the condenser.	Remove items blocking airflow.

SERVICE LIMITS

UDE0080/UDP0080

In addition to the standard safety controls, such as the high pressure cutout, your Manitowoc ice machine features built-in service limits, which will stop the ice machine if conditions arise which could cause a major component failure.

Before calling for service, re-start the ice machine using the following procedure:

- Move the toggle switch to the Off position to turn off the ice machine, then move the toggle switch to the On position again to start the ice machine, blue light will.
 - A. If the service limit feature has stopped the ice machine, it will restart after a short delay.
 Proceed to step 2.
 - B. If the ice machine does not restart, see "Ice machine does not operate" on the previous page.
- Allow the ice machine to run to determine if the condition is recurring.
 - If the ice machine stops again, the condition has recurred.

 Call for service.

If the ice machine continues to run, the condition has corrected itself. Allow the ice machine to continue running.

DIAGNOSING AN ICE MACHINE THAT WILL NOT RUN UDE0080/UDP0080

A Warning

High (line) voltage is applied to the control board (terminals #2 and #4) at all times. Removing control board fuse or moving the toggle switch to OFF will not remove the power supplied to the control board.

- Verify primary voltage is supplied to ice machine and the fuse/circuit breaker is closed.
- 2. Verify control board fuse is okay.
- 3. If the bin switch light functions, the fuse is okay.
- 4. Verify the bin switch functions properly. A defective bin switch can falsely indicate a full bin of ice.
- Verify ON/OFF/WASH toggle switch functions properly. A defective toggle switch may keep the ice machine in the OFF mode.
- Verify low DC voltage is properly grounded. Loose DC wire connections may intermittently stop the ice machine.
- Be sure Steps 1 6 were followed thoroughly.
 Intermittent problems are not usually related to the control board.
- 8. Replace the control board.

SERVICE LIMIT FEATURE

UDE0080/UDP0080

In addition to the standard safety controls, your Manitowoc ice machine features built-in service limits that will stop the ice machine if conditions arise which could cause a major component failure.

Service Limit #1:

If the freeze time reaches 60 minutes, the control board automatically initiates a harvest cycle. 3 cycles outside the time limit = 1 hour Stand-by Mode.

Service Limit #2:

If the harvest time reaches 3.5 minutes, the control board automatically returns the ice machine to the freeze cycle. 3 cycles outside the time limit = Service Limit (must be MANUALLY reset).

Service Limit Stand-by Mode:

The first time a service limit shut down occurs, the ice machine turns off for 60 minutes (Stand-by Mode). The ice machine will then automatically restart to see if the problem reoccurs.

During the Stand-by Mode the harvest light will be flashing continuously and a service limit indication can be viewed. If the same service limit is reached a second time (the problem has reoccurred), the ice machine will initiate a service limit shut down and remain off until it is manually restarted. During a service limit shut down the harvest light will be flashing continuously.

Determining Which Service Limit Stopped the Ice Machine: When a service limit condition causes the ice machine to stop, the harvest light on the control board continually flashes on and off. Use the following procedures to determine which service limit has stopped the ice machine.

- 1. Move the toggle switch to OFF.
- 2. Move the toggle switch back to ON.
- Watch the harvest light. It will flash one or two times, corresponding to service limits 1 and 2, to indicate which service limit stopped the ice machine.

After service limit indication, the ice machine will restart and run until a service limit is exceeded again.

Service Limit Notes

- A continuous run of 100 harvests automatically erases the service limit code.
- The control board will store and indicate only one service limit – the last one exceeded.
- If the toggle switch is cycled OFF and then ON prior to reaching the 100-harvest point, the last service limit exceeded will be indicated.

Service Limit Checklist

UDE0080/UDP0080

The following checklists are designed to assist the service technician in analysis. However, because there are many possible external problems, do not limit your diagnosis to only the items listed.

Service Limit #1

Freeze time exceeds 60 minutes for 6 consecutive freeze cycles.

Possible Cause Checklist

Improper installation

 Refer to "Installation/Visual Inspection Checklist" on page 195

Water System

- Water Level too high or defective float (water escaping water trough)
- Low water pressure (20 psig min.)
- High water pressure (80 psig max.)
- High water temperature (90°F/32.2°C max.)
- Clogged water distribution tube
- Defective water pump

Electrical System

- Harvest cycle not initiated electrically
- Contactor not energizing
- Compressor electrically non-operational
- Restricted condenser air flow
- High inlet air temperature (110°F/43.3°C max.)
- Condenser discharge air re-circulation
- Dirty condenser fins
- · Defective fan cycling control
- · Defective fan motor
- Low water pressure (20 psig min.)
- High water temperature (90°F/32.2°C max.)
- Dirty condenser

Refrigeration System

- Non-Manitowoc components
- Improper refrigerant charge
- · Defective compressor
- TXV starving or flooding (check bulb mounting)
- Non-condensible in refrigeration system
- Plugged or restricted high side refrigerant lines or component
- Defective harvest valve

Service Limit #2

Harvest time exceeds 3.5 minutes for 3 Consecutive harvest cycles.

Possible Cause Checklist

Improper installation

 Refer to "Installation/Visual Inspection Checklist" on page 195

Water System

- Water area (evaporator) dirty
- · Dirty/defective water dump valve
- Vent tube not installed on water outlet drain
- Water freezing behind evaporator
- Plastic extrusions and gaskets not securely mounted to the evaporator
- Low water pressure (20 psig min.)
- Loss of water from sump area
- Clogged water distribution tube
- Dirty/defective water inlet float
- Defective water pump

Electrical system

- · Bin switch defective
- Premature harvest

Refrigeration system

- Non-Manitowoc components
- Improper refrigerant charge
- Defective harvest valve
- TXV flooding (check bulb mounting)
- Defective fan cycling control

DIAGNOSING ICE THICKNESS CONTROL CIRCUITRY UDE0080/UDP0080

Ice Machine Does Not Cycle Into Harvest when Water Contacts the Ice Thickness Control Probe

Step 1 Bypass the freeze time lock-in feature by moving the ON/OFF/WASH switch to OFF and back to ON. Wait until the water starts to flow over the evaporator.

Step 2 Clip the jumper wire to the ice thickness probe and any cabinet ground.

Step 2 Jumper wire connected from probe to ground		
Monitoring Harvest Light	Correction	
The harvest light comes on, and	The ice thickness control	
6-10 seconds later, ice machine	circuitry is functioning properly.	
cycles from freeze to harvest.	Do not change any parts.	
The harvest light comes on but	The ice control circuitry is	
the ice machine stays in the	functioning properly. The ice	
freeze sequence.	machine is in a six minute	
	freeze time lock-in. Verify	
	Step 1 of this procedure was	
	followed correctly.	
The harvest light does not	Proceed to Step 3.	
come on.		

Step 3 Disconnect the ice thickness probe from the control board terminal. Clip the jumper wire to the terminal on the control board and any cabinet ground. Monitor the harvest light.

Step 3 Jumper wire connected from control board terminal to ground		
Monitoring Harvest Light	Correction	
The harvest light comes on, and	The ice thickness probe is	
6-10 seconds later, ice machine	causing the malfunction.	
cycles from freeze to harvest.		
The harvest light comes on but	The control circuitry is	
the ice machine stays in the	functioning properly. The ice	
freeze sequence.	machine is in a six minute	
	freeze time lock-in (verify step 1	
	of this procedure was followed	
	correctly).	

Step 3 Jumper wire connected from		
control board terminal to ground		
Monitoring Harvest Light	Correction	
The harvest light does not	s not The control board is causing th	
energize. malfunction.		

Ice Machine Cycles Into Harvest Before Water Contact with the Ice Thickness Probe

Step 1 Bypass the freeze time lock-in feature by moving the ON/OFF/WASH switch to OFF and back to ON. Wait until the water starts to flow over the evaporator, then monitor the harvest light.

Step 2 Disconnect the ice thickness probe from the control board terminal.

Step 2 Disconnect probe from control board terminal.		
Monitoring Harvest Light	Correction	
The harvest light stays off and	The ice thickness probe is	
the ice machine remains in the	causing the malfunction. Verify	
freeze sequence.	that the Ice Thickness probe is	
	adjusted correctly.	
The harvest light comes on,	The control board is causing the	
and 6-10 seconds later, the ice	malfunction.	
machine cycles from freeze to		
harvest.		

ICE PRODUCTION CHECK

UDE0080/UDP0080

The amount of ice a machine produces directly relates to the operating water and air temperatures. This means an ice machine with a 70°F (21°C) ambient temperature and 50°F (10°C) water produces more ice than the same ice machine with 90°F (32°C) ambient and 70°F (21°C) water.

- Determine the ice machine operating conditions:
 Air temperature entering condenser:
 Air temperature around ice machine:
 Water temperature entering sump trough:
- Refer to the appropriate model in the "Cycle Times, 24 Hr. Ice Production and Refrigerant Pressure Charts" on page 251. Use the operating conditions determined in Step 1 to find published 24-Hour Ice Production:
 - Times are in minutes.
 Example: 1 min. 15 sec. converts to 1.25 min.
 (15 seconds ÷ 60 seconds = .25 minutes)
 - Weights are in pounds.
 Example: 2 lb. 6 oz. converts to 2.375 lb.
 (6 oz. ÷ 16 oz. = .375 lb.)

Perform an ice production check using the formula below.

Weighing the ice is the only 100% accurate check.

- 4. Compare the results of step 3 with step 2. Ice production is normal when these numbers match closely. If they match closely, determine if:
 - Another larger ice machine is required.
 - Relocating the existing equipment to lower the load conditions is required.

INSTALLATION/VISUAL INSPECTION CHECKLIST UDE0080/UDP0080

Ice machine is not level

· Level the ice machine

Condenser is dirty

• Clean the condenser

Water filtration is plugged (if used)

Install a new water filter

Water drains are not run separately and/or are not vented

 Run and vent drains according to the Installation Manual

WATER SYSTEM CHECKLIST

UDE0080/UDP0080

A water-related problem often causes the same symptoms as a refrigeration system component malfunction.

Water system problems must be identified and eliminated prior to replacing refrigeration components.

Water area (evaporator) is dirty

Descale as needed

Water inlet pressure not between 20 and 80 psig (1–5 bar, 138–552 kPa)

 Install a water regulator valve or increase the water pressure

Incoming water temperature is not between 40°F (3°C) and 90°F (32°C)

 If too hot, check the hot water line check valves in other store equipment

Water filtration is plugged (if used)

Install a new water filter

Vent tube is not installed on water outlet drain

See Installation Instructions

Hoses, fittings, etc., are leaking water

Repair/replace as needed

Water valve is stuck open, closed or is leaking

Descale/replace as needed

Water is spraying out of the sump trough area

Stop the water spray

Water is leaking through the sump trough overflow

• Set the water level 1/4"-3/8" below standpipe

Uneven water flow across the evaporator

Descale the ice machine

Water is freezing behind the evaporator

· Correct the water flow

Plastic extrusions and gaskets are not secured to the evaporator

• Remount/replace as need.

Refrigeration Diagnostics

UDE0080/UDP0080

Perform the procedures on the preceding pages before performing refrigeration diagnostics. The first pages cover an overview of the diagnostic procedures followed by diagnostics checklists.

Install thermometer thermocouples on Suction and Discharge line:

- Digital thermometers with remote thermocouples must be used to obtain temperatures.
- Suction and Discharge line thermocouples must be within 3" (76.2 mm) of the compressor.
- Thermocouples must be insulated.
- Doors and all panels must be in place.
- Initial freeze cycle is not used for diagnostics.
- Start monitoring temperatures 3 minutes into the second freeze cycle.

Compare Suction and Discharge temperatures to your model in the charts starting on page 204.

The charts list normal suction and discharge temperatures.

Analysis

Discharge Line Temp	Suction Line Temp	Ice Fill Pattern	Refer to Diagnostics for:
Normal	Normal	Less fill on the left side of the evaporator	This is normal operation
Low (20°F [-7°C] or more)	Low (20°F [-7°C] or more)	Less fill on the left side of the evaporator	Expansion Valve Flooding
Normal or High	High (10°F [-12°C] or more)	Less fill on the left side and top 2 rows of the evaporator	Low on Refrigerant or Expansion Valve Starving
Normal	Low (5°F [-15°C] or less)	Less fill on the left side of the evaporator	Refrigerant Overcharge

FLOODING EXPANSION VALVE SYMPTOMS

A flooding expansion valve will have discharge and suction line temperatures 20°F (-7°C) lower than normal freeze cycle temperatures. Normal suction line temperature and low discharge line temperature DO NOT verify a flooding valve. Both discharge line temperature and suction line temperature must be low to verify a flooding expansion valve. Ice fill pattern is thin on the left hand side of the evaporator.

STARVING EXPANSION VALVE/LOW REFRIGERANT CHARGE SYMPTOMS:

- A. Ice Fill Pattern
- Thin on top two rows of the evaporator
- Thin on entire left side of the evaporator
- Thick on the bottom of the evaporator
 - B. Freeze time longer than normal

Diagnosis can be confirmed by adding installing a temporary access valve and adding 2 oz (56.7 g) of refrigerant: If the suction line temperature drops or the ice fill pattern on the top two rows fills in, the ice machine is low on refrigerant. Refer to charging procedures for access valve installation/removal procedure.


OVERCHARGED SYSTEM SYMPTOMS

Suction line temperature will be slightly low during freeze cycle 5°F (-15°C). Discharge line temperature is normal. Actual amperage readings will be higher than nameplate rating.

ANALYZING ICE FORMATION PATTERN

Evaporator ice formation pattern analysis is helpful in ice machine diagnostics.

Analyzing the ice formation pattern alone cannot diagnose an ice machine malfunction. However, when this analysis is used along with Manitowoc's Refrigeration System Operational Analysis Table, it can help diagnose an ice machine malfunction.



Normal Ice Formation

Ice forms across the entire evaporator surface.

At the beginning of the Freeze cycle, it may appear that more ice is forming on the inlet of the evaporator than at the outlet. At the end of the Freeze cycle, ice formation at the outlet will be close to, or just a bit thinner than, ice formation at the inlet. The dimples in the cubes at the outlet of the evaporator may be more pronounced than those at the inlet. This is normal.

If ice forms uniformly across the evaporator surface, but does not do so in the proper amount of time, this is still considered a normal ice fill pattern.

Extremely Thin at Evaporator Outlet

There is no ice, or a considerable lack of ice formation on the outlet of the evaporator.

Examples: No ice at all at the outlet of the evaporator, but ice forms at the inlet half of the evaporator. Or, the ice at the outlet of the evaporator reaches the correct thickness, but the inlet of the evaporator already has 1/2" to 1" of ice formation.

Possible cause: Water loss, low on refrigerant, starving TXV, hot water supply, faulty float valve, etc.

Extremely Thin at Evaporator Inlet

There is no ice, or a considerable lack of ice formation at the inlet of the evaporator. Examples: The ice at the outlet of the evaporator reaches the correct thickness, but there is no ice formation at all at the inlet of the evaporator.

Possible cause: Insufficient water flow, flooding TXV, etc.

Spotty Ice Formation

There are small sections on the evaporator where there is no ice formation. This could be a single corner, or a single spot in the middle of the evaporator. This is generally caused by loss of heat transfer from the tubing on the backside of the evaporator.

No Ice Formation

The ice machine operates for an extended period, but there is no ice formation at all on the evaporator.

Possible cause: Water float valve, water pump, starving expansion valve, low refrigerant charge, compressor, etc.

ANALYZING DISCHARGE LINE TEMPERATURE UDE0080/UDP0080

1.	Determine the ice machine operating conditions:	
	Air temperature entering condenser	
	Air temperature around ice machine	
	Water temperature entering sump trough	
2.	Refer to "Installation/Visual Inspection Checklist" on page 195 for ice machine being checked.	
	the operating conditions determined in step 1 to find published normal discharge temperatures.	
	Freeze Cycle	
	Harvest Cycle	

3. Perform an actual discharge temperature check.

	· ·	
	Freeze Cycle	Harvest Cycle
	Temperature	Temperature
Beginning of		
Cycle		
Middle of		
Cycle		
End of		
Cycle		

4. Compare the actual discharge temperature (Step 3) with the published discharge temperature (Step 2).

The discharge temperature is normal when the actual temperature falls within the published temperature range for the ice machine's operating conditions. It is normal for the discharge temperature to be lower at the beginning of the freeze cycle, then climb through out the freeze cycle.

Discharge Line Temperature High Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 195

Restricted Condenser Air Flow

- High inlet air temperature
- · Condenser discharge air re-circulation
- Dirty condenser fins
- · Defective fan cycling control
- Defective fan motor

Improper Refrigerant Charge

- Overcharged
- Non-condensible in system
- Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- High side refrigerant lines/component restricted (before mid-condenser)

Freeze Cycle Discharge Temperature Low Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 195

Improper Refrigerant Charge

- Undercharged
- · Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- High side refrigerant lines/component restricted (before mid-condenser)
- Defective fan cycle control

ANALYZING SUCTION LINE TEMPERATURE

UDE0080/UDP0080

The suction line temperature gradually drops throughout the freeze cycle. The actual suction temperature (and drop rate) changes as the air and water temperature entering the ice machine changes. These variables also determine the freeze cycle times. To analyze and identify the proper suction temperature drop throughout the freeze cycle, compare the published suction temperature to the published freeze cycle time.

NOTE: Analyze discharge temperature before analyzing suction temperature. High or low discharge temperature may be causing high or low suction temperature.

Determine the ice machine energting conditions

Ι.	Determine the ice machine operating conditions:	
	Air temperature entering condenser	_
	Air temperature around ice machine	_
	Water temperature entering sump trough	_
	the operating conditions determined in step 1 to fi published normal suction temperatures.	nd
	Freeze Cycle	
	Harvest Cycle	
2.	Perform an actual suction temperature check.	

	Freeze Cycle Temperature	Harvest Cycle Temperature
Beginning of Cycle		
Middle of Cycle		
End of Cycle		

3. Compare the actual suction temperature (Step 3) with the published suction temperature (Step 2).

The suction temperature is normal when the actual temperature falls within the published temperature range for the ice machine's operating conditions. It is normal for the suction temperature to be higher at the beginning of the freeze cycle, then drop through out the freeze cycle.

Suction Temperature High Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 195

Discharge Pressure

 Discharge temperature is too high, and is affecting suction temperature, refer to "Discharge Line Temperature High Checklist" on page 203.

Improper Refrigerant Charge

- Overcharged
- Wrong type of refrigerant
- Non-condensible in system

Other

- Non-Manitowoc components in system
- · Harvest valve leaking
- TXV flooding (check bulb mounting)
- Defective compressor

Suction Temperature Low Checklist

Improper Installation

 Refer to "Installation/Visual Inspection Checklist" on page 195

Discharge Pressure

 Discharge temperature is too low, and is affecting suction temperature, refer to "Freeze Cycle Discharge Temperature Low Checklist" on page 203.

Improper Refrigerant Charge

- Undercharged
- Wrong type of refrigerant

Other

- Non-Manitowoc components in system
- Improper water supply over evaporator refer to "Water System Checklist" on page 196.
- Loss of heat transfer from tubing on back side of evaporator
- Restricted/plugged liquid line drier
- Restricted/plugged tubing in suction side of refrigeration system
- TXV starving

NOTE: Do not limit your diagnosis to only the items listed in the checklists.

COMPARING EVAPORATOR INLET/OUTLET TEMPERATURES

UDE0080/UDP0080

The temperatures of the suction line entering and leaving the evaporator alone cannot diagnose an ice machine. However, comparing these temperatures during the freeze cycle can help diagnose an ice machine malfunction.

The actual temperatures entering and leaving the evaporator vary by model, and change throughout the freeze cycle. This makes documenting the "normal" inlet and outlet temperature readings difficult. The key to the diagnosis lies in the difference between the two temperatures five minutes into the freeze cycle. These temperatures must be within 7°F (4°C) of each other.

Use this procedure to document freeze cycle inlet and outlet temperatures.

- Use a quality temperature meter, capable of taking temperature readings on curved copper lines.
- Attach the temperature meter sensing device to the copper lines entering and leaving the evaporator.

Important

Do not simply insert the sensing device under the insulation. It must be attached to and reading the actual temperature of the copper line.

- 3. Wait five minutes into the freeze cycle.
- 4. Record the temperatures below and determine the difference between them.

Inlet Temperature	Difference must be within 7°F (4°C) at 5 minutes into the freeze cycle	
-------------------	--	--

 Use this with other information gathered on the Refrigeration System Operational Analysis Table to determine the ice machine malfunction.

DISCHARGE LINE TEMPERATURE ANALYSIS

UDE0080/UDP0080

Knowing if the discharge line temperature is increasing, decreasing or remaining constant can be an important diagnostic tool. Maximum compressor discharge line temperature on a normally operating ice machine steadily increases throughout the freeze cycle. Comparing the temperatures over several cycles will result in a consistent maximum discharge line temperature.

- Ambient air temperatures affect the maximum discharge line temperature.
- Higher ambient air temperatures at the condenser equal higher discharge line temperatures at the compressor.
- Lower ambient air temperatures at the condenser equal lower discharge line temperatures at the compressor.

NOTE: Regardless of ambient temperature, the freeze cycle discharge line temperature will be higher than 150°F (66°C) on a normally operating ice machine.

PROCEDURE

Connect a temperature probe on the compressor discharge line within 6" (15.2 cm) of the compressor. Observe the discharge line temperature for the last three minutes of the freeze cycle and record the maximum discharge line temperature.

Discharge Line Temperature Above 150°F (66°C) at End of Freeze Cycle:

Ice machines that are operating normally will have consistent maximum discharge line temperatures above 150°F (66°C).

Verify the expansion valve sensing bulb is positioned and secured correctly.

Discharge Line Temperature Below 150°F (66°C) at End of Freeze Cycle

Ice machines that have a flooding expansion valve will have a maximum discharge line temperature that decreases each cycle.

Verify the expansion valve sensing bulb is 100% insulated and sealed airtight. Condenser air contacting an incorrectly insulated sensing bulb will cause overfeeding of the expansion valve.

HARVEST VALVE

UDE0080/UDP0080

The harvest valve is an electrically operated valve that opens when energized, and closes when de-energized.

Normal Operation

The valve is de-energized (closed) during the freeze cycle and energized (open) during the harvest cycle. The valve is positioned between the and the evaporator and performs two functions:

- Prevents refrigerant from entering the evaporator during the freeze cycle.
 - The harvest valve is not used during the freeze cycle. The harvest valve is de-energized (closed) preventing refrigerant flow from the receiver into the evaporator.
- Allows refrigerant vapor to enter the evaporator in the harvest cycle.

During the harvest cycle, the harvest valve is energized (open) allowing refrigerant gas from the discharge line of the compressor to flow into the evaporator. The heat is absorbed by the evaporator and allows release of the ice slab

Exact temperatures vary according to ambient temperature and ice machine model.

Harvest Valve Analysis

The valve can fail in two positions:

- Valve will not open in the harvest cycle.
- Valve remains open during the freeze cycle.

VALVE WILL NOT OPEN IN THE HARVEST CYCLE

Although the circuit board has initiated a harvest cycle, the evaporator temperature remains unchanged from the freeze cycle.

VALVE REMAINS OPEN IN THE FREEZE CYCLE:

Symptoms of a harvest valve remaining partially open during the freeze cycle can be similar to symptoms of an expansion valve, float valve or compressor problem. Symptoms are dependent on the amount of leakage in the freeze cycle.

A small amount of leakage will cause increased freeze times and an ice fill pattern that is "Thin at the Outlet", but fills in at the end of the cycle.

As the amount of leakage increases the length of the freeze cycle increases and the amount of ice at the outlet of the evaporator decreases.

Refer to the Parts Manual for proper valve application. If replacement is necessary, use only "original" Manitowoc replacement parts.

Use the following procedure and table to help determine if a harvest valve is remaining partially open during the freeze cycle.

- 1. Wait five minutes into the freeze cycle.
- 2. Feel the inlet of the harvest valve(s).

Important

Feeling the harvest valve outlet or across the harvest valve itself will not work for this comparison.

The harvest valve outlet is on the suction side (cool refrigerant). It may be cool enough to touch even if the valve is leaking.

3. Feel the compressor discharge line.

AWarning

The inlet of the harvest valve and the compressor discharge line could be hot enough to burn your hand. Just touch them momentarily.

 Compare the temperature of the inlet of the harvest valves to the temperature of the compressor discharge line.

Findings	Comments
The inlet of the harvest valve	This is normal as the discharge
is cool enough to touch and	line should always be too hot to
the compressor discharge	touch and the harvest valve inlet,
line is hot.	although too hot to touch during
	harvest, should be cool enough
Cool & Hot	to touch after 5 minutes into the
	freeze cycle.
The inlet of the harvest	This is an indication something is
valve is hot and approaches	wrong, as the harvest valve inlet
the temperature of a hot	did not cool down during the
compressor discharge line.	freeze cycle. If the compressor
	dome is also entirely hot, the
Hot & Hot	problem is not a harvest valve
	leaking, but rather something
	causing the compressor (and the
	entire ice machine) to get hot.
Both the inlet of the harvest	This is an indication something is
valve and the compressor	wrong, causing the compressor
discharge line are cool	discharge line to be cool to the
enough to touch.	touch. This is not caused by a
	harvest valve leaking.
Cool & Cool	

THIS PAGE INTENTIONALLY LEFT BLANK

Component Check Procedures

MAIN FUSE

Function

The control board fuse stops ice machine operation if electrical components fail causing high amp draw.

Specifications

- 80/140/190/240/310 Series 250 Volt, 10 amp.
- 65 Series 250 Volt, 8 amp.

AWarning

High (line) voltage is applied to the control board at all times. Removing the control board fuse or pressing the power button will not remove the power supplied to the control board.

Check Procedure

 If the curtain light is on with the ice damper closed, the fuse is good.

▲ Warning

Disconnect electrical power to the entire ice machine before proceeding.

Remove the fuse. Check the resistance across the fuse with an ohmmeter.

Reading	Result
Open (OL)	Replace fuse
Closed (O)	Fuse is good

BIN SWITCH

80/140/190/240/310 Series

Function

Bin switch operation is controlled by the movement of the ice damper. The bin switch has two main functions:

Terminating the harvest cycle and returning the ice machine to the freeze cycle.

This occurs when the bin switch is opened and closed again within 30 seconds of opening during the harvest cvcle.

2. Automatic ice machine shut-off.

> If the storage bin is full at the end of a harvest cycle, the sheet of cubes fails to clear the ice damper and holds it down. After the ice damper is held down for 30 seconds, the ice machine shuts off.

The ice machine remains off until enough ice is removed from the storage bin to allow the sheet of cubes to drop clear of the ice damper. As the ice damper swings back to the operating position, the bin switch closes and the ice machine restarts.

Important

The ice damper must be up (bin switch closed) to start ice making.

Check Procedure

- 1. Press the power button to OFF.
- 2. Watch the curtain light on the control board.
- Move the ice damper upward, toward the evaporator. The bin switch must close. The curtain light "on" indicates the bin switch has closed properly.
- Move the ice damper away from the evaporator. The bin switch must open. The curtain light "off" indicates the bin switch has opened properly.

Ohm Test

- Disconnect the bin switch wires to isolate the bin switch from the control board.
- Connect an ohmmeter to the disconnected bin switch wires.
- 3. Cycle the bin switch open and closed numerous times by opening and closing the water curtain.

NOTE: To prevent mis-diagnosis:

- Always use the water curtain magnet to cycle the switch (a larger or smaller magnet will affect switch operation).
- Watch for consistent readings when the bin switch is cycled open and closed (bin switch failure could be erratic).

TOUCH PAD

140/190/240/310 Series

Function

User interface to select ice making, delay start or cleaning cycle and provides feedback on ice machine operation.

Check For Normal Operation

Action	Normal Function	
Press and hold the control	All Touch Pad lights turn on	
board test button for 3 seconds		
Press test button	All Touch Pad lights turn off	
Press power button	Power light turns on	
With power light energized	Cycles through 4 hour delay,	
press the delay button 4 times	12 hour delay, 24 hour delay	
	and off	
Press and hold the power	Power light turns off	
button for 3 seconds		
Press and hold the clean button	Clean light turns on	
for 3 seconds		
Press and hold the clean button	Clean light turns off	
for 3 seconds		

If any switches do not operate correctly, disconnect main power to the ice machine to reset the control board and perform a second test. If the second test doesn't show normal function, perform the Ohm test to verify the issue is not a wiring or control board issue.


Ohm Test

Disconnect power from ice machine.

Disconnect wire from control board and Ohm touch pad and interconnecting wire to verify correct operation. Pressing and depressing the touch pad must open and close the circuit. A switch that functions correctly will close as the button is pressed and open as the button is released.

Do not insert electrical probe into end of connector. This will stretch the connector and cause intermittent connection issues. All readings must be taken on the flat exterior of the connector.

Selection	Wires
On/Off	#2 & #7
Delay	#3 & #7
Clean	#4 & #7



Control Board Connector

FLOAT SWITCHES 140/190/240/310 Series

Function

Open and close to indicate to the control board the level of water in the water trough.

Specifications

Normally closed, float operated magnetic reed switch.

The float switch contacts are closed in the down position. When water raises the float to the up position the magnet in the float opens the contacts.

Check Procedure

The ice machine uses two float switches.

Ice Thickness Float -Indicates the water level has been reached.

Harvest Float - Indicates a harvest cycle needs to be initiated.

Initial testing can be performed by viewing the control board light(s) while raising and lowering the float. The corresponding control board light must turn on and off when the float is raised and lowered.

Harvest Float Switch:

- A. The light must be on in the up position.
- B. The light must be off in the down position.

1 Caution


Do not disassemble float for Descaling - Incorrect reassembly of the float will result in an ice machine that will not harvest.

Ice Thickness Float Switch:

- A. The light must be off in the down position.
- B. The light must be on in the up position.

If the control board light does not respond to the float proceed with step 1 below.

- Disconnect power to the ice machine, pull the wire connector for the float switch through the bulkhead and disconnect.
- 2. Attach an ohm meter lead to each float switch wire.
- Place the float in the down position The float switch must be closed.
- 4. Place the float in the up position The float switch must be open.



NOTE: Make adjustments with the ice machine in the off position. Making adjustments during the freeze cycle may produce an initial sheet of ice that is thicker than future cycles.

Float	Float Up	Float Down
Ice Thickness Float	OL (Open)	Closed
Harvest Float	OL (Open)	Closed

WATER TROUGH THERMISTOR

140/190/240/310 Series

Function

Thermistor resistance values change with temperature. The value supplied to the control board is used to identify temperature at the thermistor location.

When the resistance value indicates a temperature of 34°F (1.1°C) the control board will delay the water pump for 25 seconds. When the water pump restarts the water inlet valve will energize for 7 seconds then turn off.

NOTE: If the ice machine is experiencing long freeze cycle shut down, we recommend removing the thermistor and bracket permanently.

Check procedure

THERMISTOR

- 1. Disconnect thermistor from control board and measure resistance.
- 2. Measure temperature at the thermistor.
- 3. Compare measured resistance/temperature readings to resistance/temperature relationship chart.
 - A. Within 10% of the published resistance value Thermistor is good
 - Not within 10% of the published resistance value
 Thermistor is defective.

CONTROL BOARD OPERATION

- Disconnect thermistor from control board The control board thermistor LED will flash 1 second on and 1 second off.
- 2. The control board will default to the 3.75 minute pump delay in the freeze cycle.

THERMISTOR CHART

Important

If the ohmmeter reads "OL," check the scale setting on the meter before assuming the thermistor is bad.

Temperature of Thermistor		Resistance	
°C	°F	K Ohms (x1000)	
-71.0	19 - 30	47.06 - 34.36	
0.0	32	32.65	
0.5	33	31.82	
1.0	33.8	31.03	
1.1	34	30.85	
1.5	34.7	30.25	
2.0	35.6	29.49	
2.5	36.5	28.76	
3.0	37	28.05	
3.5	38	27.36	
4.0 - 10.5	39 - 51	26.68 - 19.43	
11.0 - 15.0	52 - 59	18.97 - 15.71	
15.5 - 20.0	60 - 68	15.35 - 12.49	
20.5 - 25.0	69 - 77	12.21 - 10.00	
25.5 - 30.0	78 - 86	9.78 - 8.05	
30.5 - 35.0	87 - 95	7.88 - 6.39	
36.5 - 40.0	98 - 104	6.14 - 5.32	
40.5 - 46.0	105 - 115	5.22 - 4.20	

NOTE: The control board will default to a 3.75 minute pump delay in the freeze cycle, whenever the thermistor is disconnected or reads outside the resistance ranges in the table.

BIN THERMOSTAT

UDE0065/UDP0065

Function

The bin thermostat stops the ice machine when the bin is full. The level of ice in the ice storage bin controls the ice machine shut-off. When the bin is full, ice cubes contact the bin thermostat bulb holder, which cools down and opens the bin thermostat to stop the ice machine. The ice machine remains off until enough ice has been removed from the bin. This causes the thermostat bulb holder to warm and closes the bin thermostat, restarting the ice machine.

Specifications

Control	Setting	
Din Thormostat	Cut in: 40°F (4.5°C)	
Bin Thermostat	Cut out: 34°F (1.0°C)	

▲ Warning

Disconnect electrical power to the entire ice machine before proceeding.

- 1. Remove the back panel to access the bin thermostat.
- Disconnect both wires from the bin thermostat and check the resistance across the bin thermostat terminals

No Ice On Bulb	Ice On Bulb	Result
Closed	Open	Thermostat good
Open	Closed	Replace Thermostat

NOTE: After covering/uncovering the bulb holder with ice, wait at least three minutes to allow the thermostat to react. (Open/Close)

LIQUID LINE THERMISTOR

UDE0065/UDP0065

Function

The liquid line thermistor senses the refrigeration system liquid line temperature. This is used in conjunction with the control board to determine the length of the freeze and harvest cycles.

Specifications

10,000 Ohms +/- 2% at 25°C (77°F)

Check Procedure

Verify that the thermistor resistance is accurate and corresponds to the high and low temperature ranges.

- Disconnect the thermistor at the control board.
 Connect an ohmmeter to the isolated thermistor wire leads.
- Using a temperature meter capable of taking readings on curved copper lines, attach the temperature meter sensing device to the liquid line next to the thermistor.

Important

Do not simply "insert" the sensing device under the insulation. It must be attached to and reading the actual temperature of the copper liquid line.

 With the ice machine running, verify that the temperature of the discharge line (step 2) corresponds to the thermistor resistance reading (step 1) as stated in the temperature/resistant chart.

Important

If the thermistor would fail closed, the light on the control board will flash rapidly. If the thermistor would fail open, the light on the control board will flash slowly.

TEMPERATURE/RESISTANCE CHART UDE0065/UDP0065

As the temperature rises at the thermistor block, the resistance drops.

Important

If the ohmmeter reads "OL," check the scale setting on the meter before assuming the thermistor is bad.

Temperature of Thermistor		Resistance	
°C	°F	K Ohms (x1000)	
15.6 - 21.1	60 - 70	15.31 - 11.88	
21.1 - 26.7	70 - 80	11.88 - 9.29	
26.7 - 32.2	80 - 90	9.29 - 7.33	
32.2 - 37.8	90 - 100	7.33 - 5.82	
37.8-43.3	100 - 110	5.82 -4.66	
43.3 - 48.9	110 - 120	4.66 - 3.75	
48.9 - 54.5	120 - 130	3.75 - 3.05	
54.5 - 60.0	130 - 140	3.05 - 2.49	
60.0 - 65.6	140 - 150	2.49 - 2.04	
65.6 - 17.1	150 - 160	2.04 - 1.68	
76.7 - 82.2	170 - 180	1.40 - 1.17	
82.2 - 87.3	180 - 190	1.17 - 0.98	
87.8 - 93.3	190 - 200	0.98 - 0.82	
93.3 - 98.9	200 - 210	0.82 - 0.70	
100	212	0.73 0.63	
Boiling w	ater bath	0.73 - 0.62	
104.4 - 110.0	220 - 230	0.59 - 0.51	
110.0 - 115.6	230 - 240	0.51 - 0.43	
115.6 - 121.1	240 - 250	0.43 - 0.37	
121.1 - 126.7	250 - 260	0.37 - 0.33	

ON/OFF/WASH TOGGLE SWITCH

65/80 Series

FUNCTION

The switch is used to place the ice machine in ON, OFF or WASH mode of operation.

SPECIFICATIONS

Single-pole, double-throw switch. The switch is connected into a varying low D.C. voltage circuit.

CHECK PROCEDURE

NOTE: Because of a wide variation in D.C. voltage, it is not recommended that a voltmeter be used to check toggle switch operation.

- 1. Inspect the toggle switch for correct wiring.
- Isolate the toggle switch by disconnecting all wires from the switch, or by disconnecting the Molex connector from the control board.
- Check across the toggle switch terminals using a calibrated ohmmeter. Note where the wire numbers are connected to the switch terminals, or refer to the wiring diagram to take proper readings.

COMPRESSOR ELECTRICAL DIAGNOSTICS

All Models

The compressor does not start or will trip repeatedly on overload.

Check Resistance (Ohm) Values

NOTE: Compressor windings can have very low ohm values. Use a properly calibrated meter.

Perform the resistance test after the compressor cools. The compressor dome should be cool enough to touch (below 120°F/49°C) to ensure that the overload is closed and the resistance readings will be accurate.

Single Phase Compressors

- Disconnect power from the condensing unit and remove the wires from the compressor terminals.
- The resistance values between C and S and between C and R, when added together should equal the resistance value between S and R.
- If the overload is open, there will be a resistance reading between S and R, and open readings between C and S and between C and R. Allow the compressor to cool, then check the readings again.

Check Motor Windings to Ground

Check continuity between all three terminals and the compressor shell or copper refrigeration line. Scrape metal surface to get good contact. If continuity is present, the compressor windings are grounded and the compressor should be replaced.

To determine if the compressor is seized check the amp draw while the compressor is trying to start.

Compressor Drawing Locked Rotor

The two likely causes of this are:

- Defective starting component
- Mechanically seized compressor

To determine which you have:

- 1. Install high and low side gauge.
- 2. Try to start the compressor.
- 3. Watch the pressures closely.
 - If the pressures do not move, the compressor is seized. Replace the compressor.
 - If the pressures move, the compressor is turning slowly and is not seized. Check the capacitors and relay.

Compressor Drawing High Amps

The continuous amperage draw on start-up should not be near the maximum fuse size indicated on the serial tag.

The wiring must be correctly sized to minimize voltage drop at compressor start-up. The voltage when the compressor is trying to start must be within $\pm 10\%$ of the nameplate voltage.

FAN CYCLE CONTROL

80/140/190/240/310 Series

Function

Cycles the fan motor on and off to maintain proper operating discharge pressure.

The fan cycle control closes on an increase, and opens on a decrease in discharge pressure.

Specifications

		,
Model	Cut-In (Close)	Cut-Out (Open)
UDE0080	145 psig ±5	110 psig ±5
UDP0080	200 psig ±5	150 psig ±5
U0140/UF0140/ U0190/UF0190	250 psig ±5	200 psig ±5
UP0140/UP0190	200 psig ±5	150 psig ±5
U0240/UF0240/ U0310/UF0310	275 psig ±5	225 psig ±5
UP0240/ UP0310	200 psig ±5	150 psig ±5

Check Procedure

Disconnect electrical power to the ice machine at the electrical service disconnect.

Verify fan motor windings are not open or grounded, and fan spins freely.

Connect manifold gauge to ice machine.

Hook voltmeter in parallel across the fan cycle control, leaving wires attached.

Reconnect electrical power to the ice machine and press the power button to ON.

Wait until water flows over the evaporator then refer to chart below.

System Pressure:	Reading Should Be:	Fan Should Be:
Above cut-in	0 volts	Running
Below cut-out	Line voltage	Off

HIGH PRESSURE CUTOUT (HPCO) CONTROL 140/190/240/310 Series

Stops the ice machine if subjected to excessive high-side pressure. The HPCO control is normally closed, and opens on a rise in discharge pressure.

Specifications

Model	Cut-In (Close)	Cut-Out (Open)	
U0140/UF0140/	300 psig ±10	450 psig ±10	
U0190/UF0190*	300 psig ±10	450 psig ±10	
UP0140/UP0190	250 psig ±10	350 psig ±10	
U0240/UF0240/	200	450	
U0310/UF0310*	300 psig ±10	450 psig ±10	
UP0240/ UP0310 250 psig ±10 350 psig		350 psig ±10	
* Must be below 300 psig to reset			

Check Procedure

- 1. Switch to OFF.
- 2. Connect manifold gauge.
- Hook voltmeter in parallel across the HPCO, leaving wires attached.
- On water-cooled models, close the water service valve to the water condenser inlet. On self-contained air-cooled models, disconnect the fan motor.
- Set to ON No water or air flowing through the condenser will cause the HPCO control to open because of excessive pressure. Watch the pressure gauge and record the cut-out pressure.

A Warning

If discharge pressure exceeds 460 psig and the HPCO control does not open, press the power button to stop ice machine operation.

Replace the HPCO control if it:

- Will not reset (below 300 psig)
- Does not open at the specified cut-out point

FILTER-DRIERS

All Models

Liquid Line Filter Drier

The filter-drier used on Manitowoc ice machines are manufactured to Manitowoc specifications.

The difference between a Manitowoc drier and an offthe-shelf drier is in filtration. A Manitowoc drier has dirt-retaining filtration, with fiberglass filters on both the inlet and outlet ends. This is very important because ice machines have a back-flushing action that takes place during every harvest cycle.

A Manitowoc filter-drier has a very high moisture removal capability and a good acid removal capacity.

Important

The liquid line drier is covered as a warranty part. The liquid line drier must be replaced any time the system is opened for repair.

Refrigerant Recovery/Evacuation

DEFINITIONS

Recover

To remove refrigerant, in any condition, from a system and store it in an external container, without necessarily testing or processing it in any way.

Recycle

To clean refrigerant for re-use by oil separation and single or multiple passes through devices, such as replaceable core filter-driers, which reduce moisture, acidity and particulate matter. This term usually applies to procedures implemented at the field job site or at a local service shop.

Reclaim

To reprocess refrigerant to new product specifications (see below) by means which may include distillation. A chemical analysis of the refrigerant is required after processing to be sure that product specifications are met. This term usually implies the use of processes and procedures available only at a reprocessing or manufacturing facility.

Chemical analysis is the key requirement in this definition. Regardless of the purity levels reached by a reprocessing method, refrigerant is not considered "reclaimed" unless it has been chemically analyzed and meets ARI Standard 700 (latest edition).

New Product Specifications

This means ARI Standard 700 (latest edition). Chemical analysis is required to assure that this standard is met.

REFRIGERANT RE-USE POLICY

Manitowoc recognizes and supports the need for proper handling, re-use, and disposal of refrigerants. Manitowoc service procedures require recapturing refrigerants, not venting them to the atmosphere.

It is not necessary, in or out of warranty, to reduce or compromise the quality and reliability of your customers' products to achieve this.

Important

Manitowoc Ice assumes no responsibility for use of contaminated refrigerant. Damage resulting from the use of contaminated, recovered, or recycled refrigerant is the sole responsibility of the servicing company.

Manitowoc approves the use of:

- 1. New Refrigerant
 - Must be of original nameplate type.
- 2. Reclaimed Refrigerant
 - · Must be of original nameplate type.
 - Must meet ARI Standard 700 (latest edition) specifications.
- 3. Recovered or Recycled Refrigerant
 - Must be recovered or recycled in accordance with current local, state and federal laws.
 - Must be recovered from and re-used in the same Manitowoc product. Re-use of recovered or recycled refrigerant from other products is not approved.

- Recovered refrigerant must come from a "contaminant-free" system. To decide whether the system is contaminant free, consider:
 - Type(s) of previous failure(s)
 - Whether the system was cleaned, evacuated and recharged properly following failure(s)
 - Whether the system has been contaminated by this failure
 - Compressor motor burnouts and improper past service prevent refrigerant re-use.
 - Refer to "System Contamination Cleanup" on page 242 to test for contamination.
- 5. "Substitute" or "Alternative" Refrigerant
 - Must use only Manitowoc-approved alternative refrigerants.
 - Must follow Manitowoc-published conversion procedures.

RECOVERY AND RECHARGING PROCEDURES 140/190/240/310 Series

Do not purge refrigerant to the atmosphere. Capture refrigerant using recovery equipment. Follow the manufacturer's recommendations.

Important

Manitowoc Ice assumes no responsibility for the use of contaminated refrigerant. Damage resulting from the use of contaminated refrigerant is the sole responsibility of the servicing company.

Important

Replace the liquid line drier before evacuating and recharging. Use only a Manitowoc (O.E.M.) liquid line filter drier to prevent voiding the warranty.

CONNECTIONS

- Suction side of the compressor through the suction service valve.
- Discharge side of the compressor through the discharge service valve.

SELF-CONTAINED RECOVERY/EVACUATION

- Place the power button in the OFF position.
- Install manifold gauge set, charging cylinder/scale, and recovery unit or two-stage vacuum pump.
- Open (backseat) the high and low side ice machine service valves, and open high and low side on manifold gauge set.
- 4. Perform recovery or evacuation:
 - A. Recovery: Operate the recovery unit as directed by the manufacturer's instructions.
 - B. Evacuation prior to recharging: Pull the system down to 500 microns. Then, allow the pump to run for an additional half hour. Turn off the pump and perform a standing vacuum leak check.

NOTE: Check for leaks using an electronic leak detector after charging the ice machine.

Follow the Charging Procedures below.

CHARGING PROCEDURES

Important

The charge is critical on all Manitowoc ice machines. Use a scale or a charging cylinder to ensure the proper charge is installed.

- 1. Be sure the power button is in the OFF position.
- 2. Close the vacuum pump valve, the low side service valve, and the low side manifold gauge valve.
- 3. Open the high side manifold gauge valve, and backseat the high side service valve.
- Open the charging cylinder and add the proper refrigerant charge (shown on nameplate) through the discharge service valve.
- 5. Let the system "settle" for 2 to 3 minutes.
- 6. Press the power button to the on position.

7. Close the high side on the manifold gauge set.

NOTE: Manifold gauge set must be removed properly to ensure that no refrigerant contamination or loss occurs.

- Make sure that all of the vapor in the charging hoses is drawn into the ice machine before disconnecting the charging hoses.
 - Run the ice machine in freeze cycle.
 - Close the high side service valve at the ice machine.
 - C. Open the low side service valve at the ice machine (when supplied) or disconnect the low loss fitting from the access valve.
 - D. Open the high and low side valves on the manifold gauge set. Any refrigerant in the lines will be pulled into the low side of the system.
 - E. Allow the pressures to equalize while the ice machine is in the freeze cycle.
 - F. Close the low side service valve at the ice machine
- Remove the hoses from the ice machine and install the caps.

RECOVERY AND RECHARGING PROCEDURES

65/80 SERIES

Do not purge refrigerant to the atmosphere. Capture refrigerant using recovery equipment. Follow the manufacturer's recommendations.

Important

Manitowoc Ice assumes no responsibility for the use of contaminated refrigerant. Damage resulting from the use of contaminated refrigerant is the sole responsibility of the servicing company.

Important

Replace the liquid line drier before evacuating and recharging. Use only a Manitowoc (OEM) liquid line filter drier to prevent voiding the warranty.

CONNECTIONS

These ice machines are critically charged. There are no refrigerant access ports on these ice machines.

- 1. Locate the high and low side process tubes.
- Install a piercing valve (saddle valve) on both the high and low side process tubes.

Important

- Remove piercing valves after charging.
- Unit is critically charged. Nitrogen must be purged through the system while brazing to prevent build up of copper oxide in the refrigeration system.
- Manifold gauge set must be removed properly to ensure that no refrigerant contamination or loss occurs. A quick disconnect is required for the high side connection.

RECOVERY/EVACUATION

- 1. Place the toggle switch in the OFF position.
- 2. Install manifold gauge set, charging scale, and recovery unit or two-stage vacuum pump.
- Open the high and low side valves on manifold gauge set.
- 4. Perform recovery or evacuation:
 - A. Recovery: Operate the recovery unit as directed by the manufacturer's instructions.
 - B. Evacuation prior to recharging: Pull the system down to 500 microns. Then, allow the pump to run for an additional half hour. Turn off the pump and perform a standing vacuum leak check.

NOTE: Check for leaks using a halide or electronic leak detector after charging the ice machine.

CHARGING PROCEDURES

Important

The charge is critical on all Manitowoc ice machines. Use a scale to ensure the proper charge is installed. A quick disconnect is required for the high side connection

- 1. Verify the toggle switch is in the OFF position.
- Close the vacuum pump valve and the low side manifold gauge valve.
- 3. Open the high side manifold gauge valve.
- Open the refrigerant cylinder and add the proper refrigerant charge (shown on nameplate) through the discharge service valve.
- Close the high side on the manifold gauge set. Add any remaining vapor charge through the suction access fitting (if necessary).

Let the system "settle" for 2 to 3 minutes.

6. Place the toggle switch in the ICE position.

NOTE: Manifold gauge set must be removed properly to ensure that no refrigerant contamination or loss occurs.

- Verify that all of the vapor in the charging hoses is drawn into the ice machine before disconnecting the charging hoses.
 - A. Run the ice machine in the freeze cycle.
 - B. Verify the refrigerant cylinder valve is closed.
 - C. Open the high and low side valves on the manifold gauge set. Any refrigerant in the lines will be pulled into the low side of the system.
 - D. Allow the pressures to equalize while the ice machine is in the freeze cycle.
 - E. Close the high and low side manifold gauge set and remove from the ice machine.
 - F. Remove the temporary access fittings

System Contamination Cleanup

ALL MODELS

This section describes the basic requirements for restoring contaminated systems to reliable service.

Important

Manitowoc Ice assumes no responsibility for the use of contaminated refrigerant. Damage resulting from the use of contaminated refrigerant is the sole responsibility of the servicing company.

DETERMINING SEVERITY OF CONTAMINATION

System contamination is generally caused by either moisture or residue from compressor burnout entering the refrigeration system.

Inspection of the refrigerant usually provides the first indication of system contamination. Obvious moisture or an acrid odor in the refrigerant indicates contamination.

If either condition is found, or if contamination is suspected use a test kit.

If a refrigerant test kit indicates harmful levels of contamination, or if a test kit is not available, inspect the compressor oil.

- 1. Remove the refrigerant charge from the ice machine.
- 2. Remove the compressor from the system.
- 3. Check the odor and appearance of the oil.
- Inspect open suction and discharge lines at the compressor for burnout deposits.
- If no signs of contamination are present, perform an acid oil test to determine the type of cleanup required.

Contamination/Cleanup Chart		
Symptoms/Findings	Required Cleanup	
	Procedure	
No symptoms or suspicion of	Normal evacuation/	
contamination	recharging	
	procedure	
Moisture/Air Contamination symptoms	Mild contamination	
Refrigeration system open to atmosphere	cleanup procedure	
for longer than 15 minutes		
Refrigeration test kit and/or acid oil test		
shows contamination		
No burnout deposits in open compressor		
lines		
Mild Compressor Burnout symptoms	Mild contamination	
Oil appears clean but smells acrid	cleanup procedure	
Refrigeration test kit or acid oil test shows		
harmful acid content		
No burnout deposits in open compressor		
lines		
Severe Compressor Burnout symptoms	Severe	
Oil is discolored, acidic, and smells acrid	contamination	
Burnout deposits found in the compressor,	cleanup procedure	
lines, and other components		

MILD SYSTEM CONTAMINATION CLEANUP PROCEDURE

- 1. Replace any failed components.
- 2. If the compressor is good, change the oil.
- 3. Replace the liquid line drier.

NOTE: If the contamination is from moisture, use heat lamps during evacuation. Position them at the compressor, condenser and evaporator prior to evacuation. Do not position heat lamps too close to plastic components, or they may melt or warp.

- 4. Follow the normal evacuation procedure, except replace the evacuation step with the following:
 - A. Pull vacuum to 1000 microns. Break the vacuum with dry nitrogen and sweep the system.

 Pressurize to a minimum of 5 psig.
 - Pull vacuum to 500 microns. Break the vacuum with dry nitrogen and sweep the system.
 Pressurize to a minimum of 5 psig.
 - C. Change the vacuum pump oil.
 - D. Pull vacuum to 500 microns. Run the vacuum pump for 1/2 hour on self-contained models, 1 hour on remotes.

NOTE: You may perform a pressure test as a preliminary leak check. You should use an electronic leak detector after system charging to be sure there are no leaks.

- Charge the system with the proper refrigerant to the nameplate charge.
- 6. Operate the ice machine.

SEVERE SYSTEM CONTAMINATION CLEANUP PROCEDURE

- 1. Remove the refrigerant charge.
- 2. Remove the compressor.
- 3. If burnout deposits are found, replace the TXV.
- Wipe away any burnout deposits from suction and discharge lines at compressor.
- 5. Sweep through the open system with dry nitrogen.
- 6. Install a new compressor and new start components.
- 7. Install suction line filter-drier in front of compressor.
- 8. Install a new liquid line drier.
- Follow the normal evacuation procedure, except replace the evacuation step with the following:
 - A. Pull vacuum to 1000 microns. Break the vacuum with dry nitrogen and sweep the system.
 Pressurize to a minimum of 5 psig.
 - B. Change the vacuum pump oil.
 - Pull vacuum to 500 microns. Break the vacuum with dry nitrogen and sweep the system.
 Pressurize to a minimum of 5 psig.
 - D. Change the vacuum pump oil.
 - E. Pull vacuum to 500 microns. Run the vacuum pump for 1 additional hour.

- 10. Charge the system with the proper refrigerant to the nameplate charge.
- 11. Operate the ice machine for one hour. Then, check the pressure drop across the suction line filter-drier.
 - A. If the pressure drop is less than 2 psig, the filterdrier should be adequate for complete cleanup.
 - B. If the pressure drop exceeds 2 psig, change the suction line filter-drier and the liquid line drier. Repeat until the pressure drop is acceptable.
- 12. Operate the ice machine for 48 72 hours. Replace the suction line and liquid line drier if necessary.
- 13. Follow normal evacuation procedures.

REPLACING PRESSURE CONTROLS WITHOUT REMOVING REFRIGERANT CHARGE

This procedure reduces repair time and cost. Use it when any of the following components require replacement, and the refrigeration system is operational and leak-free.

- Fan cycle control
- High pressure cut-out control
- High side access valve
- Low side access valve
 - 1. Disconnect power to the ice machine.
 - Follow all manufacturers' instructions supplied with the pinch-off tool. Position the pinch-off tool around the tubing as far from the pressure control as feasible. (See the figure on next page.) Clamp down on the tubing until the pinch-off is complete.

AWarning

Do not unsolder a defective component. Cut it out of the system. Do not remove the pinch-off tool until the new component is securely in place.

- 3. Cut the tubing of the defective component with a small tubing cutter.
- Solder the replacement component in place. Allow the solder joint to cool.
- 5. Remove the pinch-off tool.
- 6. Re-round the tubing.

NOTE: The pressure controls will operate normally once the tubing is re-rounded. Tubing may not re-round 100%.

Total System Refrigerant Charge

Important

This information is for reference only. Refer to the ice machine serial number tag to verify the system charge. Serial plate information overrides information listed in the charts.

UDE0065/UDP0065 & UDE0080/UDP0080

Model	Air-Cooled	Water-Cooled	Refrigerant
			Туре
UDE0065	5.8 oz		R134A
000000	(165 g)	-	K134A
LIDDOOCE	3.8 oz	-	D200
UDP0065	(110 g)		R290
	8 oz		24244
UDE0080	(227 g)	-	R134A
LIDDOGGG	3.8 oz		D200
UDP0080	(110 g)	-	R290

U0140/U0190/U0240/U0310 - R404A

Model	Air-Cooled	Water-Cooled	Refrigerant Type	
U0140	10 oz	11 oz	R404A	
00140	(283 g)	(312 g)	K4U4A	
U0190	12 oz		R404A	
00190	(340 g)	-	N404A	
U0240	13 oz	12 oz	R404A	
00240	(369 g)	(340 g)		
U0310				
Before	15 oz	14 oz	R404A	
Serial Number	(425 g)	(397 g)	K4U4A	
310304977				
U0310				
After	15 oz	18 oz	R404A	
Serial Number	(425 g)	(510 g)	N4U4A	
310304978				

UF0140/UF0190/UF0240/UF0310 - R404A

Model	Air-Cooled	Water-Cooled	Refrigerant Type	
UF0140	6.7 oz	11 oz	R404A	
	(12 g)	(312 g)		
UF0190	12 oz		R404A	
	(340 g)	-		
UF0240	13 oz	13 oz	R404A	
	(369 g)	(369 g)		
UF0310	15 oz	18 oz	R404A	
	(425 g)	(510 g)		

UP0140/UP0190/UP0240/UP0310 - R290

Model	Air-Cooled Water-Cooled		Refrigerant Type
UP0140	4.9 oz (140 g)	-	R290
UP0190	4.9 oz (140 g)	-	R290
UP0240	5.3 oz (150 g)	5.3 oz (150 g)	R290
UP0310	5.2 (147 g)	3.9 (110 g)	R290
UP0310 230V/60Hz Only	4.5 (127 g)	-	R290

THIS PAGE INTENTIONALLY LEFT BLANK

Charts

Cycle Times, 24 Hr. Ice Production and Refrigerant Pressure Charts

These charts are used as guidelines to verify correct ice machine operation.

Accurate collection of data is essential to obtain the correct diagnosis.

- Production and cycle times are for dice cube Half dice cube cycle times can be 1-2 minutes faster depending on model and ambient temperature.
- Ice production checks that are within 10% of the chart are considered normal. This is due to variances in water and air temperature. Actual temperatures will seldom match the chart exactly.
- Refer to "Operational Analysis Chart" for the list of data that must be collected for refrigeration diagnostics.
- Zero out manifold gauge set before obtaining pressure readings to avoid mis-diagnosis.
- Discharge and suction pressure are highest at the beginning of the cycle. Suction pressure will drop throughout the cycle. Verify the pressures are within the range indicated.
- Record beginning of freeze cycle suction pressure one minute after the water pump energizes.
- Ice Production De-rate %
 - 60 Hz Dice and Half Dice production de-rate as shown
 - 60 Hz Regular cube production de-rate is 7%.
 - 50 Hz Dice / Half Dice production de-rate is 12%.
 - 50 Hz Regular cube production de-rate is 14%.

UD0065A/UDE0065A SELF-CONTAINED AIR-COOLED R134A

NOTE: These characteristics will vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water Temperature °F/°C			Harvest
Condenser °F/°C	50/10	70/21	90/32	Time
50°F 10°C	9.4-12.4	10.7-14.1	11.7-15.5	
70°F 21°C	9.6-12.7	11.2-14.8	12.3-16.3	
80°F 27°C	10.7-14.1	12.6-16.7	14.0-18.6	4.25 .2.5
90°F 32°C	12.0-15.9	14.0-18.6	15.6-20.9	1.25 - 3.25
100°F 38°C	15.2-20.2	16.6-22.2	18.3-24.5	
110°F 43°C	20.3-27.3	21.1-28.4	22.0-29.5	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	erature °F/°C	
Entering Condenser °F/°C	50/10	70/21	90/32	
50°F	58 lbs	52 lbs	48 lbs	
10°C	26 kgs	24 kgs	22 kgs	
70°F	57 lbs	50 lbs	46 lbs	
21°C	26 kgs	23 kgs	21 kgs	
80°F	52 lbs	45 lbs	41 lbs	
27°C	24 kgs	20 kgs	19 kgs	
90°F	47 lbs	41 lbs	37 lbs	
32°C	21 kgs	19 kgs	17 kgs	
100°F	38 lbs	35 lbs	32 lbs	
38°C	17 kgs	16 kgs	15 kgs	
110°F	29 lbs	28 lbs	27 lbs	
43°C	13 kgs	13 kgs	12 kgs	

Based on average ice slab weight of 0.4 - 0.6 lbs (0.2 - 0.3 kgs).

Operating Temperatures UD0065A/UDE0065A

Air Temp.	Freeze	Cycle	Harvest Cycle	
Entering	Discharge	Suction	Discharge	Suction
Condenser	Line	Line	Line	Line
°F/°C	Temp °F/°C	Temp °F/°C	Temp °F/°C	Temp °F/°C
50°F	105-120 °F	52-12 °F	130-140 °F	100-115 °F
10°C	40-50 °C	1111 °C	54-60 °C	38-46 °C
70°F	125-155 °F	604 °F	145-155 °F	115-135 °F
21°C	51-68 °C	1620 °C	63-68 °C	46-57 °C
80°F	130-160 °F	70-0 °F	155-170 °F	110-145 °F
27°C	54-71 °C	2118 °C	68-77 °C	43-63 °C
90°F	150-165 °F	75-5 °F	165-175 °F	125-150 °F
32°C	66-74 °C	2415 °C	74-79 °C	51-66 °C
100°F	175-185 °F	85-10 °F	185-195 °F	145-165 °F
38°C	79-85 °C	29-12 °C	85-91 °C	63-74 °C
110°F	180-190 °F	90-12 °F	190-200 °F	145-170 °F
43°C	82-88 °C	3211 °C	88-93 °C	63-77 °C

UDP0065A SELF-CONTAINED AIR-COOLED

R290

NOTE: These characteristics will vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Entering	Water	Temperature	°F/°C	Harvest
Condenser °F/°C	50/10	70/21	90/32	Time
70°F	9.5-12.5	10.7-14.1	11.7-15.5	
21°C	J.J-12.J	10.7-14.1	11.7-15.5	
80°F	10.7-12.7	12.5-16.7	12.3-16.5	
27°C	10.7-12.7	12.5-10.7	12.5-10.5	1.25-3.25
90°F 32°C	12.0-16.0	14.0-18.5	15.5-21.0	1.25-3.25
100°F 38°C	15.2-20.2	16.5-22.2	18.5-24.5	

Times in minutes

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10	70/21	90/32		
50°F	58 lbs	52 lbs	48 lbs		
10°C	26 kgs	23 kgs	22 kgs		
70°F	57 lbs	50 lbs	46 lbs		
21°C	26 kgs	23 kgs	21 kgs		
80°F	56 lbs	45 lbs	41 lbs		
27°C	25 kgs	20 kgs	19 kgs		
90°F	53 lbs	47 lbs	37 lbs		
32°C	24 kgs	21 kgs	17 kgs		
100°F	47 lbs	40 lbs	34 lbs		
38°C	21 kgs	18 kgs	15 kgs		

Based on average ice slab weight of 0.4 - 0.6 lbs (0.2 - 0.3 kgs).

Operating Pressures UDP0065A

A*. T F. I	Freeze	e Cycle
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	150-220 psig	40-21 psig
10°C	10.3-15.2 bar	2.8-1.4 bar
70°F	150-220 psig	46-21 psig
21°C	10.3-15.2 bar	3.2-1.4 bar
80°F	150-230 psig	53-23 psig
27°C	10.3-15.9 bar	3.7-1.6 bar
90°F	175-245 psig	58-23 psig
32°C	12.1-16.9 bar	4.0-1.6 bar
100°F	220-270 psig	60-23 psig
38°C	15.2-18.6 bar	4.1-1.6 bar

Air Temp. Entering	Harves	t Cycle
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	100-115 psig	55-70 psig
10°C	6.9-7.9 bar	3.8-4.8 bar
70°F	100-120 psig	55-75 psig
21°C	6.9-8.3 bar	3.8-5.2 bar
80°F	115-130 psig	55-85 psig
27°C	7.9-9.0 bar	3.8-5.9 bar
90°F	130-150 psig	55-95 psig
32°C	9.0-10.3 bar	3.8-6.6 bar
100°F	150-170 psig	60-110 psig
38°C	10.3-11.7 bar	4.1-7.6 bar

UD0080A/UDE0080A SELF-CONTAINED AIR-COOLED R134A

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Water	Harvest		
Condenser °F/°C	50/10	70/21	90/32	Time
70°F 21°C	14.2-16.8	17.1-20.2	21.5-25.4	
80°F 27°C	16.5-19.5	19.1-26.1	23.9-28.1	10.25
90°F 32°C	18.8-22.2	21.5-25.4	27.3-32.1	1.0 - 2.5
110°F 43°C	22.2-26.1	25.9-30.5	31.7-37.3	

Times in minutes

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10	70/21	90/32		
70°F	110 lbs	93 lbs	75 lbs		
21°C	50 kgs	42 kgs	34 kgs		
80°F	96 lbs	84 lbs	68 lbs		
27°C	44 kgs	38 kgs	31 kgs		
90°F	85 lbs	75 lbs	60 lbs		
32°C	37 kgs	34 kgs	27 kgs		
110°F	73 lbs	63 lbs	52 lbs		
43°C	33 kgs	29 kgs	24 kgs		

Based on average ice slab weight of 1.1 - 1.4 lbs (0.5 - 0.6 kgs).

Operating Temperatures UD0080A/UE0080A

50°F/10°C WATER TEMPERATURE

Air Temp.	Freeze	Cycle	Harves	t Cycle
Entering	Discharge	Suction	Discharge	Suction
Condenser	Line	Line	Line	Line
°F/°C	Temp °F/°C	Temp °F/°C	Temp °F/°C	Temp °F/°C
50°F	150-165 °F	67-50 °F	155-190 °F	50-60 °F
10°C	66-74 °C	19-10 °C	68-88 °C	10-16 °C
70°F	155-185 °F	67-50 °F	160-190 °F	50-60 °F
21°C	68-85 °C	19-10 °C	71-88 °C	10-16 °C
80°F	170-190 °F	71-58 °F	175-190 °F	52-65 °F
27°C	78-88 °C	22-14 °C	79-88 °C	11-18 °C
90°F	180-205 °F	75-65 °F	185-210 °F	55-75 °F
32°C	82-96 °C	24-18 °C	85-99 °C	13-24 °C
100°F	190-215 °F	85-70 °F	195-220 °F	60-75 °F
38°C	88-102 °C	29-21 °C	91-104 °C	16-24 °C

70°F/21°C WATER TEMPERATURE

Air Temp.	Freeze	Cycle	Harves	t Cycle
Entering	Discharge	Suction	Discharge	Suction
Condenser	Line	Line	Line	Line
°F/°C	Temp °F/°C	Temp °F/°C	Temp °F/°C	Temp °F/°C
50°F	155-175 °F	68-58 °F	160-175 °F	50-60 °F
10°C	68-79 °C	20-14 °C	71-79 °C	10-16 °C
70°F	160-185 °F	70-50 °F	160-190 °F	50-65 °F
21°C	71-85 °C	21-10 °C	71-85 °C	10-18 °C
80°F	170-200 °F	75-58 °F	170-200 °F	55-70 °F
27°C	77-93 °C	24-14 °C	77-94 °C	13-21 °C
90°F	180-205 °F	85-65 °F	185-210 °F	55-75 °F
32°C	82-96 °C	29-18 °C	85-99 °C	13-24 °C
100°F	190-220 °F	88-70 °F	200-220 °F	60-75 °F
38°C	88-104 °C	31-21 °C	93-104 °C	16-24 °C

Operating Temperatures UD0080A/UDE0080A

90°F/32°C WATER TEMPERATURE

Air Temp.	Freeze	Cycle	Harves	t Cycle
Entering	Discharge	Suction	Discharge	Suction
Condenser	Line	Line	Line	Line
°F/°C	Temp °F/°C	Temp °F/°C	Temp °F/°C	Temp °F/°C
50°F	155-180 °F	75-50 °F	160-185 °F	52-65 °F
10°C	68-82 °C	24-10 °C	71-85 °C	11-18 °C
70°F	160-185 °F	75-53 °F	165-190 °F	52-65 °F
21°C	71-85 °C	24-12 °C	74-88 °C	11-18 °C
80°F	170-195 °F	80-58 °F	175-195 °F	57-75 °F
27°C	77-91 °C	27-14 °C	79-91 °C	14-24 °C
90°F	190-205 °F	85-64 °F	195-215 °F	55-75 °F
32°C	88-96 °C	29-18 °C	90-102 °C	13-24 °C
100°F	190-215 °F	91-70 °F	195-220 °F	60-80 °F
38°C	88-102 °C	33-21 °C	91-104 °C	16-27 °C

UDP0080A SELF-CONTAINED AIR-COOLED

R290

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.				
Entering	Water	Temperature	°F/°C	Harvest
Condenser °F/°C	50/10	70/21	90/32	Time
50°F	9.8-11.3	13.2-14.7	14.4-15.9	
10°C	9.6-11.5	15.2-14.7	14.4-15.9	
70°F	10.6-12.1	15.0-18.5	16.7-18.2	
21°C	10.0-12.1	13.0-18.3	10.7-18.2	
80°F	14.5-18.5	14.8-16.1	18.7-20.2	1.0-2.5
27°C	14.5-16.5	14.0-10.1	10.7-20.2	1.0-2.5
90°F	16.1-19.0	19.1-24.7	21.5-23.0	
32°C	10.1-19.0	15.1-24.7	21.3-23.0	
100°F 38°C	17.1-22.0	21.5-25.2	27.3-32.1	

Times in minutes

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C				
Entering Condenser °F/°C	50/10	70/21	90/32		
50°F	117 lbs	92 lbs	85 lbs		
10°C	53 kgs	42 kgs	39 kgs		
70°F	110 lbs	95 lbs	75 lbs		
21°C	50 kgs	43 kgs	34 kgs		
80°F	96 lbs	84 lbs	68 lbs		
27°C	44 kgs	38 kgs	31 kgs		
90°F	85 lbs	75 lbs	60 lbs		
32°C	39 kgs	34 kgs	27 kgs		
100°F	79 lbs	68 lbs	52 lbs		
38°C	36 kgs	31 kgs	24 kgs		

Based on average ice slab weight of 1.1 - 1.4 lbs (0.5 - 0.6 kgs).

Operating Pressures UDP0080A

FREEZE CYCLE

A1. T F.1. 1	Freeze Cycle		
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure	
50°F	140-205 psig	46-18 psig	
10°C	9.7-14.1 bar	3.2-1.2 bar	
70°F	145-205 psig	46-18 psig	
21°C	10.0-14.1 bar	3.2-1.2 bar	
80°F	160-210 psig	50-20 psig	
27°C	11.0-14.5 bar	3.4-1.4 bar	
90°F	165-225 psig	50-20 psig	
32°C	11.4-15.5 bar	3.4-1.4 bar	
100°F	220-255 psig	53-23 psig	
38°C	15.2-17.6 bar	3.7-1.6 bar	

Air Town Entering	Harvest Cycle		
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure	
50°F	85-120 psig	60-90 psig	
10°C	5.9-8.3 bar	4.1-6.2 bar	
70°F	85-120 psig	60-90 psig	
21°C	5.9-8.3 bar	4.1-6.2 bar	
80°F	95-120 psig	80-95 psig	
27°C	6.6-8.3 bar	5.5-6.6 bar	
90°F	100-125 psig	90-105 psig	
32°C	6.9-8.6 bar	6.2-7.2 bar	
100°F	110-140 psig	100-110 psig	
38°C	7.6-9.7 bar	6.9-7.6 bar	

U0140A/UF0140A SELF-CONTAINED AIR-COOLED R404A

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Water Temperature °F/°C		
Condenser °F/°C	50/10	70/21	90/32	Time
70°F	10.2-11.7	12.4-14.1	13.0-14.8	
21°C	10.2-11.7	12.4-14.1	15.0-14.6	
80°F	11.2-12.8	13.0-14.8	14.6-16.5	
27°C	11.2-12.0	13.0-14.0	14.0-10.5	
90°F	11.8-13.4	14.6-16.5	17.6-19.9	1.0-2.5
32°C	11.0 15.4	14.0 10.3	17.0 15.5	1.0 2.5
100°F	14.6-16.5	17.6-19.9	19.9-17.6	
38°C	14.0-10.5	17.0-19.9	19.9-17.0	
110°F 43°C	16.5-18.7	19.9-17.6	20.3-23.0	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	°F/°C
Entering Condenser °F/°C	50/10	70/21	90/32
70°F	130 lbs	110 lbs	105 lbs
21°C	54 kgs	43 kgs	41 kgs
80°F	120 lbs	105 lbs	95 lbs
27°C	49 kgs	41 kgs	35 kgs
90°F	115 lbs	95 lbs	85 lbs
32°C	46 kgs	35 kgs	29 kgs
100°F	95 lbs	85 lbs	80 lbs
38°C	35 kgs	29 kgs	27 kgs
110°F	85 lbs	80 lbs	70 lbs
43°C	29 kgs	27 kgs	21 kgs

Based on average ice slab weight of 1.1 - 1.4 lbs (0.5 - 0.6 kgs).

Operating Pressures U0140A/UF0140A

FREEZE CYCLE

Air Temp. Entering	Freeze	Freeze Cycle		
Condenser °F/°C	Discharge Pressure	Suction Pressure		
50°F	200-250 psig	55-18 psig		
10°C	13.8-17.2 bar	3.8-1.2 bar		
70°F	200-250 psig	60-20 psig		
21°C	13.8-17.2 bar	4.1-1.4 bar		
80°F	220-265 psig	65-22 psig		
27°C	15.2-18.3 bar	4.5-1.5 bar		
90°F	240-315 psig	70-24 psig		
32°C	16.5-21.7 bar	4.8-1.7 bar		
100°F	300-380 psig	80-30 psig		
38°C	20.7-26.2 bar	5.5-2.1 bar		
110°F	310-400 psig	90-32 psig		
43°C	21.4-27.6 bar	6.2-2.2 bar		

Suction pressure drops gradually throughout the freeze cycle

Air Temp. Entering	Harves	t Cycle
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	135-170 psig	75-110 psig
10°C	9.3-11.7 bar	5.2-7.6 bar
70°F	140-170 psig	75-120 psig
21°C	9.7-11.7 bar	5.2-8.3 bar
80°F	145-190 psig	75-120 psig
27°C	10-13.1 bar	5.2-8.3 bar
90°F	165-200 psig	75-120 psig
32°C	11.4-13.8 bar	5.2-8.3 bar
100°F	200-235 psig	75-120 psig
38°C	13.8-16.2 bar	5.2-8.3 bar
110°F	210-240 psig	75-120 psig
43°C	14.5-165 bar	5.2-8.3 bar

U0140W/UF0140W SELF-CONTAINED WATER-COOLED

R404A

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Freeze Time Water Temperature °F/°C			Harvest
Condenser °F/°C	50/10	70/21	90/32	Time
70°F 21°C	9.8-11.2	11.2-12.8	13.0-14.8	
80°F 27°C	10.2-11.7	11.8-13.4	13.8-15.6	
90°F 32°C	11.8-13.4	13.0-14.8	15.5-17.5	1.0-2.5
100°F 38°C	13.0-14.8	15.5-17.5	17.6-19.9	
110°F 43°C	14.6-16.5	17.6-19.9	20.3-23.0	

Times in minutes

24 Hour Ice Production

Air Temp. Entering	Water Temperature °F/°C		
Condenser °F/°C	50/10	70/21	90/32
70°F	135 lbs	120 lbs	105 lbs
21°C	61 kgs	54 kgs	48 kgs
80°F	130 lbs	115 lbs	100 lbs
27°C	59 kgs	52 kgs	45 kgs
90°F	115 lbs	105 lbs	90 lbs
32°C	52 kgs	48 kgs	41 kgs
100°F	105 lbs	90 lbs	80 lbs
38°C	48 kgs	41 kgs	36 kgs
110°F	95 lbs	80 lbs	70 lbs
43°C	43 kgs	36 kgs	32 kgs

Based on average ice slab weight of 1.1-1.4 lbs (0.5-0.6 kgs). Water Regulating Valve set to 230 PSIG discharge pressure Condenser Water Usage = 185 gallons per 100 lbs of ice at $90^{\circ}\text{F}/70^{\circ}\text{F}$.

Operating Pressures U0140W/UF0140W

FREEZE CYCLE

Air Temp. Entering	Freeze	Freeze Cycle		
Condenser °F/°C	Discharge Pressure	Suction Pressure		
50°F	225-235 psig	55-22 psig		
10°C	15.5-16.2 bar	3.8-1.5 bar		
70°F	225-235 psig	65-24 psig		
21°C	15.5-16.2 bar	4.5-1.7 bar		
80°F	225-240 psig	65-24 psig		
27°C	15.5-16.5 bar	4.5-1.7 bar		
90°F	225-245 psig	65-24 psig		
32°C	15.5-16.9 bar	4.5-1.7 bar		
100°F	225-245 psig	70-25 psig		
38°C	15.5-16.9 bar	4.8-1.7 bar		
110°F	225-245 psig	70-26 psig		
43°C	15.5-16.9 bar	4.8-1.8 bar		

Suction pressure drops gradually throughout the freeze cycle

Air Temp. Entering	Harves	t Cycle
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	135-155 psig	90-115 psig
10°C	9.3-10.7 bar	6.2-7.9 bar
70°F	145-160 psig	100-130 psig
21°C	10.0-11.0 bar	6.69-9.0 bar
80°F	145-165 psig	100-130 psig
27°C	10.0-11.4 bar	6.69-9.0 bar
90°F	145-165 psig	110-130 psig
32°C	10.0-11.4 bar	7.6-9.0 bar
100°F	150-175 psig	115-140 psig
38°C	10.3-12.1 bar	7.9-9.7 bar
110°F	150-180 psig	115-145 psig
43°C	10.3-12.4 bar	7.9-10.0 bar

UP0140A SELF-CONTAINED AIR-COOLED

R290

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Water	Freeze Time Water Temperature °F/°C		
Condenser °F/°C	50/10	70/21	90/32	Time
70°F 21°C	10.2-11.7	12.3-13.7	13.0-14.8	
80°F 27°C	11.2-12.9	13.0-14.9	14.5-16.5	1025
90°F 32°C	11.8-13.7	14.5-16.5	17.5-20.0	1.0-2.5
100°F 38°C	14.6-16.5	17.6-20.0	17.5-21.5	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	Water Temperature °F/°C		
Entering Condenser °F/°C	50/10	70/21	90/32	
70°F	130 lbs	110 lbs	105 lbs	
21°C	59 kgs	50 kgs	48 kgs	
80°F	120 lbs	105 lbs	95 lbs	
27°C	54 kgs	48 kgs	43 kgs	
90°F	115 lbs	95 lbs	85 lbs	
32°C	52 kgs	43 kgs	39 kgs	
100°F	95 lbs	85 lbs	80 lbs	
38°C	43 kgs	39 kgs	36 kgs	

Based on average ice slab weight of 1.1 - 1.4 lbs (0.49 - 0.63 kgs).

Operating Pressures UP0140A

FREEZE CYCLE

Air Temp. Entering	Freeze Cycle		
Condenser °F/°C	Discharge Pressure	Suction Pressure	
50°F	140-210 psig	45-17 psig	
10°C	9.7-14.5 bar	3.1-1.2 bar	
70°F	140-215 psig	54-17 psig	
21°C	9.7-14.8 bar	3.7-1.2 bar	
80°F	150-220 psig	55-17 psig	
27°C	10.3-15.2 bar	3.8-1.2 bar	
90°F	160-225 psig	58-17 psig	
32°C	11.0-15.5 bar	4.0-1.2 bar	
100°F	205-230 psig	60-20 psig	
38°C	14.1-15.9 bar	4.1-1.4 bar	

Suction pressure drops gradually throughout the freeze cycle

Air Temp. Entering	Harvest Cycle		
Condenser °F/°C	Discharge Pressure	Suction Pressure	
50°F	95-120 psig	65-95 psig	
10°C	6.6-8.3 bar	4.5-6.6 bar	
70°F	100-120 psig	70-95 psig	
21°C	6.9-8.3 bar	4.8-6.6 bar	
80°F	105-120 psig	75-95 psig	
27°C	7.2-8.3 bar	5.2-6.6 bar	
90°F	120-140 psig	90-114 psig	
32°C	8.3-9.7 bar	6.2-7.9 bar	
100°F	140-160 psig	110-135 psig	
38°C	9.7-11.0 bar	7.6-9.3 bar	

U0190A/UF0190A SELF-CONTAINED AIR-COOLED R404A

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Water Temperature °F/°C		
Condenser °F/°C	50/10	70/21	90/32	Time
70°F	16.1-18.3	19.8-22.5	21.2-24.0	
21°C	10.1-10.5	19.6-22.5	21.2-24.0	
80°F	19.8-22.5	21.9-24.9	24.5-27.8	
27°C	15.6-22.5	21.5-24.5	24.5-27.8	
90°F	21.9-24.9	23.6-26.8	29.0-32.9	1.0-2.5
32°C	21.5 24.5	25.0 20.0	25.0 52.5	1.0 2.5
100°F	25.5-29.0	29.1-32.9	32.0-36.2	
38°C	23.3-29.0	29.1-32.9	32.0-30.2	
110°F 43°C	29.1-32.9	32.0-36.2	33.6-38.1	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	°F/°C
Entering Condenser °F/°C	50/10	70/21	90/32
70°F	200 lbs	165 lbs	155 lbs
21°C	91 kgs	75 kgs	70 kgs
80°F	165 lbs	150 lbs	135 lbs
27°C	75 kgs	68 kgs	61 kgs
90°F	150 lbs	140 lbs	115 lbs
32°C	68 kgs	64 kgs	52 kgs
100°F	130 lbs	115 lbs	105 lbs
38°C	59 kgs	52 kgs	48 kgs
110°F	115 lbs	105 lbs	100 lbs
43°C	52 kgs	48 kgs	45 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 - 1.3 kgs).

Operating Pressures U0190A/UF0190A

FREEZE CYCLE

Air Temp. Entering	Freeze	Cycle
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	200-250 psig	60-38 psig
10°C	13.8-17.2 bar	4.1-2.6 bar
70°F	200-260 psig	80-38 psig
21°C	13.8-17.9 bar	5.5-2.6 bar
80°F	240-290 psig	80-39 psig
27°C	16.5-20.0 bar	5.5-2.7 bar
90°F	260-330 psig	80-40 psig
32°C	17.9-22.8 bar	5.5-2.8 bar
100°F	310-380 psig	85-41 psig
38°C	21.4-26.2 bar	5.9-2.8 bar
110°F	315-390 psig	90-41 psig
43°C	21.7-26.9 bar	6.2-2.8 bar

Suction pressure drops gradually throughout the freeze cycle

Air Town Entoring	Harves	Harvest Cycle		
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure		
50°F	150-170 psig	90-110 psig		
10°C	10.3-11.7 bar	6.2-7.6 bar		
70°F	150-170 psig	95-130 psig		
21°C	10.3-11.7 bar	6.6-9.0 bar		
80°F	160-190 psig	100-130 psig		
27°C	11.0-13.1 bar	6.9-9.0 bar		
90°F	160-190 psig	100-130 psig		
32°C	11.0-13.1 bar	6.9-9.0 bar		
100°F	180-210 psig	105-135 psig		
38°C	12.4-14.5 bar	7.2-9.3 bar		
110°F	180-215 psig	110-135 psig		
43°C	12.4-14.8 bar	7.6-9.3 bar		

UP0190A SELF-CONTAINED AIR-COOLED

R290

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Water	Freeze Time Water Temperature °F/°C		
Condenser °F/°C	50/10	70/21	90/32	Time
70°F 21°C	13.9-16.0	16.9-18.9	18.0-20.3	
80°F 27°C	15.0-17.2	17.0-20.1	19.4-22.4	1025
90°F 32°C	16.2-18.5	19.5-22.5	21.6-25.0	1.0-2.5
100°F 38°C	19.0-21.5	20.4-24.0	23.4-26.5	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	°F/°C
Entering Condenser °F/°C	50/10	70/21	90/32
70°F	200 lbs	165 lbs	155 lbs
21°C	91 kgs	75 kgs	70 kgs
80°F	165 lbs	150 lbs	135 lbs
27°C	75 kgs	68 kgs	61 kgs
90°F	150 lbs	140 lbs	115 lbs
32°C	68 kgs	64 kgs	52 kgs
100°F	130 lbs	115 lbs	105 lbs
38°C	59 kgs	52 kgs	48 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 - 1.3 kgs).

Operating Pressures UP0190A

FREEZE CYCLE

Air Temp. Entering	Freeze	Freeze Cycle		
Condenser °F/°C	Discharge Pressure	Suction Pressure		
50°F	130-210 psig	50-21 psig		
10°C	9.0-14.5 bar	3.4-1.4 bar		
70°F	150-210 psig	53-23 psig		
21°C	10.3-14.5 bar	3.7-1.6 bar		
80°F	160-230 psig	55-23 psig		
27°C	11.0-15.9 bar	3.8-1.6 bar		
90°F	195-260 psig	60-24 psig		
32°C	13.4-17.9 bar	4.1-1.7 bar		
100°F	200-280 psig	65-25 psig		
38°C	13.8-19.3 bar	4.5-1.7 bar		

Suction pressure drops gradually throughout the freeze cycle

Air Town Futoring	Harves	t Cycle
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	80-110 psig	68-72 psig
10°C	5.5-7.6 bar	4.7-5.0 bar
70°F	85-115 psig	70-80 psig
21°C	5.9-7.9 bar	4.8-5.5 bar
80°F	95-120 psig	70-85 psig
27°C	6.6-8.3 bar	4.8-5.9 bar
90°F	115-170 psig	80-95 psig
32°C	7.9-11.7 bar	5.5-6.6 bar
100°F	120-175 psig	70-105 psig
38°C	8.3-12.1 bar	4.8-7.2 bar

U0240A/UF0240A SELF-CONTAINED AIR-COOLED R404A

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Temperature	°F/°C	Harvest
Condenser °F/°C	50/10	70/21	90/32	Time
70°F	14.1-16.1	17.0-19.3	18.6-21.1	
21°C	14.1-16.1	17.0-19.5	10.0-21.1	
80°F	15.2-17.4	18.0-20.5	20.5-23.3	
27°C	15.2-17.4	18.0-20.5	20.5-25.5	
90°F	16.5-18.8	20.5-23.3	22.7-25.8	1.0-2.5
32°C	10.5-18.8	20.5-23.3	22.7-23.8	1.0-2.5
100°F	19.2-21.8	21.9-24.9	23.6-26.8	
38°C	15.2-21.8	21.5-24.9	25.0-20.8	
110°F 43°C	21.9-24.9	23.6-26.8	24.5-27.8	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	°F/°C
Entering Condenser °F/°C	50/10	70/21	90/32
70°F	225 lbs	190 lbs	175 lbs
21°C	102 kgs	86 kgs	79 kgs
80°F	210 lbs	180 lbs	160 lbs
27°C	95 kgs	82 kgs	73 kgs
90°F	195 lbs	160 lbs	145 lbs
32°C	88 kgs	73 kgs	66 kgs
100°F	170 lbs	150 lbs	140 lbs
38°C	77 kgs	68 kgs	64 kgs
110°F	150 lbs	140 lbs	135 lbs
43°C	68 kgs	64 kgs	61 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 - 1.3 kgs).

Operating Pressures U0240A/UF0240A

FREEZE CYCLE

Air Temp. Entering	Freeze	Cycle
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	220-275 psig	65-32 psig
10°C	15.2-19.0 bar	4.5-2.2 bar
70°F	220-310 psig	75-34 psig
21°C	15.2-21.4 bar	5.2-2.3 bar
80°F	270-330 psig	80-36 psig
27°C	18.6-22.8 bar	5.5-2.5 bar
90°F	290-350 psig	80-38 psig
32°C	20.0-24.1 bar	5.5-2.6 bar
100°F	320-410 psig	85-39 psig
38°C	22.1-28.3 bar	5.9-2.7 bar
110°F	355-430 psig	90-40 psig
43°C	24.5-29.7 bar	6.2-2.8 bar

Suction pressure drops gradually throughout the freeze cycle

Air Town Entering	Harves	t Cycle
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	145-200 psig	85-110 psig
10°C	10.0-13.8 bar	5.9-7.6 bar
70°F	155-210 psig	90-120 psig
21°C	10.7-14.5 bar	6.2-8.3 bar
80°F	175-225 psig	90-140 psig
27°C	12.1-15.5 bar	6.2-9.7 bar
90°F	185-245 psig	90-150 psig
32°C	12.8-16.9 bar	6.2-10.3 bar
100°F	200-260 psig	90-155 psig
38°C	13.8-17.9 bar	6.2-10.7 bar
110°F	220-280 psig	90-160 psig
43°C	15.2-19.3 bar	6.2-11.0 bar

UP0240A SELF-CONTAINED AIR-COOLED

R290

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Temperature	°F/°C	Harvest
Condenser	50/10	70/21	90/32	Time
°F/°C	30/10	70/21	30/32	
70°F	13.9-16.0	16.9-18.9	18.0-20.3	
21°C	13.9-16.0	16.9-18.9	18.0-20.3	
80°F	15.0-17.2	17.0-20.1	19.4-22.4	
27°C	15.0-17.2	17.0-20.1	19.4-22.4	1.0-2.5
90°F	16.2-18.5	19.5-22.5	21.6-25.0	1.0-2.5
32°C	10.2-16.5	19.5-22.5	21.0-25.0	
100°F	19.0-21.5	20.4-24.0	23.4-26.5	
38°C	19.0-21.5	20.4-24.0	23.4-26.5	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	°F/°C
Entering Condenser °F/°C	50/10	70/21	90/32
70°F	225 lbs	190 lbs	175 lbs
21°C	102 kgs	86 kgs	79 kgs
80°F	210 lbs	180 lbs	160 lbs
27°C	95 kgs	82 kgs	73 kgs
90°F	195 lbs	160 lbs	145 lbs
32°C	88 kgs	73 kgs	66 kgs
100°F	170 lbs	150 lbs	140 lbs
38°C	77 kgs	68 kgs	64 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 - 1.3 kgs).

Operating Pressures UP0240A

FREEZE CYCLE

Air Tanan Fatarina	Freeze Cycle		
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure	
50°F	145-205 psig	40-14 psig	
10°C	10.0-14.1 bar	2.8-1.0 bar	
70°F	150-210 psig	42-15psig	
21°C	10.3-14.5 bar	2.9-1.0 bar	
80°F	160-230 psig	46-18 psig	
27°C	11.0-15.9 bar	3.2-1.2 bar	
90°F	180-240 psig	51-20 psig	
32°C	12.4-16.5 bar	3.5-1.4 bar	
100°F	230-280 psig	54-24 psig	
38°C	15.9-19.3 bar	3.7-1.7 bar	

Suction pressure drops gradually throughout the freeze cycle

	Harves	t Cycle
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	90-105 psig	55-65 psig
10°C	6.2-7.2 bar	3.8-4.5 bar
70°F	90-105 psig	60-70 psig
21°C	6.2-7.2 bar	4.1-4.8 bar
80°F	95-110 psig	65-85 psig
27°C	6.6-7.6 bar	4.5-5.9 bar
90°F	105-125 psig	65-95 psig
32°C	7.2-8.6 bar	4.5-6.6 bar
100°F	115-150 psig	70-105 psig
38°C	7.9-10.3 bar	4.8-7.2 bar

U0240W/UF0240W SELF-CONTAINED WATER-COOLED R404A

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Temperature	°F/°C	Harvest
Condenser °F/°C	50/10	70/21	90/32	Time
70°F	16.1-18.3	17.0-19.3	18.0-20.5	
21°C	10.1-16.5	17.0-19.5	18.0-20.5	
80°F	16.5-18.8	17.5-19.9	18.6-21.1	
27°C	10.5-16.6	17.5-19.9	10.0-21.1	
90°F	18.0-20.5	19.2-21.8	20.5-23.3	1.0-2.5
32°C	18.0-20.3	19.2-21.8	20.5-23.3	1.0-2.5
100°F	18.6-21.1	19.8-22.5	21.2-24.0	
38°C	10.0-21.1	19.6-22.5	21.2-24.0	
110°F 43°C	19.2-21.8	20.5-23.3	21.9-24.9	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	°F/°C
Entering Condenser °F/°C	50/10	70/21	90/32
70°F	200 lbs	190 lbs	180 lbs
21°C	91 kgs	86 kgs	82 kgs
80°F	195 lbs	185 lbs	175 lbs
27°C	88 kgs	84 kgs	79 kgs
90°F	180 lbs	170 lbs	160 lbs
32°C	82 kgs	77 kgs	73 kgs
100°F	175 lbs	165 lbs	155 lbs
38°C	79 kgs	75 kgs	70 kgs
110°F	170 lbs	160 lbs	150 lbs
43°C	77 kgs	73 kgs	68 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 - 1.3 kgs). Water regulating valve set to maintain 235 PSIG discharge pressure. Condenser water usage = 149 gallons per 100 lbs of ice at $90^{\circ}F/70^{\circ}F$.

Operating Pressures U0240W/UF0240W

FREEZE CYCLE

Air Town Fotoning	Freeze Cycle		
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure	
50°F	230-240 psig	65-30 psig	
10°C	15.9-16.5 bar	4.5-2.1 bar	
70°F	230-240 psig	70-32 psig	
21°C	15.9-16.5 bar	4.8-2.2 bar	
80°F	230-240 psig	70-34 psig	
27°C	15.9-16.5 bar	4.8-2.3 bar	
90°F	230-240 psig	70-36 psig	
32°C	15.9-16.5 bar	4.8-2.5 bar	
100°F	230-245 psig	75-35 psig	
38°C	15.9-16.9 bar	5.2-2.4 bar	
110°F	230-250 psig	80-38 psig	
43°C	15.9-17.2 bar	5.5-2.6 bar	

Suction pressure drops gradually throughout the freeze cycle

	Harves	t Cycle
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	130-150 psig	80-110 psig
10°C	9.0-10.3 bar	5.5-7.6 bar
70°F	135-160 psig	90-120 psig
21°C	9.3-11.0 bar	6.2-8.3 bar
80°F	135-160 psig	90-120 psig
27°C	9.3-11.0 bar	6.2-8.3 bar
90°F	135-165 psig	90-120 psig
32°C	9.3-11.4 bar	6.2-8.3 bar
100°F	135-170 psig	90-120 psig
38°C	9.3-11.7 bar	6.2-8.3 bar
110°F	140-175 psig	95-125 psig
43°C	9.7-12.1 bar	6.6-8.6 bar

UP0240W SELF-CONTAINED WATER-COOLED R290

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Temperature	°F/°C	Harvest
Condenser	50/10	70/21	90/32	Time
°F/°C				
70°F	15.9-17.9	16.9-18.9	18.0-20.3	
21°C	15.9-17.9	10.9-10.9	16.0-20.5	
80°F	16.3-18.4	17.3-19.5	18.4-20.5	
27°C	10.5-16.4	17.3-19.5	18.4-20.5	1.0-2.5
90°F	17.0-19.9	19.0-20.4	19.1-21.8	1.0-2.5
32°C	17.0-19.9	19.0-20.4	19.1-21.8	
100°F 38°C	18.0-21.0	19.5-21.8	20.8-24.0	

Times in minutes

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C		
Entering	50/10	70/21	90/32
Condenser °F/°C	lbs/kgs	lbs/kgs	lbs/kgs
70°F	210 lbs	190 lbs	180 lbs
21°C	95.3 kgs	86.2 kgs	81.6 kgs
80°F	200 lbs	185 lbs	175 lbs
27°C	90.7 kgs	83.9 kgs	79.4 kgs
90°F	190 lbs	170 lbs	160 lbs
32°C	86.2 kgs	77.1 kgs	72.6 kgs
100°F	180 lbs	165 lbs	155 lbs
38°C	81.6 kgs	74.8 kgs	70.3 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 - 1.3 kgs). Water regulating valve set to maintain 235 PSIG discharge pressure. Condenser water usage = 166 gallons per 100 lbs of ice at $90^{\circ}F/70^{\circ}F$.

Operating Pressures UP0240W

FREEZE CYCLE

Air Temp. Entering	Freeze Cycle		
	Discharge Pressure	Suction Pressure	
Condenser °F/°C	PSIG/BAR	PSIG/BAR	
50°F	160-180 psig	48-17 psig	
10°C	11.0-12.4 bar	3.3-1.2 bar	
70°F	160-180 psig	52-20 psig	
21°C	11.0-12.4 bar	3.6-1.4 bar	
80°F	160-180 psig	52-20 psig	
27°C	11.0-12.4 bar	3.6-1.4 bar	
90°F	160-180 psig	53-23 psig	
32°C	11.0-12.4 bar	3.7-1.6 bar	
100°F	160-180 psig	54-24 psig	
38°C	11.0-12.4 bar	3.7-1.7 bar	

Suction pressure drops gradually throughout the freeze cycle

Air Town Fatoring	Harves	t Cycle
Air Temp. Entering Condenser °F/°C	Discharge Pressure PSIG/BAR	Suction Pressure PSIG/BAR
50°F	90-105 psig	60-70 psig
10°C	6.2-7.2 bar	4.1-4.8 bar
70°F	90-110 psig	60-70 psig
21°C	6.2-7.6 bar	4.1-4.8 bar
80°F	95-110 psig	65-85 psig
27°C	6.6-7.6 bar	4.5-5.9 bar
90°F	105-125 psig	65-95 psig
32°C	7.2-8.6 bar	4.5-6.6 bar
100°F	105-145 psig	65-100 psig
38°C	7.2-10.0 bar	4.5-6.9 bar

U0310A/UF0310A SELF-CONTAINED AIR-COOLED R404A

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Temperature	°F/°C	Harvest
Condenser °F/°C	50/10	70/21	90/32	Time
70°F 21°C	10.0-11.5	11.8-13.4	14.1-16.1	
80°F				
27°C	10.4-11.9	12.3-14.0	13.5-15.4	
90°F 32°C	11.0-12.6	13.5-15.4	15.2-17.4	1.0-2.5
100°F 38°C	12.3-14.0	15.2-17.4	17.5-19.9	
110°F 43°C	15.6-17.8	19.2-21.8	21.2-24.0	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	°F/°C
Entering Condenser °F/°C	50/10	70/21	90/32
70°F	305 lbs	265 lbs	225 lbs
21°C	138 kgs	120 kgs	102 kgs
80°F	295 lbs	255 lbs	235 lbs
27°C	134 kgs	116 kgs	107 kgs
90°F	280 lbs	235 lbs	210 lbs
32°C	127 kgs	107 kgs	95 kgs
100°F	255 lbs	210 lbs	185 lbs
38°C	116 kgs	95 kgs	84 kgs
110°F	205 lbs	170 lbs	155 lbs
43°C	93 kgs	77 kgs	70 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 - 1.3 kgs).

Operating Pressures U0310A/UF0310A

FREEZE CYCLE

Air Temp. Entering	Freeze	Cycle
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	200-250 psig	45-18 psig
10°C	13.8-17.2 bar	3.1-1.2 bar
70°F	200-250 psig	50-18 psig
21°C	13.8-17.2 bar	3.4-1.2 bar
80°F	200-270 psig	55-20 psig
27°C	13.8-18.6 bar	3.8-1.4 bar
90°F	240-300 psig	60-22 psig
32°C	16.5-20.7 bar	4.1-1.5 bar
100°F	275-350 psig	65-23 psig
38°C	19.0-24.1 bar	4.5-1.6 bar
110°F	300-375 psig	70-25 psig
43°C	20.7-25.9 bar	4.8-1.7 bar

Suction pressure drops gradually throughout the freeze cycle

A*- T F-1	Harves	t Cycle
Air Temp. Entering Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	130-150 psig	75-105 psig
10°C	9.0-10.3 bar	5.2-7.2 bar
70°F	135-150 psig	75-105 psig
21°C	9.3-10.3 bar	5.2-7.2 bar
80°F	140-175 psig	75-110 psig
27°C	9.7-12.1 bar	5.2-7.6 bar
90°F	165-185 psig	105-125 psig
32°C	11.4-12.8 bar	7.2-8.6 bar
100°F	175-220 psig	130-150 psig
38°C	12.1-15.2 bar	9.0-10.3 bar
110°F	210-240 psig	135-155 psig
43°C	14.5-16.5 bar	9.3-10.7 bar

UP0310A SELF-CONTAINED AIR-COOLED

R290

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp. Entering	Water	Freeze Time Water Temperature °F/°C		
Condenser °F/°C	50/10	70/21	90/32	Time
70°F 21°C	10.8-11.5	11.6-13.6	14.0-16.0	
80°F 27°C	11.0-12.1	12.5-14.0	13.5-15.5	1025
90°F 32°C	11.3-12.8	13.5-15.7	15.2-17.5	1.0-2.5
100°F 38°C	12.1-14.2	15.2-17.5	17.5-20.0	

Times in minutes

24 Hour Ice Production

Air Temp.	Wat	Water Temperature °F/°C		
Entering Condenser °F/°C	50/10	70/21	90/32	
70°F	305 lbs	265 lbs	235 lbs	
21°C	138 kgs	120 kgs	107 kgs	
80°F	295 lbs	255 lbs	225 lbs	
27°C	134 kgs	116 kgs	102 kgs	
90°F	280 lbs	235 lbs	210 lbs	
32°C	127 kgs	107 kgs	95 kgs	
100°F	255 lbs	210 lbs	185 lbs	
38°C	116 kgs	95 kgs	84 kgs	

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 – 1.3 kgs).

Operating Pressures UP0310A

FREEZE CYCLE

Air Temp. Entering	Freeze Cycle		
Condenser °F/°C	Discharge Pressure	Suction Pressure	
50°F	150-220 psig	40-9 psig	
10°C	10.3-15.2 bar	2.8-0.6 bar	
70°F	150-220 psig	46-9 psig	
21°C	10.3-15.2 bar	3.2-0.6 bar	
80°F	150-230 psig	53-10 psig	
27°C	10.3-15.9 bar	3.7-0.7 bar	
90°F	175-245 psig	58-11 psig	
32°C	12.1-16.9 bar	4.0-0.8 bar	
100°F	220-270 psig	60-11 psig	
38°C	15.2-18.6 bar	4.1-0.8 bar	

Suction pressure drops gradually throughout the freeze cycle

Air Temp. Entering	Harves	t Cycle
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	100-115 psig	55-70 psig
10°C	6.9-7.9 bar	3.8-4.8 bar
70°F	100-120 psig	55-75 psig
21°C	6.9-8.3 bar	3.8-5.2 bar
80°F	115-130 psig	55-85 psig
27°C	7.9-9.0 bar	3.8-5.9 bar
90°F	130-150 psig	55-95 psig
32°C	9.0-10.3 bar	3.8-6.6 bar
100°F	150-170 psig	60-110 psig
38°C	10.3-11.7 bar	4.1-7.6 bar

U0310W/UF0310W - SELF-CONTAINED WATER-COOLED R404A

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.	Freeze Time			
Entering	Water	Temperature	°F/°C	Harvest
Condenser °F/°C	50/10	70/21	90/32	Time
70°F	11.5-13.2	11.3-12.9	12.0-13.7	
21°C	11.5-15.2	11.5-12.9	12.0-15.7	
80°F	10.0-11.5	11.5-13.2	12.3-14.0	
27°C	10.0-11.5	11.5-15.2	12.5-14.0	
90°F	10.2-11.7	12.6-14.3	13.1-15.0	1.0-2.5
32°C	10.2-11.7	12.0-14.3	13.1-13.0	1.0-2.5
100°F	10.4-11.9	12.6-14.3	13.5-15.4	
38°C	10.4-11.9	12.0-14.5	15.5-15.4	
110°F 43°C	10.6-12.2	12.8-14.7	13.8-15.7	

Times in minutes

24 Hour Ice Production

Air Temp.	Wate	er Temperature	°F/°C
Entering Condenser °F/°C	50/10	70/21	90/32
70°F	270 lbs	275 lbs	260 lbs
21°C	122 kgs	125 kgs	118 kgs
80°F	305 lbs	270 lbs	255 lbs
27°C	138 kgs	122 kgs	116 kgs
90°F	300 lbs	250 lbs	240 lbs
32°C	136 kgs	113 kgs	109 kgs
100°F	295 lbs	250 lbs	235 lbs
38°C	134 kgs	113 kgs	107 kgs
110°F	290 lbs	245 lbs	230 lbs
43°C	132 kgs	111 kgs	104 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0 - 1.3 kgs). Water regulating valve set to maintain 235 PSIG discharge pressure. Condenser water usage = 149 gallons per 100 lbs of ice at $90^{\circ}F/70^{\circ}F$.

Operating Pressures U0310W/UF0310W

FREEZE CYCLE

Air Temp. Entering	Freeze	Cycle
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	230-240 psig	50-24 psig
10°C	15.9-16.5 bar	3.4-1.7 bar
70°F	230-240 psig	50-25 psig
21°C	15.9-16.5 bar	3.4-1.7 bar
80°F	235-240 psig	50-26 psig
27°C	16.2-16.5 bar	3.4-1.8 bar
90°F	235-240 psig	55-27 psig
32°C	16.2-16.5 bar	3.8-1.9 bar
100°F	235-250 psig	60-27 psig
38°C	16.2-17.2 bar	4.1-1.9 bar
110°F	235-255 psig	60-28 psig
43°C	16.2-17.6 bar	4.1-1.9 bar

Suction pressure drops gradually throughout the freeze cycle

Air Temp. Entering	Harvest Cycle	
Condenser °F/°C	Discharge Pressure	Suction Pressure
50°F	150-175 psig	75-90 psig
10°C	10.3-12.1 bar	5.2-6.2 bar
70°F	150-175 psig	75-90 psig
21°C	10.3-12.1 bar	5.2-6.2 bar
80°F	155-175 psig	75-95 psig
27°C	10.7-12.1 bar	5.2-6.6 bar
90°F	165-180 psig	80-100 psig
32°C	11.4-12.4 bar	5.5-6.9 bar
100°F	165-180 psig	80-100 psig
38°C	11.4-12.4 bar	5.5-6.9 bar
110°F	165-180 psig	80-100 psig
43°C	11.4-12.4 bar	5.5-6.9 bar

UP0310W - SELF-CONTAINED WATER-COOLED R290

NOTE: These characteristics may vary depending on operating conditions.

Cycle Times

Freeze Time + Harvest Time = Total Cycle Time

Air Temp.		Freeze Time		
Entering	Water Temperature °F/°C		Harvest	
Condenser	50/10	70/21	90/32	Time
°F/°C	30/10	70/21	90/32	
70°F	9.8-13.1	11.2-12.8	11.9-13.5	
21°C	9.8-13.1	11.2-12.8	11.9-13.5	
80°F	10.0-11.2	11.4-13.0	12.3-13.8	
27°C	10.0-11.2	11.4-13.0	12.3-13.8	1.0-2.5
90°F	10.0-11.4	12.1-14.1	13.0-15.0	1.0-2.5
32°C	10.0-11.4	12.1-14.1	15.0-15.0	
100°F	10.3-11.7	12.2-14.2	13.2-15.1	
38°C	10.5-11./	12.2-14.2	13.2-15.1	

Times in minutes

24 Hour Ice Production

Air Temp.	Water Temperature °F/°C		
Entering	50/10	70/21	90/32
Condenser °F/°C	lbs/kgs	lbs/kgs	lbs/kgs
70°F	305 lbs	265 lbs	235 lbs
21°C	138 kgs	120 kgs	107 kgs
80°F	300 lbs	255 lbs	225 lbs
27°C	136 kgs	116 kgs	102 kgs
90°F	295 lbs	235 lbs	210 lbs
32°C	134 kgs	107 kgs	95 kgs
100°F	290 lbs	250 lbs	235 lbs
38°C	132 kgs	113 kgs	107 kgs

Based on average ice slab weight of 2.3 - 2.9 lbs (1.0-1.3 kgs). Water regulating valve set to maintain 235 PSIG discharge pressure - Condenser water usage = 160 gallons per 100 lbs of ice at $90^{\circ}F/70^{\circ}F$.

Operating Pressures UP0310W

FREEZE CYCLE

Air Town Entering	Freeze Cycle	
Air Temp. Entering Condenser °F/°C	Discharge Pressure PSIG/BAR	Suction Pressure PSIG/BAR
50°F	160-180 psig	36-14 psig
10°C	11.0-12.4 bar	2.5-1.0 bar
70°F	160-180 psig	37-15 psig
21°C	11.0-12.4 bar	2.6-1.0 bar
80°F	160-180 psig	37-15 psig
27°C	11.0-12.4 bar	2.6-1.0 bar
90°F	160-180 psig	42-12 psig
32°C	11.0-12.4 bar	2.9-0.8 bar
100°F	160-180 psig	42-14 psig
38°C	11.0-12.4 bar	2.9-1.0 bar

Suction pressure drops gradually throughout the freeze cycle

Air Town Entering	Harvest Cycle		
Air Temp. Entering Condenser °F/°C	Discharge Pressure PSIG/BAR	Suction Pressure PSIG/BAR	
50°F	100-140 psig	55-70 psig	
10°C	6.9-9.7 bar	3.8-4.8 bar	
70°F	100-140 psig	55-70 psig	
21°C	6.9-9.7 bar	3.8-4.8 bar	
80°F	100-140 psig	55-70 psig	
27°C	6.9-9.7 bar	3.8-4.8 bar	
90°F	110-160 psig	55-75 psig	
32°C	7.6-11.0 bar	3.8-5.2 bar	
100°F	110-160 psig	55-75 psig	
38°C	7.6-11.0 bar	3.8-5.2 bar	

THIS PAGE INTENTIONALLY LEFT BLANK

THIS PAGE INTENTIONALLY LEFT BLANK

Diagrams

Wiring Diagrams

The following pages contain electrical wiring diagrams. Be sure you are referring to the correct diagram for the ice machine you are servicing.

A Warning

Always disconnect power before working on electrical circuitry.


Wiring Diagram Legend

The following symbols are used on all of the wiring diagrams:

- Internal Compressor Overload (Some models have external compressor overloads)
- ** Fan Motor Run Capacitor
 (Some models do not incorporate fan motor run capacitor)
- () Wire Number Designation (The number is marked at each end of the wire)
- —>>— Multi-pin Connection (Electrical Box Side) —>>— (Compressor Compartment Side)

UP0140/UP0190/UP0240 & UP0310 (50 HZ) 1 Ph - Self Contained Air & Water-cooled

WIRING DIAGRAM



000018273 REV. 01


UP0140/UP0190/UP0240, UP0310 (50 HZ) 1 Ph - Self Contained Air & Water-cooled

Number	Component
3	Bin Switch
5	Compressor
7	Compressor Overload
12	Compressor Start Capacitor
13	Compressor Start Relay
14	Condenser Fan Motor
17	Contactor Coil
18	Contactor Contacts
19	Control Board
25	Fan Cycle Control
26	Float Switch - Harvest
27	Float Switch-Water Level
28	Fuse
31	High Pressure Cutout
40	On/Off/Clean Switch
41	See Control Board Schematic For Detail
42	Solenoid Valve
49	Thermistor - J4
55	Water Dump Valve
56	Water Inlet Valve
58	Water Pump
	Wire Colors
BLK	Black
BLU	Blue
BRN	Brown
PNK	Pink
PRPL	Purple
RED	Red
WHT	White
YEL	Yellow
Refer to contr	ol board schematic for control board detail

UP0310 (60 HZ)

1 Ph - Self Contained Air & Water-cooled

WIRING DIAGRAM



000018274 REV 02


UP0310 (60 HZ) 1 Ph - Self Contained Air & Water-cooled

Number	Component	
3	Bin Switch	
5	Compressor	
13	Compressor Start Relay	
14	Condenser Fan Motor	
17	Contactor Coil	
18	Contactor Contacts	
19	Control Board	
25	Fan Cycle Control	
26	Float Switch - Harvest	
27	Float Switch - Water Level	
28	Fuse	
31	High Pressure Cutout	
40	On/Off/Clean Switch	
42	Solenoid Valve	
49	Thermistor - J4	
55	Water Dump Valve	
56	Water Inlet Valve	
58	Water Pump	
Wire Colors		
BLK	Black	
BLU	Blue	
BRN	Brown	
PNK	Pink	
PRPL	Purple	
RED	Red	
WHT	White	
YEL	Yellow	
Refer to contro	ol board schematic for control board detail	

U0140/U0190/U0240 WITH J4 THERMISTOR TERMINAL

1 Ph - Self Contained Air & Water-cooled

WIRING DIAGRAM



U0140/U0190/U0240 With J4 Thermistor Terminal


1 Ph - Self Contained Air & Water-cooled

Number	Component
3	Bin Switch
5	Compressor
7	Compressor Overload
12	Compressor Start Capacitor
13	Compressor Start Relay
14	Condenser Fan Motor
17	Contactor Coil
18	Contactor Contacts
19	Control Board
25	Fan Cycle Control
26	Float Switch - Harvest
27	Float Switch-Water Level
28	Fuse
31	High Pressure Cutout
40	On/Off/Clean Switch
41	See Control Board Schematic For Detail
42	Solenoid Valve
49	Thermistor - J4
55	Water Dump Valve
56	Water Inlet Valve
58	Water Pump
	Wire Colors
BLK	Black
BLU	Blue
BRN	Brown
PNK	Pink
PRPL	Purple
RED	Red
WHT	White
YEL	Yellow
Refer to contro	ol board schematic for control board detail

U0140/U0190/U0240 BEFORE J4 THERMISTOR TERMINAL

1 Ph - Self Contained Air & Water-cooled

WIRING DIAGRAM



U0140/U0190/U0240 Before Thermistor Terminal


1 Ph - Self Contained Air & Water-cooled

Number	Component
3	Bin Switch
5	Compressor
7	Compressor Overload
12	Compressor Start Capacitor
13	Compressor Start Relay
14	Condenser Fan Motor
17	Contactor Coil
18	Contactor Contacts
19	Control Board
25	Fan Cycle Control
26	Float Switch - Harvest
27	Float Switch-Water Level
28	Fuse
31	High Pressure Cutout
40	On/Off/Clean Switch
41	See Control Board Schematic For Detail
42	Solenoid Valve
55	Water Dump Valve
56	Water Inlet Valve
58	Water Pump
	Wire Colors
BLK	Black
BLU	Blue
BRN	Brown
PNK	Pink
PRPL	Purple
RED	Red
WHT	White
YEL	Yellow
Refer to control board schematic for control board detail	

U0310 WITH J4 THERMISTOR TERMINAL

1 Ph - Self Contained Air & Water-cooled

WIRING DIAGRAM




U0310 With J4 Thermistor Terminal

1 Ph - Self Contained Air & Water-cooled

Number	Component
3	Bin Switch
5	Compressor
7	Compressor Overload
9	Compressor PTCR
11	Compressor Run capacitor
12	Compressor Start Capacitor
14	Condenser Fan Motor
17	Contactor Coil
18	Contactor Contacts
19	Control Board
25	Fan Cycle Control
26	Float Switch - Harvest
27	Float Switch - Water Level
28	Fuse
31	High Pressure Cutout
40	On/Off/Clean Switch
41	See Control Board Schematic For Detail
42	Solenoid Valve
49	Thermistor - J4
55	Water Dump Valve
56	Water Inlet Valve
58	Water Pump
	Wire Colors
BLK	Black
BLU	Blue
BRN	Brown
PNK	Pink
PRPL	Purple
RED	Red
WHT	White
YEL	Yellow
Refer to contr	rol board schematic for control board detail

U0310 **BEFORE J4 THERMISTOR TERMINAL**

1 Ph - Self Contained Air & Water-cooled



U0310 BEFORE J4 THERMISTOR TERMINAL


1 Ph - Self Contained Air & Water-cooled

Number	Component
3	Bin Switch
5	Compressor
7	Compressor Overload
9	Compressor PTCR
11	Compressor Run capacitor
12	Compressor Start Capacitor
14	Condenser Fan Motor
17	Contactor Coil
18	Contactor Contacts
19	Control Board
25	Fan Cycle Control
26	Float Switch - Harvest
27	Float Switch - Water Level
28	Fuse
31	High Pressure Cutout
40	On/Off/Clean Switch
41	See Control Board Schematic For Detail
42	Solenoid Valve
55	Water Dump Valve
56	Water Inlet Valve
58	Water Pump
	Wire Colors
BLK	Black
BLU	Blue
BRN	Brown
PNK	Pink
PRPL	Purple
RED	Red
WHT	White
YEL	Yellow
Refer to contr	ol board schematic for control board detail

UD0065/UDE0065/UDP0065

1 Ph - Self Contained Air-cooled

WIRING DIAGRAM



040006021 REV 01


UD0065/UDE0065/UDP0065 1 Ph Self Contained Air-cooled

Number	Component
4	Bin Thermostat
5	Compressor
7	Compressor Overload
13	Compressor Start Relay
14	Condenser Fan Motor
17	Contactor Coil
18	Contactor Contacts
19	Control Board
23	Jumper Air cooled or Drain Pump Safety Switch Water-cooled
28	Fuse
32	Ice Thickness Control
34	Light Harvest
40	On/Off/Clean Switch
41	See Control Board Schematic For Detail
42	Solenoid Valve Harvest
49	Thermistor Liquid Line
54	Transformer
56	Water Inlet Valve
58	Water Pump
Refer to control board schematic for control board detail	

UE0080/UDE0080/UDP0080

1 Ph - Self Contained Air-cooled

WIRING DIAGRAM



040006743


UE0080/UDE0080/UDP0080 1 Ph Self Contained Air-cooled

Number	Component
3	Bin Switch
5	Compressor
7	Compressor Overload
12	Compressor Start Capacitor
13	Compressor Start Relay
14	Condenser Fan Motor
17	Contactor Coil
18	Contactor Contacts
25	Fan Cycle Control
40	On/Off/Clean Switch
42	Solenoid Valve Harvest
58	Water Pump
Refer to control board schematic for control board detail	

Electronic Control Boards

UF / UP MODELS

UF0140/UP0140 UF0190/UP0190 UF0240/UP0240 UF0310/UP0310




UF / UP Models

CONTROL BOARD COMPONENTS

Number	Component
1	LED Water Pump Relay
2	LED Compressor Relay
3	LED Water Dump Valve Relay
4	LED Harvest Solenoid Valve
5	LED Clean
6	LED Thermistor
7	LED Thermistor
8	LED Thermistor
9	LED Water Fill Valve
10	LED Harvest Float
11	LED Water Level Float
12	LED Bin Switch
13	LED Safety Limit 2
14	LED Safety Limit 1
15	LED Harvest
16	LED Test Mode
17	Fuse
18	Motor Connector 12V - J8
19	EC Fan Motor Connector 12V - J9
20	Bin Switch Connector - J5
21	Float Switch Water Level
22	Float Switch Harvest
23	Thermistor 2 - J10
24	Test Switch
25	Thermistor 1 - J4

CONTROL BOARD U MODELS

with J4 Thermistor Terminal



U Models


With J4 Thermistor Terminal

CONTROL BOARD COMPONENTS

Number	Component
1	LED Water Pump Relay
2	LED Compressor Relay
3	LED Water Dump Valve Relay
4	LED Harvest Solenoid Valve
5	LED Clean
6	LED Thermistor
7	JP1 Jumper or Thermistor Connector
8	LED Water Fill Valve
9	LED Harvest Float
10	LED Water Level Float
11	LED Bin Switch
12	LED Safety Limit 2
13	LED Safety Limit 1
14	LED Harvest
15	LED Test Mode
16	Fuse
17	Bin Switch Connector - J5
18	Float Switch Water Level
19	Float Switch Harvest
20	Test Switch

CONTROL BOARD U MODELS

Before to J4 Thermistor Terminal




U Models

Before To J4 Thermistor Terminal

CONTROL BOARD COMPONENTS

Number	Component
1	Water Pump Relay
2	Compressor Relay
3	Water Dump Valve Relay
4	Harvest Solenoid Valve
5	Water Inlet Valve Relay
6	Fuse
7	LED Ice Level Float
8	LED Test Mode
9	LED Curtain Switch
10	LED Safety Limit 2
11	LED Safety Limit 1
12	LED Harvest
13	LED Water Level Float
14	Test Switch
15	Bin Switch Connector J5
16	Float Switch Water Level
17	Float Switch Harvest

ELECTRONIC CONTROL BOARD UD0065/UDE0065/UDP0065




UD0065/UDE0065/UDP0065

CONTROL BOARD COMPONENTS

Number	Component
1	Liquid Line Thermistor
2	Ice Thickness Adjustment
3	Overflow Jumper Wire
4	Harvest Light
5	Fuse
6	Control Board Transformer

ELECTRONIC CONTROL BOARD UE0080/UDE0080/UDP0080




UDE0080/UDP0080

CONTROL BOARD COMPONENTS


Number	Component			
1	Ice Thickness Probe Connection			
2	Ice/Off/Clean Toggle Switch Connection			
3	Bin Switch Light			
4	Harvest Light			
5	Control Board Transformer			
6	Compressor Relay			
7	Harvest Valve Relay			
8	Water Pump Relay			
9	Line Voltage Connector			
10	Fuse			

Tubing Schematics


UDE0065/UDP0065



UDE0080/UDP0080 & U0140/UF0140/UP0140



U0190/UF0190/UP0190 U0240/UF0240/UP0240 U0310/UF0310/UP0310



THIS PAGE INTENTIONALLY LEFT BLANK



MANITOWOC ICE 2110 SOUTH 26TH STREET MANITOWOC, WI 54220

800-545-5720 WWW.MANITOWOCICE.COM

©2024 Manitowoc Ice except where explicitly stated otherwise. All rights reserved.

Part Number 000018622 Rev 00 04/25