




BERKELEY
MACHINERY

Visicut 3850 OPERATION MANUAL

Fully Automatic Paper Core Cutting Machine



Index of Contents

	Page
1.0 Technical Parameters	1
2.0 Safety Notice	2
3.0 Transportation & Storage	3
4.0 Installation	4
5.0 Electric Control Introduction	5
6.0 Maintenance Instruction	6

1.0 Technical parameters

Manufacturer information

Berkeley Machinery, Eagle Business Park,

Units 11 & 12 Talon Court, Yaxley,


Peterborough PE7 3EH

Tel: +44(0) 1474 854 294

Website: www.berkeleymachinery.com

E-mail: info@berkeleymachinery.com

Machine model & ID plate



Main technical parameters

Max Paper Core Length	3850mm
Paper Core Inner Diameter	38-152.4mm
Maximum Paper Core Thickness	17mm
Cutting Length	10-1925mm
Cutting Speed	60 Cuts/Min
Cutting Accuracy	+(-)0.2mm
Cutting Mode	Paper Tube Rotates, Blades and Mandrel Keep Static
Blades	Automatic Rotation
Module	2 Sets
Paper Core Preloading	Manual
Working Pressure	0.6Mpa
Voltage	220 / 380V

2.0 Safety notice

Index of Contents

2.1 Symbols on the machines ----- 2-2

2.2 Conventional use ----- 2-2

2.3 Systematic actions ----- 2-2

2.4 Operator duties ----- 2-3

2.5 Safety requirements in standard & special operation ----- 2-3

2.6 Electric device ----- 2-4

2.7 Gas, dust, stream and smog ----- 2-4

2.8 Oil, grease, miscellaneous chemicals ----- 2-5

2.9 Important safety point ----- 2-5



SAFETY NOTICE

Each person who works with this machine or carries out repair work or maintenance work must read and understand this chapter

Symbols

The following warnings in the form of symbols are fixed on the machine.



Be careful where this symbol is on the machine, improper operation may cause injuries.

Symbols on the machine


The following warnings in the form of symbols are fixed on the machine.



Caution - Electric Danger.



Warning about mechanical injury for fingers.




Caution about rotating parts.



Caution, about mechanical pressing down on hand.



Warning about mechanical injury for foot.



Caution, lubricate the parts regularly.



Caution, Mind Your Head.



Warning, do not operate without authorization.

Conventional use

The machine as well as the equipment has been manufactured according to the latest standards and safety regulations. Special care must be taken to prevent both personal injury and physical damage.

Machine and equipment must be in perfect condition and operated only by trained workers. Any troubleshooting, have an effect on the mechanical safety, should be solved or repaired immediately.

The machine is manufactured to cut longer tube to smaller cut cores.

The manufacturer should not take over any responsibility for damages resulting from use for any purpose not allowed. Unconventional use occurs due to activities which are not according to this manual and/or the regulations of maintenance.

Systematic actions

The operation manual should always be placed in clear sight where the machine is in use.

It is required to observe all general regulations in order to prevent injuries and damages as well as to keep the conditions safe.

Regulations in view of dangerous goods and traffic rules are to be strictly obeyed.

That applies also to welding- of constructional parts, installation and safety devices and valves.

Spare parts should be exchanged according to the technical regulations stated by the manufacturer. Original spare parts are recommended. Amendments in view of the software are not allowed.

Operator duties

All operating works on the machine should be performed by a skilled operator, legal regulations in view of minimum age must be observed. The operator's individual duties for operation preparation, maintenance and repair should be clearly classified. Only trained personnel should be appointed.

Only explicitly authorized workers should handle the machine.

The operator should have the responsibility and the authority to deny mechanical workings which are not according to the transport and safety regulations.

Training and work on the machine are strictly forbidden without the attendance of a trained operator.

All electric works of system and equipment should be performed by only the skilled technician.

Safety requirements in standard & special operation

Standard operation

Avoid operating in any mode which is not good for safety.

All necessary actions which could endanger safety should be avoided. Take all actions to guarantee safety.

Start operating the machine only when protective and safe devices as separated type, safety device, emergency stop device, sound-warning device and exhaust device are working in proper condition.

Machine and equipment should be checked in view of damages or malfunction regularly with change of shift. Changes or trouble have to be reported to the person in charge, if applicable, stop the machine and lock it. When malfunction or any other error occurs, stop the machine immediately and lock it.

When starting or stopping the machine it is required to always check indicators as explained in the operation manual.

Before starting, consider the danger of third parties.

Never stop operating the suction mechanism during the working process.

Special operation

Spare parts used for maintenance or repair must be disposed of. The control- maintenance- and repair work stated in the manual must be strictly observed periodically, as well as the regulations for changes of spare parts. The work should be done by authorized personnel only.

A person in charge should be appointed before starting maintenance and repair works. Check the safety of the working place.

If the machine is stopped because of maintenance and repairing, make sure that it will not start unexpectedly.

Put a warning board on the power switch before locking the power switch.

Before maintenance or repair work, connections and bolting should be cleaned of oil and glue. Never use caustic cleanser, and only fiber-free cleansing towels.

All opened bolting connections should be activated after work. All work needs to be according to the operation manual.

All shut down, dismantled safety devices should be replaced after the work process. Wear and tear elements should be disposed of safely according to the regulations.

Electric device

Only use original fuses according to the stated voltage and amperage. Stop the machine immediately when malfunctions occur.

Electric system and electric equipment should be done by a skilled electrician or finished by a trained engineer under the electrician's supervision, which should accord with the regulations..

The machine must be shut down before maintenance, repair or control workings, according to the stated rules.

An inspection of the electric equipment should be made periodically. Loose, damaged or not fixed connections should be disposed of immediately.

When handling the voltage components, another electrician has to be there to press the emergency stop button, as a precaution.. The working area needs to be surrounded by red and white safety tape. Only use insulating tools.

Gas, dust, stream and smog

Before using the machine for welding, cutting and burnishing, clean up dust and other tinder around the work area. These working processes should only be made by trained personnel.

When working in a narrow closed area please observe the national regulations.

Oil, Grease, miscellaneous chemicals

During working with oil, grease and miscellaneous chemicals the regulations have to be observed.

Be careful with hot lubricant and auxiliary materials. (Danger of fire)

Important Safety points

1. Before starting the machine, check all parts and buttons and see if all of them are in their intended working position. All safety facilities are in normal position. Note that the people around the machine are in a safe position.
2. If the machine suddenly stops working, do not restart immediately, the trained personnel should press the "stop" button, and find the reason for the sudden stop. If the machine has a problem, then ask a professional technician to repair it, after troubleshooting, then restart the machine.
3. When the machine is running, no adjustment shall be made. Except the allowed adjustable parts. All other adjustments and maintenance shall be done when the machine is completely stopped. Don't put your hands into the machine running section until the machine is fully stopped.
4. Do not use improper tools to fix the machine. After the maintenance job is done, check the tools and clean away the wasted materials, in case of any malfunctions.

5. When the machine is powered on, do not open the electric cabinet. Please allow professional and qualified employees to do the electric operation job.
6. It is forbidden for unauthorized personnel to adjust the machine. When the machine is running, it is strictly prohibited to climb over or through into the machine.
7. Do maintenance and replace the defective and damaged safety devices in time. And quickly report any abnormal conditions.
8. Keep the machine surrounding clean, tidy the tools, and sweep away the wasted paper.
10. Keep this operation manual safe, and keep it where it can be easily accessed.. If the manual is lost, please contact us directly.

3.0 Transportation & Storage

Qualified technicians are required for fork truck and crane operation. Wire rope or ring belt must be used to the specification which is matched to the machine weight. Please pay attention not to collide with other objects in the surrounding areas.

During transport, the temporary storage temperature should be between 68 °F - 100 °F

In the process of transport and storage, the machine should not be drenched by rain or water.

In the process of transport and storage, the machine should not be in contact with corrosive gasses.

In the process of transport and storage, the machine should not be inverted.

In the process of transport and storage, the machine should not impact or fall down.

4.0 Installation

Index of Contents

4.1 Installation information ----- 4-2

4.2 Unit weight information ----- 4-3

4.3 Ground plan ----- 4-4

Unpacking, transport and movements of the machine.

No person should be allowed to be next to the machine while executing the above.

Environment temperature: 0 °F- 104 °F, relative humidity below 85%.

Avoid strong electromagnetic interference around the machine.

Do not open the electrical case when the machine is powered, only professional people can operate the electrical installations.

After unloading

- Lifting equipment for 5 tons is required.
- Remove all packing.
- Check machine and spare parts in view of probable damages.
- Check completeness of spare parts.

In case of damage please inform the below mentioned companies in written form:

- Railway company, truck forwarder or shipping company
- Insurance company
- Berkeley Machinery

Installation location and condition

- Vibration-free
- Land subsidence shall not be greater than 2%, hard surface
- No need to fix it with screws and bolts into the ground after machine leveling.

After the installation


- Removal of anti-corrosive grease and oil should be done with kerosene or benzene
- Do not use sharp tools when removing

Unit weight information

One Package total gross weight is 2 tons



Schematic and Floorplan



Unit: mm

The connection of electric power and compressed air to the machine should only be performed by an authorized technician.

The electric plan must be used.

5.0 Electric control introduction

Index of Contents

Touch screen interface introduction - - - - - 5-7

Touch screen interface introduction

- Home page



VisiCut 3850

Automatic Paper Core Cutting Machine

- Operation Screen

Home
 Control
 Authorization
 Monitor
 Parameters
 Error

Normal

Output Reset

Reset

Length Preset

000000

Tube Count

000000

No.	Length	Qty	Count
01	0000.0	000000	000000
02	0000.0	000000	000000
03	0000.0	000000	000000
04	0000.0	000000	000000
05	0000.0	000000	000000
06	0000.0	000000	000000
07	0000.0	000000	000000

08	0000.0	000000	000000
09	0000.0	000000	000000
10	0000.0	000000	000000
11	0000.0	000000	000000
12	0000.0	000000	000000
13	0000.0	000000	000000
14	0000.0	000000	000000
15	0000.0	000000	000000

+000000.0

Chuck Position

+000.0

Cutter Position

+0.000

Cutter Compensation

conveyor stop




Manual conveyor

Single Mode

Auto Loading







Cycle Start

Normal	Display machine status
Output Reset	Reset 'Final Tubes Accumulate'
Reset	Recover all actions to original positions
Length Preset 000000	A button 'Length Preset' and 'Measure Length' Preset Manual measure length and Preset Machine automatic measure length
Tube Count 000000	Counting how many pieces paper tube cut
+000000.0 Chuck Position	The chuck position currently, it is only displayed data, no need set up
+000.0 Cutter Position	The knife position currently, it is only displayed data, no need set up
+0.000 Cutter Compensation	Fine tuning knife cutting depth
conveyor stop	Switch, conveyor start or conveyor stop in Manual Mode
Manual conveyor	Automatic Conveyor mode Or Auto Conveyor mode

	Single Mode: Machine always cut tube based on No. 01 Preset Length Continual Mode: Machine cut tube based on No.1 – No.15 Preset Length
	Automatic Loading or Manual Loading Paper tube button
	Cycle Start or Cycle Stop, it is use for start or stop loading parent paper core
Setting your cutting parameters	

No.	Length	Qty	Count				
01	0000.0	000000	000000	08	0000.0	000000	000000
02	0000.0	000000	000000	09	0000.0	000000	000000
03	0000.0	000000	000000	10	0000.0	000000	000000
04	0000.0	000000	000000	11	0000.0	000000	000000
05	0000.0	000000	000000	12	0000.0	000000	000000
06	0000.0	000000	000000	13	0000.0	000000	000000
07	0000.0	000000	000000	14	0000.0	000000	000000
				15	0000.0	000000	000000

- Manual Operate

 Home		 Control		 Authorization		 Monitor		 Parameters		 Error	
Reset				00.00 Hz		00.00 Hz		00.00 Hz			
Middle Clamp Support	Push Cut Core			Main Motor		Fedding Frequency		Fedding Frequency			
Clamp Support Rise	Clamp Support Fall										
Unloader Onward	Unloading Return			+000.0 mm		+000.0 mm		+000.0 mm			
Loading Valve	Clamp Valve			Cutter Origin		Cutting Position		Cutting Back Position			
Push Tube	Unloading Support					Cutter Onward		Cutter Return			
Final Tube Value	Wastage Valve										
Tube Push Forward	Tube Push Return			+00000.0 mm							
Loader Stand UP	Loader Stand Down			Chuck Origin		Chuck Return		Chuck Forward			

Reset			
Middle Clamp Support	Middle Clamp Supporter, clamps the tube	Push Cut Core	Push cut long core at one side
Clamp Support Rise	Middle Clamp Support section rise / stop	Clamp Support Fall	Middle Clamp Support section fall / start
Unloader Onward	Unloading the final waste tube forward	Unloading Return	Unloading the final waste tube backward
Loading Valve	Paper tube store loading tube action	Clamp Valve	Catching tube
Push Tube	Pressure rollers press the tube	Unloading Support	U shape plate unloading the final waste tube
Final Tube Value	Control the cut small tube unloading plate	Wastage Valve	Control the waste tube unloading plate
Tube Push Forward	Pushing the long core into cutting system	Tube Push Return	Return the tube
Loader Stand UP	Loading the long core stand up	Loader Stand Down	Loading the long tube stand down
00.00 Hz	Main motor frequency	00.00 Hz	No.1 Cutting motor frequency
Main Motor		Fedding Frequency	

00.00 Hz	No.2 Feeding tube motor frequency	+000.0 mm	Pressing this button the cutting system will search and return original position
Feeding Frequency		Cutter Origin	
+000.0 mm	Cut off paper tube position	+000.0 mm	After cut off the knife return position when machine stops
Cutting Position		Cutting Back Position	
Cutter Onward	Knife forward cutting	Cutter Return	Knife backward cutting
+00000.0 mm	Pressing this button the chuck system will search and return original position		
Chuck Origin			
Chuck Forward	Chuck forward	Chuck Return	Chucking backward

- I/O Monitor

Home

Control

Authorization

Monitor

Parameters

Error

I0.0

Start

I0.1

Emergency Stop

I0.2

Spare

I0.3

Chuck Origin

I0.4

Cutting Limit

I0.5

Stop

I0.6

Main Motor Error

I0.7

Chuck Servo Error

I1.0

Cutter Servo Error

I1.1

Length Measure Test

I1.2

Cutter Origin

I1.3

Testing Longer Tube

I1.4

Spare

I1.5

Spare

I1.6

Spare

I1.7

Spare

I2.0

Material Signal

I2.1

Pusher Back Position

I2.2

Lifting Down Limit

I2.3

UP

I2.4

Down

I2.5

Unloading Forward Arrive

I2.6

Unloading Backward Arrive

I2.7

Spare

Q0.0

Cutting Servo Pulse

Q0.1

Cutter Servo Pulse

Q0.2

Clipping Servo Direction

Q0.3

Main Motor

Q0.4

Clamp Valve

Q0.5

Unloading Backward Valve

Q0.6

Unloading Forward Valve

Q0.7

Cutter Servo Direction

Q1.0

Press Tube Down

Q1.1

Final Tube Valve

Q1.2

Unloading Support Down

Q1.3

Conveyor

Q1.4

Loading Valve

Q1.5

Wastage Valve

Q1.6

Push Tube Forward Valve

Q1.7

Push Tube Backward Valve

Q1.0

Start Instruct

Q1.1

Loader Stand UP

Q1.2

Loader Stand Down

Q1.3

Clamp Support Fall

Q1.4

Clamp Support Clamping

Q1.5

Spare

Q1.6

Clamp Support Rise

Q1.7

Push Longer Tube

[Home](#)[Control](#)[Authorization](#)[Monitor](#)[Parameters](#)[Error](#)

I3.0 No.1 Safety Door

I3.1 No.2 Safety Door

I3.2 No.3 Safety Door

I3.3 No.4 Safety Door

I3.4 No.5 Safety Door

I3.5 No.6 Safety Door

I3.6 Testing Lack Air Pressure

I3.7 Spare

I4.0 Clamp Support Test Up


I4.1 Clamp Support Test Down

I4.2 Support Clamp Position Testing

I4.3 Clamp Support Loose



- Error Alarm



- Working Parameter

Home	Control	Authorization	Monitor	Parameters	Error
<div>0000.0 - 0000.0 - 0000.0 = 0000.0</div> <div>Tube Length First Waste Tube Length Tube End Length Effective length</div>					
Check Manual Move Speed			00.000		
Cutting Auto Speed			00.000		
Cutter Manual Move Speed			00.000		
Cutter Speed			00.000		
Cutter Return Speed			00.000		
Cut-Off Time			0000.0		
Final Tubes Total			0000000000		
Final Tubes Accumulate			0000000000		
System Password					
000000					
Work Parameter					
Cut First Waste Tube			Bring Longer Tube Forward		
Total Reset		Bring First Waste Tube Plate Forward		Last Waste Tube Plate Close	

Password is 666666

0000.0 Tube Length	Long tube total length	Cut First Waste Tube	Switch: Cut first waste tube or can be set to not cut first waste tube
0000.0 First Waste Tube Length	The first waste tube length	Bring Longer Tube Forward	Switch: Push cut long tube at one side or can be set to not push cut long tube at one side
0000.0 Tube End Length	The final waste tube length	Total Reset	Reset total quantity of cut paper tube
0000.0 Effective length	Output effective tube total length	Bring First Waste Tube Plate Forward	Switch: Unloading First Waste Tube Plate
		Last Waste Tube Plate Close	Switch: Unloading Last Waste Tube Plate
Check Manual Move Speed	00.000	Manual Mode, chuck system moving speed	
Cutting Auto Speed	00.000	Auto Mode, chuck system moving speed	
Cutter Manual Move Speed	00.000	Manual Mode, the knife cutting speed	

Cutter Speed	00.000	Auto Mode, the knife cutting speed
Cutter Return Speed	00.000	Auto Mode, the knife return speed
Cut-Off Time	0000.0	Auto Mose, the knife cut off
Final Tubes Total	0000000000	All cut tubes length
Final Tubes Accumulate	0000000000	All cut tubes quantity







- **Running Parameters and Servo Parameters**

 Home		 Control		 Authorization		 Monitor		 Parameters		 Error	
Loading Delay		00.0		System Password		000000		Running Parameters			
Push Tube Delay		00.0		Push Longer Tube Delay		00.0		Servo Parameters			
Cutting Delay		00.0		Testing Longer Tube Delay		00.0					
Main Motor Start Delay		00.0		Unloading Longer Tube Delay		00.0					
Unloading & Feeding Delay		00.0		Longer Tube Delay Unloading		00.0					
Unloading Support Clamp Down Delay		00.0									
Start Remove The Last Waste Tube Delay		00.0									
Remove Last Waste Tube Time		00.0									
Loading Delay		00.0									
Wastage Trim Length		0000.0									

Loading Delay	00.0	Paper tube infeed loading tube delay time
Push Tube Delay	00.0	Pressure roller press tube time from original position to press the tube
Cutting Delay	00.0	Blades cutting tube time delay
Main Motor Start Delay	00.0	Start machine time delay
Unloading & Feeding Delay	00.0	Unloading tube forward time delay
Unloading Support Clamp Down Delay	00.0	U shape Chuck fall time delay
Start Remove The Last Waste Tube Delay	00.0	Unloading Last waste tube plate start time delay
Remove Last Waste Tube Time	00.0	Separated the last tube with the last waste tube time delay
Loading Delay	00.0	Close the transfer belt time delay
Wastage Trim Length	0000.0	Feeding the first waste tube distance
System Password	000000	666666, you can reset the password
Push Longer Tube Delay	00.0	Blade cut long tube and pusher start working time delay

Testing Longer Tube Delay	00.0	Blade cut testing delay
Unloading Longer Tube Delay	00.0	U shape Chuck return time delay after it will push cut long tube
Longer Tube Delay Unloading	00.0	Unloading Long tube plate recover time when it unloads long tube

- Running Parameters And Servo Parameters

 Home		 Control		 Authorization		 Monitor		 Parameters		 Error	
Chuck Original Speed		00.000		Cutter Origin Speed		00.000		Running Parameters			
Chuck Origin		000000		Cutter Origin Deviation		000000		Servo Parameters			
Chuck Limit Position		0000.0		Cutter Manual Move Speed		00.000					
Chuck Measure Length Speed		00.000		Cutter Speed		00.000					
Chuck Measure Length Deviation		0000.0		Cutter Return Speed		00.000					
Chuck Servo Delay		0000.0		Cutter Servo Delay		0000.0					
Support Clamp Start		0000.0									
Support Clamp Stop		0000.0									

Chuck Original Speed	00.000	The chuck system finding original position speed
Chuck Origin	000000	Set up chuck system original position
Chuck Limit Position	0000.0	The chuck system limited position
Chuck Measure Length Speed	00.000	The sensor controls the chuck system measure long tube length speed
Chuck Measure Length Deviation	0000.0	Fixed data, 'Chuck measure length' tolerance
Chuck Servo Delay	0000.0	Chuck moving stop time
Support Clamp Start	0000.0	The middle support section starts working time when the clamps arrive in this position
Support Clamp Stop	0000.0	The middle support section stops working time when the clamps arrive in this position
Cutter Origin Speed	00.000	The cutter finding original position speed
Cutter Origin Deviation	000000	Set up the cutter original position gap between the real position
Cutter Manual Move Speed	00.000	Thecutter feeding speed in manual mode

Cutter Speed	00.000	The Cutter cutting speed
Cutter Return Speed	00.000	The Cutter return speed
Cutter Servo Delay	0000.0	The Cutter moving stop speed

6.0 Maintenance Instruction

Machine appearance:

1. The machine should be wiped frequently and kept clean. It is absolutely forbidden to stick tape on the machine.
2. Please carry out anti-rust treatment on the machine every 35 days.
3. Regularly check the damage of gears, belts, and blades on the machine, and replace accessories in time.
4. If there is any damage to the drive belt of each part, please replace it immediately.
5. Check whether there is any air leakage in each air circuit. If there is any air leakage, replace the joint or sealing ring.

Machine electric elements:

1. Wipe the motor regularly, check insulation and grounding, heat exhaust fan of electrical appliances to achieve integrity, cleanliness and reliability. All kinds of wires and appliances in the electric box should pay attention to dust prevention and heat dissipation. The electric box door should be closed.
2. When it needs to be checked and repaired, it should be opened.