

JULY 1994 VER 1.0

**FX650 PROFESSIONAL 3  
OPERATION MANUAL  
(MOFX650PRO-01)**

## CONTENTS

	PAGE
CHAPTER 1. UNIT IDENTIFICATION.	
1.1    MTC Cabinet	1-1
1.2    Operator Station	1-3
1.3    Manual Pulse Generator (MPG)	1-5
CHAPTER 2. OPERATION OPERATOR STATION	
2.1    Operation of Operator Station	2-1
2.2    Power ON/OFF and Emergency Stop	2-1
2.3    Cycle Start/stop and Spindle Operation	2-2
2.4    NC Mode	2-4
2.5    NC Functions	2-6
2.6    Auxiliary Functions	2-9
2.7    Selector Switches and Rotary Switches	2-11
2.8    Indicators	2-13
2.9    Main Control Panel Flexible Switches	2-15
2.10   Manual Pulse Generator (MPG)	2-17
CHAPTER 3. EMERGENCY STOP AND ALARM	
3.1    Emergency Stop Operation	3-1
3.2    Alarm Operation	3-3
CHAPTER 4. PROCEDURE FOR START-UP AND POWER OFF	
4.1    Turning On Power	4-1
4.2    Turning On Air Supply.	4-2
4.3    Turning Off Power	4-2
CHAPTER 5. MANUAL MODE	
5.1    Introduction	5-1
5.2    Manual Axis Feed	5-1
5.3    Manual Reference (Zero Point) Point Return	5-3
5.4    Axis Overtravel	5-3
5.5    Starting & Stopping Spindle	5-4
5.6    Spindle Fixed Angle Positioning (Orientation)	5-4
5.7    Spindle Tool Loading/Unloading	5-5
5.8    Automatic Tool Changer (ATC)	5-5
5.9    Nozzle Coolant	5-5

## CHAPTER 6 MDI MODE

6.1	MDI Mode	6-1
-----	----------	-----

## CHAPTER 7 EDIT MODE

7.1	Introduction	7-1
7.2	Part Program Storage and Editing Screens	7-1
7.3	Part Program Library Management Screens	7-4

## CHAPTER 8 MEMORY MODE

8.1	Power On and Memory Mode Selection	8-1
8.2	Machine Reference	8-2
8.3	Display of Axes Position	8-3
8.4	Tool Offset	8-7
8.5	Work Coordinate System	8-12
8.6	Set up For Memory Operation	8-14
8.7	Program Run In Memory Mode	8-17
8.8	Program Re-start	8-24

## CHAPTER 9 DNC/TAPE MODE

9.1	Introduction	9-1
9.2	DNC Operation From A Computer	9-1
9.3	Tape Operation	9-2

## CHAPTER 10 ATC OPERATION.

10.1	Control Panel	10-1
10.2	Tool Loading and Unloading	10-2
10.3	Set up For ATC Operation	10-5
10.4	ATC Operation	10-10
10.5	Restoration of ATC From Hang up	10-14
10.6	Additional Features in ATC For Heavy Tool	10-16

## CHAPTER 11 PC SCREEN

11.1	PC Screen Type	11-1
11.2	PC Initial Screen (Primary Operation Screen)	11-2
11.3	Tool Detail Screen	11-5
11.4	Tool Monitor Screen	11-8
11.5	Help Screen	11-12
11.6	Alarm Screen	11-13
11.7	Diagnose Screen	11-16
11.8	Maintenance Screen	11-18
11.9	Parameter Screen	11-23
11.10	Regular Maintenance Screen	11-27

**CHAPTER 12 TOOL MONITORING FUNCTION**

12.1	Tool Monitoring Functions	12-1
12.2	Adaptive Control Function	12-1
12.2	Study Function	12-1
12.3	SL Function	12-3
12.4	AC Function	12-4
12.5	Program Example	12-5
12.6	Tool Life Monitoring Function	12-6
12.7	Tool Monitor Alarm	12-6
12.8	Tool Monitor Mode Selection	12-7
12.9	M Codes For Tool Monitoring Functions	12-7

**CHAPTER 13 SPARE TOOL SELECTION (STS)**

13.1	Spare Tool Selection (STS)	13-1
13.2	Registration Of Spare Tool	13-1
13.3	Tool Length and Cutter Compensation For Spare Tool	13-2
13.4	Program Example.	13-2

**CHAPTER 14 DIRECT SPARE TOOL CHANGE**

14.1	Direct Spare Tool Change	14-1
14.2	DNC Operation Program	14-3
14.3	Restriction Of Direct Spare Tool Change	14-3

**CHAPTER 15 15.1 One Touch Function**

15.1	One Touch Function	15-1
15.2	Functional Details	15-2

**APPENDIX A1 M-CODE LIST**

A1-1
------

**APPENDIX A2 ALARM MESSAGES**

A2-1
------