



**S16 (P),(D)**

**S20 (P),(D)**

**S25 (P),(D)**

**SUPER SWISS TURN**  
**CNC Precision Automatic Lathes**

**OPERATION MANUAL**



**PRECISION TSUGAMI**

CONTENTS	Page
FOREWORD .....	1
SECTION 1: SAFETY .....	3
1-1 Cautions concerning operation of machine .....	3
1-2 Cautions concerning the tooling .....	4
1-3 Cautions concerning the electrical system .....	4
1-4 Cautions concerning unintended operations .....	4
SECTION 2: DESCRIPTION OF MACHINES .....	6
2-1 Description of machines .....	6
2-2 Peripheral equipment .....	7
2-3 Standard specifications and accessories .....	8
2-4 Optional specifications and accessories .....	14
2-5 Machine dimensions and nomenclature of major components .....	22
2-6 Transporting the machine .....	33
2-7 Installing the machine .....	34
SECTION 3: OPERATION .....	37
3-1 Operation panels and controls .....	37
3-2 Operation .....	43
3-2-1 Basic operations .....	43
3-2-2 Manual operations .....	45
3-2-3 Automatic operations .....	47
3-2-4 Setting the T-axis offset .....	48
3-2-5 Setting the B-axis offset .....	54
3-3 Original TSUGAMI displays and procedures for use .....	56
3-3-1 Title display .....	57
3-3-2 #1 operator's panel display .....	58
3-3-3 Bar-feeder operation setting display .....	61
3-3-4 #2 operator's panel display .....	62
3-3-5 #3 operator's panel display .....	63
3-3-6 #1 timer setting display .....	64
3-3-7 #2 timer setting display .....	65
3-3-8 BFA timer setting display for bar feeder for S16/20/25 machines .....	66
3-3-9 BFB timer setting display for bar feeders made by other makers .....	67
3-3-10 Product-counter setting display .....	68
3-3-11 Running-time indicator display .....	69
3-3-12 Lamp-indicator (LED) displays .....	70

3-3-13 Status display (NC) .....	71
3-3-14 Status displays (output signals to machine side) .....	72
3-3-15 Status display (output signals to operation panel) .....	75
3-3-16 Status display (output signals to TSUGAMI bar feeder for S16/20/25) .....	77
3-3-17 Status display (output signals to bar feeders made by other makers) .....	78
3-3-18 Status displays (input signals from machine side) .....	79
3-3-19 Status displays (input signals from bar feeders made by other makers) .....	82
3-3-20 Alarm messages .....	83
3-3-21 Bar-feeder alarm messages .....	102
3-3-22 Alarm messages for bar feeders made by other makers .....	103
3-4 Optional functions .....	110
<b>SECTION 4: ADJUSTMENTS, INSPECTIONS &amp; MAINTENANCE .....</b>	<b>115</b>
4-1 Changing guide-bushing adapters .....	115
4-2 Adjusting guide-bushing clearance .....	117
4-3 Changing spindle/sub-spindle collet chucks .....	117
4-4 Adjusting the spindle collet-chuck chucking force and changing toggles .....	119
4-5 Adjusting the sub-spindle collet-chuck chucking force and changing toggles .....	121
4-6 Checking and adjusting belt tension .....	122
4-7 Inspecting the lubrication and coolant systems .....	123
4-8 Adjusting the lubricating-oil volume and changing filters .....	124
4-9 Setting the machine origin positions .....	125
4-9-1 X-axis origin position .....	127
4-9-2 Z-axis origin position .....	128
4-9-3 T1-axis origin position .....	128
4-9-4 T2-axis origin position .....	129
4-9-5 B-axis origin position .....	129
4-10 Cautions when setting the T1- and T2-axis origin positions .....	130
4-11 Original TSUGAMI-developed alarms .....	131
4-12 Maintenance parts .....	132
<b>SECTION 5: PROGRAMMING .....</b>	<b>141</b>
5-1 Programming methods .....	142
5-2 Coordinate system .....	144
5-3 M-codes .....	147

5-4 G-codes .....	153
5-5 S-codes .....	157
5-6 T-codes .....	158
5-7 Special functions .....	159
5-7-1 Back-end-machining control functions .....	159
5-7-2 Z-axis-following control function .....	161
5-7-3 Sub-spindle control .....	162
5-7-4 Bar-feeder program example .....	165
5-7-5 Programming method for synchronized control of spindle and sub-spindle .....	166
5-8 Program preparation .....	167
5-8-1 Considerations prior to preparing a program .....	167
1) Parts drawing .....	167
2) Machining processes .....	167
3) Tooling zone .....	168
4) Tool layout .....	168
5) Machining conditions .....	170
6) Program preparation .....	170
5-8-2 Program preparation .....	171
1) Example of pattern for start and end of a program .....	171
2) Example of program for OD-machining (turning, chamfering, cut-off, product receiving) .....	172
3) Example of program for a face-drilling operation .....	175
4) Example of program for forward product extraction .....	176
5) Example of program for a cross-drilling operation .....	177
6) Example of program for a 2-sur-face flat-machining operation with an ehd mill .....	178
7) Example of program for a face-tapping operation .....	179
8) Example of program for a cross-tapping operation .....	180
9) Example of program for a cut-off and receiving operation .....	182
10) Example of program for a back-end-drilling operation .....	184
11) Example of program for a back-end-tapping operation .....	185
12) Example of program for a back-end- threadcutting operation .....	187
5-8-3 Additional machining-program examples .....	189
1) Example #1 .....	189
2) Example #2 .....	196

3) Example #3 .....	206
4) Example #4 .....	212
5-9 Reference for machining condition .....	219
5-9-1 Reference for selecting the cutting speed .....	219
5-9-2 Thread cutting count table .....	220
5-9-3 Incomplete thread length when thereading .....	221
5-9-4 Feed conditions .....	222
5-9-5 Cutting conditions .....	224
SECTION 6: APPENDIX .....	226
6-1 Piping diagram .....	226
6-2 Measurement of dilution ratio of soluble cutting oil .....	227