

MAX65s MACHINE

MAINTENANCE MANUAL

(V0616I-E1E-XA)



MAKINO

Contents

1.1	General.....	1-1
1.2	Safety Precaution	1-1
2.1	Introduction.....	2-1
3.1	Introduction to Electrical Control Functions.....	3-1
3.2	CNC UNIT	3-2
3.3	Electrical Specifications	3-3
3.4	CNC Control Specifications	3-5
4.1	Introduction.....	4-1
4.2	Cleaning and Replacing Cabinet Air Filter	4-2
4.3	Fuse Replacement	4-2
4.3.1	Replacing Fuse in CPU Unit:	4-3
4.3.2	Replacing Fuse in the Power Supply Module for Drives.....	4-4
4.3.3	Replacing Fuse in the Servo Amplifier Module.....	4-5
4.3.4	Replacing Fuse in Spindle Amplifier Module	4-6
4.4	Batteries Replacement	4-7
4.4.1	Replacing Battery for Data Memory Backup	4-7
4.4.2	Replacing Batteries for Absolute Pulse Coder in α Series Servo Amplifier Module	4-8
4.5	Replacing Fan Motor in CNC Unit.....	4-9
4.6	Replacing LCD Backlight	4-10
5.1	Introduction.....	5-1
5.2	DI/DO Address and Bit Display	5-2
5.3	Inputting/Outputting Data	5-3
5.3.1	Parameter Initialization	5-3

5.3.2	Outputting CNC Parameters	5-5
5.3.3	Outputting Pitch Error Compensation Amount.....	5-5
5.3.4	Outputting Custom Macro Variable Values.....	5-5
5.3.5	Outputting Tool Compensation Amount	5-5
5.3.6	Outputting Part Program	5-6
5.3.7	Inputting CNC Parameters	5-6
5.3.8	Inputting Pitch Error Compensation Amount	5-6
5.3.9	Inputting Custom Macro Variable Values	5-7
5.3.10	Inputting Tool Compensation Amount	5-7
5.3.11	Inputting Part Programs	5-8
5.4	Troubleshooting the CNC Unit	5-8
5.4.1	Neither Manual Operation nor Automatic Operation can be Executed	5-9
5.4.2	Jog Operation cannot be Done	5-12
5.4.3	Handle Operation cannot be Done	5-12
5.4.4	Automatic Operation Cannot be Done.....	5-14
5.4.5	Cycle Start LED Signal has Turned OFF.....	5-19
5.4.6	Nothing is Displayed on LCD	5-21
5.5	Interface between CNC and PMC	5-21
5.6	Troubleshooting the Machine.....	5-39
5.7	ATC Standby Conditions.....	5-40
5.8	Moving ATC to Standby Condition	5-40
6.1	Introduction.....	6-1
6.2	CNC Alarm Display.....	6-2
6.3	CNC Alarm History Display	6-3
6.4	List of CNC Alarms	6-3
6.4.1	Alarms on Programs and Operation	6-3
6.4.2	Background Edit Alarm	6-21
6.4.3	Absolute Pulse Coder (APC) Alarm.....	6-22
6.4.4	Serial Pulse Coder (SPC) Alarms.....	6-22

6.4.5	Servo Alarms	6-24
6.4.6	Overtravel Alarms	6-28
6.4.7	Overheat Alarms	6-28
6.4.8	Rigid Tapping Alarm	6-29
6.4.9	Spindle Alarms.....	6-29
6.4.10	System Alarms.....	6-33
7.1	Introduction.....	7-1
7.2	PMC Alarm Screen.....	7-1
7.3	PMC Alarm History Display.....	7-2
7.4	PMC Operator Alarm Message.....	7-2
8.1	Introduction.....	8-1
8.1.1	Servo Alarm List	8-2
8.1.2	Spindle Alarm List.....	8-3
8.2	Power Supply Module Trouble Shooting.....	8-4
8.2.1	Alarm Code 01.....	8-4
8.2.2	Alarm Code 02.....	8-5
8.2.3	Alarm Code 03.....	8-5
8.2.4	Alarm Code 04.....	8-5
8.2.5	Alarm Code 05.....	8-6
8.2.6	Alarm Code 06.....	8-6
8.2.7	Alarm Code 07.....	8-6
8.3	Servo Amplifier Troubleshooting.....	8-7
8.3.1	Abnormal Current Alarms (8,9,A,B,C,D,E)	8-7
8.3.2	IPM Alarms (8.,9.,A.,b.,C.,d. and E.)	9-9
8.3.3	Control Power Supply Undervoltage Alarm (2 in the LED display)	8-10
8.3.4	DC Link Undervoltage Alarm (5 in the LED display).....	8-10
8.3.5	Fan Stopped Alarm (1 in the LED display)	8-10
8.3.6	Current Conversion Error Alarm.....	8-10
8.3.7	Overload Alarm.....	8-10
8.3.8	Feedback Disconnected Alarm	8-11
8.3.9	Motor Overheat Alarm.....	8-11

8.3.10	Invalid Servo Parameter Setting.....	8-12
8.3.11	Pulse Coder Error Alarm.....	8-12
8.3.12	Rotation Speed Data Error Alarm.....	8-12
8.3.13	Pulse Coder Communication Error Alarm.....	8-13
8.4	Spindle Amplifier Module Troubleshooting.....	8-13
8.4.1	Alarm A0, A1.....	8-14
8.4.2	Alarm AL-01.....	8-14
8.4.3	Alarm AL-02.....	8-15
8.4.4	Alarm AL-03.....	8-16
8.4.5	Alarm AL-07.....	8-16
8.4.6	Alarm AL-09.....	8-16
8.4.7	Alarm AL-12.....	8-17
8.4.8	Alarm AL-13.....	8-17
8.4.9	Alarm AL-15.....	8-18
8.4.10	Alarm AL-16.....	8-18
8.4.11	Alarm AL-19.....	8-18
8.4.12	Alarm AL-20.....	8-19
8.4.13	Alarm AL-24.....	8-19
8.4.14	Alarm AL-25.....	8-20
8.4.15	Alarm AL-26.....	8-20
8.4.16	Alarm AL-27.....	8-21
8.4.17	Alarm AL-28.....	8-22
8.4.18	Alarm AL-29.....	8-23
8.4.19	Alarm AL-31.....	8-23
8.4.20	Alarm AL-32.....	8-24
8.4.21	Alarm AL-34.....	8-24
8.4.22	Alarm AL-35.....	8-24
8.4.23	Alarm AL-36.....	8-25
8.4.24	Alarm AL-37.....	8-25
8.4.25	Alarm AL-39.....	8-26
8.4.26	Alarm AL-40.....	8-26
8.4.27	Alarm AL-41.....	8-27
8.4.28	Alarm AL-42.....	8-27

8.4.29 Alarm AL-43.....	8-28
8.4.30 Alarm AL-44.....	8-29
8.4.31 Alarm AL-46.....	8-29
8.4.32 Alarm AL-47.....	8-30
8.4.33 Alarm AL-49.....	8-30
8.4.34 Alarm AL-50.....	8-31
8.4.35 Alarm AL-52, AL-53.....	8-31
8.4.36 Alarm AL-54.....	8-31
8.4.37 Alarm AL-55.....	8-32
8.4.38 Alarm AL-56.....	8-32
9.1 Introduction.....	9-1
9.2 FSSB Parameter Initialization.....	9-1
9.2.1 Automatic Setting.....	9-2
9.2.2 Manual Setting 2.....	9-4
APPENDIX	
1.1 Limit Switches and Solenoid Valves.....	10-1
2.1 Field I/O List.....	11-1
2.2 Operator Panel I/O List.....	11-6
3.1 Connector Location and Application in FS16I Controller.....	12-1
4.1 Connector, Interposing Relay locations in Main PCB.....	13-1