



*Changes for the Better*

**CNC**

**MELDAS AC SPINDLE**  
**MDS-B-SPT Series**  
**MDS-C1-SPT Series**

**SPECIFICATIONS AND INSTRUCTION MANUAL**



**BNP-C3015A(ENG)**

# CONTENTS

## I. MDS-B/C1-SPT Spindle System Configuration Section

1. Outline .....	I-1
1.1 Features .....	I-1
1.2 Precautions for use .....	I-2
2. System Configuration .....	I-3
3. Unit Installation .....	I-7
4. Connection of Each Unit .....	I-9
4.1 Layout of each unit .....	I-10
4.2 Link bar specifications .....	I-10
4.3 Precautions for installing multiple power supply units .....	I-12
4.4 Precautions when installing multiple spindle drive units to one power supply unit....	I-13
5. Connector and Cable Specifications .....	I-14
5.1 Half pitch connector and cable connection system .....	I-14
5.2 Cable details .....	I-15
5.2.1 SH21 cable (Semi-ordered part) [For B/C1-CV Û B/C1-SPT connection].....	I-15
5.2.2 Spindle control circuit cable list .....	I-16
5.2.3 Cable assembly procedure .....	I-21
6. Outline Drawing .....	I-25
6.1 List of outlines .....	I-25
6.2 Power supply unit .....	I-26
6.3 Spindle drive unit .....	I-27
6.4 AC reactor .....	I-28
6.5 Contactor .....	I-29
6.6 NFB .....	I-29
7. Heating Value .....	I-30
8. Selection of Capacity .....	I-31
8.1 Selection of the power supply unit (MDS-B/C1-CV) .....	I-31
8.2 Selection of the power supply capacity .....	I-31
8.3 Selection of wire size .....	I-32
8.4 Selection of AC reactor, contactor and NFB .....	I-35

## II. MDS-B/C1-CV Power Regeneration Type Power Supply Section

1. Power Supply Unit .....	II-1
1.1 Model configuration .....	II-1
1.2 List of specifications .....	II-2
1.3 Hardware and parameter setting .....	II-3
1.4 Status display .....	II-4
1.4.1 7-segment LED display .....	II-4
1.4.2 Charge lamp .....	II-4
1.5 List of alarms and warnings .....	II-5
1.6 Explanation of connectors and terminal block .....	II-7
1.7 Functions added with MDS-B Series (Power supply external emergency stop function) .....	II-8
1.8 Main circuit connection .....	II-10

## I. MDS-B/C1-SPT Spindle Drive Unit System Section

Model, Configuration and Connection .....	III-1
1.1 Model configuration .....	III-1
1.2 Configuration .....	III-2
1.2.1 Basic configuration (No additional specifications) .....	III-2
1.2.2 With orientation function .....	III-2
1.3 Device-to-device connections .....	III-4
Specifications .....	III-5
2.1 AC spindle motor and controller specifications .....	III-5
2.2 Output characteristics .....	III-9
2.3 Outline dimension drawings .....	III-11
2.3.1 Motor .....	III-11
Status Display and Parameter Settings .....	III-16
3.1 Status display with 7-segment LED .....	III-17
3.2 Spindle parameters .....	III-18
3.3 Spindle specification parameters screen .....	III-39
3.4 Spindle monitor screen .....	III-40
3.5 Control input signals .....	III-41
3.6 Control output signals .....	III-43
3.7 Meter outputs .....	III-46
3.8 Output interface .....	III-48
Optional Specifications and Parts .....	III-49
4.1 Orientation specifications (optional) .....	III-49
4.1.1 1-point orientation using magnetic sensor .....	III-49
4.1.2 4096-point orientation using encoder .....	III-57
4.1.3 4096-point orientation using motor built-in encoder .....	III-60
4.1.4 Operation of orientation .....	III-60
4.2 Synchronous tap function (option) .....	III-63
4.2.1 Closed type synchronous tap .....	III-63
4.2.2 Semi-closed type synchronous tap .....	III-63
4.2.3 Operation of synchronous tap .....	III-63
4.3 C-axis control (optional) .....	III-64
4.3.1 When using encoder (OSE90K+1024 BKO-NC6336H01) .....	III-64
4.3.2 When using built-in encoder (MBE90K) .....	III-67
4.3.3 When using built-in encoder (MHE90K) .....	III-67
4.4 Single parts (optionally supplied parts) .....	III-68
4.4.1 Power step-down transformer .....	III-68
4.4.2 Noise filter .....	III-70
4.5 Other optional specifications .....	III-72
4.6 Theoretical acceleration and deceleration times .....	III-73

## 7. Maintenance MDS-B/C1-SPT Spindle System Configuration Section

Starting up the System .....	IV-1
1.1 Startup procedures .....	IV-1
1.2 Status display with 7-segment LED .....	IV-2
Adding and Replacing Units and Parts .....	IV-3
2.1 Replacing the unit .....	IV-3
2.2 Unit fan .....	IV-6
Daily Maintenance .....	IV-7
3.1 Maintenance tools .....	IV-7
3.2 Periodic inspections .....	IV-7
Maintenance Parts .....	IV-9
Selection of Leakage Breaker .....	IV-10
Noise Filter .....	IV-11

<b>V. Maintenance MDS-B-CVE/MDS-C1/CV Power Supply Section</b>	
1. Troubleshooting	V-1
1.1 Status display	V-1
1.2 Troubleshooting according to power supply alarm	V-3
1.3 Power supply warning	V-12

**VI. Maintenance MDS-B/C1-SPT Spindle Drive Unit Section**

1. Adjustment Procedures	VI-1
1.1 Starting up	VI-1
1.2 Confirming the speed loop	VI-1
1.2.2 Adjusting and confirming the motor (spindle) speed	VI-1
1.2.3 Adjusting the deceleration time	VI-2
1.3 Adjusting the orientation	VI-2
1.3.1 Operation	VI-2
1.3.2 Operation sequence	VI-2
1.3.3 Encoder orientation/motor built-in encoder orientation stop position	VI-3
1.3.4 Diagram of orientation parameter relation	VI-4
1.3.5 Preparation for motor built-in encoder orientation adjustment	VI-4
1.3.6 Preparation for encoder orientation adjustment	VI-5
1.3.7 Preparation for magnetic sensor orientation adjustment	VI-6
1.3.8 Adjusting the orientation	VI-7
1.3.9 Adjusting the servo rigidity	VI-7
1.3.10 Delay/advance control and PI control	VI-8
1.3.11 Troubleshooting for orientation trouble	VI-8
1.4 Adjusting the synchronous tap	VI-10
2. Troubleshooting	VI-11
2.1 Introduction	VI-11
2.2 Step 1	VI-11
2.3 Step 2	VI-12
2.4 List of alarms and warnings	VI-15
2.5 Approach per phenomenon	VI-16
2.5.1 Details when alarm or warning is displayed on the 7-segment display	VI-16
2.5.2 Details when alarm or warning is not displayed on 7-segment unit	VI-25
2.6 Periodic inspections	VI-28
2.6.1 Inspecting the control unit	VI-28
2.6.2 Inspecting the motor	VI-28
3. Disassembling and Assembling the Motor	VI-29
3.1 Disassembling and assembling the SJ type AC spindle motor	VI-29
3.2 Disassembling and assembling the SJ-N type AC spindle motor	VI-37
4. Handling the Orientation Detector	VI-46
4.1 Magnetic sensor type 1-point orientation	VI-46
4.1.1 Operation of magnet and sensor	VI-46
4.1.2 Sequences, etc.	VI-47
4.2 Encoder type 4096-point orientation	VI-47
4.2.1 Configuration	VI-47
4.2.2 Sequences, etc.	VI-47
4.3 Motor built-in encoder type 4-96-point orientation	VI-47
4.3.1 Sequences, etc.	VI-47

endix 1	Parameter Setting List .....	1
endix 2	Unit Conversion Table .....	1
endix 3	Explanation of Large Capacity Spindle Unit Specifications .....	1
	Outline .....	1
	List of units .....	1
	Selection of AC reactor (B-AL), contactor and NFB .....	1
	Outline of units .....	2
	Panel cut dimension drawing .....	3
	Detailed outline drawing .....	4
	Heating value .....	7
	Selection of power capacity .....	7
	Selecting of wire size .....	7
	3. Drive unit connection screw size .....	8
	1. Connection of Each Unit .....	8
	2. Restrictions .....	10
	3. Parameters .....	11
	4. Precautions .....	11