

CNC LATHE
LR15

with OSP5000L-G CNC SYSTEM

OPERATION & MAINTENANCE MANUAL
(5th Edition)

TABLE OF CONTENTS

	<u>PAGE</u>
SECTION 1 INTRODUCING YOUR NC LATHE	1
SECTION 2 MACHINE SPECIFICATIONS	2
2-1. SPECIFICATION TABLE	2
2-2. MACHINE DIMENSIONS	4
2-2-1. Model T-2S x 25 \emptyset	4
2-2-2. Model C-2S x 6 $\emptyset\emptyset$	5
2-3. FOUNDATION PLAN	6
2-3-1. Model C-2S x 6 $\emptyset\emptyset$	6
2-3-2. Model T-2S x 25 \emptyset	7
SECTION 3 MACHINE OPERATION	8
3-1. BEFORE STARTING OPERATIONS	8
3-1-1. NC Operation	9
3-2. MACHINE OPERATION	10
3-2-1. Hydraulic Power Unit	10
3-2-2. Selection of Spindle Drive Gear Range	13
3-2-3. Hydraulic Power Chuck	15
3-2-4. Cutting Soft Top Jaws of Power Chuck	21
3-2-5. Hydraulic Tailstock Operation	23
3-2-6. Interlock	33
3-2-7. Adjusting Coolant Throttle Valves	34
3-2-8. After Completion of A Day's Operation	34
3-2-9. Manually Operated Chuck (Four Jaw Independent Chuck)	35
SECTION 4 MAINTAINING YOUR NC LATHE IN THE BEST CONDITION	
- REGULAR INSPECTION AND MAINTENANCE OF MACHINE	43
4-1. LUBRICATION	44
4-1-1. Headstock Lubrication System	48
4-1-2. Slideway Lubrication System	48
4-2. CLEANING THE FILTERS	50
4-3. ADJUSTING CENTRALIZED LUBRICATION UNIT	51
4-4. CLEANING COOLANT TANK	52

	<u>PAGE</u>
4-5. TENSIONING BELTS	53
4-5-1. Spindle Drive Belts	53
4-5-2. Timing Belt for Z-axis Servomotor	55
4-5-3. Timing Belt for X-axis Servomotor	56
4-6. OTHER MAINTENANCE ITEMS	57
4-6-1. Adjustment of Turret Index Speed	57
4-6-2. Check the Bed Level	58
4-6-3. Alignment of Headstock	58
4-6-4. Adjustment of Tapered Gibs	60
4-7. TROUBLESHOOTING FOR SIMPLE MECHANICAL TROUBLE	62
4-7-1. Trouble with Headstock	62
4-7-2. Trouble with Turret	63
4-7-3. Replacing Shear Pin	73
4-7-4. Others	75
SECTION 5 HANDLING AND INSTALLATION OF MACHINE	76
5-1. CARE IN HANDLING A PRECISION MACHINE	76
5-2. FOUNDATION REQUIREMENTS	78
5-3. GENERAL PROCEDURE FOR INSTALLATION	78
5-4. LEVELLING THE MACHINE	80
5-5. POWER REQUIREMENTS	81
SECTION 6 SPARE PARTS LIST	83
6-1. HYDRAULICS	83
6-2. ELECTRICALS (ON MACHINE)	84
6-3. CONSUMABLE ITEMS	85
SECTION 7 TECHNICAL DATA	86
7-1. TOOLHOLDER DIMENSIONS	86
7-2. TOOL INTERFERENCE DIAGRAM	87
7-3. WORKING RANGE DIAGRAM - Model T-2S	88
7-4. WORKING RANGE DIAGRAM - Model C-2S (Dead center)	89
7-5. DIMENSION OF SPINDLE NOSE (JIS-A2-6)	90
7-6. HYDRAULIC POWER CHUCK AND CYLINDER	91
7-7. HYDRAULIC CIRCUIT DIAGRAM	92
7-8. TAILSTOCK (C-2S)	94

	<u>PAGE</u>
SECTION 8 OPTIONAL SPECIFICATIONS	95
8-1. TOUCH SETTER M	95
8-1-1. Outline of Touch Setter M	95
8-1-2. Precautions in Handling Touch Setter	96
8-1-3. Sensor Readjustment	98
8-1-4. Spare Parts	99
8-2. GAUGING ATTACHMENT	100
8-2-1. Overview	100
8-2-2. Operation and Cautions on Operation	101
8-2-3. Inspection and Maintenance	102
8-2-4. Spare Parts	103
8-3. BUILT-IN TAILSTOCK	104
8-3-1. Overview	104
8-3-2. Specifications	104
8-3-3. Tailstock Bearing Life	105

Note 1: To avoid any confusion over the use of the letter "O (oh)" and figure "0 (zero)" in this manual, the numerical value "0 (zero)" is expressed as "Ø" if there is any possibility of misunderstanding.

Note 2: LR series model designations

1S (w/o tailstock)	=	T-1S
2S (w/o tailstock)	=	T-2S
1S w/tailstock	=	C-1S
2S w/tailstock	=	C-2S

