

**WIRE ELECTRICAL DISCHARGE MACHINE**

**EC32/EC64**

(MGW-GL)

**INSTRUCTION MANUAL**

**(MECHANICAL EDITION)**

**MAKINO MILLING MACHINE CO., LTD.**

**6EC4-MC01-9406(E)**



# CONTENTS

|  |                |
|--|----------------|
| <b>1. SPECIFICATION .....</b>  | <b>1-1</b>     |
| <b>1.1 Name of Each Part .....</b>                                     | <b>1-1</b>     |
| <b>1.2 Specifications .....</b>  | <b>1-2</b>     |
| (1) Specifications by model .....                                      | 1-2            |
| (2) Specifications common to EC32 and EC64 .....                       | 1-3            |
| <b>1.3 Axis Assignment .....</b>                                       | <b>1-7</b>     |
| <b>1.4 Machine Coordinate System, Origin and Reference Point .....</b> | <b>1-8</b>     |
| <br><b>2. CAUTIONS FOR SAFETY .....</b>                                | <br><b>2-1</b> |
| <br><b>3. FUNCTIONS AND HANDLING OF MAIN PARTS .....</b>               | <br><b>3-1</b> |
| <b>3.1 Power Switches .....</b>  | <b>3-1</b>     |
| <b>3.2 Z Axis .....</b>  | <b>3-2</b>     |
| (1) Z axis position and taper machining .....                          | 3-2            |
| <b>3.3 Wire System .....</b>   | <b>3-3</b>     |
| <b>3.3.1 Wire path .....</b>   | <b>3-3</b>     |
| <b>3.3.2 Wire delivery .....</b>                                       | <b>3-4</b>     |
| (1) Name of major components .....                                     | 3-4            |
| (2) Wire loading method .....  | 3-8            |
| <b>3.3.3 Wire guide unit (upper) .....</b>                             | <b>3-9</b>     |
| <b>3.3.4 Upper head .....</b>  | <b>3-11</b>    |
| (1) Splashguard .....  | 3-11           |
| <b>3.3.5 Lower head .....</b>  | <b>3-12</b>    |
| (1) Name of main parts .....   | 3-12           |
| (2) Replacing diamond guide and press guide .....                      | 3-13           |
| (3) Replacing the energizing plate .....                               | 3-16           |
| (4) Replacing of V guide .....   | 3-16           |
| (5) Adjustment of nozzle guard height .....                            | 3-18           |
| (6) Replacing dielectric nozzle .....                                  | 3-19           |
| (7) Installation of head cover .....                                   | 3-20           |
| (8) Parts not to be loosened .....                                     | 3-20           |
| <b>3.3.6 Wire guide unit (lower) .....</b>                             | <b>3-21</b>    |
| <b>3.3.7 Wire winding .....</b>  | <b>3-22</b>    |
| <b>3.3.8 Automatic wire threading .....</b>                            | <b>3-23</b>    |
| <b>3.3.9 Wire vertical alignment .....</b>                             | <b>3-23</b>    |
| (1) Wire vertical alignment .....                                      | 3-23           |
| (2) Precautions on wire vertical adjustment .....                      | 3-25           |



|   |      |
|---|------|
| 3.3.10 Line-up between positioning guide and K shaft .....                    | 3-26 |
| 3.4 Taper Cutting Unit .....  | 3-29 |
| 3.4.1 Appearance .....  | 3-29 |
| 3.4.2 Taper machining and mechanical limitation .....                         | 3-29 |
| 3.5 Dielectric Fluid System .....   | 3-31 |
| 3.5.1 Dielectric fluid circuit diagram and dielectric fluid supply unit ..... | 3-31 |
| 3.5.2 Function of each part .....   | 3-33 |
| 3.5.3 Tank filling for dielectric fluid supply unit .....                     | 3-35 |
| (1) Checking before tank filling .....  | 3-35 |
| (2) Tank filling .....  | 3-35 |
| 3.5.4 Replenishment and change of dielectric fluid .....                      | 3-36 |
| (1) Replenishment of dielectric fluid .....                                   | 3-36 |
| (2) Change of dielectric fluid .....  | 3-36 |
| 3.5.5 Change of filter and filter element .....                               | 3-36 |
| (1) Change of dielectric filter .....   | 3-36 |
| (2) Change of jet filter element .....  | 3-37 |
| 3.5.6 Change of ion exchange resin .....                                      | 3-38 |
| 3.5.7 Cleaning of raw water inlet assembly .....                              | 3-39 |
| 3.5.8 Air breathing of flushing pump .....                                    | 3-40 |
| 3.5.9 Others .....  | 3-40 |
| 3.6 Air System .....  | 3-41 |
| 3.6.1 Pneumatic circuit diagram .....   | 3-41 |
| 3.6.2 Function of each part .....   | 3-42 |
| 3.7 Work Tank .....   | 3-44 |
| 3.8 Workpiece Clamping .....  | 3-45 |
| 3.8.1 Machining area .....  | 3-45 |
| 3.8.2 Workpiece fixture .....   | 3-46 |
| 3.8.3 Fasteners .....   | 3-48 |
| 4. OPERATION AT START-UP .....  | 4-1  |
| 4.1 Start-up Procedure .....  | 4-1  |
| 4.2 Checking Before Start of Machining .....                                  | 4-2  |
| (1) Machine .....   | 4-2  |
| (2) Dielectric fluid supply unit .....  | 4-2  |
| 5. OPERATION AT END OF WORK .....   | 5-1  |
| (1) Unloading workpiece .....   | 5-1  |
| (2) Replenishment and change of dielectric fluid .....                        | 5-1  |
| (3) Cleaning each part of machine .....                                       | 5-1  |

|                                 |     |
|---------------------------------|-----|
| (4) Turning the power off ..... | 5-1 |
| 6. INSPECTION .....             | 6-1 |
| 6.1 Periodic Inspection .....   | 6-1 |
| 6.2 Maintenance .....           | 6-1 |