User's Manual

MANUAL No. 4603

PJ311Z·T Profile Projecter with OPTOEYE

Mitutoyo

CONTENTS

1. OUTLINE 1
1.1 Outline 1
1.2 System Configuration 3
1.2.1 PJ311Z3, Z4 (Single mount type with a Zoom lens of 10X - 50X) 4
1.2.2 PJ311T3, T4 (3-mount turret type, with 10X lens) 5
1.3 Nomenclature 6
1.3.1 Projector main unit 6
1.3.2 Control panel 9
1.3.3 Angle unit and X, Y counter 10
1.3.4 Optoeye dispolay panel 11
1.3.5 Rear panel 11
1.3.6 Power panel (Right side) 12

2. SETUP AND ADJUSTMENT 13
2.1 Transport and Setup 13
2.1.1 Transport 13
2.1.2 Environmental conditions 14
2.1.3 Setting up the main unit 15
2.1.4 Removing the carrying handles 15
2.2 Assembly 16
2.2.1 Installing the microstage and Digimatic Head 16
2.2.2 Connecting the external counter 18
2.2.3 Mounting the projection lens 19
2.2.4 Removing the projection lens 19
2.2.5 Setting the power voltage 20
2.2.6 Connecting the power cord 21
2.3 Initial Checks (Functional check) 22
2.3.1 Connectors checks 22
2.3.2 Control panel check 22
2.3.3 Contour illumination control knob 23
2.3.4 Fine focusing knob (PJ311Z4, T4) 23
2.3.5 Focusing wheel (PJ311Z3, T3) 23
2.3.6 Microstage 23
2.3.7 Projection screen 24
2.4 Initial Checks (Performance check) 25
2.4.1 Checking the position of the contour illumination lamp filament 25
2.4.2 Insertion of a color filter 26
2.4.3 Checking the magnification accuracy 27
2.4.4 Checking the microstage travel direction 29
2.4.5 Checking microstage feed error 30
2.4.6 Checking the resolution (in contour illumination mode) 30
2.5 Adjustment 31
2.5.1 Adjusting the magnification (This is performed by the Mitutoyo service personnel) 31
2.5.2 Aligning the microstage travel direction to the cross-hair lines 31

2.5.3 Centering the protractor screen
(This adjustment is performed by the Mitutoyo service personnel) 32

3. OPERATION 35
3.1 Projection Lens Selection 35
3.1.1 Selecting the magnification of the zoom lens (PJ311Z series) 36
3.1.2 Selecting the magnification by the turret (PJ311T series) 38
3.1.3 Note on selecting the magnification 38
3.2 Contour Illuminator Brightness Selector Switch and Method of Projection 39
3.2.1 Projection by the contour illumination 39
3.2.2 Projection by surface illumination 40
3.2.3 Projection by both the contour and surface illumination 41
3.3 Positioning the Workpiece 42
3.4 Focusing and Positioning the Workpiece 44
3.4.1 Focusing 44
3.4.2 Positioning the workpiece 45
3.5 Rectangular coordinate measurement (with the X, Y counter) 46
3.5.1 Function of each part 47
3.5.2 Measurememt without using the optoeye 50
3.5.3 Measurememt using the optoeye 51
3.5.4 Measurememt using hte optoeye and MICROPAK 5 55
3.6 Dimensional measurement using a scale 61
3.7 Comparison with an overlay chart 61
3.8 Angle measurement 62

4. TROUBLESHOOTING 69
4.1 Troubleshooting 69
4.1.1 The power switch is ON,
but the pilot lamp is not lit and the fan motor does not operate 69
4.1.2 The illumination lamp does not light
when the main switch and illumination switches are ON 70
4.1.3 The X, Y-axis counter does not operate when the power switch is ON 71
4.1.4 The angle counter does not operate when the power switch is ON 71
4.1.5 Troubleshooting for abnormal optoeye operation 72
4.1.6 Stickiness or binding is felt in focusing 72
4.1.7 Error is observed in glass scale or overlay chart measurement 73
4.1.8 Abnormal microstage movement, and measurement errors occur 73
4.1.9 Abnormal protractor screen operation 73
4.1.10 Partially obscured image 73

5. MAINTENANCE 75
5.1 Maintenance of Optical Components 75
5.1.1 Projection lens 75
5.1.2 Mirror (surface reflecting mirror) 75
5.1.3 Screen glass 75

5.2 Maintenance of Mechanical Components 76
5.2.1 Projector main unit 76
5.2.2 Microstage 76
5.3 Replacing Disposable Parts 77
5.3.1 Bulbs for contour and surface illuminators 77
5.3.2 Fuse 79
5.3.3 Stage glass 80
5.4 Periodic Inspection 80
5.5 Repair Parts List 81

6. SPECIFICATIONS 83
6.1 Specifications 83
6.1.1 PJ311Z3 specifications 83
6.1.2 PJ311Z4 specifications 84
6.1.3 PJ311T3 specifications 85
6.1.4 PJ311T4 specifications 86
6.1.5 Edge sensor specification 87
6.1.6 Data output 88
6.1.7 Connector pin assignemt 91
6.1.8 Dip switch 92
6.2 Performance Table for the PJ311 Series Profile Projector 93
6.3 Optical Path 94
6.4 Dimensions 95
6.4.1 PJ311Z series main unit 95
6.4.2 PJ311T series main unit 96
6.4.3 Microstage 97
6.5 Accessories 98
6.5.1 Standard accessories (PJ311Z3, Z4) 98
6.5.2 Standard accessories (PJ311T3, T4) 98
5.5.3 Optional Accessories 99
6.6 System Configuration 101
6.7 Electric circuit diagram 103
6.7.1 Electric cirucit diagram (PJ311Z3,T3) 103
6.7.2 Electric circuit diagram (PJ311Z4,T4) 104

APPENDICES 105
1 Alignment Error 105
1.1 Alignment methods 105
1.2 Errors due to Workpiece Edge Conditions 106
2 Observation Error of Contour in Cylinder Measurement 107
MSPC (Mitutoyo Statistical Process Control) System 110

SERVICE NETWORK 114