AMADA CAM

OPERATORS MANUAL

Revision 1
Release Date: March 5, 1993

U.S. AMADA, LTD.
7025 Firestone Blvd.
Buena Park, CA 90601

AMADA CAM

TABLE OF CONTENTS

CHAPTER 1 - GENERAL INFORMATION

INTRODUCTION 1-1
OVERVIEW 1-1
SPECIAL FEATURES 1-2
HUMAN ENGINEERING 1-2
PROGRAM AIDS 1-2
PART DESIGN AND PROGRAM SEQUENCE VERIFICATION . . . 1-2
CONFIGURABILITY 1-3
HARDCOPY SUPPORT 1-3
FILE MANAGEMENT 1-3
PROGRAM TRANSFER 1-3
BACKWARD COMPATIBILITY 1-4
CONVENTIONS USED IN THIS MANUAL 1-4
SELECTION TECHNIQUES 1-5
MOVING THE HIGHLIGHT BAR 1-5
TYPING THE COMMAND LETTER 1-5
DYNAMIC LISTS 1-5
FUNCTION KEYS 1-6
ESC KEY 1-6

CHAPTER 2 - HARDWARE SETUP

SUPPLIED EQUIPMENT 2-1
MINIMUM HARDWARE REQUIREMENTS 2-1
SECURITY BLOCK INSTALLATION 2-2

CHAPTER 3 - SETUP AND SOFTWARE INSTALLATION

INITIAL SETUP 3-1
INSTALLING THE SOFTWARE 3-1
VERIFYING THE CONFIG.SYS AND AUTOEXEC.BAT FILES 3-6
THE AUTOEXEC.BAT FILE 3-6
THE CONFIG.SYS FILE 3-7
ALLOCATING MORE MEMORY 3-8
UPDATING YOUR MENU PROGRAM 3-8

CHAPTER 4 - SYSTEM CONFIGURATION

THE CONFIGURATION MENU 4-1
DISPLAY AND COLOR MONITOR 4-3
SET COLOR INDEX 4-4
HARD COPY PARAMETERS 4-5
PLOTTER COM PORT 4-5
HARD COPY DEVICE 4-6
PLOTTER X LENGTH 4-7
PLOTTER Y LENGTH 4-7
PLOTTER ORIENTATION 4-8
PLOT SINGLE HIT FOR G78/G79 4-9
PLOTTER BAUD RATE 4-9
GRAPHIC POINTER DEVICE 4-10
DIGITIZER X LENGTH 4-10
DIGITIZER Y LENGTH 4-11
MAX NUMBER OF PROGRAMS 4-11
DNC COM PORT 4-12
TAPE PUNCHER/READER COM PORT 4-12
SAVING THE NEW CONFIGURATION 4-12
CHANGING COLORS 4-13
FOR ALL MONITORS/DRIVERS EXCEPT TECMAR 4-13
HUE VALUE 4-14
SATURATION VALUE 4-14
LIGHTNESS VALUE 4-14
FOR TECMAR MONITORS/DRIVERS 4-15

CHAPTER 5 - DATA ORGANIZATION

STORAGE DIRECTORIES 5-1
ROOT DIRECTORY 5-1
DIRECTORIES 5-1
SUBDIRECTORIES 5-2
FILES 5-2
REACHING A FILE 5-3
HANDLING DIRECTORIES AND FILES 5-3
LISTING FILES 5-3
AMADA CAM 5-3

DOS 5-3
THE AMADA CAM DIRECTORY 5-4
FILE TYPES AND FILENAME EXTENSIONS 5-6
UTILITY FILES 5-6
MACHINE PARAMETER FILES 5-6
PROGRAM FILES 5-7
RELATIONSHIP BETWEEN MACHINE PARAMETER FILES AND PROGRAM FILES 5-7
MACHINE PAGE 5-7
TOOL PAGE 5-8

CHAPTER 6 - GETTING STARTED

STARTING THE PROGRAM 6-1
EDIT G-CODE/GRAPHIC PLOT SIMULATOR 6-2
FILE MANAGEMENT/STORAGE 6-2
2D CAD/CAM 6-2
POST PROCESSOR/OPTIMIZER 6-2
HARDCOPY CAD PLOT/DRAWING 6-2
DNC DATA TRANSFER 6-2
04PC/2000PA SMART DNC 6-2
TAPE PUNCH/READ 6-2
MACHINE PARAMETER MANAGEMENT 6-2
SYSTEM UTILITIES 6-2
QUIT 6-2

CHAPTER 7 - EDITOR GENERAL INFORMATION

THE EDITOR 7-1
STARTING THE EDITOR 7-1
START-UP PROMPT 7-2
CREATING A NEW FILE 7-2
EDITING AN EXISTING FILE 7-3
RESUMING THE PREVIOUS EDIT 7-3
CANCELING AN EDIT 7-3
EDITING DISPLAY FORMAT 7-4
STATUS LINE 7-4
PULLDOWN MENU 7-5
CLOSING A SUBMENU 7-6

FUNCTION KEY LABELS 7-6
PROGRAM CONFIGURATION 7-6
MACHINE AND TOOL CONFIGURATION 7-6
SHEET AND SIMULATION PARAMETER SETUP 7-7
ENTERING G-CODE STATEMENTS 7-7
PLACING COMMENTS IN G-CODE PROGRAM 7-7
BLOCK SKIP 7-8
LINE NUMBERS AND STATEMENT NUMBERS 7-8
CONCLUDING AN EDIT 7-8

CHAPTER 8 - EDITOR PROGRAMMING AIDS

EDITOR PROGRAMMING AIDS 8-1
THE HELP KEY (F1) 8-1
G-CODE 8-2
FUNCTION KEYS 8-3
EDITOR COMMANDS 8-4
ONLINE HELP 8-5
SYNTAX CHECKING 8-6
SYNTAX CHECK MENU 8-6
WHOLE G-CODE CHECK 8-6
ON-LINE CHECKING 8-6
ERROR HANDLING 8-6
SYNTAX ERRORS 8-7
DESIGN ERRORS 8-7
BUFFER ERROR-FLAGGING 8-7
SYNTAX ERROR DETECTION 8-7
DESIGN ERROR DETECTION 8-7
NON-DETECTABLE DESIGN ERRORS 8-8
ERROR CODES 8-8
ERROR HANDLING FUNCTIONS MENU 8-8
ERROR HANDLING OPERATIONS 8-9
SER-ER FUNCTION KEY 8-9
MATHEMATICS PACKAGE 8-10
MEMORY PAD 8-10
INSERTING MEMORY PAD VALUES INTO G-CODE STATEMENTS 8-11
USING MEMORY PAD VALUES IN MATH FUNCTIONS 8-11
UPDATING VALUES IN THE MEMORY PAD 8-11

INPUT FIELDS 8-11
OUTPUT FIELDS 8-12
EXPRESSION RULES 8-12
MATH FUNCTIONS MENU 8-13
MATH FUNCTIONS DISPLAY DYNAMICS 8-13
FUNCTION NAME 8-14
DIRECTIONS/ERRORS 8-14
PROBLEM DEFINITION 8-15
BASIC STEPS IN USING THE MATH FUNCTIONS 8-17
SOLVE FORMULA FUNCTION 8-18
FILLET (CORNER RADIUS) 8-18
TANGENT LINE(S) FROM ONE POINT TO A CIRCLE 8-19
TANGENT LINE(S) BETWEEN TWO CIRCLES 8-19
TANGENT OF TWO CIRCLES 8-20
INTERSECTION OF A LINE TO A CIRCLE 8-20
INTERSECTION BETWEEN TWO CIRCLES 8-20
LINE BETWEEN TWO POINTS 8-21
TANGENT LINE TO A CIRCLE 8-21
INTERSECTION OF TWO LINES 8-21
LINE MOVE LEFT OR RIGHT 8-22
LINE ROTATE 8-22

CHAPTER 9 - EDITOR CONFIGURATION FUNCTIONS

TOOL AND MACHINE CONFIGURATION 9-1
ASSOCIATED MACHINE PARAMETER FILE 9-1
DEFAULT MACHINE PARAMETER FILE 9-2
WORKING COPY MACHINE PARAMETER FILE 9-2
INITIALIZATION OF WORKING COPY MACHINE PARAMETER FILE 9-2
TOOL/MACHINE FUNCTIONS MENU 9-3
TOOL/MACHINE OPERATIONS 9-3
TOOL CHANGE (F2) 9-4
OFFSET CHANGE (PLASMA) 9-6
USED TOOL LIST 9-7
MACHINE SELECT 9-7
PRINT TOOL LIST 9-8
DISPLAY MACHINE PARAMETERS 9-8

AUTO UPDATE TOOL 9-8
FUNCTION KEYS 9-9
TOOL KEY (F2) 9-9
SETUP 1 (F3) 9-9
SETUP 2 (F4) 9-10
DEFAULT SETUP PAGE FIELD VALUES 9-10
REQUIRED UPDATES 9-11
MODIFYING FIELDS 9-11
FIELD FORMATS AND LEGAL VALUES 9-12
USE OF FIELDS 9-12
SAVING THE SETUP PAGE 9-13

CHAPTER 10 - EDITOR WORD PROCESSING FUNCTIONS

EDITOR WORD PROCESSING FUNCTIONS 10-1
CTRL KEY USE AND NOTATION 10-1
BASIC EDITING FUNCTIONS 10-2
ON-LINE COMMAND SUMMARY 10-2
ENABLING INSERT MODE 10-3
INSERTING CHARACTERS 10-3
INSERTING LINES 10-3
DELETE FUNCTIONS 10-4
SCROLLING FUNCTIONS 10-4
CURSOR MOVEMENT COMMANDS 10-4
RELATIVE CURSOR MOVES 10-4
"GOTO" CURSOR MOVES 10-5
TEXT BLOCK FUNCTIONS 10-5
BLOCK FUNCTIONS MENU 10-5
MARKING TEXT BLOCKS 10-6
BLOCK OPERATIONS 10-7
COPY 10-7
MOVE 10-7
DELETE 10-7
WRITE 10-7
READ 10-7
BLOCK HIDE/SHOW 10-8
BRANCH AND SEARCH FUNCTIONS 10-8
GOTO/FIND FUNCTIONS MENU 10-8

GOTO OPERATION (TOP, END, LINE, COLUMN) 10-9
TOP OF FILE 10-9
END OF FILE 10-9
LINE 10-9
COLUMN 10-9
FIND AND FIND/REPLACE 10-10
FIND 10-10
FIND/REPLACE 10-11
SEARCH OPTIONS WINDOW 10-11
G (GLOBAL SEARCH) 10-11
B (BACKWARD SEARCH) 10-11
U (IGNORE UPPER/LOWER CASE SETTING) 10-11
W (ONLY MATCH ON STRING IF A WHOLE WORD) . . . 10-11
N (NO CONFIRMATION) 10-12
1..9 10-12
GN (WHOLE FILE-NO CONFIRMATION) 10-12
FIND FUNCTION KEY 10-12
WINDOW FUNCTIONS 10-12
WINDOW FUNCTIONS MENU 10-12
WINDOW OPERATIONS (SELECT, OPEN, CLOSE) 10-13
SELECT 10-13
OPEN 10-13
CLOSE 10-13

CHAPTER 11 - GRAPHICS PROCESSOR

STARTING UP THE MACHINE G-CODE SIMULATOR/ GRAPHICS PROCESSOR 11-1
RETURNING TO THE EDITOR 11-1
GRAPHICS CURSOR 11-2
CURSOR MOVEMENT KEYS 11-2
MOUSE USAGE 11-3
LOGITECH MOUSE: 3 BUTTONS 11-3
MICROSOFT MOUSE: 2 BUTTONS 11-3
CURSOR COORDINATES 11-3
CURSOR MOVEMENT UNIT 11-3
CURSOR TRAVEL MODE 11-4
DRAWING SCALE 11-4

ATTACHED MONITOR COLOR SCHEME 11-4
LOCAL BLACK/WHITE SCHEME 11-4
DRAWING SYMBOLS 11-5
CLAMP SYMBOLS 11-5
WORKHOLDER SYMBOLS 11-5
MOVE SYMBOL 11-5
DRAWING SPEED CONTROL 11-6
THE "FIRST DRAW" 11-6
SUBSEQUENT DRAWS 11-6
IDLE MODE 11-6
GRAPHICS FUNCTION MENU 11-7
COMMAND SHORTHAND 11-7
PARAMETERS PROMPTS 11-8
TYPING COORDINATES 11-8
SNAPPING COORDINATES 11-8
TABLE OF FUNCTION PARAMETERS 11-9
ARC (G29) 11-9
LINE AT ANGLE (G28) 11-10
GRID (G36/G37) 11-10
BOLT HOLE CIRCLE (G29) 11-11
NIBBLING ARC (G68)/PUNCHING ARC (G78)/ PLASMA ARC (G02 or G03) 11-12
NIBBLING ARC (G69)/PUNCHING ARC (G79)/ PLASMA ARC (G01) 11-13
RECTANGULAR CUTOUT (G67) 11-14
SHEAR PROOF (G66) 11-14
GRAPHICS OPERATIONS 11-15
ZOOM 11-15
PAN 11-15
RECALL VIEW 11-15
WHOLE VIEW 11-15
ADD A GRID 11-15
ERASE GRIDS 11-15
MEASURE 11-16
SELECT POINT 11-16
CHOOSE PATTERN 11-16

HARDCOPY PLOT 11-17
HARDCOPY PLOT TO DISK FILE 11-20
CALLING ZOOM OR PAN WHILE IN ANOTHER FUNCTION . . 11-20
USE OF SETUP PAGE PARAMETERS IN GRAPHICS PROCESSING 11-20
SHEET SIZE 11-20
CLAMPS 11-20
BLOCK SKIP 11-20
MULTIPLE PARAMETERS 11-21
ENGLISH/METRIC 11-21
USING IDENTITY LINE OPTION FROM EDITOR 11-21

CHAPTER 12 - EDITOR FILE MANAGEMENT FUNCTIONS

OVERVIEW 12-1
FORMAT OF FILENAME PROMPT 12-1
DEFAULT PATH IN FILENAME PROMPTS 12-1
SPECIFYING ALTERNATE PATHS 12-2
SPECIFYING FILENAMES 12-2
WHAT GETS SAVED 12-2
WHAT DOES NOT GET SAVED 12-3
FILE FUNCTIONS MENU 12-3
FILE OPERATIONS 12-3
FINISH 12-3
SAVE AND CONTINUE 12-3
QUIT 12-4
MERGE 12-4
WRITE 12-4
PRINT 12-4
DIR 12-5
FINISH FUNCTION KEY 12-5
RESCUE FILE 12-6

CHAPTER 13 - FILE MANAGEMENT/STORAGE

OVERVIEW 13-1
FILE MANAGEMENT/STORAGE MAIN MENU 13-1
THE SYSTEM DEFAULT DIRECTORY 13-2
LIST PROGRAMS 13-2
DELETE 13-3

BUILD 13-4
SEARCH 13-4
EDIT 13-5
PRINT DIRECTORY (PR-DIR) 13-6
PRINT FILE (PR-FIL) 13-7
RENAME 13-10
DISPLAY FILE (DISFIL) 13-11
FINISH 13-14
SELECT DRIVE 13-15
CHANGE DIRECTORY 13-16
ADD A DIRECTORY 13-17
DELETE A DIRECTORY 13-18
BACKUP A DIRECTORY 13-18
FORMATTING A FLOPPY DISK 13-20
WHOLE DIRECTORIES BACKUP 13-22
CURRENT DIRECTORY BACKUP 13-22
MODIFIED FILES BACKUP 13-23
SPECIFIED FILES BACKUP 13-23
RESTORE A DIRECTORY 13-23
WHOLE DIRECTORIES RESTORE 13-24
SPECIFIED FILES RESTORE 13-25
TRANSFER TO/FROM ARIES 13-26
ESCAPE TO MAIN MENU 13-27

CHAPTER 14 - POST PROCESSOR/OPTIMIZER

POST PROCESSOR/OPTIMIZER MAIN MENU 14-1
CAD/CAM TO G-CODE CONVERSION 14-1
G-CODE TO CAD/CAM CONVERSION 14-3
SINGLE HIT CONVERSION 14-4
TOOL SORT 14-7
BASIC ALGORITHM 14-7
AUTO REPOSITIONING 14-7
CLAMP DEADZONE AVOIDANCE 14-7
PATTERN BREAKING 14-8
SPECIFYING THE BLOCK 14-8
STARTING BLOCK 14-9
MIDDLE BLOCK 14-9

ENDING BLOCK 14-9
TOOL PATH OPTIMIZATION 14-10
MULTIPLE PART GENERATION 14-18
TOOL PRIORITY 14-20
QUADRANT AND DIRECTION 14-21
GENERATING MULTIPLE PARTS FROM A G-CODE PROGRAM 14-25
ACCURATE TIME STUDY 14-26
EXTRA POST PROCESSOR 14-28
BLANK SHEET REGISTRATION 14-28
SAVE 14-30
QUIT 14-30
PRINT 14-31
ERASE 14-31
INSERT 14-32
RETURN TO MAIN MENU 14-32

CHAPTER 15 - HARDCOPY CAD PLOT/DRAWING

HARDCOPY CAD PLOT/DRAWING 15-1

CHAPTER 16 - DNC DATA TRANSFER

DNC DATA TRANSFER 16-1
PARAMETERS 16-2
6M CONTROL 16-2
AMADAN 04-PC 16-2
AMADAN 04-PA 16-2
DOWNLOAD TO 6M CONTROL 16-3
DOWNLOAD TO MC 2000 PA 16-5
DOWNLOAD TO 04P-A 16-5
DOWNLOAD TO 04P-C 16-5
UPLOAD TO 6M CONTROL 16-6
UPLOAD TO MC 2000 PA 16-7
UPLOAD TO 04P-A 16-7
UPLOAD TO 04P-C 16-7

CHAPTER 17 - SMART DNC

INTRODUCTION 17-1
CABLE CONNECTIONS 17-1
CNC PARAMETERS 17-2

SELECTING PART PROGRAMS ON A DIRECTORY PAGE 17-2
SMART DNC 17-3
SMART DNC 04PC MAIN MENU 17-3
CONFIGURATION 17-4
SMART DNC SEND DATA MENU 17-5
PROGRAM & SETUP 17-6
JOB SCHEDULE 17-7
QUIT 17-8
SMART DNC RECEIVE DATA MENU 17-9
PROGRAM & SETUP 17-9
JOB SCHEDULE 17-11
DIRECTORY 17-13
QUIT 17-14
SMART DNC DELETE DATA MENU 17-15
SINGLE PROGRAM & SETUP 17-15
MULTI-PROGRAM & SETUP 17-16
QUIT 17-18
SEND MAIL 17-19
EDIT 17-22
SETUP 17-22
JOB SCHEDULE 17-26
QUIT 17-27

CHAPTER 18 - TAPE PUNCH/READ

TAPE PUNCH 18-1
PUNCHING PAPER TAPES 18-2
READING PAPER TAPES 18-5
SPECIFY FILE NAME 18-5
READ TO EDIT FILE 18-6

CHAPTER 19 - MACHINE PARAMETER MANAGEMENT

MACHINE PARAMETER FILES 19-1
MACHINE PARAMETER FILE COMPONENTS 19-1
MACHINE PARAMETER MANAGEMENT 19-1
DISPLAY/MODIFY MACHINE PARAMETER FILE 19-2
SELECTING THE MACHINE PARAMETER FILE 19-2
CHANGING THE MACHINE PAGE 19-3
MACHINE PAGE FIELDS 19-3

MACHINE NAME 19-3
TABLE SIZE AND OVERTRAVEL 19-4
UNITS 19-4
CONTROLLER 19-4
TURRET TYPE 19-4
NIBBLE PITCH 19-4
NIBBLE ANGLE 19-4
HIT RATE 19-5
PRESS STROKE 19-5
FEED RATE 19-5
DEFAULT VALUES 19-5
CLAMP TYPE 19-5
PLASMA ATTACHED 19-5
EXTRA MEMORY 19-5
NOZZLE TYPE 19-5
PAPERTAPE CODE 19-5
MAX MACRO MEMORY 19-5
MACHINE PAGE FUNCTION KEYS 19-6
QUIT (<F3>) 19-6
SELECT (<F5>) 19-6
VIPROS (<F6>) 19-6
TOOL (<F7>) 19-6
PLASMA (<F8>) 19-6
DEADZONE (<F9>) 19-7
SAVE (<F10>) 19-7
CHANGING THE TOOL PAGE 19-8
TYPE 19-9
X-SIZE 19-9
Y-SIZE 19-9
ANGLE 19-9
RADIUS 19-9
DIE-C 19-9
FILENAME 19-9
TOOL TYPES AND REQUIRED DIMENSIONS 19-10
CHANGING THE PLASMA OFFSET PAGE 19-11
CHANGING THE DEADZONE PAGE 19-12

SPECIAL HEEL TOOL SUPPORT 19-12
MACHINE PARAMETER FILE ADDITION 19-13
VIPROS SUPPORT 19-13
ERASE MACHINE PARAMETER FILE 19-13

CHAPTER 20 - SYSTEM UTILITIES

THE UTILITY SUBSYSTEM MENU 20-1
UPDATE DATA FILE FROM AMPUNCH 1C TO 1E (1400) 20-2
DATA CONVERSION FROM AMPUNCH 1 (1200) TO 1E (1400) . . . 20-3
SYSTEM CONFIGURATION DEFINE 20-5
PLASMA CYCLE TIME FILE MAINTENANCE 20-6
DISPLAY/MODIFY TIME STUDY FIELD 20-6
ADDITION TIME STUDY FILE 20-8
ERASE TIME STUDY FILE 20-9
TURRET TABLE MAINTENANCE 20-10
DISPLAY/MODIFY TURRET FILE 20-11
TURRET FILE ADDITION 20-12
ERASE TURRET FILE 20-14
MACHINE TABLE MAINTENANCE 20-15
BUILD SPECIAL TOOL 20-17
SPECIAL TOOL PROGRAM FORMAT 20-17
USING BUILD SPECIAL TOOL 20-18
MODIFYING AN EXISTING SPECIAL TOOL FILE 20-19
CREATING A NEW SPECIAL TOOL FILE 20-20
HOW TO USE A SPECIAL TOOL 20-21
FILE TRANSFER UTILITY 20-22
UPDATE CAD DIRECTORY 20-25
VIPROS SLOTTING PARAMETER 20-27
SLOTTING TOOL 20-27
SLOTTING CUT 20-27
FORMING AND MARKING TOOL 20-28
GENERATION OF G60 CODES 20-28
SLOTTING PARAMETER 20-28
VIPROS PITCH & SPEED TABLE 20-30
VIPROS TOOL & M-CODE TABLE 20-32

VIPROS INVENTORY TOOL MAINTENANCE 20-33
<F2>-BACKUP 20-34
<F3>-EDIT 20-35
<F4>-SORT 20-35
<F5>-RULES 20-35
<F6>-UNITS 20-37
<F7>-ADD 20-38
<F8>-RESTORE 20-38
<F9>-PRINT 20-39
<F10>-EXIT 20-39
AUTO TOOL FITTING PRIORITY 20-40
PLOT MAXIMUM AREA 20-41
RETURN TO MAIN MENU 20-42

APPENDIX A
SYNTAX ERROR CODES A-1
APPENDIX B
SMART DNC ERROR CODES B-1