INSTRUCTION MANUAL

VERTICAL MACHINING CENTER

FNC128-A

(Spindle Head of 8000 rpm)

(PROFESSIONAL 3)

MAKINO MILLING MACHINE CO., LTD.

No. FN1022-92

CONTENTS

Page

A. SPECIFICATIONS

1. GENERAL A-1
2. MAIN DIMENSIONS AND VALUES A-5
3. EXTERNAL DIMENSIONS DIAGRAM A-19
4. LAYOUT DRAWING A-20

B. INSTALLATION

1. SELECTING THE MACHINE LOCATION B-1
2. ARRANGEMENT B-1
3. POWER AND AIR SUPPLIES B-1
4. FOUNDATION B-1
5. HOISTING B-3
6. INSTALLATION B-6
7. PIPING AND WIRING B-8
8. LUBRICATION B-15
9. PREPARATIONS FOR OPERATION B-20
10. TURNING THE POWER ON B-24
11. LEVELING B-27

C. OPERATION

1. PARTS DESIGNATION C-1
2. SAFETY MEASURES C-2
3. HANDLING MAIN CONTROL PARTS C-3
4. EMERGENCY STOP C-12
5. PROCEDURE FOR START-UP C-15
6. RUNNING C-16
7. PROCEDURE FOR SHUT-DOWN C-26

D. SPINDLE HEAD

1. PARTS DESIGNATION D-1
2. HOW TO HANDLE THE MAIN PARTS D-2
3. HOW TO OPERATE THE SPINDLE D-5
4. SPINDLE LOAD METER (Fig. 2.1 ④) D-7

E. LUBRICATING UNIT

1. SPINDLE TEMPERATURE CONTROLLER E-1
2. AUTOMATIC LUBRICATOR E-6

CONTENTS - (cont'd)

Page

F. COOLANT UNIT

1. PARTS DESIGNATION F-1

2. HOW TO HANDLE THE MAIN PARTS F-2

G. ATC UNIT

1. PARTS DESIGNATION G-1

2. HOW TO HANDLE THE MAIN PARTS G-2

3. OPERATION G-6

4. RETURN FROM EMERGENCY STOP MIDWAY THROUGH ATC OPERATION G-13

H. HYDRAULIC & PNEUMATIC UNITS

1. HYDRAULIC UNIT H-1

2. PNEUMATIC UNIT H-5

SPECIFICATIONS

CONTENTS

		Page
1.	GENERAL	A-1
1.1	General View of the Machine and Nomenclature of Each Part.	A-1
1.2	Description of Each Part	A-2
2.	MAIN DIMENSIONS AND VALUES	A-5
2.1	Machine	A-5
2.1.1	Range of movement	A-5
2.1.2	Spindle (See Figs. 2.1 and 2.2)	A-5
2.1.3	Table	A-5
2.1.4	Feed	A-5
2.1.5	Machine zero point	A-6
2.1.6	ATC unit	A-6
2.1.7	Hydraulic unit	A-7
2.1.8	Coolant unit	A-7
2.1.9	Pneumatic supply	A-7
2.1.10	Power sources	A-9
2.1.11	Power supply	A-9
2.1.12	Machine weight	A-9
2.1.13	Options	A-10
2.2	Numerical Control Unit (PROFESSIONAL 3)	A-11
3.	EXTERNAL DIMENSIONS DIAGRAM	A-19
4.	LAYOUT DRAWING	A-20

INSTALLATION

CONTENTS

		Page
1.	SELECTING THE MACHINE LOCATION	B-1
2.	ARRANGEMENT	B-1
3.	POWER AND AIR SUPPLIES	B-1
4.	FOUNDATION	B-1
5.	HOISTING	B-3
6.	INSTALLATION	B-6
7.	PIPING AND WIRING	B-8
7.1	Piping and Wiring of Coolant Unit	B-8
7.2	Piping and Wiring of Spindle Temperature Controller	B-10
7.3	Connecting the Air Supply	B-11
7.4	Wiring of Pendant Type Main Control Box	B-13
7.5	Connecting the Power Supply	B-14
8.	LUBRICATION	B-15
8.1	Lubricating Oil	B-15
8.2	Hydraulic Oil	B-19
9.	PREPARATIONS FOR OPERATION	B-20
9.1	Wiping off the Rust Preventive	B-20
9.2	Removing the Clamps	B-20
10.	TURNING THE POWER ON	B-24
11.	LEVELING	B-27

OPERATION

MACHINE BODY

CONTENTS

		Page
1.	PARTS DESIGNATION	C-1
2.	SAFETY MEASURES	C-2
3.	HANDLING MAIN CONTROL PARTS	C-3
3.1	Main Power Switch	C-3
3.2	Main Control Box	C-4
3.2.1	Main control panel	C-5
3.2.2	Portable control panel	C-7
4.	EMERGENCY STOP	C-12
5.	PROCEDURE FOR START-UP	C-15
5.1	Turning On Power	C-15
5.2	Confirming Air Pressure	C-15
6.	RUNNING	C-16
6.1	Manual Operations (manual mode)	C-16
6.1.1	Jog feed (manual feedrate)	C-16
6.1.2	Manual rapid traverse	C-16
6.1.3	Handle feed	C-17
6.1.4	Manual reference point return	C-18
6.2	Automatic Operation	C-19
6.2.1	Automatic operation mode	C-19
6.2.2	Set-up for automatic operation	C-20
6.2.3	Start-up of automatic operation	C-21
6.2.4	Temporary stop and restart of automatic operation	C-22
6.2.5	Shut-down of automatic operation	C-25
7.	PROCEDURE FOR SHUT-DOWN	C-26
7.1	Shut-Off Power Supply	C-26
7.2	Cleaning the Surrounding Area	C-26

SPINDLE HEAD

CONTENTS

		Page
1.	PARTS DESIGNATION	D-1
2.	HOW TO HANDLE THE MAIN PARTS	D-2
2.1	Control Panel	D-2
2.1.1	Main control panel (Fig. 2.1)	D-2
2.1.2	Spindle clamp/unclamp button (Fig. 2.2)	D-3
2.2	Turning the Spindle Manually	D-4
2.3	Prohibitions	D-4
3.	HOW TO OPERATE THE SPINDLE	D-5
3.1	Starting and Stopping the Spindle	D-5
3.2	Spindle Specified Angle Stop (Orientation)	D-5
3.3	Loading and Unloading a Tool	D-6
4.	SPINDLE LOAD METER (Fig. 2.1 (4))	D-7

LUBRICATING UNIT

CONTENTS

		Page
1.	SPINDLE TEMPERATURE CONTROLLER	E-1
1.1	Nomenclature	E-1
1.2	Operation	E-3
1.3	Change of Spindle Lubricant	E-4
1.4	Spindle Lubricant	E-5
2.	AUTOMATIC LUBRICATOR	E-6
2.1	Nomenclature	E-6
2.2	Operation	E-7
2.3	Lubricating Oil	E-7

COOLANT UNIT

CONTENTS

		Page
1.	PARTS DESIGNATION	F-1
2.	HOW TO HANDLE THE MAIN PARTS	F-2
2.1	Coolant and Air Blow ON/OFF Switches	F-2
2.2	Standard Coolant	F-2
2.2.1	Coolant nozzle and flow adjusting valve	F-2
2.2.2	Applicable coolants	F-3
2.3	Air Blow	F-3

ATC UNIT

CONTENTS

		Page
1.	PARTS DESIGNATION	G-1
2.	HOW TO HANDLE THE MAIN PARTS	G-2
2.1	Control Panel	G-2
2.1.1	ATC magazine operation panel (Fig. 2.1)	G-2
2.2	Limited Weight and Size of Tools	G-2
2.3	Loading/Unloading a Tool On/From the Tool Magazine	G-4
3.	OPERATION	G-6
3.1	ATC Unit Stand-By	G-6
3.2	Registering Tool Number	G-6
3.2.1	Method to enter the tool numbers sequentially from pot 01 (reference pot)	G-7
3.2.2	How to register the tool number of a specific pot only	G-9
3.3	Calling a Tool	G-11
3.4	Automatic Tool Changing by MDI Procedure	G-11
3.5	Automatic Tool Changing by Tape Operation or Memory Operation	G-12
4.	RETURN FROM EMERGENCY STOP MIDWAY THROUGH ATC OPERATION	G-13

HYDRAULIC & PNEUMATIC UNITS

CONTENTS

		Page
1.	HYDRAULIC UNIT	H-1
1.1	Nomenclature	H-1
1.2	Hydraulic Oil Heating Switch	H-2
1.3	Operation	H-3
1.4	Hydraulic Oil	H-4
2.	PNEUMATIC UNIT	H-5
2.1	Nomenclature	H-5
2.2	Lubricating Oil	H-7