TOOL LIFE MANEGEMENT/
CUTTING MONITOR/
INDIVIDUAL TOOL NO. FUNCTION

MICON 16 – III

INSTRUCTION MANUAL

MONICOS – AIII M

10–1993

SEIKI Hitachi Seiki Co.,Ltd.

CONTENTS

I. TOOL LIFE MANAGEMENT ..... 1 - 1

1 Tool Life Management ..... 1 - 1

1.1 Function ..... 1 - 1

1.2 Motion ..... 1 - 1

1.3 Unit of life ..... 1 - 2

1.4 Tool condition ..... 1 - 3

2 Spare Tool Management ..... 1 - 3

2.1 Function ..... 1 - 3

2.2 Motion ..... 1 - 3

2.3 Designation of offset ..... 1 - 4

2.4 Spare tool data ..... 1 - 4

3 Tool Check Before Machining ..... 1 - 4

3.1 Function ..... 1 - 4

3.2 Motion ..... 1 - 4

4 Tool Skip, Tool Reset (Option) ..... 1 - 5

5 Program of Tool Life Management ..... 1 - 5

5.1 Exclusive M code for tool life ..... 1 - 5

5.1.1 Stop/release of tool life and cutting monitoring function (M54/M53) ..... 1 - 5

5.1.2 Stop/release of feedhold by expired tool (M56/M55) ..... 1 - 5

5.1.3 Offset/release of spare tool offset (M45/M46) ..... 1 - 5

5.1.4 Tool check before machining (M51/M59) ..... 1 - 6

5.1.5 Automatic setting of life data (M57/M59) ..... 1 - 7

5.2 Example pf program ..... 1 - 8

6 Operation of Tool Life ..... 1 - 9

6.1 Preparation of operation ..... 1 - 9

6.2 Machining operation ..... 1 - 9

6.3 Tool change ..... 1 - 9

6.4 Operating procedure of tool life ..... 1 - 9

7 Tool Life Screen ..... 1 - 10

7.1 Setting of tool name ..... 1 - 11

7.2 Setting of life unit ..... 1 - 12

7.3 Setting of life value ..... 1 - 12

7.4 Deletion of use, setting data ..... 1 - 12

8 Spare Tool Screen ..... 1 - 13

8.1 Setting of call up No. ..... 1 - 14

8.2 Setting of tool name ..... 1 - 14

8.3 Setting of life unit ..... 1 - 14

8.4 Setting of life value ..... 1 - 15

8.5 Registration of call up No. (Spare group) ..... 1 - 15
8.6 Deletion of call up No. (Spare group) ..... 1 - 15
8.7 Registration of spare tool ..... 1 - 15
8.8 Deletion of spare tool ..... 1 - 16
9 Screen of Tool Condition List ..... 1 - 16
9.1 Deletion and skip of tool condition ..... 1 - 17
9.2 Display of defective tool list ..... 1 - 18
10 Parameter of Tool Life Management and Its Setting ..... 1 - 18
10.1 Display method of parameter ..... 1 - 18
10.2 Setting method of parameter ..... 1 - 18
10.3 Parameter of tool life relations ..... 1 - 19
11 Alarm ..... 1 - 19

II. CUTTING MONITOR ..... 2 - 1
1 Outline ..... 2 - 1
2 Monitoring Method ..... 2 - 1
2.1 Monitoring axis ..... 2 - 1
2.2 Unit of monitoring data ..... 2 - 2
2.3 Selection of monitoring function ..... 2 - 2
3 Monitoring Function ..... 2 - 2
3.1 Overload detection ..... 2 - 2
3.2 Noload detection ..... 2 - 2
3.3 Wear detection ..... 2 - 3
3.4 Adaptive control (Feedrate override control) ..... 2 - 4
3.5 Reduction of air cutting time (Feedrate override control) ..... 2 - 4
4 Program of Cutting Monitor ..... 2 - 5
4.1 Exclusive M code for cutting monitor ..... 2 - 5
4.1.1 Stop or release of tool life and cutting monitoring function (M54/53) ..... 2 - 5
4.1.2 Automatic setting of monitoring data (M58/M59) ..... 2 - 5
4.2 Example of program ..... 2 - 7
5 Setting of Data ..... 2 - 8
5.1 Selection of main monitoring axis ..... 2 - 8
5.2 Selection of monitoring function ..... 2 - 8
5.3 Setting of monintoring data ..... 2 - 8
5.3.1 Manual setting ..... 2 - 8
5.3.2 Automatic setting ..... 2 - 9
5.4 Monitoring Range ..... 2 - 9
6 Operation of Cutting Monitor ..... 2 - 10
6.1 Condition of monitoring operation ..... 2 - 11

6.2 Overload detection ..... 2 - 11
6.3 Noload detection ..... 2 - 12
6.4 Wear detection ..... 2 - 12
6.5 Adaptive control ..... 2 - 12
6.6 Reduction of air cutting time ..... 2 - 13
6.7 Operating procedure of cutting monitor ..... 2 - 14
7 Load Setting Screen ..... 2 - 15
7.1 Selection of main monitoring axis ..... 2 - 16
7.2 Selection of monitoring function ..... 2 - 16
7.3 Data setting ..... 2 - 17
7.4 Deletion of data ..... 2 - 17
8 Load Graph Screen ..... 2 - 18
9 Life Graph Screen ..... 2 - 19
10 Display and Setting of Parameter ..... 2 - 20
10.1 Display of parameter screen ..... 2 - 20
10.2 Setting of parameter ..... 2 - 20
10.3 Selection of monitoring data method (Parameter 8000) ..... 2 - 20
10.4 Selection of initial setting (Parameter 8001) ..... 2 - 21
10.5 Selection of function (Parameter 8002) ..... 2 - 21
10.6 Display of monitoring data (Parameter 8004) ..... 2 - 21
10.7 Parameter of automatic calculation (Parameter 8006 ~ 8029) ..... 2 - 21
10.8 Parameter of timer (Parameter 8030 ~ 8044) ..... 2 - 22
10.9 Parameter of adaptive control ..... 2 - 23
10.10 Parameter data ..... 2 - 24
11 Alarm ..... 2 - 24

III. INDIVIDUAL TOOL NO. FUNCTION ..... 3 - 1
1 Function ..... 3 - 1
2 Individual Tool No. Method ..... 3 - 1
2.1 Setting of data ..... 3 - 1
2.2 Command of program ..... 3 - 1
2.3 Spare tool management ..... 3 - 1
2.4 Setting of spare tool ..... 3 - 2
2.5 Tool life screen ..... 3 - 2
2.6 Spare tool screen ..... 3 - 3
2.7 Screen of tool condition list ..... 3 - 3
3 Functional No. Method ..... 3 - 4
3.1 Setting of data ..... 3 - 4
3.2 Command of program ..... 3 - 4

3.3 Spare tool management ..... 3 - 4
3.4 Tool life screen ..... 3 - 5
3.5 Screen of tool condition list ..... 3 - 6
4 Tool Offset ..... 3 - 7
4.1 Setting data ..... 3 - 7
4.2 Deletion of data ..... 3 - 7