OPERATION MANUAL

MG POWER SUPPLY

(WITH CRT)

MAKINO MILLING MACHINE CO., LTD.

G02-8302(E)

CONTENTS

1. OUTLINE 1

2. SPECIFICATIONS 2

2.1 Standard Specifications 2
2.2 Options 12
2.3 G Function 13
2.4 M Function 14
2.5 P Function 15
2.6 Outside Views 16

3. OPERATION PANELS 17

3.1 Main Operation Panel 17
3.1.1 CRT (optional) 17
3.1.2 LED displays 18
3.2 Power Control Panel 19
3.3 Portable Operation Panel 20

4. OPERATION 21

4.1 Input Power 21
4.2 Portable Operation Panel 22
4.3 Auxiliary Control Panel for CRT (CRT-compatible) 23
4.4 Start, Stop, Reset Operations 23
4.5 Keyboard 24
4.6 Main and Sub Modes 26
4.6.1 MANUAL mode 27
4.6.2 POSITION mode 30
4.6.3 SINGLE mode 31
4.6.4 EDIT mode 33

4.6.5 MEMORY mode 34
4.6.6 TAPE mode (optional) 35
4.6.7 SPARK-CONDITION mode 36
4.6.8 DIAGNOSE mode 37
4.7 PRO/COM 38
4.8 ABS/INC 39
4.9 Power Out 40
4.10 PRO Reset 40
4.11 Specification of Machining Conditions 41
4.12 Changing and Registering Machining Conditions 43
4.12.1 Procedure for changing machining conditions 43
4.12.2 T900 level machining conditions (User's area) 44
4.12.3 Procedure for registering machining conditions 44
4.12.4 Machining elements 45
4.12.5 Low-wear machining circuit 46
4.12.6 GC circuit 46
4.12.7 Charge machining circuit 46
4.12.8 Glazed finishing 47
4.13 Pattern Machining 49
4.13.1 Pattern mode 50
4.13.2 Servo-axis and quadrant 51
4.13.3 Ordinary pattern 51
4.13.4 Step pattern 52
4.13.5 Expanded pattern 53
4.13.6 Peck pattern 54
4.14 Power Control Panel 55
4.14.1 Periodic jump and automatic jump 55
4.14.2 Discharge condition display 56
4.14.3 Off-time adjustment 56
4.14.4 Servo adjustment 57
4.14.5 Servo voltage display 57

4.15 Program Input 58
4.15.1 Preoperation for input (Deleting memory) 58
4.15.2 Program input method 59
4.15.3 Searching sequence number 61
4.15.4 Confirmation of program (LED display) 61
4.15.5 Checking error block upon tape input 61
4.16 Program Modification 62
4.16.1 Procedure for inserting new block 62
4.16.2 Procedure for deleting block 63
4.16.3 Deleting and adding a part of the block 63
4.16.4 Condition of G code and M code 64
4.17 Operation by Memory 64
4.17.1 Programming 64
4.17.2 Optional stop M01 67
4.17.3 Program stop M00 67
4.17.4 Single block 68
4.18 Programmed Machining 68
4.18.1 Subprogram (Multiple piece cutting) 68
4.18.2 Simultaneous 3-axis machining 70
4.18.3 Taper machining 71
4.18.4 Time-managed machining 72
4.18.5 Jump code 73
4.18.6 Model program function (CRT-compatible) 75
4.19 Specification of Coordinate System (G92) 75
4.20 Setting Removal Amount 76
4.20.1 Automatic depth machining 77
4.21 Retract and Return Functions 78
4.21.1 Visual inspection of machining conditions during machining 78
4.21.2 When machining is complete 79

4.22 Contact Sensing, Centering 79
4.22.1 Contact sensing (G84) 79
4.22.2 Centering of grooves (G85) 80
4.22.3 Centering of holes (G85) 81
4.22.4 Centering of plates (G86, G87) 82
4.22.5 Centering of cylinders (G88, G89) 83
4.23 Diagnosis 84
4.23.1 Alarm display and alarm reset 84
4.23.2 Display of cumulative operating time 85
4.24 Dielectric Branching Unit (Optional) 86
4.25 AEC (Optional) 86
4.25.1 Automatic return to and from AEC position (G28, G29) 87
4.25.2 Program for AEC operation 91
4.26 Electrode Indexing Device (YCD, optional) 92
4.27 C-axis (Optional) 93
4.28 Changing Inch/Millimeter System of Units (CRT-compatible) .. 95
4.29 Automatic Parameter Transfer (Model-dependent Setting) 97
4.30 Parameter Table 99