VONA
CNC EDM
ITE/CW

USER'S MANUAL

SPARK-EROSION MACHINE

CNC EDM
ITE/CW

PRIMA E 250
PRIMA E 400
PRIMA E 900

(Version 3.3.0/4.0.0)

CNC EDM
ITE/CW

P-0110091-0397

INDEX

PAGE

CHAPTER 1: GENERAL

1.1. RECEPTION 1-1
1.2. TRANSPORT 1-1
1.3. SITE PREPARATION 1-5
1.4. AXIS UNBLOCKING 1-5

CHAPTER 2: DESCRIPTION OF THE MACHINE

2.1. CHARACTERISTICS OF THE MACHINE 2-1
2.2. WORKING TABLE 2-2
2.3. AUXILIARY COMMANDS 2-3
2.4. GUIDING AND SETTING OF THE WIRE 2-4
2.5. UPPER NOZZLE HEIGHT CONTROL 2-5
2.6. THE DIELECTRIC'S COMMANDS 2-6

CHAPTER 3: AUTOMATIC SELF-CLEANNING MINERAL FILTER

3.1. GENERAL POINTS 3-1
3.2. DESCRIPTION OF THE COMPONENTS 3-2
3.3. CLEANING THE FILTER (MANUAL) 3-5
3.4. PERIODIC MANUAL OPERATION: REMOVING SLUDGE 3-6
3.5. EROSION PROCESS 3-9

CHAPTER 4: NUMERICAL CONTROL UNIT

4.1. TECHNICAL DATA 4-1

4.1.1. NUMERICAL CONTROL 4-1

4.2. THE CONTROLS 4-3

4.2.1. CENTRAL SWITCH 4-4
4.2.2. GENERAL ON BUTTON 4-4
4.2.3. GENERAL OFF BUTTON 4-4
4.2.4. MAIN LIGHT 4-4

4.2.5. EMERGENCY STOP 4-4
4.2.6. AMMETER 4-5
4.2.7. VOLMETER 4-5
4.2.8. WORK LEDS INDICATOR 4-5
4.2.9. "CRT" SCREEN 4-5

4.2.9.1. PAGE TITLE 4-6
4.2.9.2. CURRENT STATUS 4-7
4.2.9.3. MESSAGES TO THE OPERATOR 4-7
4.2.9.4. DATE AND HOUR 4-7
4.2.9.5. ALARM INDICATION 4-7
4.2.9.6. SPECIFIC PAGE INFORMATION 4-7
4.2.9.7. FUNCTION MENUS 4-8

4.2.10. THE CONTROL PANEL 4-9

4.2.10.1. FIELD KEYS 4-9
4.2.10.2. MANUAL CONTROL KEYBOARD 4-9

4.2.10.2.1. AXIS CONTROL KEYBOARD 4-9
4.2.10.2.2. MANUAL OPERATION SELECTOR KEYBOARD. 4-10

4.2.10.3. NUMERICAL KEYBOARD 4-11
4.2.10.4. PAGE INFORMATION AREA CONTROL 4-11
4.2.10.5. EXECUTION CONTROL 4-11

4.3. USING THE NUMERICAL CONTROL 4-12

4.3.1. BASE PAGE 4-13

4.3.1.1. BASE SUBPAGE 4-14

4.3.2. MANUAL OPERATIONS 4-15

4.3.2.1. MANUAL MOVEMENTS (JOG) 4-17
4.3.2.2. STEP BY STEP 4-17
4.3.2.3. MANUAL ROUTE MEMORIZATION 4-18
4.3.2.4. RETURN BY MEMORIZED TRAVERSE 4-18
4.3.2.5. MACHINE ZERO SEARCH 4-18
4.3.2.6. CENTER CYCLES 4-19

4.3.2.6.1. INTERNAL CENTERING 4-19
4.3.2.6.2. WORKPIECE CONTACT 4-19
4.3.2.6.3. EXTERNAL CENTERING 4-20

4.3.2.7. OFSETS AND TRAVERSE POINTS 4-21
4.3.2.8. CONFIGURATION 4-23

4.3.3. IMMEDIATE EXECUTION OPERATIONS. (EMDI) 4-25

4.3.4. OPERATION BY PROGRAM 4-26

4.3.4.1. PROGRAM DIRECTORY 4-26

4.3.4.1.1. COPY OF PROGRAMS 4-27
4.3.4.1.2. END OF PROGRAM TRANSMISSION / RECEPTION 4-27
4.3.4.1.3. ERASE OF PROGRAMS 4-28

4.3.4.2. PROGRAM EDITING 4-29

4.3.4.2.1. BLOCK MODIFICATION 4-31
4.3.4.2.2. BLOCK ENTER 4-31
4.3.4.2.3. BLOCK ERASE 4-32
4.3.4.2.4. END OF EDITING 4-32
4.3.4.2.5. FORWARD PAGE 4-32
4.3.4.2.6. BACKWARD PAGE 4-32
4.3.4.2.7. GRAPHIC EDITING 4-32(I)

4.3.5. PROGRAM EXECUTION 4-33

4.3.5.1. WORK PLANNING 4-34
4.3.5.2. PROGRAM DISPLAY DURING EXECUTION 4-36
4.3.5.3. WIRE DIAMETER COMPENSATION 4-37
4.3.5.4. TAPER CUTTING 4-38
4.3.5.5. STATUS 4-39
4.3.5.6. GRAPHIC PARAMETERS 4.40
4.3.5.7. GRAPHIC 4-42

4.3.6. MACHINE OPERATIONS 4-44

4.3.6.1. PREPARATORY MACHINE OPERATIONS 4-46
4.3.6.2. TECHNOLOGY TABLES 4-47

4.3.7. ALARMS 4-48
4.3.8. SYSTEM 4-49

4.3.8.1. CONSUMABLES 4-51

4.3.9. DIAGNOSTICS 4-53

4.4. PROGRAMMING 4-54

4.4.1. END OF PROGRAM 4-55

4.4.2. SETTING: COORDINATES / OFFSET / CONTACTS TOLERANCE / WIRE COMPENSATION / TAPER CUTTING ANGLE / ANGLE INCREMENT 4-56
4.4.3. LINEAR / CIRCULAR X Y U V INTERPOLATION 4-60
4.4.4. ABSOLUTE/INCREMENTAL 4-64
4.4.5. TRAVERSE 4-66
4.4.6. SELECTION MODE 4-68
4.4.6.1. WIRE / WORKPIECE PAR 4-68
4.4.6.2. GENERATOR PARAMETERS 4-69

4.4.7. TIME DWELL / STATE 4-70
4.4.8. EXECUTION MODE: NORMAL / DRY RUN 4-71
4.4.9. ASSIGNING THE PARAMETER VALUE (P0 to P9) 4-72
4.4.10. JUMP 4-73
4.4.11. SUBROUTINE 4-76
4.4.12. SUBROUTINE RETURN 4-78
4.4.13. MACRO 4-79
4.4.14. INNER CENTERING 4-81
4.4.15. WORKPIECE MID POINT 4-82
4.4.16. WORKPIECE CONTACT (FACING) 4-83
4.4.17. AUTOMATIC RETURN TO INITIAL POINT 4-84
4.4.18. ACTIVATE / DEACTIVATE PORT 4-86
4.4.19. METRIC / INCHES 4-87
4.4.20. VECTOR 4-88
4.4.21. COMPENSATION 4-90
4.4.22. TAPER CUTTING 4-94
4.4.23. PROGRAM ORIGIN 4-95
4.4.24. SCALE 4-96
4.4.25. ROTATION 4-99
4.4.26. AXIS REVERSE (MIRROR) 4-104
4.4.27. CHANGE OF AXES 4-108
4.4.28. START GENERATOR SETTINGS 4-110(I)
4.4.29. MEMORIZE ACTUAL POSITION TO TRAVERSE POINT 4-110(II)
4.4.30. MEMORIZE ACTUAL POSITION IN OFFSET 4-110(IV)

4.5. CUTTING MODES 4-111

4.5.1. INTRODUCTION 4-111
4.5.2. VERTICAL CUTTING 4-112
4.5.3. TAPER CUTTING 4-113
4.5.4. XYUV CUTTING 4-117
4.5.5. DRAWING OF CUTTING 4-119

4.6. PROGRAMMING EXAMPLES 4-120

4.6.1. EXAMPLE 1: VERTICAL CUTTING; die and pounch 4-120

4.6.2. EXAMPLE 2: TAPER CUTTING 4-122

4.7. PRIMA ISO CODE 4-124

4.8. LIST OF ALARMS 4-130

CHAPTER 5: THE WORK IN GENERAL

5.1. WORKPIECE POSITION IN THE MACHINE 5-2
5.2. CHECKING PROGRAM IN GRAPHICS 5-2

5.2.1. NOMINAL CHECKING 5-2
5.2.2. CHECKING COMPENSATION 5-2
5.2.3. CHECKING TAPER CUTTING 5-2

5.3. CENTERING OPERATION EXECUTION 5-5
5.4. CHECKING PROGRAM IN DRY RUN 5-5
5.5. INTERING EROSION CONDITIONS 5-5

5.5.1. SETTING OFFSET 5-6

CHAPTER 6: PREVENTIVE MAINTENANCE

6.1. MACHINE 6-1

6.1.1. UPPER HEAD ASSEMBLY 6-1

6.1.1.1 CURRENT PICKUP 6-1
6.1.1.2 WIRE GUIDE 6-2
6.1.1.3 PLASTIC NOZZLES 6-2
6.1.1.4 WORKING CABLE TERMINALS 6-2
6.1.1.5 INSULATION PIECE FOR THE UPPER NOZZLE ASSEMBLY 6-3
6.1.1.6 WIRE COOLING AND CURRENT PICKUP 6-4
6.1.1.7 CLEANING

6.1.2 LOWER HEAD ASSEMBLY 6-5

6.1.2.1 LOWER POWER OUTLET 6-5
6.1.2.2 WIRE GUIDE 6-6
6.1.2.3 PLASTIC NOZZLE 6-6
6.1.2.4 SLIDE 6-6
6.1.2.5 FEED ROLLERS 6-6
6.1.2.6 BELT 6-8

6.1.2.7 WIRE OUTLET TAPERS 6-9
6.1.2.8 WORK CABLE TERMINALS 6-9
6.1.2.9 LOWER HEAD INSULATION 6-9
6.1.2.10 LOWER HEAD COOLING 6-9
6.1.2.11 CLEANING 6-9

6.1.3 FRONT PANEL 6-10

6.1.3.1 SPOOL-HOLDER 6-11
6.1.3.2 FIRST ROLLER ASSEMBLY 6-12
6.1.3.3 BRAKE ASSEMBLY 6-12
6.1.3.4 SECOND ROLLER ASSEMBLY - DYNAMO 6-13
6.1.3.5 WIRE-GUIDING ROLLERS 6-13

6.1.4 SECONDARY THREADING ASSEMBLY 6-14

6.1.4.1 LUBRICATION AND CLEANING 6-14

6.1.5 WORK TABLE 6-15

6.1.5.1 INSPECTION OF WORK CABLE 6-15
6.1.5.2 CLEANING 6-15
6.1.5.3 DRAINAGE TUBE 6-15

6.1.6 PNEUMATIC OIL 6-15
6.1.7 COORDINATE AXES 6-16

6.1.7.1 CLEANING AND LUBRICATING THE GUIDES 6-16
6.1.7.2 GEAR BOX 6-17

6.2 FILTER 6-18

6.2.1 RESINS 6-18
6.2.2 CLEANING THE CONDUCTOMETER DETECTOR 6-19
6.2.3 SLUDGE REMOVAL 6-19
6.2.4 REPLACEMENT OF LIQUID 6-19

6.3 GENERATOR

6.3.1 CLEANING THE AIR FILTER 6-20

ANNEX I: ACCURACY IN TAPER CUTTING
ANNEX II: AUTOMATICALLY ADJUST WIRE VERTICALITY
ANNEX III: WIRE CUTTER (optional)