

CanAm Machinery

Job #53153-K April 4, 2018

Item: Black Clawson 24PS/PH screen, serial #7020-S

- 1. Disassemble complete and inspect.
- 2. Clean and sandblast all parts.
- 3. Check shaft in lathe for runout. OK
- 4. Check Basket fits. OK
- 5. Check bearing fits. OK
- 6. Furnish new SKF bearings, Garlock seals and fasteners.
- 7. Furnish new mechanical seal and O-rings.
- 8. Furnish new safety guards.
- 9. Assemble screen complete.
- 10. Paint with machinery enamel.

