


40#-24T TOOLS
DISK TYPE MAGAZINE
INSTRUCTION



CHEN SOUNG INDUSTRIAL CO., LTD.

NO.62-6, Jhongcherd., Shengang, Taichung, Taiwan R.O.C

TEL:886-4-25624338 FAX:886-4-25629520

E-mail:sunsango@ms31.hinet.net

CATALOGUE

A、Instruction1
B、Structure	
Body & Magazine Structure Drawing2
Body & Magazine Structure Parts List3~4
Tool Arm Structure Drawing5
Tool Arm Structure Parts List6
Boring Tool Sleeve Structure Drawing7
Boring Tool Sleeve Structure Parts List8
Pot up-down Cylinder Structure Drawing9
Pot up-down Cylinder Structure Parts List10
Indexing Structure Drawing11
Indexing Structure Parts List12
C、Electrical Control	
Control Element Position Explanatory Drawing13
Sequence diagram of electric action14
Wire Junction Box Continue Drawing15
Motor & Limits Switch Wiring Diagram16
Air Pressure Wiring Diagram17
Control Circuit Reference Diagram18

D · ATC Cam

ATC Explanatory Drawing19
Input Shaft & Parts list20
Output & Motor Structure & Parts list21
Rocker Structure & Parts list22
Signal Structure & Parts list	...23
Adjustment of Arm24
Time Chart25
Adjustment of Cover26
Dismantled Procedure27

E · Trouble Shooting

Trouble Shooting28-30
Maintain31-32
Note33

F · Magazine Maintenance34