

# **Okamoto**

**PRECISION SURFACE GRINDING MACHINE**

**MODEL: PSG-450CN**

**MODEL: PSG-450BN**

**MODEL: PSG-450AN**

**OPERATION AND INSTRUCTION MANUAL**

# CONTENTS

Section 1	Principal parts of the machine .....	1 — 1a
Section 2	Specifications	2 — 1
	* Specifications .....	2 — 1
	* Working range & external diagram .....	2 — 2a
Section 3	Installation	3 — 1
	* Lifting of the machine .....	3 — 1
	* Shipping clamps .....	3 — 2
	* Cleaning of the machine .....	3 — 2
	* Levelling of the machine .....	3 — 2
	* Connection to power supply .....	3 — 3
Section 4	Lubrication	4 — 1
	* Filling of oil .....	4 — 1
	* Lubrication system diagram .....	4 — 2
Section 5	Operating instruction	5 — 1
	* Functions of switch and levers on the front .....	5 — 1
	* Functions of switches on the control panel .....	5 — 2
	* Table longitudinal movement .....	5 — 3
	* Saddle cross movement .....	5 — 3
	* Vertical feed of wheel head .....	5 — 3a
	* Mounting of the grinding wheel .....	5 — 4
	* Balancing of the grinding wheel .....	5 — 4
	* Dressing of the grinding wheel .....	5 — 5a
	* Operator's checking before grinding operation .....	5 — 5a
	* Trial running of the machine .....	5 — 5b
	* Traverse automatic grinding cycle (Step feed) .....	5 — 6a
	* Traverse automatic grinding cycle (Crisscross) .....	5 — 7
	* Plunge automatic grinding cycle .....	5 — 7c
Section 6	Maintenance	6 — 1a
	* Hydraulic circuit diagram .....	6 — 1a
	* Hydraulic pressure adjustment .....	6 — 2
	* Adjustment of lubrication to slide ways .....	6 — 3
	* Replacement of printed circuit board .....	6 — 4
	* Grinding faults and their corrections .....	6 — 5
Section 7	Electric circuit diagram	7 — 1a
	* Electric circuit diagram .....	7 — 1a
	* Connection diagram of control switch .....	7 — 4
	* Layout diagram of control switch .....	7 — 5
	* Layout diagram of power box .....	7 — 6a
	* Layout diagram of electrical parts .....	7 — 7a