


Bridgeport **TEXTRON**

Bridgeport

Vertical Milling Machine

OPERATION AND
MAINTENANCE MANUAL
Including Spare Parts
Catalogue



2485-

SECTION

I	Page	<u>INSTALLATION</u>
	1.1	Handling
	1.2	Cleaning
	1.3	Floor Plan
	1.4	Foundation Power Supply
	1.5	Initial Setting Ancillary Equipment
II		<u>OPERATION</u>
	2.1	Machine Controls
	2.2	J-Head Controls
	2.3	2J2-Head Controls
	2.4	Mechanical Table Feed
	2.5	Infinitely Variable Table Feed
	2.6	M-Head Controls
	2.7	E-Head Controls
	2.8	Heidenhain DRO 731/B with Memofix
III		<u>LUBRICATION</u>
	3.1	Basic Machine
	3.2	J-Head
	3.3	2J2-Head
	3.4	Feed Boxes
	3.5	M and E-Head
IV		<u>MAINTENANCE</u>
		GENERAL
	4.1	Table Screw Assembly
	4.2	Cross Screw Assembly
	4.3	Gib Strip Adjustment
		J-HEAD
	4.4	Belt Replacement
		Brake Shoe Replacement
	4.5	Balance Spring Replacement
		Feed Trip Adjustment
	4.6	Collet Aligning Screw
	4.7	Quill Removal
		2J2-HEAD
	4.8	Motor Removal
	4.9	Belt Replacement
	4.10	Brake Shoe Replacement

SECTION

IV

Page MAINTENANCE (contd)

M-HEAD

4.11 Vee Belt Replacement

4.12 Quill Removal

E-HEAD

4.13 Removing Motor

Changing Speed

Removing Reduction Drive Unit or Ram

Changing the Gearcase Oil

V

SPECIFICATION AND EXTRA EQUIPMENT

5.1 Bridgeport BRJ

5.2 Bridgeport BRJ-Head

5.3 Bridgeport BR2J2

5.4 Bridgeport BR2J2-Head

5.5 Bridgeport BRM

5.6 Bridgeport BRM-Head

5.7 Bridgeport E-Head

5.8 Extra Equipment

VI

SPARE PARTS DRAWINGS & PARTS LISTS

6.1 Basic Machine

6.2 Leadscrew

6.3 J-Head Top Housing

6.4 J-Head, J-1 Assembly

6.5 2J2-Head Top Housing

6.6 2J2-Head Back Gear

6.7 6F Longitudinal Varifed Box

6.8 6F Gross Varifed Box

6.9 E-Head

6.10 M-Head

6.11 Lubrication System

6.12 Heidenhain DRO 731/B Plus Table Equipment

6.13 Additional Manuals Available

6.14 Additional Information

VII

ELECTRICAL SCHEMATIC DIAGRAM

7.1 Electrical Panel for use with Feedbox

7.2 Panel 3 for Longitudinal & Cross Feed (English)

7.3 Bridgeport Fitted with Standard Panel 3 Longitudinal/
Cross Feed Type WD145/D

7.4 Wiring Layout for Digital Read-Out WD135/B