

纪和机械制造(上海)有限公司

KIWA-CW MachineManufacturing(SHANGHAI) Co.,Ltd

上海闵行区联曹路260号厂房I厂房. 邮编: 201108 TEL: (862)64349898 FAX: (8621)64349188

Triple V21i-R

[FANUC SYSTEM Oi-MC]

OPERATION

INDEX

INDEX

PREFACE	[Page i]
INDEX	[Page ii to iv]
SAFETY PRECAUTIONS	[Page 1 to 21]
A. MACHINE COMPOSITION	[Page a-1]
B. OUTLINE OF MACHINE	[Page b-1 to b-6]
B-1 Description of Machine	Page b-1
B-2 Features	Page b-5
B-3 Construction	Page b-6
C. SWITCHES AND PUSHBUTTONS	[Page c-1 to c-35]
C-1 Electric Box	Page c-1
C-2 Operation Panel of Machine	Page c-4
C-3 Other Operation Switches and Pushbuttons	Page c-33
D. STARTING AND ENDING OPERATION	[Page d-1 to d-10]
D-1 Emergency Stop	Page d-1
D-2 Turning ON Power	Page d-3
D-3 Warming-up Operation.....	Page d-5
D-4 Turning OFF Power	Page d-7
D-5 After Turning OFF Power	Page d-8
D-6 Measures in Power Failure.....	Page d-9

INDEX

E. MANUAL OPERATION	[Page e-1 to e-7]
E-1 Zero Point Return	Page e-1
E-2 JOG Feed	Page e-2
E-3 Rapid Traverse	Page e-3
E-4 Handle Feed	Page e-4
E-5 Setting/Taking off Spindle Tool	Page e-5
E-6 Spindle Revolution and Stop	Page e-7
F. MDI OPERATION	[Page f-1 to f-5]
F-1 MDI (Manual Data Input) Operation	Page f-1
F-2 Spindle Revolution in MDI	Page f-3
F-3 Spindle Orientation in MDI	Page f-4
F-4 ATC Magazine Indexing and Tool Change	Page f-5
G. AUTOMATIC OPERATION	[Page g-1 to g-9]
G-1 Starting Automatic Operation	Page g-2
G-2 Stopping and Restarting Automatic	Page g-4
Operation	
G-3 Door Safety Interlock	Page g-6
H. ATC OPERATION	[Page h-1 to h-14]
H-1 Tool Setting and Removal	Page h-1
H-2 Tool Registration	Page h-2
H-3 Tool Exchange in MDI Operation	Page h-10
H-4 Tool Exchange in Automatic Operation ...	Page h-11
H-5 How to Set Special Tool	Page h-12
H-6 Description of LCD Displays	Page h-13

INDEX

I. AUTOMATIC PALLET CHANGE (APC)	[Page i-1 to i-9]
I-1 Movement of APC	Page i-1
I-2 APC in Manual Mode	Page i-2
I-3 MDI Operation	Page i-6
I-4 Automatic Operation	Page i-8
J. EMERGENCY STOP	[Page j-1]
J-1 Cases of Emergency	Page j-1
J-2 To Release Emergency Stop Status	Page j-1
K. INTERFERENCE	[Page k-1 to k-5]
K-1 Work-piece and Travels	Page k-1
K-2 ATC Interference Area	Page k-2
K-3 MAX. area on Pallet.....	Page k-3
K-4 Tool	Page k-4
K-5 Pullstud	Page k-5
L. MISCELLANEOUS FUNCTIONS (M CODE)	[Page l-1 to l-3]
L-1 M Function Code List	Page l-1
L-2 Remarks to use M Function Code	Page l-3
M. ALARM MESSAGE	[Page m-1 to m-6]
M-1 Alarm Message	Page m-1
M-2 Operation Message (Machine Side)	Page m-5
APPENDIX-I SPINDLE THROUGH COOLANT SYSTEM	[Page APPENDIX-I-1 to 2]
APPENDIX-II CHIP CONVEYOR	[Page APPENDIX-II-1]
APPENDIX-III MACRO PROGRAM	[Page APPENDIX-III to 3]