



Miyano CNC Lathe

Model : BNC-34/42C5 (0i-TC)

Machine User's Manual



CONTENTS

BNC-34/42C5

(0I-TC)

No.2 (05.12)

SAFETY GUIDELINES

DANGER

WARNING

CAUTION

NOTICE

LOCATION OF WARNING LABELS

NOTES TO USERS

INTENDED USE OF THE MACHINE

1. INSTALLATION
2. OUTLINE OF MACHINE
3. TOOLING
4. NC OPERATION
5. C s AXIS
6. MACHINE OPERATION
7. PROGRAMMING
8. MAINTENANCE
9. TROUBLE SHOOTING