

TRANSLATED FROM CHINESE

CW6180B HORIZONTAL LATHE

CW6280B GAP-BED TYPE LATHE

INSTRUCTION BOOK

(For Mechanical & Hydraulic Units)

**SHENYANG NO. 1 MACHINE TOOL WORKS
THE PEOPLE'S REPUBLIC OF CHINA**

Ver.1.0 / Dec., 2002

3039B

CONTENTS

1	MATTERS NEEDING APPLICATION TO SAFETY PROTECTION	5
1.1	Electrical Shock Danger	5
1.2	Danger Resulting from Extrusion, Twine and Throw-off.....	5
1.3	Danger Resulting from Cutting, Scalding and Slipping	6
1.4	Miscellaneous	6
2	MAIN APPLICATIONS OF THE MACHINE	7
3	SPECIFICATIONS OF THE MACHINE	8
3.1	Main Specifications	8
3.2	Spindle	8
3.3	Feed System	8
3.4	Carriage	9
3.5	Tailstock	9
3.6	Power System.....	9
3.7	Cooling System	9
3.8	Controls and Lubricating System.....	10
3.9	Accessories	10
3.10	Overall Dimensions and Weights of the Machines	10
4	HANDLING, INSTALLATION AND TRIAL RUNNING	11
4.1	Handling.....	11
4.2	Installation.....	11
4.3	Cleaning and Trial Running	11
5	CONTROLLING SYSTEM AND HYDRAULIC SYSTEM	21
5.1	Arrangement Drawing of Control Levers for the Machine with Center Distance of 1.5m and 3m	21
5.2	Arrangement Drawing of Control Levers for the Mach. with Center Distance of 4m and more than 4m	23
5.3	Description of Hydraulic System	25
5.3.1	Description of Hydraulic System for the Machine of 1.5m and 3m	25
5.3.2	Description of Hydraulic System of the Machine with Size of 4m and more than 4m	27
6	DRIVING SYSTEM AND BEARINGS	30
7	SETTING UP OF THE MACHINE	36
7.1	Setting up of Feed System	38
7.2	For Cutting Special Threads by Means of Change Gears.....	39
7.3	For Cutting Inch Threads of 19 t.p.i	39
7.4	For Fine Feeds	39
7.5	For Broaching Oil Groove or Keyways with Carriage	39
7.6	Turning tapers	40
8	ADJUSTMENT AND LUBRICATION OF THE MACHINE	41
8.1	Adjustment of the Spindle Bearings	41
8.2	Adjustment of Safety Device in the Apron.	42
8.3	Adjustment of the Backlash Between the Cross Slide Leadscrew and Nut.....	42

8.4 Lubrication of the Machine.....	44
9 WEARING PARTS.....	45