NC LATHE

TW10 & TW20

MACHINE INSTRUCTION MANUAL



SAFETY GUIDE CONTENTS

- 1 PRECAUTIONS FOR SAFETY WORK
- 2 DEFINITION AND RISK OF ALARM SYSMBOLS
- 3 BASED PRECAUTIONS
- 4 PRECAUTIONS FOR MACHINE INSTALLATION
- 5 PRECAUTIONS FOR POWER ON/OFF
- 6 PRECAUTIONS FOR SET-UP WORK
- 7 PRECAUTIONS FOR MACHINE OPERATION
- 8 PRECAUTIONS ON DAILY INSPECTION
- 9 PRECAUTIONS ON MAINTENANCE
- 10 PRECAUTIONS ABOUT MACHINING ACCURACY
- 11 PRECAUTIONS FOR COOLANT SELECTION
- 12 CAUTION LABEL
- 13 SAFETY EQUIPMENT

INSTRUCTION MANUAL CONTENTS

Preface

- 1 OUTLINE
- 2 INSTALLATION
- 3 · LUBRICATION AND OILING
- 4 STRUCTURE, MAINTENANCE AND ADJUSTMENT OF COMPONENTS