

XV560A

MECHANICAL MANUAL

VERTICAL MACHINING CENTER

**OP5214ME00
R001**

CONTENTS

PREFACE	PAGE
CHAPTER 1 INSTRUCTION FOR SAFETY	
1-1 Basic introduction for safe operation	1-1 ~ 1-2
1-2 Symbols and designations connected with	1-3 ~ 1-4
1-3 Safety precautions	1-5
1-3-1 Basic operating practices.....	1-5
1-3-2 Before switching power on	1-4 ~ 1-6
1-3-3 After control power switch has been turned on.....	1-6
1-3-4 Routine inspections	1-7
1-3-5 Warming up.....	1-7
1-3-6 Preparation	1-7
1-3-7 Operation.....	1-8
1-3-8 To interrupt machining.....	1-9
1-3-9 Completing a job	1-9
1-3-10 Safety devices.....	1-9
1-3-11 Preparation for maintenance operation	1-9
1-3-12 Maintenance operation	1-10
1-3-13 Until operation is begun after maintenance.....	1-10
1-4 Danger areas.....	1-11
1-4-1 Area with moving parts	1-11 ~ 1-12
1-4-2 High voltage areas	1-13 ~ 1-14
1-5 Safety devices	1-15 ~ 1-17
1-5-1 Warning plate position	1-18
1-5-2 Instruction plate position.....	1-19
1-6 ID. nameplate of machine	1-20

CHAPTER 2 DESCRIPTION OF MACHINE

2-1 Function and fields of application.....	2-1
2-2 Specification	2-2
2-3 Accessories	2-3
2-4 Circumstance for operation.....	2-4
2-4-1 Airborne noise	2-4
2-4-2 Lighting	2-4
2-5 Out view dimensions and main parts of machine	2-5
2-5-1 Out view dimensions.....	2-5
2-5-2 Main parts of machine.....	2-6
2-6 Dimensions of working space	2-7
2-6-1 Movements of X,Y,Z-Axes.....	2-7
2-6-2 X,Y-Axis travels.....	2-8
2-6-3 Y,Z-Axis travels	2-9
2-6-4 ATC travel.....	2-10

CHAPTER 3 DESIGN AND FEATURES

3-1 Spindle	3-1 ~ 3-3
3-1-1 Tool shank & pull stud	3-4 ~ 3-5
3-1-2 Spindle output	3-6 ~ 3-7
3-2 Design on feeding unit	3-8
3-2-1 X axis.....	3-8
3-2-2 Y axis.....	3-9
3-2-3 Z axis	3-10
3-2-4 Table size & T slot dimension.....	3-11
3-3 Axis travel devices.....	3-12
3-3-1 X axis.....	3-12
3-3-2 Y axis.....	3-12
3-3-3 Z axis	3-13
3-4 ATC (Automatic Tool Changer).....	3-14
3-4-1 ATC system.....	3-14
3-4-2 ATC cycle	3-15 ~ 3-17

CHAPTER 4 PREPARATION BEFORE TRANSPORT AND INSTALLATION

4-1 Minimum space for foundation and maintenance.....	4-1
4-2 Power supplies	4-1
4-2-1 Electric	4-1
4-2-2 Grounding.....	4-1
4-2-3 Air.....	4-1
4-2-4 Cutting fluid	4-1
4-3 Installation environment	4-2 ~ 4-3

CHAPTER 5 TRANSPORT AND INSTALLATION

5-1 Packing.....	5-1
5-1-1 Parking Procedure	5-1 ~ 5-2
5-2 Safety precautions	5-2
5-3 Machine lifting.....	5-3 ~ 5-5
5-4 Temporary storage	5-6
5-5 Machine installation.....	5-6 ~ 5-7
5-5-1 Installation of major auxiliary equipments.....	5-7
5-5-1-1 Chip conveying equipments.....	5-7 ~ 5-8
5-6 Disposal after installation	5-9 ~ 5-10

CHAPTER 6 PREPARATION BEFORE MACHINE TRIAL RUN

6-1 Removing lifting tools and fixtures	6-1
6-2 Cleaning machine.....	6-1
6-2-1 Cleaning the watching glass on the door and window	6-1
6-2-2 Procedure for replacing the PC board.....	6-1 ~ 6-2
6-3 Leveling machine	6-3
6-4 Preparation for operation	6-4
6-4-1 Precautions regarding safety.....	6-5
6-5 Checking before operation	6-6
6-6 Warming up of spindle.....	6-7