

Machine Installation  
& Parts List

"  
M Codes

WIRE-EDM SYSTEM

M Series ASW530/FW540/FW840

(FOR SOFTWARE V420.01 FLASH)

2007/09/01

# **CONTENTS**

<b>Chapter One. Machine Installation &amp; Parts List.....</b>	<b>4</b>
<b>Part One. Machine Installation.....</b>	<b>4</b>
1、Machine Installation .....	4
2、Move the machine after unload wooden case.....	5
3、Wiring of control tank.....	10
4、How the wire control system coil the wire up.....	18
5、Lists of wire cut consumption parts.....	21
<b>Part Two. Parts List .....</b>	<b>22</b>
1、The upper and lower guides.....	22
2、X,Y-Axis.....	28
3、U,V-Axis.....	30
4、Main Axis.....	32
5、Wire recede (One).....	34
6、Wire recede (Two).....	37
7、Casting.....	40
<b>Chapter Two. Operation Manual.....</b>	<b>43</b>
<b>Part One. Basic Operation Application.....</b>	<b>43</b>
1、How to use controller of wire cut EDM.....	43
2、Operation instructions of main screens.....	61
<b>Part Two. Machine Operation Panel.....</b>	<b>155</b>
1、Remote box control.....	158
2、Discharging condition part.....	161
3、Control function part.....	162
4、Instructions of function keys.....	165
<b>Part Three. Basic Function Operation.....</b>	<b>167</b>
1、How to position.....	167
2、How to measure.....	169
3、How to edit machining file.....	177
4、How to prepare.....	186
5、How to monitor.....	187
6、How to handle wire break.....	188
7、How to discharge manually.....	190
<b>Part Four. How to prepare.....</b>	<b>192</b>

**WEDM Operation Manual**

<b>Part Five. Trial Cutting Examples.....</b>	<b>198</b>
1、 Instructions of screen display.....	199
2、 Operation of function Key(right side of operation panel).....	201
3、 Adjustment of cutting speed.....	203
4、 Height adjustment of Z axis.....	204
5、 Machining conditions & results.....	205
6、 Important terms definition of wire cut.....	207
<b>Part Six. Cutting Skills &amp; Utility Examples.....</b>	<b>209</b>
1、 Explanation of EDM parameter.....	209
2、 How to increase cutting speed.....	211
3、 How to increase machining precision.....	212
4、 What's 2 <sup>nd</sup> machining.....	214
5、 Automatic corner function.....	215
6、 Display function of graph travel limit.....	222
7、 Modification function of taper and wire diameter compensation.....	225
<b>Chapter Three. Alarm Messages &amp; Failure.....</b>	<b>228</b>
Part One. Alarm messages of wire cut.....	228
Part Two. Get rid of simple failure.....	234
<b>Chapter Four. NC Program Editing.....</b>	<b>246</b>
1、 Basic Concept.....	246
2、 Preparative & Subsidiary function.....	252
3、 G88 and G89 automatic corner clearance function.....	296
4、 Program description.....	299
5、 Function of simplification program.....	305
6、 Main points for editing the program.....	308
<b>Chapter Five. Maintenance.....</b>	<b>321</b>
Part One. Wire cut EDM maintenance.....	321
Part Two. Routine maintenance tables of wire cut EDM.....	327
<b>Chapter Six. Technical manual for wire cut EDM.....</b>	<b>330</b>
Part One. Use and Introduction of wire cut EDM.....	330
Part Two. Setting method and description of machining condition.....	335
Part Three. Taper machining condition setting and how to upgrade machining precision.....	345
Part Four. Management and usage of working liquid.....	349
Part Five. Reason analysis of machining deformation and how to improve machining precision.....	355