



Parts Manuals



POWERING BUSINESS. EMPOWERING PEOPLE

Info.	Note	Part No.	Part Name	Req. Qty.
IY		2853185	ENGINE AR	1
SY		4P3363	FITTING GP-EXHAUST	1
SY		5N2438	LINES GP-FLEXIBLE FUEL	1
SY		5N9527	FITTING GP-EXHAUST	1
IY		8N8481	LINES GP-AIR STARTING	1
IY		8N9639	GUARD GP-DAMPER	1
IY		9Y0851	RAIL GP-ENGINE SUPPORT	1
SY		1036668	FLANGE GP-EXHAUST	1
IY		2106112	DRAIN GP-ENGINE OIL	1
IY		2319999	BOX GP-JUNCTION	1
NY		4P-0558	AIR CLEANER GP	2

IY	7C8122	LINES GP-WATER	1
IY	9Y9171	HOUSING & REGULATOR GP	1
NY	115-3634	FILTER-SOOT	2
IY	1550718	LINES GP-WATER	1
IY	2320889	WIRING GP-AIR SHUTOFF	1
IY	2414902	PUMP GP-FUEL PRIMING	1
IY	2426278	FILTER GP-ENGINE OIL	1
IY	2733285	LINES GP-FUEL	1
IY	2745749	SHUTOFF GP-AIR	1
IY	2807516	WIRING GP-ENGINE	1
IY	2924521	MOUNTING GP-INSTRUMENT PANEL	1
IY	8N8477	STARTING MOTOR GP-AIR	1
IY	7W9742	FILTER GP-FUEL	1
NY	7N6782	INDICATOR GP-AIR FILTER CHANGE	1
IY	8N8486	SILENCER GP-AIR STARTING	1
IY	3052259	MOUNTING GP-BOX	1
IY	3052262	CONTROL GP-AIR STARTING	1
IY	3148399	CONNECTION GP-WATER	1
IY	3156145	PAN GP-OIL	1
IY	3072046	WIRING GP-SENSOR	1
IY	3309781	MOUNTING GP-AIR CLEANER	1
IY	2926051	MOUNTING GP-CONTACTOR	1
IY	290-3213	BOX GP-INSTRUMENT PANEL	1
IY	2396365	WIRING GP-ENGINE ELECTRONIC	1
SY	1889765	FILTER GP-WATER SEP & FUEL	1
IY	7E2858	ALTERNATOR GP-CHARGING	1
IY	7E4836	MOUNTING GP-ALTERNATOR	1
IY	7W5780	GUARD GP-BELT	1
IY	1664357	DRIVE GP-ACCESSORY	1
IY	2539546	WIRING GP-ALTERNATOR	1
IY	1519228	GUARD GP-BELT	1
IY	2735835	CONTROL GP-FUEL	1
Y	2853185	ENGINE AR	1

SY	4P-0558	AIR CLEANER GP	2
SY	4P3363	FITTING GP-EXHAUST	1
SY	5N2438	LINES GP-FLEXIBLE FUEL	1
SY	5N9527	FITTING GP-EXHAUST	1
SY	7C8122	LINES GP-WATER	1
SY	7N6782	INDICATOR GP-AIR FILTER CHANGE	1
SY	8N8481	LINES GP-AIR STARTING	1
SY	1036668	FLANGE GP-EXHAUST	1
SY	115-3634	FILTER-SOOT	2
SY	1889765	FILTER GP-WATER SEP & FUEL	1
SY	2733285	LINES GP-FUEL	1
SY	3309781	MOUNTING GP-AIR CLEANER	1
SY	6L4502	CHART-PLATE & FILM	1
IY	2853185	ENGINE AR	1
SY	4P3363	FITTING GP-EXHAUST	1
SY	5N2438	LINES GP-FLEXIBLE FUEL	1
SY	5N9527	FITTING GP-EXHAUST	1
IY	8N8481	LINES GP-AIR STARTING	1
IY	8N9639	GUARD GP-DAMPER	1
IY	9Y0851	RAIL GP-ENGINE SUPPORT	1
SY	1036668	FLANGE GP-EXHAUST	1
IY	2106112	DRAIN GP-ENGINE OIL	1
IY	2319999	BOX GP-JUNCTION	1
NY	4P-0558	AIR CLEANER GP	2
IY	7C8122	LINES GP-WATER	1
IY	9Y9171	HOUSING & REGULATOR GP	1
NY	115-3634	FILTER-SOOT	2
IY	1550718	LINES GP-WATER	1
IY	2320889	WIRING GP-AIR SHUTOFF	1
IY	2414902	PUMP GP-FUEL PRIMING	1
IY	2426278	FILTER GP-ENGINE OIL	1
IY	2733285	LINES GP-FUEL	1
IY	2745749	SHUTOFF GP-AIR	1

IY	2807516	WIRING GP-ENGINE	1
IY	2924521	MOUNTING GP-INSTRUMENT PANEL	1
IY	8N8477	STARTING MOTOR GP-AIR	1
IY	7W9742	FILTER GP-FUEL	1
NY	7N6782	INDICATOR GP-AIR FILTER CHANGE	1
IY	8N8486	SILENCER GP-AIR STARTING	1
IY	3052259	MOUNTING GP-BOX	1
IY	3052262	CONTROL GP-AIR STARTING	1
IY	3148399	CONNECTION GP-WATER	1
IY	3156145	PAN GP-OIL	1
IY	3072046	WIRING GP-SENSOR	1
IY	3309781	MOUNTING GP-AIR CLEANER	1
IY	2926051	MOUNTING GP-CONTACTOR	1
IY	290-3213	BOX GP-INSTRUMENT PANEL	1
IY	2396365	WIRING GP-ENGINE ELECTRONIC	1
SY	1889765	FILTER GP-WATER SEP & FUEL	1
IY	7E2858	ALTERNATOR GP-CHARGING	1
IY	7E4836	MOUNTING GP-ALTERNATOR	1
IY	7W5780	GUARD GP-BELT	1
IY	1664357	DRIVE GP-ACCESSORY	1
IY	2539546	WIRING GP-ALTERNATOR	1
IY	1519228	GUARD GP-BELT	1
IY	2735835	CONTROL GP-FUEL	1
Y	2853185	ENGINE AR	1
SY	4P-0558	AIR CLEANER GP	2
SY	4P3363	FITTING GP-EXHAUST	1
SY	5N2438	LINES GP-FLEXIBLE FUEL	1
SY	5N9527	FITTING GP-EXHAUST	1
SY	7C8122	LINES GP-WATER	1
SY	7N6782	INDICATOR GP-AIR FILTER CHANGE	1
SY	8N8481	LINES GP-AIR STARTING	1
SY	1036668	FLANGE GP-EXHAUST	1
SY	115-3634	FILTER-SOOT	2

SY	1889765	FILTER GP-WATER SEP & FUEL	1
SY	2733285	LINES GP-FUEL	1
SY	3309781	MOUNTING GP-AIR CLEANER	1
SY	6L4502	CHART-PLATE & FILM	1

Key:

- S - Shipped Loose
- Y - Separate Illustration
- I - Installed
- N - Not Installed

