



JAGENBERG

JAGENBERG INC.
ENFIELD

SECTION:

WINDER GENERAL
DESCRIPTION


DATE: 01/01/90

REV: 0

PAGE: 24

JAGENBERG INC. P.O. Box 188 Enfield, CT 06082

The following illustrates a typical setup of unwind stand, edge guiding system and winder.





JAGENBERG

JAGENBERG INC.
ENFIELD

SECTION:

WINDER GENERAL
DESCRIPTION

DATE: 01/01/90

REV: 0

PAGE: 25

JAGENBERG INC. P.O. Box 188 Enfield, CT 06082

In the following section of this manual, major machine assemblies will be located, and their function will be described. Some assemblies may not be specific to your machine, they have been included only for informational purposes.

