



## MAINTENANCE MANUAL

---

# GLS-250C

---

**HIGH-PRECISION 4-AXIS CNC  
OPTICAL PROFILE GRINDER  
with FANUC Series 20i-FA**

 **TECNO WASINO** co.,ltd.

## CONTENTS

|  | Page      |
|--|-----------|
| <b>1. LUBRICATION .....</b>  | <b>1</b>  |
| 1-1 Lubricating sections and recommended lubricants .....                  | 1         |
| 1-2 Automatic lubrication system .....                                     | 3         |
| 1-3 Manual greasing system .....   | 4         |
| <b>2. PROJECTOR AND ILLUMINATION DEVICE .....</b>                          | <b>5</b>  |
| 2-1 Replacement of desiccant .....   | 5         |
| 2-1-1 Replacement of silica gel in the hygrosensor .....                   | 5         |
| 2-1-2 Replacement of desiccant in the projector .....                      | 6         |
| 2-2 Cleaning of optical parts (lenses, mirrors) .....                      | 7         |
| 2-2-1 Precautions when cleaning optical glass parts .....                  | 7         |
| 2-2-2 Cleaning of optical glass parts .....                                | 7         |
| 2-2-3 Cleaning of optical parts in the projector .....                     | 8         |
| 2-2-4 Cleaning of optical parts in the diascopic illumination device ..... | 9         |
| 2-3 Troubleshooting for projector and illumination device .....            | 10        |
| <b>3. MACHINE TROUBLES AND REMEDIES .....</b>                              | <b>12</b> |
| 3-1 Trouble symptoms .....   | 12        |
| 3-2 Troubleshooting .....  | 13        |
| 3-2-1 Emergency stop .....   | 13        |
| 3-2-2 Wheel spindle failure .....  | 14        |
| 3-2-3 Reciprocating slide continuous operation failure .....               | 15        |
| 3-2-4 Table vertical feed failure .....                                    | 16        |
| 3-2-5 Handle feed failure .....  | 17        |
| 3-2-6 Program start failure .....  | 18        |
| 3-2-7 CNC tape reader-puncher failure .....                                | 18        |
| 3-2-8 Reciprocating slide inching operation failure .....                  | 19        |
| 3-2-9 Reference point return failure .....                                 | 20        |
| <b>4. CNC UNIT .....</b>   | <b>21</b> |
| 4-1 Pitch error offset .....   | 21        |
| 4-1-1 NC parameter setting for pitch error offset .....                    | 21        |
| 4-1-2 Setting of pitch error offset data .....                             | 23        |
| 4-1-3 Example of pitch error offset data setting .....                     | 24        |
| 4-2 Maintenance of CNC unit .....  | 25        |
| 4-2-1 Replacement of CNC memory backup battery .....                       | 25        |

|   | Page      |
|---|-----------|
| 4-2-2 Replacement of servo amplifier backup batteries ..... | 26        |
| 4-2-3 NC alarms .....                                       | 26        |
| <b>5. CONTROL BOX .....</b>                                 | <b>27</b> |
| 5-1 Cleaning and replacement of heat exchanger filter ..... | 27        |