





3512B Industrial Engine

机器 序列号 - PK200

机器 构建日期 - 2016/10/28

3512B Industrial Engine

发动机 序列号 - PK200

发动机 构建日期 - 2016/10/28

CATERPILLAR

ADD BEARING GREASE WITH THE TYPE, AMOUNT, AND INTERVAL LISTED BELOW. DO NOT OVERFILL AND DO NOT MIX GREASES. ALLOW THE GREASE TO PURGE BY RUNNING THE GENERATOR WITH THE DRAIN TUBE OPEN FOR APPROXIMATELY ONE HOUR. CLOSE THE DRAIN TUBE.

USE CATERPILLAR GREASE AS LISTED BELOW.

EXCITER END DRIVE END

GREASE PART NO.

454-0291

454-0291

INTERVAL (SERVICE HOURS/MONTHS WHICHEVER COMES FIRST)

2000/12

2000/12

WEIGHT (OZ / g)

1.8/51.2

1.8/51.2

VOLUME (FLUID OZ / ml)

2/59

2/59

REFER TO THE OPERATION AND MAINTENANCE MANUAL FOR ADDITIONAL LUBRICATION AND MAINTENANCE INFORMATION.

40946906

106-818-1