




NOTE:

ROLLS ARE GREASE LUBRICATED.

- - LUBRICATION POINTS
TENDING AND DRIVE SIDES.
(GREASE) APPROX. (114) POINTS.
- △ - AUTOGUIDE LUBRICATION
OIL FILL FRONT SIDE.
CHECK OIL LEVEL.
- * - SEE OPERATION AND MAINTENANCE
PAGES FOR MORE INFORMATION
FOURPINNER LUBRICATION.

CERTIFIED
PRINT

OCT 15 2001

CUSTOMER INITIATED
CHANGES MAY EFFECT
PRICE AND DELIVERY

[illegible]