



High speed AWT Operation Manual

SOFTWARE : L6,C6

MANUAL VER : D1

DATE : 2005.04

Copyright Reserved

CHING HUNG MACHINERY & ELECTRIC INDUSTRIAL CO., LTD.

 886-4-23365250

Please Read This Manual Thoroughly Before Operation

CONTENTS

Chapter 1 Introduction of the 3RD generation AWT	1
1-1 Preface.....	1-1
1-2 Illustration of AWT Wire Feed Assembly.....	1-2
1-3 HAND BOX with AWT	1-6
Chapter 2 Setting for AWT Hardware and Software.....	2
2-1 AWT Setting Data 1 (Operation Parameter).....	2-1
2-2 RFQ.....	2-8
Chapter 3 AWT Alarm and Maintenance.....	3
3-1 Explanation of AWT Basic Action.....	3-1
3-2 Alarm Message.....	3-5
3-3 Trouble shooting.....	3-9
3-4 Basic Maintenance.....	3-20

VER : E5B1056D1