

704-0001-754
February 1997
BMC 30/M & HT/M
Revision A

PARTS LISTINGS & WIRING DIAGRAMS
for the HURCO
Bedmill Machining Centers
BMC 30/M & HT/M

Proprietary

HURCO Companies, Inc. reserves the right to incorporate any modifications or improvements in machines and machine specifications which it considers necessary, and does not assume any obligation to make any said changes in machines or equipment previously sold.

HOW TO ORDER REPLACEMENT PARTS

Hurco maintains a large inventory of service spare parts. Our Parts Order Processing personnel are thoroughly trained to handle all requests for replacement parts and can also answer your questions concerning the status of an existing order and shipping information, etc.

Orders for parts may be placed by telephone (voice line 1-800-638-1849, fax line 1-317-328-2812) or by mail with a purchase order to:

Hurco Manufacturing Company
Parts Order Processing
One Technology Way
P.O. Box 68180
Indianapolis, IN 46268-0180

We need the following explicit information in order to process your parts order. Please have this information at hand if making a phone order.

1. Hurco CNC mill/machine center serial number. This number is located on the general information and warning label attached to the power cabinet door near the disconnect switch.
2. Your company name and complete address, including the postal zip code.
3. Name and telephone number of the person ordering the parts (include area code and extension).
4. COMPLETE shipping address (include the name and department of the person to receive the part). Also provide any special shipping instructions, including the desired mode of shipment (e.g., Air Express, UPS Blue, Standard UPS, etc.). Parts will be shipped prepaid and billed via invoice.
5. Your company's purchase order number, even if the machine is under warranty.
6. Complete address to which invoices are to be mailed.
7. Give the Hurco part number, part name (description), and quantity. Also state where you got this number (maintenance manual, parts list manual, off the old part).

SPECIAL NOTES ON RETURNING PARTS

When you return a part to Hurco, please fill out the Return Authorization Tag sent to you, and ship the part to Hurco in the original container if possible.

All defective parts replaced under warranty agreement **must be returned** to Hurco within thirty (30) days.

PARTS LIST and WIRING DIAGRAMS

This parts list is for use as an aid in the identification, requisition and issuance of part for the Hurco bedmill machine. Use only the part numbers specified within this manual for replacement parts. To locate a part number: 1) Identify the assembly that contains the component part from the Contents list below; 2) Refer to the page that illustrates the assembly breakdown; 3) Locate the component part and its item number on the illustration then refer to the item number within the part listing to determine its description and the Hurco part number.

CONTENTS

Description	Drawing #
BMC 30/M & 30HT/M	
Machine Tool Mechanical Drawings	
Frame Assy. (BMC 30/M)	003-1000-023 thru 026
Frame Assy. (BMC 30HT/M)	003-1000-027 thru 030
Base Assy.	003-1010-002
Saddle Assy.	003-1010-004
Table Assy.	003-1010-008
Head & Column Assy.	003-1011-001
Spindle & Headstock Assy.	003-1012-001
Spindle Transmission Assy.	003-1014-004
X Axis Way Cover Assy.	003-1008-001
Y Axis Way Cover Assy.	003-1008-002
Z Axis Way Cover Assy.	003-1008-003 ✓
X Axis Limit Switch & Dog Assy.	003-1019-001
Y Axis Limit Switch & Dog Assy.	003-1019-002
Z Axis Limit Switch & Dog Assy.	003-1019-003 ✓
Automatic Tool Changer Assy.	005-0005-001
BT Pneumatic Tool Changer Assy.	005-0005-005
Spindle Assy.	003-1015-001
X/Y/Z Axis Transmission Assy. (BMC 30HT/M)	003-1013-018/019/020
X/Y/Z Axis Transmission Assy. (BMC 30/M)	003-1013-015/016/017
Chip Conveyor Assy.	003-1005-006
CE Full Enclosure Additions Assy.	003-1008-009
Transformer Mounting Assy.	003-1007-017
Enclosure & Coolant System Assy. (UK & Germany)	003-1008-007
Enclosure & Coolant System Assy. (US & Asia)	003-1008-013

Description	Drawing #
Electro-Mechanical Subsystems Drawings	
Oil/Air Plate Assy.	003-1006-005
Lube, Pneumatic & Coolant Assy.	003-1006-006
Washdown Option Assy.	003-1005-007
Air Index Assy.	005-0005-002
Head Air Panel Assy.	003-1006-004
Control Cabinet Assembly Drawings	
Pendant & Control Cabinet Assy.	003-1009-011
Pendant & CE Control Cabinet Assy.	003-1009-010/012
BMC 30HT/M CE Control Cabinet Assy.	003-1007-010
BMC 30/M CE Control Cabinet Assy.	003-1007-012
BMC 30/M Control Cabinet Assy.	003-1007-011
BMC 30HT/M Control Cabinet Assy.	003-1007-014
ISA Card Cage W/PS	002-4428-011
ISA/P Card Cage, M/C Dual VGA Assy.	007-3002-002
ISA Pentium CPU ST Assy.	007-3003-001
Communications Port/Hourmeter Assy.	002-4421-004
Operator Control Console Assembly Drawings	
Console Base w/ Remote Jog Assy.	002-4427-005
Keyboard Door Assy.	002-3506-004
CRT Enclosure, English, Max 3 Assy.A397	002-3508-001/003
CRT 12" Mono VGA Chassis	425-0001-011
Canbus Remote Jog Unit Assy.	002-4427-010
Electrical & Mechanical Schematics	
a-Axis Connection	003-2022-005
Elec. Diagrams for BMC 30HT with Siemens Drive	003-1022-014
Elec. Diagrams for BMC 30M with Siemens Drive	003-1022-007
BMC 30HT Wire List Assy.	003-1022-015
BMC 30M Wire List Assy.	003-1022-012
Interconnect Diagram BMC 30HT	003-1022-016
Interconnect Diagram BMC 30M	003-1022-013
Console Pushbutton PCB	415-0190-004
Lube Schematic	003-1022-005
Coolant Schematic	003-1022-004
Pneumatic Schematic	003-1022-003
Max 3 ISA/Renishaw Probe Schematic	002-4122-031
Harness Assembly Drawings	
CNC/CONS DC (128") Harness Assy.	002-4403-015
ATC Harness Assy.	002-4403-016
Remote Station Harness Assy.	002-4403-017
CRP4 DC Power Harness	423-4204-014
ISA/DSP TTI I/O Harness	423-4400-002
ISA Canbus Controller I/O Harness	423-4400-005
ISA/DSP Servo I/O Harness	423-4400-006
ISA Canbus DC Harness	423-4400-008

Description	Drawing #
Harness Assembly Drawings	
ISA/DSP SYNC Harness	423-4400-011
IEC to PS Harness	423-4400-013
PS to DC Power Harness	423-4400-014
Video Signal Harness	423-4401-044
Color Monitor, 110VAC Power Harness	423-4401-056
ISA FDD Pendant Harness	423-4401-061
ISA Console DC Power Harness	423-4401-062
ISA Console Canbus Harness	423-4401-063
ISA Keyboard Extension Harness	423-4401-064
IOIF J1 Harness	423-4401-065
IOIF J2 Harness	423-4401-066
DCI/O J1 Harness	423-4401-067
DCI/O J2 Harness	423-4401-068
Magazine Rotate PB Harness	423-4401-081
CRP4-TB10 Harness	423-4401-087
Remote E-Stop Harness	423-4401-088
Waylube Motor Harness	423-4401-089
84" IEC FEM Power Harness	423-4401-090
Air Pressure Harness	423-4401-091
Drawbar Unclamp Harness	423-4401-092
Drawbar Clamp Harness	423-4401-093
Spindle Unclamp PB Harness	423-4401-094
Transformer 115V Secondary Harness	423-4401-098
Flood Coolant Pump Power Harness	423-4401-099
CRP-4TB3 Harness	423-4401-100
Unclamp Solenoid Harness	423-4401-101
Air Blast Solenoid Harness	423-4401-102
Spindle Purge Solenoid Harness	423-4401-103
TB3 To Ballast Harness	423-4401-104
Right Work Lamp Harness	423-4401-105
Left Work Lamp Harness	423-4401-106
Light Switch Harness	423-4401-107
CRP4-TB1/TB9 Harness	423-4401-110
Transformer 400V Primary Harness	423-4401-111
X-Axis Limit Switch Harness	423-4401-112
Y-Axis Limit Switch Harness	423-4401-113
Z-Axis Limit Switch Harness	423-4401-114
ISA FDD to CIN Power Harness	423-4402-001
ISA FDD to CIN Signal Harness	423-4402-002
CIN to Remote Jog Port Harness	423-4402-007
External Remote Jog Plug Harness	423-4402-008
Mouse to CIN Harness	423-4402-009
ISA Remote Jog Harness	423-4403-001
ISA Remote Jog Harness	423-4403-003

Description	Drawing #
Harness Assembly Drawings	
Index Port Harness	423-4405-009/010/034
Spindle Motor Power Harness	423-4405-064
Spindle Motor Fan Harness	423-4405-065
Main Disc. Power Harness	423-4405-069
X-Axis Motor Encoder Harness	423-4405-073
Y-Axis Motor Encoder Harness	423-4405-074
Z-Axis Motor Encoder Harness	423-4405-075
Spindle Motor Encoder Harness	423-4405-076
I/O to Infeed I/R Module Harness	423-4405-077
I/O to Main Spindle Module Harness	423-4405-078
I/O to Axis Module Harness	423-4405-079
X-Axis Motor Power Harness	423-4405-081
Y-Axis Motor Power Harness	423-4405-082
Z-Axis Motor Power Harness	423-4405-083
Transformer Input Power Harness	423-4405-084
FPC to Console Pushbutton Harness	423-6824-001
FPC to PGM Entry Keyboard Harness	423-6824-002
Softkey to Machine Harness	423-6824-003
Machine Function to PGM Entry Keyboard Harness	423-6824-004
Trackball & E-Stop Button Harness	423-6825-001
Mecca FPC/TB4 Harness	423-6826-002
Mecca FPC/TB5 Harness	423-6826-003
Prox SW ISA Remote Jog Harness	423-6827-004