

MACHINE TOOLS  
**TAKISAWA**<sup>®</sup>

# MAC-V5 PARTS LIST

MB09262A

CONTENTS

PAGE

1	BED & COLUMN ASSEMBLY	(MB02001-000) .....	1-1,2
2	HEAD STOCK	(MB10001C000) .....	2-1,2
3	INSIDE COMPONENTS FOR HEAD STOCK 1	(MB10004B000) .....	3-1,2
	INSIDE COMPONENTS FOR HEAD STOCK 2	(MB10005D000) .....	3-3,4
4	FEED DEVICE FOR X AXIS	(MB20001C000) .....	4-1,2
5	LIMITE SWITCH (X,Y AXIS)	(MB20002A000) .....	5-1,2
6	FEED DEVICE FOR Y AXIS	(MB21001C000) .....	6-1,2
7	FEED DEVICE FOR Z AXIS	(MB22001C000) .....	7-1,2
8	LIMITE SWITCH (Z AXIS)	(MB22002B000) .....	8-1,2
9	CABLE DUCT	(MB22003-000) .....	9-1,2
10	SADDLE & TABLE ASSEMBLY	(MB30001F000) .....	10-1,2
11	MAGAZINE-1	(MB40001A000) .....	11-1,2,3,4 5,6,7
12	ATC-1	(MB41001C000) .....	12-1,2,3
13	OIL HYDRAULIC	(MB41005-000) .....	13-1,2