

MACHINE TOOLS
TAKISAWA

TC-2 MII

USER'S MANUAL

NC LATHE CONTENTS

PREFACE

PRECAUTIONS FOR SAFETY AND MAINTENANCE	S-1
1. SPECIFICATION	1-1
1-1. Machine specification	1-1
1-2. Name of each component	1-5
2. INSTALLATION	2-1
2-1. Installtaion of the machine	2-1
2-2. Lifting the machine	2-4
2-3. Power supply	2-6
3. LUBRICATION AND OILING	3-1
3-1. Lubrication and oiling of each part	3-1
4. STRUCTURE, MAINTENANCE AND ADJUSTMENT OF EACH PART	4-1
4-1. Headstock	4-1
4-1-1. Structure of spindle and main dimensions	4-1
4-1-2. Spindle speed/output diagram	4-1
4-1-3-a Centering of headstock	4-16
4-1-3-b Check of tool slide and spindle center height	4-16
4-1-4. Adjustment of belt tension	4-19
4-2. Tailstock	4-23
4-2-1. Structure and major dimensions of tailstock	4-23
4-2-2. Thrust of tailstock spindle	4-24
4-2-3. Centering of tailstock	4-25
4-3. Tool slide	4-26
4-3-1. Major dimensions of tool slide	4-26
4-3-2. Interior construction of tool slide	4-27
4-4. Hydraulic system	4-28
4-4-1. Hydraulic unit	4-28
4-4-2. Hydraulic circuit diagram	4-29
4-4-3. Adjustment of hydraulic valves and others	4-31
4-5. Grasping force of hydraulic chuck	4-32
5. APPENDIX AND ATTACHED DRAWING	5-1
5-1. Machine-adhered name plate	5-1

NC DEVICE CONTENTS

	Page
1. NC DEVICE SPECIFICATION	1- 1
1-1. NC device specification (with TC-F)	1- 1
1-1-1. Name of NC device	1- 1
1-1-2. Specification	1- 1
1-1-3. Additional specification	1- 5
1-2. NC device specification (with FANUC-15-TF)	1- 9
1-2-1. Name of NC device	1- 9
1-2-2. Specification	1- 9
1-2-3. Additional specification	1-14
 2. OPERATION PANEL	 2- 1
2-1. List of operation indication symbols	2- 1
2-2. Operation panel	2- 3
 3. MACHINE OPERATION	 3- 1
3-1. Power ON and OFF	3- 1
3-2. Manual operation	3- 2
3-2-1. Rapid traverse	3- 2
3-2-2. Jog feed	3- 3
3-2-3. Hand feed	3- 4
3-2-4. Retrun to reference position	3- 5
3-2-5. Indexing of tool slide	3- 6
3-2-6. Spindle start	3- 7
(1). Spindle start	3- 7
(2). Spindle speed	3- 7
(3). Drive conditions of spindle	3- 8
3-3. Automatic operation	3- 9
3-3-1. Automatic opeation staring	3- 9
3-3-2. Automatic operation hold	3-10
3-3-3. Automatic operation termination	3-10
3-3-4. MDI operation	3-11

3-3-5. Switches to be used during automatic operation	3-12
(1). Optional block skip (block delete)	3-12
(2). Optional stop	3-12
(3). Machine lock	3-12
(4). Dry run & program check	3-13
(5). Feedrate override	3-13
(6). Rapid traverse override	3-14
(7). Spindle speed override	3-14
3-3-6. Interruption of the manual operation during the auto operation	3-15
(1). Method of interruption	3-15
(2). Continuation of the automatic operation	3-16
3-3-7. Program stop and optional stop	3-17
3-4. Edit of program	3-18
3-4-1. Memory of program	3-18
3-4-2. Program edit	3-18
3-5. Other switches and indications	3-19
3-5-1. Emergency stop	3-19
3-5-2. Reset	3-19
3-5-3. Normal and reverse jaws of chuck	3-19
3-5-4. Coolant oil	3-20
3-5-5. Working lamp	3-20
3-5-6. Chuck CLAMP and UNCLAMP	3-20
3-5-7. Tailstock spindle	3-21
3-5-8. Front door safety cancel switch	3-21
3-5-9. Load meter of spindle motor	3-21
3-5-10. Buzzer	3-22
3-5-11. Operation error	3-22
4. REACTION TO ALARM	4- 1
4-1. NC alarm	4- 1
4-2. Motor alarm	4- 1
4-3. Operation error	4- 1

PROGRAM CONTENTS

	Page
1. General Description	1
2. Program Edit Steps	2
3. Major Functions and Symbol Descriptions	4
A) XZUW	4
B) G-Function used frequently	5
B-1. Constant surface speed control	9
B-2. G Function List	14
C) M Function	15
D) S Function	16
E) T Function	16
E-1. Tool Offset Number	16
4. Coordinate system setting, nose setting	17
A) Coordinate system setting	17
A-1. Auto coordinate system setting	17
A-2. Work coordinate system shift	17
B) Nose setting	19
B-1. Outer diameter	19
B-2. Inner diameter tool A	20
B-3. Inner tool B	21
5. Cutting Speed Table	22
6. Carbide Tool Turning Standard Condition	23
7. Drill Machining Cutting Standard Conditions	24
8. Program Example	25
9. Appendix	27
A) Cutting Depth and Count	27
B) Tool Error for Nose R (Arc Cutting)	28
C) Nose R Compensation List	29