



KIA CENTER V25 (FANUC Oi-MB) MACHINING CENTER

INSTALLATION MAINTENANCE MANUAL

VERSION No. : 2.0



KIA HEAVY INDUSTRIES

2601MAU02F2
2003. 05.

CONTENTS

INSTALLATION

1. Accepting Preparatives.....	5
1-1. Check List of Machining Center Accepting Preparative Procedures.....	7
1-2. Inquiry and Application for Admission to a NC Class.....	8
2. Conveyance And Installation.....	9
2-1. Conveyance of Machine.....	11
2-2. Installation.....	12
2-3. Main body Specifications.....	14
2-4. Specification for NC Unit(FANUC SYSTEM Oi-MB).....	16
2-5. Principal Dimensional Drawings.....	19
2-6. Axis Stroke and Reference Point.....	20
2-7. Foundation Plan.....	21
2-8. How to Lift the Machine.....	22
3. Delivery.....	23
3-1. Preparations for the Attendant Inspection.....	25
3-2. Delivery of the Machine, from bring In to Operation Guidance.....	27
3-3. Lists of Preparatory Items When Delivering the Machine.....	28

MAINTENANCE

1. Maintenance And Lubrication.....	33
1-1. Daily Maintenance.....	35
1-2. When the Alarm Lamp Turn On.....	35
1-3. Lubrication Oil Supply.....	36
1-4. Pneumatic Circuit Diagram.....	38
1-5. List of Limit Switches.....	39

1-6. List of Solenoid Valves.....	40
2. Checking and Adjustment of Main Functions.....	41
2-1. Relation among X, Y, Z Axis.....	43
2-2. Zero Return Adjustment.....	46
2-3. ATC.....	50
2-4. ATC Function Check.....	57
2-5. PC Time Setting.....	63
2-6. Adjustmet, Repair & Setting of rigid Tapping.....	66
2-7. Repair & Manual Operation of Dual Table.....	72
3. Main Power Function Check.....	73
3-1. Magnet Switch.....	75
3-2. Thermal Relay.....	76
3-3. Circuit Protector.....	77
3-4. Contact Relay.....	77
4. Ladder Diagram Description.....	79
4-1. Ladder Diagram.....	81
4-2. I/O Interface.....	81
4-3. Ladder Diagram Description.....	84
5. PC Alarm List.....	85
5-1. PC Alarm List.....	87