

OPERATION MANUAL

# **CUSTOM MACRO**

**MGC, MGW-E**



**MAKINO MILLING MACHINE CO., LTD.**

MG-01-8704/E

## CONTENTS

|                                                                                | Page |
|--------------------------------------------------------------------------------|------|
| 1. GENERAL DESCRIPTION .....                                                   | 1    |
| 1.1 Features of Custom Macro .....                                             | 1    |
| 1.2 Custom Macro and Run Mode .....                                            | 2    |
| 2. SUBPROGRAM .....                                                            | 3    |
| 2.1 Types of Subprogram Calls .....                                            | 3    |
| 2.2 Nesting of Subprogram .....                                                | 10   |
| 3. MACRO COMMAND CODES .....                                                   | 12   |
| 3.1 Functions of Macro Command Codes .....                                     | 12   |
| 3.2 Parameter and Variable Function .....                                      | 12   |
| 3.3 System Variables .....                                                     | 21   |
| 3.4 Operation Function .....                                                   | 62   |
| 3.5 Judgement and Branch Functions .....                                       | 65   |
| 3.6 Repetition Function .....                                                  | 68   |
| 3.7 Suppress Command of External Control Function .....                        | 71   |
| 3.8 Effect of Bracket .....                                                    | 72   |
| 3.9 External Output Function .....                                             | 73   |
| 4. REGISTRATION OF CUSTOM MACRO .....                                          | 77   |
| 4.1 Preparation of Program Tape .....                                          | 77   |
| 4.2 Registration of Program .....                                              | 77   |
| 4.3 Edit of Program .....                                                      | 77   |
| 4.4 Display of Compile Error Message .....                                     | 78   |
| 5. CUSTOM MACRO RUN .....                                                      | 80   |
| 5.1 Custom Macro Test Procedure .....                                          | 80   |
| 5.2 Alarm Message Display Under Run .....                                      | 86   |
| 5.3 Pseudo Command Code Call Parameter Setting .....                           | 89   |
| 5.4 Characteristics Specification of Non-holding<br>Type Common Variable ..... | 91   |