

WIRE-CUT EDM SYSTEMS



Series

OPTIONS

MITSUBISHI ELECTRIC CORPORATION ©

(2nd version)



CONTENTS

1. FIGURE CHECK EQUIPMENT	1-1
1.1 Foreword	1-1
1.2 Figure check equipment	1-1
1.2.1 Compatible equipment	1-1
1.2.2 Configuration	1-1
1.3 Operation procedures	1-2
1.4 Accessories	1-3
1.5 Spare parts	1-3
2. 20KG WIRE SPECIFICATION	2-1
2.1 Introduction	2-1
2.2 Specifications	2-1
2.3 Construction	2-2
2.4 Operation procedure	2-3
2.4.1 Switch operation	2-3
2.4.2 Attachment of 20kg coiled wire bobbin	2-3
2.4.3 How to stretch wire	2-4
2.4.4 Disposition of used wire	2-4
2.4.5 Setting of pretension value	2-4
2.4.6 Countermeasures	2-7
3. LARGE WATER PURIFIER	3-1
3.1 Outline	3-1
3.2 Specifications	3-1
3.3 Names of parts	3-2
3.4 Connections	3-3
3.5 Operation	3-4
3.6 Resin replacement	3-4
3.6.1 On handling the water purifier (ion exchange resin)	3-4
3.6.2 Ion exchange resin replacement procedure	3-6
3.7 Filter element replacement procedure	3-7
3.8 Maintenance and water draining	3-7
3.8.1 Maintenance	3-7
3.8.2 Water draining (when replacing the resin cylinder and when there is danger of freezing)	3-8

C Series

4. REMOTE CONTROL	4-1
4.1 Foreword	4-1
4.2 Manual operation box	4-1
4.2.1 Models which can use the remote control unit	4-1
4.2.2 Configuration	4-1
4.3 Operations	4-2
5. RS-232C TRANSMISSION BETWEEN THE CONTROL UNIT AND EXTERNAL DEVICES (HOST COMPUTER)	5-1
5.1 Transmission outline	5-1
5.2 Transmission Format	5-3
5.3 Codes	5-4
5.4 NC send-receive timing	5-5
5.4.1 NC side data receive (control code system)	5-5
5.4.2 NC side data send (control code system)	5-6
5.5 Format	5-7
5.6 Data input/output	5-8
5.6.1 Signals	5-8
5.6.2 Connector and pin arrangement	5-9
5.6.3 Data input from I/O device	5-10
5.6.4 Data output to I/O device	5-13
5.6.5 Data comparison with I/O device	5-17
5.6.6 Interrupt of DC type data I/O	5-19
5.7 BTR operation	5-20
5.7.1 Operation	5-20
5.8 Interface	5-21
6. 3.5 INCH FLOPPY DISK DEVICE	6-1
6.1 FD-3.5 operation	6-1
6.1.1 General	6-1
6.1.2 Operating panel	6-1
6.1.3 Handling	6-2
6.1.4 I/O procedure for NC tape and E-pack	6-5
6.1.5 Various functions	6-18
6.1.6 Error display	6-26
6.1.7 FLD specification for FD-3.5	6-26
6.1.8 Precautions in using the FD-3.5II	6-27
6.1.8.1 Precautions in setting communications parameters	6-27
6.1.8.2 Precautions concerning file names that can be handled by the FD-3.5II	6-28
6.1.8.3 Other precautions	6-28

6.2	File transfer	6-29
6.2.1	General	6-29
6.2.2	Transfer method	6-30
6.2.3	Others	6-40