




OPERATION MANUAL

Correct operation and periodical inspection are indispensable to safety use of the machine.

This operation manual contains the following chapters:

- | | |
|-----------|--|
| CHAPTER 1 | Mechanical Instructions |
| CHAPTER 2 | Inspection and Maintenance Manual |
| CHAPTER 3 | Mechanical Drawings and Circuit Diagrams |
| CHAPTER 4 | Operating Instructions |

Thoroughly understand the contents of this manual and use as ready reference for operation and maintenance.

2006/3

CHAPTER 1

Mechanical Instructions

— APPLICABLE MODEL —

GS—1535

CHAPTER 1 Table of Contents

1-1.Specifications of the Machine	1-4
1-2.Standard Accessories, Optional Accessories and Special Specifications	1-5~1-6
1-3.Parts Name	1-7
1-4.Dimensiona1 Drawing of the Machine	1-8
1-5.Installation	
1-5-1 Installation location	
(a) Environment of installation location	1-9~1-10
(b) Power supply	1-11
(c) Foundation work	1-12~1-14
1-5-2 Carrying or moving the machine	
(a) Preparation for moving the machine	1-15
(b) Fastener position	1-15~1-16
(c) Lifting and carrying the machine	
• Precautions for lifting and carrying the machine with a crane etc.	1-16~1-18
• Precautions for lifting and carrying the machine with a forklift	1-19
• Precautions for moving the machine by means of rollers	1-20

1-5-3 Installing the machine

- (a) Installation of the machine body 1-21
- (b) Setting up the optional accessories and attachments for special specifications 1-21

1-6. Preparation for operation

- 1-6-1 Electrical wiring 1-22
- 1-6-2 Connecting power supply 1-23
- 1-6-3 Turning on power supply
 - (a) Check points before turning on power supply 1-24
 - (b) Turning on power supply 1-25
 - (c) Check points after turning on power supply 1-25

CHAPTER 2

Inspection and Maintenance

— APPLICABLE MODEL —

GS-1 535

CHAPTER 2 Table of Contents

2-1 Oil Management

2-1-1	Surface Grinding Machine Oiling Guidance Table	2-4
-------	--	-----

2-1-2	Handling of Oil	2-5
-------	-----------------	-----

2-1-3 Check Oiling

(a)	Check oiling on each side of slide surface	2-6
-----	--	-----

(b)	Check oiling to vertical feed driving part.	2-7
-----	---	-----

(c)	Check oiling to centralized lubrication device	2-8
-----	--	-----

2-1-4 Lubricating Oil

(a)	List of lubricating oil	2-9
-----	-------------------------	-----

(b)	Table of oil property	2-9
-----	-----------------------	-----

2-2 Daily inspection

2-2-1 Inspection at Time of Starting Daily Work

(a)	Inspection before power-ON	2-10
-----	----------------------------	------

(b)	Inspection after power-ON	2-10
-----	---------------------------	------

2-2-2	Inspection before Starting Operation	2-11~2-12
-------	--------------------------------------	-----------

2-2-3	Warming-up Run of Machine	2-13
-------	---------------------------	------

2-2-4	Inspection during Operation	2-13
-------	-----------------------------	------

2-2-5	Inspection at Time of Closing Daily Work	2-13~2-14
-------	--	-----------

2-2-6	Cleaning of Machine	2-14
-------	---------------------	------

2-3	Periodical Inspection (Maintenance and Security)	
2-3-1	Periodical inspection	
(a)	Check points before 0maintenance work	2-15~2-16
(b)	List of periodical inspection	2-17
2-3-2	Periodical inspection for vertical feed screw and exchange of screw	2-18
2-3-3	Check the thermal relay movement	2-19
2-4	Trouble-shooting	
2-4-1	Machine trouble and Counter-measures	2-20
2-4-2	Explanation about Flow-chart Symbol	2-20
2-4-3	Trouble diagnosis and Remedy (Flow-chart outline)	2-21
2-4-4	Flow-chart	2-22~2-25

CHAPTER 3

Mechanical Drawings and Circuit Diagrams.

— APPLICABLE MODEL —

GS-1535

CHAPTER 3 Table of Contents

3-0	Lubricating System Diagram	3-3
3-1	Mechanical Drawings and Parts List	
3-1-1	Spindle assembly	3-4~3-5
3-1-2	Spindle wheel guard	3-6~3-7
3-1-3	Column assembly	3-8~3-9
3-1-4	Table assembly	3-10~3-11
3-1-5	Saddle assembly	3-12~3-13
3-1-6	Longitudinal hand feed assembly	3-14~3-15
3-1-7	Cross feed assembly	3-16~3-17
3-1-8	Base assembly	3-18~3-19
3-1-9	Vertical hand feed assembly	3-20~3-21
3-1-10	Vertical assembly	3-22~3-23
3-3	Electric Circuit Diagram	3-24

CHAPTER 4

Operating Instructions

— APPLICABLE MODEL —

GS-1 535

CHAPTER 4 Table of Contents

4-1	Operating instructions	
4-1-1	Operating panel	4-3
4-1-2	Functions of operating panel and automatic neutrolator	4-4
4-1-3	Vertical feed handwheel	4-5
4-1-4	Cross feed handwheel	4-5
4-1-5	Longitudinal feed handle	4-5
4-1-6	Operating procedure	4-6
4-1-7	About the use of automatic neutrolator	4-6
4-1-8	About the grinding for non-magnetic workpiece	4-7
4-2	Handling of grinding wheel	
4-2-1	Mounting and dismounting of the wheel	4-8~4-11
4-2-2	「Truing」 dressing	4-12
4-2-3	Balancing the grinding wheel	4-12~4-14
4-2-4	Repairing the wheel	4-14
4-2-5	Adjusting the nozzle	4-15
4-3	Dressing	
4-3-1	Dressing conditions	4-16~4-17
4-3-2	How to mount the diamond dresser	4-18
4-3-3	How to dress the peripheral surface of the wheel correctly	4-18~4-19