

MODEL JD23-35

OPEN BACK INCLINABLE PRESS

OPERATION MANUAL

Rated Ram Pressure 35 ton

ZHE JIANG METALFORMING MACHINE WORKS

THE PEOPLE'S REPUBLIC OF CHINA

Contents

- I. Operation theory and application
- II. Specification
- III. Construction and adjustment
 - 1. Frame
 - 2. Ram
 - 3. Clutch
 - 4. Control mechanism
 - 5. Brake
 - 6. Driving system
- IV. Electrical system
- V. Lubrication
- VI. Installation
- VII. Adjustment and start
- VIII. Daily maintenance
- IX. Accuracy test
- X. Troubles and remedies
- XI. List of wearing parts and accessories

Drawings

1. Operation theory
2. General view
3. Frame
4. Ram
5. Clutch
6. Control mechanism
7. Brake
8. Driving system
9. Electrical system
10. Foundation plan