

MACHINE TOOLS
TAKISAWA[®]

TC-4 PARTS LIST

HX04261

C O N T E N T S

PAGE

1.	HEAD STOCK (HX06001-000B)	1-1, 1-2
2.	SPINDLE (HX06002-000)	2-1, 2-2
3.	HEAD STOCK (HX06003-000A)	3-1, 3-2
4.	SPINDLE (HX06004-000)	4-1, 4-2
5.	MOTOR BASE (HX07001-000C)	5-1, 5-2
6.	X AXIS FEED DEVICE (HX10001-000C)	6-1, 6-2
7.	LIMIT SWITCH FOR X AXIS (HX10003-000A)	7-1, 7-2
8.	Z AXIS FEED DEVICE (HX11001-000A)	8-1, 8-2
9.	LIMIT SWITCH FOR Z AXIS (HX11003-000A)	9-1, 9-2
10.	BED (HX15001-000B)	10-1, 10-2
11.	CARRIAGE (HX17001-000B)	11-1, 11-2
12.	TURRET (HX20001-000B)	12-1, 12-4
13.	TOOLING (HX22001-000)	13-1, 13-8
14.	HYDRAULIC CIRCUIT (HX40001-000C)	14-1, 14-2
15.	HYDRAULIC CONNECTION (HX40007-000D)	15-1, 15-4
16.	HEAD STOCK LUBRICATION (HX42001-000)	16-1, 16-2
17.	TAIL STOCK (HX51001-000B)	17-1, 17-2
18.	LIMIT SWITCH OF TAIL STOCK (HX51006-000)	18-1, 18-2
19.	HYDRAULIC CHUCK (HX52001-000)	19-1, 19-2
	HYDRAULIC CHUCK (HX52004-000)	19-3, 19-4
20.	COOLANT SYSTEM (HX53001-000B)	20-1, 20-2
21.	BED (HX15005-000A)	21-1, 21-2
22.	COVER (HX30005-000)	22-1, 22-8
23.	DUCT (HX39002-000)	23-1, 23-2