

A large, stylized white graphic on an orange background, resembling a stylized 'M' or a fan-like shape with five segments radiating from a central point.

Mazak

OPERATING MANUAL

for

SUPER QUICK TURN

200/250

MANUAL No. : H320SG0061E

**OPERATING
MANUAL**



OPERATING MANUAL

for

SUPER QUICK TURN

200/250

MANUAL No. : H320SG0061E

Before using this machine and equipment, fully understand the contents of this manual to ensure proper operation. Should any questions arise, please ask the nearest Technical/Service Center.

IMPORTANT NOTICE

1. Be sure to observe the safety precautions described in this manual and the contents of the safety plates on the machine and equipment. Failure may cause serious personal injury or material damage. Please replace any missing safety plates as soon as possible.
2. No modifications are to be performed that will affect operation safety. If such modifications are required, please contact the nearest Technical/Service Center.
3. For the purpose of explaining the operation of the machine and equipment, some illustrations may not include safety features such as covers, doors, etc. Before operation, make sure all such items are in place.
4. This manual was considered complete and accurate at the time of publication, however, due to our desire to constantly improve the quality and specification of all our products, it is subject to change or modification. If you have any questions, please contact the nearest Technical/Service Center.
5. Always keep this manual near the machinery for immediate use.
6. If a new manual is required, please order from the nearest Technical/Service Center with the manual No. or the machine name, serial No. and manual name.

Issued by *Manual Publication Section, Yamazaki Mazak Corporation, Japan*

CONSTRUCTION

Part 1 PRELIMINARIES TO MACHINE OPERATION

Chapter 1 INTRODUCTION

Chapter 2 SAFETY PRECAUTIONS

Part 2 MACHINE OPERATION

Chapter 1 MACHINE OVERVIEW

Chapter 2 OPERATING PANEL AND FUNCTIONS OF SWITCHES

Chapter 3 PREPARATION FOR OPERATION

Chapter 4 MANUAL OPERATION

Chapter 5 PREPARATION FOR MACHINING

Part 3 OPERATING NC UNIT AND PREPARATION FOR AUTOMATIC OPERATION

Chapter 1 PREPARATION FOR AUTOMATIC OPERATION

Chapter 2 DISPLAY OVERVIEW

Chapter 3 DATA SETTING METHODS

Chapter 4 DISPLAYS RELATED TO THE MACHINE OPERATIONAL STATUS

Chapter 5 DISPLAYS RELATED TO MACHINING SET UP

Chapter 6 DISPLAYS RELATED TO PROGRAM CREATION

Chapter 7 DISPLAYS RELATED TO TOOLS

Chapter 8 DISPLAYS RELATED TO PARAMETERS

Chapter 9 DISPLAY RELATED TO DATA STORAGE

Chapter 10 DISPLAYS RELATED TO DIAGNOSIS

Part 4 AUTOMATIC OPERATION

Chapter 1 AUTOMATIC OPERATION EXECUTION

Chapter 2 SELECTING EXECUTION CONDITIONS

Chapter 3 CHANGING THE CUTTING CONDITIONS

Chapter 4 STOPPING AUTOMATIC OPERATION

Chapter 5 MANUAL INTERRUPTION

Chapter 6 OPERATIONS POSSIBLE DURING AUTOMATIC OPERATION

Chapter 7 COMPLETION OF OPERATION

Part 5 APPENDIX

Chapter 1 STANDARD SPECIFICATION OF THE MACHINE

Chapter 2 M-CODE LIST

Chapter 3 ALARM LIST

PART 1

PRELIMINARIES TO MACHINE OPERATION

CONTENTS

	Page
1 INTRODUCTION	1-1
1-1 List of Manuals to Be Used	1-1
1-2 Numbering System for Pages	1-1
1-3 Numbering System for Figures and Tables	1-1
1-4 Distinction between Standard and Optional Specifications	1-2
2 SAFETY PRECAUTIONS	2-1
2-1 Rule	2-1
2-2 Basic Safety Items	2-1
2-3 Clothing and Personal Safety	2-3
2-4 Safety Items Related to Operation	2-4
2-5 Safety Items Related to Gripping Workpiece and Tooling	2-5
2-6 Safety Items Related to Maintenance	2-6
2-7 Safety Items Related to Workplace	2-7
2-8 Safety Items Related to Chip Conveyor	2-7
2-9 Safety Equipment	2-8
2-10 Remarks on the Cutting Conditions Recommended by the NC	2-8
2-11 Safety Nameplates	2-8

PART 2

MACHINE OPERATION

CONTENTS

	Page
1 MACHINE OVERVIEW	1-1
1-1 Features	1-1
1-2 Overview of Mechanisms	1-1
1-3 Overview of Control System	1-3
1-4 Disposition of Machine Components	1-4
1-5 Coordinate Axes	1-5
2 OPERATING PANEL AND FUNCTIONS OF SWITCHES	2-1
2-1 NC Operating Panel	2-1
2-1-1 Disposition of switches and indicator lamps	2-1
2-1-2 Controls on the NC operating panel	2-2
2-2 Auxiliary Operating Panel (☆)	2-5
2-3 Data I/O Panel	2-7
3 PREPARATION FOR OPERATION	3-1
3-1 Inspection at the Start of Operation	3-1
3-2 How to Stop the Machine	3-2
3-2-1 How to stop the machine in emergencies	3-2
3-2-2 Other stopping methods	3-2
3-3 Procedure for Switching the Power ON	3-2
3-4 Inspection after Switching the Power ON	3-4
3-5 Switching the Power OFF	3-5
3-6 Zero-Point Return	3-5

3-7 Warmup Operation.....	3-7
3-8 Opening/Closing of Chuck (★)	3-8
4 MANUAL OPERATION	4-1
4-1 Selection of Manual Operation Mode	4-1
4-2 Spindle Operation	4-1
4-2-1 Spindle start.....	4-1
4-2-2 Spindle stop.....	4-3
4-2-3 Spindle jog.....	4-3
4-3 X- and Z-Axis Feed Operation	4-3
4-3-1 X- and Z-axis rapid feed	4-4
4-3-2 X- and Z-axis cutting feed.....	4-5
4-3-3 X- and Z-axis manual pulse feed	4-6
4-4 Tool Selection	4-7
4-4-1 Rotation of turret.....	4-7
4-5 Tailstock Operation	4-8
4-5-1 Checking before tailstock operation	4-8
4-5-2 Moving the tail spindle.....	4-9
4-5-3 Moving the tailstock body	4-10
4-6 Other Manual Operations	4-13
4-6-1 Soft limit and its release	4-13
4-6-2 MACHINE LOCK	4-14
4-6-3 WORK LIGHT and COOLANT MANUAL	4-14
4-6-4 Manual operation of parts catcher (★)	4-15
4-6-5 Manual operation of the automatic door.....	4-16

4-7 SET UP Switch	4-17
5 PREPARATION FOR MACHINING	5-1
5-1 Mounting of Tools.....	5-1
5-1-1 Mounting/removal of tool holder and tools	5-1
5-2 Preparation for Gripping Workpiece (Soft Jaw Machining)	5-3
5-2-1 In the case of workpiece external gripping	5-3
5-2-2 In the case of workpiece internal gripping	5-5

PART 3

OPERATING NC UNIT AND PREPARATION FOR AUTOMATIC OPERATION

2-axis Specification

CONTENTS

	Page
1 PREPARATION FOR AUTOMATIC OPERATION	1-1
1-1 Preparation Steps for Automatic Operation	1-1
2 DISPLAY OVERVIEW	2-1
2-1 Name of the Components of Each Display	2-1
2-2 Types of Displays	2-4
2-3 DISPLAY MAP Display	2-5
2-4 Windows	2-6
2-5 Task Bar of "Windows"	2-8
3 DATA SETTING METHODS	3-1
3-1 Setting Data and Address	3-2
3-2 Selecting Menu Data	3-3
3-3 Erasing Data	3-3
3-4 Modifying Data	3-4
3-5 Incremental Input	3-4
3-6 Saving Data onto the Hard Disk	3-4
4 DISPLAYS RELATED TO THE MACHINE OPERATIONAL STATUS	4-1
4-1 POSITION Display	4-1
4-2 MEASURE Display	4-6
4-3 EIA MONITOR Display	4-9
4-4 MACHINING - MONITORING Display	4-12

4-5	MACHINING NAVIGATION - RESULT Display	4-17
5	DISPLAYS RELATED TO MACHINING SET UP	5-1
5-1	SET UP MANAG. Display	5-1
5-2	TRACE Display	5-14
5-3	SET UP RECORD Display	5-18
5-4	CHUCK JAW DATA Display	5-22
5-5	SPINDLE LOAD GRAPHIC DISPLAY Display	5-24
6	DISPLAYS RELATED TO PROGRAM CREATION	6-1
6-1	PROGRAM Display	6-1
6-2	SHAPE CHECK Display	6-2
6-3	TOOLPATH Display	6-4
6-4	PROCESS LAYOUT Display	6-17
6-5	TPC EDIT Display	6-23
6-6	PROGRAM FILE Display	6-25
6-7	MACHINING NAVIGATION - PREDICT Display	6-30
7	DISPLAYS RELATED TO TOOLS	7-1
7-1	TOOL DATA Display	7-1
7-2	TOOL OFFSET Display	7-26
7-3	TOOL LIFE Display	7-32
8	DISPLAYS RELATED TO PARAMETERS	8-1
8-1	CUTTING CONDITION (REGIST) Display	8-1
8-2	CUTTING CONDITION (PERCENTAGE) Display	8-4

8-3	CUTTING CONDITION (TURNING) Display	8-6
8-4	CUT LEARN Display.....	8-8
8-5	USER PARAMETER Display.....	8-10
8-6	MACHINE PARAMETER Display	8-11
8-7	WORK OFFSET Display.....	8-12
8-8	MACRO VARIABLE Displays	8-16
9	DISPLAY RELATED TO DATA STORAGE	9-1
9-1	DATA I/O Display.....	9-1
9-1-1	Display operations	9-2
9-1-2	Data input/output in text file format	9-21
10	DISPLAYS RELATED TO DIAGNOSIS	10-1
10-1	DIAGNOSIS (ALARM) Display	10-2
10-2	DIAGNOSIS (ALARM HISTORY) Display.....	10-3
10-3	DIAGNOSIS (PLC SIGNAL) Display.....	10-4
10-4	MAINTENANCE CHECK Display	10-5
10-4-1	Data display for normal check items	10-5
10-4-2	Data display for long-term check items (1500 and 3000 hours check items).....	10-6
10-5	RUNNING CONTROL Display.....	10-7
10-6	DIAGNOSIS (VERSION) Display.....	10-12
10-7	DIAGNOSIS (MONITOR) Display.....	10-13
10-8	DIAGNOSIS (OPTION) Display	10-17
10-9	DATA ERASE Window	10-18
10-10	ACCUMULATED TIME Window	10-18

PART 4

AUTOMATIC OPERATION

CONTENTS

Page

1	AUTOMATIC OPERATION EXECUTION	1-1
1-1	Automatic Operation Execution Procedure	1-1
1-2	Types of Automatic Operation Mode	1-3
1-2-1	Auto mode operation	1-4
1-2-2	Restart mode operation	1-15
1-2-3	MDI operation	1-21
1-2-4	Single-process mode operation	1-23
2	SELECTING EXECUTION CONDITIONS	2-1
2-1	Optional Stop	2-1
2-2	Dry Run	2-3
2-3	Machine Lock	2-4
2-4	Work Light	2-5
2-5	Barrier Cancel	2-5
2-6	Block Skip	2-6
2-7	Single Block	2-6
2-8	Comparison Stop	2-7
3	CHANGING THE CUTTING CONDITIONS	3-1
3-1	Rapid Feed Override	3-1
3-2	Cutting Feed Override	3-2
3-3	Spindle/Milling-Spindle Override	3-3
3-4	VFC Function	3-5

4	STOPPING AUTOMATIC OPERATION	4-1
4-1	Emergency Stop	4-1
4-2	Reset	4-2
4-3	Feed Hold	4-3
4-4	Stopping by Changeover to a Manual Operation Mode	4-3
4-5	Single-block Stop	4-4
4-6	Program Stop	4-4
4-7	Stopping by Turning the Power Off	4-5
5	MANUAL INTERRUPTION	5-1
5-1	Handle Interruption	5-1
5-2	TPS Function	5-3
6	OPERATIONS POSSIBLE DURING AUTOMATIC OPERATION	6-1
6-1	Data Rewriting	6-1
7	COMPLETION OF OPERATION	7-1
7-1	Procedure for Switching the Power OFF	7-1
7-2	Cleaning and Inspections on Completion of Operation	7-1