

CNC SYSTEM

OSP5000L-G

LC Series CNC Lathes

MAINTENANCE MANUAL (2nd Edition)

TABLE OF CONTENTS

	<u>PAGE</u>
SECTION 1 SPECIAL FEATURES OF OSP5000 SERIES	1
SECTION 2 SUMMARY OF OPERATION	2
SECTION 3 STRUCTURE OF OSP5000L-G	3
3-1. CPU UNIT	3
3-2. SERVO DRIVE UNIT	4
3-3. RELAY AND MAGNET SWITCH CIRCUITS	4
3-4. SPINDLE DRIVE MOTOR CONTROL	4
3-5. CONTROL ENCLOSURE	4
3-6. OPERATION PANEL	5
3-7. ABSOLUTE POSITION FEEDBACK ENCODERS	5
3-8. COOLING UNIT	5
SECTION 4 MAINTENANCE AND INSPECTION	6
4-1. INSPECTION DURING INSTALLATION	6
4-1-1. Installation Site	6
4-1-2. Environmental Requirements	7
4-1-3. Power Supply Voltage Inspection	7
4-2. PERIODICAL INSPECTION	8
4-3. OPERATION AND STRUCTURE OF THE NC	9
4-3-1. Example of Operation	9
4-3-2. Description on Each Major NC Unit	10
4-4. SELF-DIAGNOSTICS	13
4-4-1. Alarm Display and Error Display	14
4-4-2. Check Data Display	14
SECTION 5 TROUBLE AND TROUBLESHOOTING	33
5-1. ANALYSIS OF TROUBLE	34
5-2. MACHINE-MOUNTED ELECTRICALS	35
5-2-1. Inspection of Limit Switches (Check Method by multi-Meter)	35
5-2-2. Inspection of Rotary Switch for Turret Indexing (Testing by Self-Diagnostic Function)	36

PAGE

5-3. BRUSHLESS SERVO MOTOR DRIVE UNIT	38
5-3-1. Configuration of BDU-A	38
5-3-2. BDU-A Protection Function and Alarm Indication	41
5-3-3. Trouble and Troubleshooting	45
5-3-4. Spare Parts of BDU-A	46
5-4. INSPECTION OF POSITION ENCODER	47
5-5. CHECK PANEL	48
5-6. CPU	49
5-6-1. Operation and Structure of the CPU	49
5-6-2. Checking CPU Operations	51
5-6-3. Loading Control Software through Floppy Disk	52
5-6-4. CPU Power Supply	55
5-7. RELAY AND MAGNET SWITCH CIRCUITS	57
5-7-1. Operation and Structure of a Relay and Magnet Switch Circuit	57
5-7-2. Inspection of a Relays and Magnet Switches	58
SECTION 6 SPINDLE DRIVE UNIT FOR DC MOTOR - SDU-600 W SERIES	61
6-1. OUTLINE	61
6-2. ALARM CONDITIONS AND DISPLAY OF SDU-600 W SERIES UNIT	64
6-2-1. Alarm Display and Details	64
6-2-2. Resetting of Alarm Condition, Replacement of Blown Fuses and Resetting of No-Fuse Circuit Breaker	65
6-3. CONSTRUCTION OF SDU-600 W SERIES SPINDLE DRIVE UNIT	68
6-3-1. Layout of Component Parts	68
6-3-2. Principle Functions	70
6-4. SPARE AND REPLACEMENT PARTS	71
6-4-1. Spare and Replacement Parts of SDU-600 W	71
6-4-2. Spare and Replacement Parts for DC Motors and Tachogenerators	72
6-5. INSPECTION AND MAINTENANCE OF DC MOTORS AND TACHOGENERATORS .	74
6-5-1. Inspection and Maintenance of Brushes	74
6-5-2. Inspection and Maintenance of Bearings	74
6-5-3. Inspection and Maintenance of Air Filter	74
6-6. TROUBLESHOOTING CHART	75

PAGE

SECTION 7	SPINDLE DRIVE UNIT FOR VAC MOTOR (YASKAWA MAKE)	77
7-1.	GENERAL	77
7-2.	CONFIGURATION	78
7-3.	PERIODIC INSPECTION	79
7-4.	TROUBLESHOOTING	80
7-4-1.	Fault Status Classes	80
7-4-2.	Troubleshooting	80
7-5.	REPLACING FUSES	87
SECTION 8	SPINDLE DRIVE UNIT FOR VAC MOTOR (OKUMA MAKE)	88
8-1.	OUTLINE	88
8-2.	MAINTENANCE AND INSPECTION	89
8-3.	TROUBLES AND TROUBLESHOOTING	90
8-3-1.	VAC Drive Unit Construction	90
8-3-2.	Operation Status Display	95
8-3-2-1.	Operations Indicating LED's	95
8-3-2-2.	Operation Status Indicating LED's	96
8-3-3.	Measures to Take	102
8-3-3-1.	Confirmation of Power Supply, Connectors and Signals	102
8-3-3-2.	Classification of Failure Occurrence Conditions and Measures	103
8-3-4.	Recovery from Failure Status	111
8-4.	FUSE REPLACEMENT	112
8-4-1.	Fuse Blown State	112
8-4-2.	Fuse Replacement	113
8-5.	SPARE PARTS LIST	114
8-6.	INPUT/OUTPUT SIGNALS	115
SECTION 9	COOLING UNIT	117
9-1.	MAINTENANCE AND INSPECTION	117

PAGE

SECTION 10 C-AXIS OF MULTIPLE-MACHINING MODEL	118
10-1. C-AXIS JOINT MECHANISM	118
10-2. C-AXIS JOINT METHODS	119
10-2-1. Checking C-axis Joint Method	119
10-2-2. Spindle Driven by C-axis During C-axis Joint	120
10-2-3. High Speed C-axis Joint A	122
10-2-4. High Speed C-axis Joint B	123
10-2-5. Supplements to Joint Method Explanations	126
10-3. C-AXIS JOINT PARAMETERS	127
10-3-1. Spindle Orientation Position Parameter	127
10-3-2. Zero Position in Spindle Orientation for C-axis Joint ...	128
10-3-3. How to Set Zero Position of Spindle Orientation for C-axis Joint	130
10-4. TROUBLE AND TROUBLESHOOTING FOR C-AXIS JOINT OPERATION	131
10-4-1. Machine Condition Checking Procedure	131
10-4-2. Troubles and Troubleshooting	135
SECTION 11 ELECTRICAL SPARE PARTS LIST	138
SECTION 12 NC-LATHE REQUIRED POWER DATA	166
APPENDED FIGURES	
OPERATION PANEL (FLAT PANEL) - OSP5000L-G	168
LAYOUT DIAGRAM OF MACHINE-MOUNTED ELECTRICALS (LC10)	169
LAYOUT DIAGRAM OF MACHINE-MOUNTED ELECTRICALS (LC20)	170
LAYOUT DIAGRAM OF MACHINE-MOUNTED ELECTRICALS (LC30/LC40)	171
LAYOUT DIAGRAM OF MACHINE-MOUNTED ELECTRICALS (LC50)	172
INTERNAL LAYOUT OF OSP5000L-G CNC UNIT (LC10)	173
INTERNAL LAYOUT OF OSP5000L-G CNC UNIT (LC20)	174
INTERNAL LAYOUT OF OSP5000L-G CNC UNIT (LC30/40)	177
INTERNAL LAYOUT OF OSP5000L-G CNC UNIT (LC50)	178

Note: To avoid any confusion over the use of the letter "O (oh)" and figure "0 (zero)" in this manual, the numerical value "0 (zero)" is expressed as "Ø" if there is any possibility of misunderstanding.