

PARTS LIST

■ Applicable Model ■

SL-200,200MC
200S,200SMC

Before operation, maintenance, and programming, read the manuals supplied by Mori Seiki, the NC unit manufacturer, and equipment manufacturers carefully so that the information in the manuals are thoroughly understood.
Keep the manuals carefully so that they will not be lost.

MORI SEIKI

PARTS LIST I

CONTENTS

1.	GENERAL VIEW	P - 1
2.	INSTALLATION DRAWING	P - 2
3.	FOUNDATION DIAGRAM	P - 3
4.	SPINDLE SPEED OUTPUT DIAGRAMS	P - 5
4.1	Headstock 1	P - 5
4.2	Headstock 2	P - 5
4.3	MC Type	P - 6
5.	TURRET INTERFERENCE DIAGRAMS	P - 7
5.1	Standard	P - 7
5.2	MC Type	P - 8
5.3	VDI Type	P - 9
5.3.1	Standard	P - 9
5.3.2	MC Type	P - 10
6.	AXIS TRAVEL DIAGRAMS	P - 11
6.1	SL-200	P - 11
6.2	SL-200MC	P - 13
6.3	SL-200S	P - 15
6.4	SL-200S (for VDI Type)	P - 16
6.5	SL-200SMC	P - 17
6.6	SL-200SMC (for VDI Type)	P - 18
7.	SPINDLE DIMENSIONS	P - 19
7.1	Headstock 1	P - 19
7.2	Headstock 2	P - 21
8.	SLIDEWAY LUBRICATION PUMP DIAGRAM	P - 23
9.	COOLANT PUMP DIAGRAM	P - 26

10.	HYDRAULIC UNIT DIAGRAMS	P – 28
10.1	General View and Specifications of Hydraulic Unit	P – 28
10.2	General View and Specifications of Chuck Valve Unit	P – 30
10.2.1	Headstock 1	P – 30
10.2.2	Headstock 1 High / Low Pressure Chuck Type	P – 32
10.2.3	Headstock 2	P – 34
10.2.4	Headstock 2 High / Low Pressure Chuck Type	P – 36
10.3	General View and Specifications of Turret Clamp / Unclamp Valve Unit	P – 38
10.4	General View and Specifications of Chucking Open / Close C-axis Clamp / Unclamp Valve Unit	P – 40
10.5	General View and Specifications of Tail Stock Spindle Valve Unit	P – 42
10.6	General View and Specifications of Turret Clamp / Unclamp, 2nd C-axis Valve Unit	P – 44
10.7	General View and Specifications of Turret Clamp, Programmable Tail Stock	P – 46
11.	AIR CIRCUIT DIAGRAMS	P – 48
11.1	Both-side Hands for Flange Type workpiece	P – 48
11.2	Parallel Hands for Flange Type workpiece, Shaft Hand Type ..	P – 50
12.	JAW TYPE AND GRIPPING RANGE OF HAND FOR GANTRY-TYPE LOADER	P – 52
12.1	LG-03 (Both-side Hands For Flange Type Workpiece)	P – 52
12.2	LG-03 (Parallel Hands For Flange Type Workpiece)	P – 53
13.	GANTRY-TYPE LOADER TRAVEL DIAGRAM	P – 54
14.	FAN COOLER	P – 55
15.	OIL COOLER (OPTION)	P – 56
16.	IN-MACHINE TOOL PRESETTER ARM INTERFERENCE DIAGRAMS	P – 60
16.1	Manual Type (Standard)	P – 60
16.2	Automatic Type (Option)	P – 61

PARTS LIST II

CONTENTS

1.	CAUTION LABELS	P – 1
2.	ASSEMBLY DIAGRAM OF HEADSTOCK	P – 3
2.1	Headstock1 (Standard)	P – 3
2.2	Headstock1 (MC Type)	P – 5
2.3	Headstock2 (Standard)	P – 7
3.	ASSEMBLY DIAGRAM OF TURRET	P – 11
3.1	Standard	P – 11
3.2	MC Type	P – 17
4.	ASSEMBLY DIAGRAM OF SADDLE	P – 19
5.	ASSEMBLY DIAGRAM OF X-AXIS DRIVE	P – 21
6.	ASSEMBLY DIAGRAM OF Z,B-AXIS DRIVE	P – 23
7.	ASSEMBLY DIAGRAM OF TAILSTOCK	P – 25
8.	ASSEMBLY DIAGRAM OF SLIDEWAY LUBRICATION OIL PIPE	P – 31
9.	ASSEMBLY DIAGRAM OF B-AXIS CROSS SLIDE	P – 33
10.	ASSEMBLY DIAGRAM OF TOOL PRESETTER (MANUAL)	P – 35
11.	ASSEMBLY DIAGRAM OF HYDRAULIC PIPE	P – 37
11.1	SL-200,200MC	P – 37
11.2	SL-200S,200SMC	P – 45
12.	ASSEMBLY DIAGRAM OF PARTS CATCHER	P – 53
13.	ASSEMBLY DIAGRAM OF LOADER	P – 55
13.1	LG-03 (Both-side hands for flange Type workpiece)	P – 55
13.2	LG-03 (Parallel hands for flange Type workpiece)	P – 57
14.	ASSEMBLY DIAGRAM OF LOADER HAND	P – 59
14.1	LG-03 (Both-side hands for flange Type workpiece)	P – 59
14.2	LG-03 (Parallel hands for flange type workpiece)	P – 61

15. ASSEMBLY DIAGRAM OF WORK STOCKER	P – 63
16. ASSEMBLY DIAGRAM OF HAND ROTATION STRUCTURE	P – 69
16.1 LG-03 (Both-side hands for flange Type workpiece)	P – 69
16.2 LG-03 (Parallel hands for flange Type workpiece)	P – 71

HOW TO ORDER THE MACHINE PARTS
