


FA-2J JUNIOR SERIES

PROGRAMMABLE CONTROLLER USERS MANUAL



CONTENTS

Chapter 1—UNITS

FEATURES	2
SYSTEM CONFIGURATION	3
UNIT OUTLINE	4
SPECIFICATIONS	7
I/O UNIT WIRING	24
OUTPUT RELAY/MODULE SPECIFICATIONS & WIRING	26
GETTING STARTED	28
START & STOP OPERATION	30
MEMORY PACK	32
INSTALLATION & WIRING	33
TROUBLE SHOOTING & MAINTENANCE	39
TEST RUN	45
DIMENSIONS & MOUNTING HOLE LAYOUT	46
TYPE LIST	47

Chapter 2—INSTRUCTION WORDS

INSTRUCTION WORDS & ALLOCATION NUMBERS	50
Instruction Word List	50
Allocation Numbers	54
BASIC INSTRUCTION	56
COMPUTING INSTRUCTION	80
Computing Instruction Function	80
Basic Computing Instruction Word List	83
Advanced Computing Instruction Word List	84

Basic Computing Instructions	86
External Preset Function	97
External Display Function	99
Advanced Computing Instructions	100
Computing Instruction Error	137
Error List	139
Keeping Arithmetic Operand	140
Computing Instruction Application Examples	141

Chapter 3—PROGRAM LOADER

PROGRAM LOADER	146
Part Description	146
Program Capacity	147
Sample Display	147
Dimensions	147
PROGRAMMING PROCEDURES	148
PROGRAMMING KEY OPERATION	150
BASIC OPERATING PROCEDURES	152
SEARCHING FOR PROGRAMS	160
FUN OPERATION	161
FUN (Function)	161
FUN (Function) Operation	161
TRANSFERRING PROGRAMS	177
PROM WRITER OPERATION	180
AUDIO CASSETTE OPERATION	184
MONITORING OPERATION	186

