

E41501-07

ConSep2000[®] II

-125/200

Instruction Manual

Issued on 1 June, 2006



TSUBAKIMOTO MAYFRAN INC.

CONTENTS

1. LIMITED WARRANTY	1
2. IMPORTANT INFORMATION	2
3. BILL OF MATERIAL OF ConSep2000 II	3
4. WARNINGS AND SAFETY INSTRUCTIONS	6
4.1 GENERAL INSTRUCTIONS	6
4.2 REMARKS.....	7
4.3 WARNING LABELS	7
5. INSTRUCTIONS FOR REPAIR AND MAINTENANCE, MALFUNCTIONS.	8
6. UNPACKING AND TRANSPORT	9
6.1 UNPACKING	9
6.2 TRANSPORT	9
7. INSTALLATION AND COMMISSIONING OF ConSsp2000 II	10
8. STARTING UP ConSsp2000 II	12
8.1 GENERAL FUNCTIONS.....	12
Make sure that the EMERGENCY STOP press button is released.....	12
8.1.1 Operation without any object to be transferred.....	12
8.2 PRECAUTIONS IN OPERATIONS	12
8.2.1 Keep open flames.	12
8.2.2 Never open the inspection hole cover.	12
8.2.3 Keep coolant to the proper level.....	12
8.2.4 Be sure to connect a back-washing pump.....	12
8.2.5 Flow control of back-washing	12
8.3 Safety devices.....	14
8.3.1 Emergency STOP button (option).....	14
8.3.2 Shock relay (Electrical/CSM type hollow shaft gear motor)	14
8.4 Lower horizontal cover	14
8.5 INSPECTION WINDOW.....	15
8.6 PRECAUTIONS FOR HANDLING TRANSFERRED OBJECTS ON THE CONVEYOR	15
9. Maintain procedure for storage	16
10. MAINTENANCE AND CHECK	16
10.1 MAINTENANCE	16
10.1.1 Driving gearmotor	16
10.1.2 Main bearing	16
10.1.3 Chain and belt.....	16



10.1.4	Filter check and change	17
10.1.5	Take-up adjustment	18
10.1.6	Y-Strainer check and cleaning	20
10.1.7	Disassembly and reassembly of the frame.....	21
10.1.8	Keep an order and cleaning around the conveyor	22
10.1.9	Maintenance and check items.....	23
11.	TROUBLESHOOTING.....	25
11.1	Safety precaution	25
11.2	Troubleshooting when the conveyor comes to a sudden stop.....	25
11.2.1	For shock relay (Electrical/CSM type hollow shaft gear motor)	25
12.	SPECIFICATIONS	27
12.1	Weight of ConSep2000II	27
12.2	SPEED AND REVOLUTIONS OF ConSep2000II	27
12.3	Capacity of chips.....	27
12.4	Coolant pump for back wash.....	28
12.5	Driving gear motor.....	28
12.5.1	Specification of hollow shaft gear motor of CSM type	28
12.6	ELECTRICAL COMPONENTS (The option)	30