

OPERATION MANUAL

BED TYPE  
UNIVERSAL MILLING  
MACHINE

DMB-U3, U5

 **Doosan**  
MANUFACTURING CO., LTD.

## C O N T E N T S

\*=====

### 1. MAIN SPECIFICATIONS AND ACCESSORIES

|                               |   |
|-------------------------------|---|
| 1-1 Main specifications-----  | 1 |
| 1-2 Standard accessories----- | 2 |
| 1-3 Optional accessories----- | 2 |

### 2. INSTALLATION OF THE MACHINE

|                                             |   |
|---------------------------------------------|---|
| 2-1 Foundation-----                         | 3 |
| 2-2 Lifting of machine-----                 | 3 |
| 2-3 Installation-----                       | 3 |
| 2-4 Levelling-----                          | 8 |
| 2-5 Electrical power supply connection----- | 8 |

### 3. DIMENSIONAL DRAWING

### 4. LUBRICATION OF THE MACHINE

|                                     |    |
|-------------------------------------|----|
| 4-1 Lubrication of the machine----- | 14 |
| 4-2 Lubrication chart-----          | 15 |

### 5. OPERATION OF THE MACHINE

|                                                      |    |
|------------------------------------------------------|----|
| 5-1 Test operation-----                              | 17 |
| 5-2 Operation the switch on pendant control box----- | 18 |
| 5-3 Spindle speed change-----                        | 21 |
| 5-3 Feed speed change-----                           | 22 |
| 5-5 Feed mechanism-----                              | 22 |
| 5-6 Backlash eliminator-----                         | 24 |
| 5-7 Clamp-----                                       | 24 |
| 5-8 Reading of travel distance-----                  | 26 |
| 5-9 Limit switch and dog-----                        | 27 |
| 5-10 Coolant equipment-----                          | 29 |

### 6. CONSTRUCTION AND MECHANISM

|                   |    |
|-------------------|----|
| 6-1 Head-----     | 30 |
| 6-2 Bed-----      | 32 |
| 6-3 Feed box----- | 34 |

## 7. ADJUSTMENT OF VARIOUS PARTS

|     |                                        |    |
|-----|----------------------------------------|----|
| 7-1 | Adjustment of the spindle bearing----- | 36 |
| 7-2 | Adjusting table, saddle, head gib----- | 37 |
| 7-3 | Adjusting various clamp lever-----     | 39 |
| 7-4 | Adjusting backlash eliminator-----     | 39 |
| 7-5 | Adjusting V-belt tension for feed----- | 40 |
| 7-6 | Adjusting main spindle brake-----      | 40 |

## 8. CLEANING

|     |                                 |    |
|-----|---------------------------------|----|
| 8-1 | Cleaning the oil strainer-----  | 41 |
| 8-2 | Cleaning the oil reservoir----- | 41 |
| 8-3 | Cleaning the wiper-----         | 42 |

## 9. DECIDING LOCATION OF SPINDLE IN UNIVERSAL HEAD

|     |                                                               |    |
|-----|---------------------------------------------------------------|----|
| 9-1 | Rotation of spindle head-----                                 | 43 |
| 9-2 | Table of relation between each angles for spiral cutting----- | 51 |
| 9-3 | Table of relation between each angles for slant cutting-----  | 52 |

## 10. ELECTRICAL CIRCUIT DIAGRAM

|      |                                     |    |
|------|-------------------------------------|----|
| 10-1 | Schematic diagram-----              | 53 |
| 10-2 | Arrangement of electric device----- | 56 |