


Honeywell

DPR100 A/B DIGITAL OPERATOR MANUAL



LEADERLINE

Better Record Your World

DPR 100 A/B DIGITAL OPERATOR MANUAL

Ref. : EN11-6156

TABLE OF CONTENTS

1	OVERVIEW.	1-1
1.1	RECORDER OVERVIEW.	1-1
2	INSTALLATION.	2-1
2.1	WARNING.	2-1
2.2	UNPACKING.	2-2
2.3	PANEL MOUNTING THE RECORDER.	2-3
2.3.1	Recommendations	2-3
2.3.2	External dimensions and cut-out	2-3
2.3.3	Installing the recorder	2-4
2.4	WIRING THE RECORDER.	2-5
2.4.1	Recommendations	2-5
2.5	TERMINAL CONNECTIONS.	2-7
2.6	FITTING THE CHART	2-8
2.6.1	Roll chart.	2-8
2.6.2	Fanfold chart	2-9
2.7	CLEANING THE PANE	2-9
2.8	INSTALLING THE PRINTING SYSTEM	2-10
2.9	CHECK LIST	2-18
3	OPERATION.	3-1
3.1	OPERATOR INTERFACE EXPLANATION	3-1
3.2	BASIC ACTIONS	3-2
3.2.1	Operators keys.	3-2
3.2.2	How to select the display type	3-3
4	PARTS LIST	4-1
4.1	TO ORDER CONSUMABLES.	4-1

TABLE OF CONTENTS

5	MODEL SELECTION GUIDE	5-1
5.1	PRODUCT IDENTIFICATION	5-1
6	PRODUCT SPECIFICATION SHEET	6-1
7	CONFIGURATION	7-1
7.1	OPERATOR INTERFACE	7-1
7.2	CONVERSION TABLE	7-2
7.3	ONE EXAMPLE : HOW TO SET THE CHART SPEED	7-5
7.4	PROMPTS EXPLANATION	7-6